

FUEL AND EMISSION CONTROL SYSTEM (DIESEL)

OUTLINE	4D— 2
SPECIFICATIONS.....	4D— 2
TROUBLESHOOTING GUIDE	4D— 3
ON-VEHICLE MAINTENANCE	4D— 4
AIR CLEANER ELEMENT.....	4D— 4
WATER DRAINING	4D— 4
AIR BLEEDING	4D— 4
INJECTION TIMING	4D— 5
IDLE SPEED	4D— 6
EXHAUST SMOKE	4D— 6
INTAKE AIR SYSTEM	4D— 7
STRUCTURAL VIEW.....	4D— 7
AIR DUCT AND AIR CLEANER.....	4D— 8
INTAKE MANIFOLD	4D— 9
SUPERCHARGING SYSTEM (RF-CX)	4D—10
TROUBLESHOOTING GUIDE.....	4D—10
ON-VEHICLE INSPECTION.....	4D—11
COMPRES SUPERCHARGER	4D—13
STARTING VALVE	4D—15
INTERCOOLER	4D—16
BOOST AIR TEMPERATURE SENSOR.....	4D—17
EXHAUST SYSTEM	4D—18
STRUCTURAL VIEW.....	4D—18
EXHAUST MANIFOLD	4D—19
EXHAUST PIPE AND MAIN SILENCER	4D—20
FUEL SYSTEM	4D—21
STRUCTURAL VIEW.....	4D—21
FUEL FILTER.....	4D—22
SEDIMENTER (GENERAL).....	4D—22
WATER LEVEL SENSOR.....	4D—23
INJECTION PUMP	4D—24
INJECTION NOZZLE	4D—31
FUEL TANK.....	4D—34

OUTLINE

The Mazda 626 offers two diesel engines; a Comprex supercharged RF-CX engine, and a normally aspirated RF-N engine.

SPECIFICATIONS

Item		Engine model	ECE		UK, GENERAL
			RF-CX	RF-N	
Fuel tank	Capacity	liters (US gal, Imp gal)	60 (15.9, 13.2)		
Fuel filter	Type		Cartridge, paper element		
Sedimenter	Type		With detector		
Injection pump	Type		Bosch VE distributor		
	Manufacturer		Diesel Kiki Co., Ltd.		
	Direction of rotation		Clockwise		
	Drive method		Timing belt		
	Plunger diameter	mm (in)	9.0 (0.35)	8.0 (0.31)	
	Cam lift	mm (in)	2.2 (0.087)		
Injection nozzle	Type		Throttle		
	Injection pressure	kPa (kg/cm ² , psi)	13,240 (135 , 1,920)		
Injection timing			ATDC 1°	TDC 0°	
Idle speed		rpm	720 ⁺³⁰ ₋₂₀		
Fast idle speed (A/C ON)		rpm	700—750		
Cold start device	Engine speed	rpm	1.100		
	Advance degree		6°		
Air cleaner	Type		Cartridge, paper element		
			Wet	Dry	
PCV system	Type		Open	Closed	

76G04D-002

TROUBLESHOOTING GUIDE

Condition	Condition Cause	Remedy
Hard starting	Fuel filter Clogged Water or air in filter Fuel Injection pump Faulty fuel cut solenoid Incorrect injection timing Air in pump Faulty pump Fuel Injection nozzle Seized needle valve Fuel dripping from nozzle Incorrect valve opening pressure Faulty glow plug Faulty cold start device Faulty supercharging system	Replace Repair Replace Adjust Bleed Replace Replace Replace Adjust Replace Adjust or replace Refer to page 4D—10
Rough Idle	Fuel filter (Refer to "Hard starting") Fuel Injection pump (Refer to "Hard starting") Fuel Injection nozzle Seized needle valve Incorrect valve opening pressure Improper mounting to nozzle holder Leakage of nozzle holder copper washer Fuel Injection pipe Cranks Leaking from joint Improper idle speed adjustment	 Replace Adjust Repair Replace Replace Repair Adjust
Engine knocking	Incorrect injection timing Low quality fuel Incorrect injection nozzle opening pressure Seized injection nozzle needle valve Fuel dripping from injection nozzle Faulty supercharging system	Adjust Replace Adjust Replace Replace Refer to page 4D—10
High fuel consumption	Fuel Injection pump Incorrect injection timing High idle speed Fuel Injection nozzle Incorrect valve opening pressure Fuel dripping from nozzle Leakage of nozzle holder copper washer Fuel leaking from connection Clogged fuel filter Clogged air cleaner	Adjust Adjust, Inspect the dashpot Repair Replace Replace Repair Replace Replace
Poor acceleration	Fuel Injection nozzle (Refer to "Hard starting") Fuel Injection pump (Refer to "Hard starting") Fuel Injection pipe (Refer to "Rough idle") Fuel filter (Refer to "Hard starting") Clogged air cleaner Faulty supercharging system	 Clean or replace Refer to page 4D—10
Excessive exhaust smoke	Clogged air cleaner Improper injection timing Faulty nozzle or nozzle holder Faulty supercharging system	Clean or replace Adjust Adjust or replace Refer to page 4D—10

76G04D-003

ON-VEHICLE MAINTENANCE

AIR CLEANER ELEMENT

Check the air cleaner element for excessive dirt, damage, or oil. Replace if necessary.


Caution

(Wet type)

Do not clean the air cleaner element with compressed air, replace if necessary.

(Dry type)

When cleaning the air cleaner element, blow dust off from the inside first, then blow off the outside.



76G04D-004


WATER DRAINING

(ECE)

1. Loosen the drain plug of the fuel filter.
2. Pump the priming pump.
3. Bleed air from the fuel filter.

(General)

1. Loosen the drain plug of the sedimenter and let the water drain. If necessary loosen the air bleeding plug.
2. Bleed air from the sedimenter.



76G04D-005


AIR BLEEDING

From Fuel Tank to Fuel Filter

1. Loosen the air bleeding plug of the fuel filter.
2. Pump the priming pump until no air bubbles flow from the air bleeding plug hole.
3. Depress the priming pump and tighten the air bleeding plug.

Note


Open only the air bleeding plug of the filter.




76G04D-006

From Fuel Filter to Injection Pump


Pump the priming pump until it becomes hard to pump.




76G04D-007




76G04D-008



76G04D-009



76G04D-010



76G04D-011

INJECTION TIMING

1. Disconnect the negative battery cable.
2. Release the CSD using the screw driver.
3. Remove the cover on the clutch housing.
4. Turn the flywheel and set the indicator at **TDC**.
5. Disconnect the injection pipes from the injection pump.

6. Remove the hydraulic head plug from the injection pump.
7. Mount the **SST** into the plug hole on the hydraulic head so the tip of the dial gauge pointer touches the plunger end of the pump and the dial gauge indicates **approx. 2.0 mm (0.08 in)**.


8. Turn the crankshaft slowly counterclockwise to 30—50° BTDC.
9. Make sure the dial indicator pointer no longer moves by slightly turning the crankshaft.
10. Set the dial gauge scale to Zero at the pointer.

11. Turn the crankshaft clockwise to align the indicator pin at **ATDC 1° (RF-CX), TDC 0° (RF-N)**.
12. Read the dial gauge.

Cam lift: 0.98—1.02 mm (0.038—0.040 in)

13. If not within the specification, adjust the injection timing. (Refer to page 4D—24.)

4D ON-VEHICLE MAINTENANCE




76G04D-012

IDLE SPEED


1. Warm up the engine to normal operating temperature.
2. Be sure the A/C switch is OFF.
3. Connect a tachometer and check the engine speed.

Idle speed: 720 ± 30 rpm



76G04D-013

4. If necessary, adjust the idle by turning the idle adjusting screw.




76G04D-014

Fast Idle Speed (A/C equipped model)

1. Turn ON the A/C switch and blower motor switch.
2. Check the engine speed.

Fast idle speed: 725 ± 25 rpm

3. If necessary, turn the adjusting screw on the idle-up actuator, and adjust the fast idle speed.



76G04D-015


EXHAUST SMOKE

Increase and decrease the engine speed several times and check that there is no black smoke. If there is, refer to the Troubleshooting Guide.


INTAKE AIR SYSTEM

STRUCTURAL VIEW

RF-CX



RF-N



76G04D-016

- 1. Intake manifold
- 2. Intercooler
- 3. Air funnel assembly
- 4. Complex supercharger


- 5. Starting valve
- 6. Air cleaner
- 7. Air duct

4D INTAKE AIR SYSTEM

AIR DUCT AND AIR CLEANER


Removal and Installation

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for air leakage.



1. Tire house cover
2. Air duct
3. Air hose
4. Air cleaner case
5. Air cleaner cover
6. Air cleaner element

76G04D-017



76G04D-018

Inspection

Air cleaner

1. Inspect the silencer in the air cleaner cover for damage.
2. Inspect the air cleaner element for excessive dirt, damage, or oil. Replace if necessary.

Caution

(Wet type)


Do not clean the air cleaner element with compressed air, replace it if necessary.

(Dry type)

When cleaning the air cleaner element, blow dust off from the inside first, then blow off the outside.

Air duct


Inspect the silencer in the air duct for damage. Replace if necessary.



76G014-019

INTAKE MANIFOLD Removal and Installation


1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for air/exhaust leakage.



76G04D-020

1. Comprex supercharger
(Refer to page 4D-13.: RF-CX)
2. Exhaust manifold
(Refer to page 4D-19.: RF-CX)

3. Vacuum hose (RF-CX)
4. Water thermo switch connector
5. Intake manifold



76G04D-021

Inspection

1. Check the intake manifold for cracks and damage.
2. Inspect the flatness of the mounting surface using a straight edge and a feeler gauge. Replace if necessary.

Distortion: 0.05 mm (0.002 in) max.


4D SUPERCHARGING SYSTEM (RF-CX)

SUPERCHARGING SYSTEM (RF-CX)

TROUBLESHOOTING GUIDE

Engine hard starting	Poor acceleration	Excessive blue smoke	Excessive black smoke	Excessive compressed air temperature (Buzzser sounds)	Excessive noise	Possible Cause	Remedy (reference page)
*	*					Comprex supercharger Rotor stuck Casing damaged Rotor bearing damaged	Replace (4D—14)
*	*		*			Drive system of Comprex supercharger Drive belt loose or worn	Repair or replace (4D—12)
*						Idler pulley damaged	
*						Pulley bolt loose or worn	
				*		Wastegate Valve not open	Clean or repace (4D—12)
	*		*			Valve not closed	
	*		*			Starting valve Valve not open	Repair or replace (4D—15)
*		*				Valve not closed	
*						Bypass valve not open	
	*		*			Bypass valve not closed	
	*					Intercooler dirty	Clean or replace (4D—16)
*	*	*	*			Intake air system Fresh air side clogged (Air cleaner element, etc.)	Repair or replace
				*		Compressed air side clogged (Intercooler, etc.)	
					*	Fresh air side leaks	
	*		*		*	Compressed air side leaks	
					*	Exhaust system Exhaust gas brokeed	Repair
*	*	*	*		*	Exhaust pipe clogged	
					*	Silencer damaged (in fender, in air cleaner, in air funnel, Comprex insulator)	Repair or replace
					*	Bolt and nut loosend	Repair

76G04D-022



76D04D-023

ON-VEHICLE INSPECTION

Boost Pressure


1. Connect a pressure gauge to the hose from the intake manifold.
2. (On chassis dynamometer, full load)
 - (1) Set the vehicle on a chassis dynamometer.
 - (2) Run the vehicle in gear at **3,000 rpm** with the acceleration pedal fully depressed.
 - (3) Measure the boost pressure.

Boost pressure:

82 kPa (0.87 kg/cm², 8.1 psi)

Note

The above inspection should be done on a chassis dynamometer. If a dynamometer is not available follow the below procedure.



76G04D-024


3. (Off chassis dynamometer, no load)
 - (1) Shift the transaxle out of gear.
 - (2) Run the engine in neutral at **3,000 rpm** of the engine no load.
 Measure the boost pressure.

Boost pressure:

5 kPa (0.05 kg/cm², 0.7 psi)


Note

The boost pressure is varied by engine speed and engine load.




76G04D-025

- (3) Remove the starting valve bypass hose.
- (4) Check that the bypass valve is closed at 3,000 rpm.
4. If the pressure is below specification, check the following. Replace the Compex supercharger if necessary.
 - (1) Intake air and exhaust passages leakage
 - (2) Intake air and exhaust passages clogged
 - (3) Wastegate (Refer to 4D—12.)
 - (4) Starting valve (Refer to 4D—15.)
 - (5) Fuel system (Injection nozzle... refer to page 4D—31, injection pump...refer to page 4D—24, etc.)
5. If the pressure exceeds specification, check the wastegate operation. (Refer to page 4D—12.)



76G04D-086


4D SUPERCHARGING SYSTEM (RF-CX)



76G04D-026

Starting Valve

1. Remove the bypass hose from the starting valve.
2. Check that the bypass valve in the starting valve opens and closes repeatedly at idle.
3. Check that the bypass valve is closed when the accelerator pedal is fully depressed when the engine speed is more than 3,000 rpm.
4. If necessary replace the starting valve.



76G04D-027

Compex Supercharger Drive Belt


1. Check the drive belt for wear, cracks, or fraying.
2. Check the drive belt deflection by applying moderate pressure (**98 N, 10 kg, 22 lb**) midway between the pulleys.
3. If necessary, loosen the bolt and adjust the belt deflection by turning the adjusting bolt.

New : 4.0—5.0 mm (0.16—0.20 in)

Used: 4.5—5.5 mm (0.18—0.22 in)

Tightening torque:

16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)



76G04D-028

Wastegate


1. Disconnect the boost air hose from wastegate to the intake manifold, and apply compressed air.

2. Check that the wastegate actuator pulls the rod at the specified pressure.

Pressure: 137 kPa (1.4 kg/cm², 20 psi)

Caution

Do not apply more than 196 kPa (2.0 kg/cm², 28 psi) pressure.




76G04D-087

COMPREX SUPERCHARGER


Removal and Installation

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for air/exhaust leakage.



76G04D-029

- | | |
|---------------------------|-------------------------|
| 1. Air hose | 6. Drive belt |
| 2. Air funnel assembly | 7. Exhaust joint pipe |
| 3. Exhaust pipe | 8. Idle pulley |
| 4. Supercharger insulator | 9. Comprex supercharger |
| 5. Exhaust manifold stay | |




76G04D-030

Caution

- a) Be careful not to bend the rod or bracket of the wastegate.
- b) Cover the intake and exhaust ports to prevent dirt or other material from entering.

4D SUPERCHARGING SYSTEM (RF-CX)




76G04D-031

Inspection

Air casing, exhaust casing, rotor housing


Check the air casing, exhaust casing, and rotor housing for cracks or damage. Replace the Comprex supercharger if necessary.



76G04D-032

Rotor and rotor bearing

Check that the rotor turns smoothly. Replace the Comprex supercharger if necessary.



76G04D-033


Air funnel

Check the air funnel and insulator for cracks or damaged. Replace if necessary.


STARTING VALVE

Removal and Installation

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for air leakage.




76G04D-034



76G04D-035

Inspeciton Bypass valve

Check that the bypass valve opens smoothly.
Replace the starting valve if necessary.



76G04D-036

Starting valve

Check that the starting valve opens smoothly.
Replace the starting valve if necessary.

Note


Resistance will be felt because of the magnet when opening the valve.

4D SUPERCHARGING SYSTEM (RF-CX)

INTERCOOLER

Removal and Installation


1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for air leakage.



76G04D-037

1. Battery
2. Battery carrier
3. Front grille (Refer to Section 14.)
4. Headlight (Refer to Section 14.)


5. Front bumper (Refer to Section 14.)
6. Cooling fan
7. Air pipe
8. Intercooler



76G04D-038

Inspection

Check the intercooler for cracks or damage. Replace if necessary.




76G04D-039

BOOST AIR TEMPERATURE SENSOR

Removal

Remove the boost air temperature sensor from the compressed air funnel.




76G04D-040

Inspection

1. Place the boost air temperature sensor in oil.
2. Heat the oil and check continuity of the sensor with an ohmmeter. Replace if necessary.

Continuity : over 150°C (302°F)
No continuity: below 143°C (289°F)



76G04D-041

Installation


Install the boost air temperature sensor in the compressed air funnel.

Tightening torque:
29—39 N·m (3.0—4.0 m·kg, 22—29 ft·lb)

4D EXHAUST SYSTEM

EXHAUST SYSTEM

STRUCTURAL VIEW




76G04D-042

- 1. Exhaust manifold
- 2. Comprex supercharger (RF-CX)
- 3. Air funnel assembly

- 4. Pre-silencer
- 5. Main silencer


EXHAUST MANIFOLD Removal and Installation

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for exhaust leakage.



76G04D-043

1. Complex supercharger (Refer to page 4D—13.: only RF-CX)
2. Exhaust manifold



76G04D-044

Inspection

1. Check the exhaust manifold for cracks and damage.
2. Inspect the flatness of the mounting surface using the straight edge and a feeler gauge. Replace if necessary.


Distortion: 0.05 mm (0.002 in) max.

4D EXHAUST SYSTEM

EXHAUST PIPE AND MAIN SILENCER

Removal and Installation

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.
3. Check for exhaust leakage.




76G04D-045

1. Front exhaust pipe bracket
2. Front exhaust pipe
3. Pre-silencer


4. Silencer hanger
5. Middle pipe
6. Main silencer

FUEL SYSTEM STRUCTURAL VIEW

RF-CX



RF-N




76G04D-046

- 1. Fuel tank
- 2. Fuel filter
- 3. Fuel injection pump

- 4. Fuel injection nozzle
- 5. Sedimenter

4D FUEL SYSTEM




76G04D-047

FUEL FILTER

On-Vehicle Inspection

Check for water in the fuel filter. If present drain the water. (Refer to page 4D—4.)




76G04D-048

Replacement Removal

1. Disconnect the water level sensor connector (ECE).
2. Remove the water level sensor. (ECE).
3. Remove the fuel filter cartridge.

Warning


Keep fire and open flame away from the fuel area.



76G04D-049

Installation

1. Apply fuel to the O-ring of the fuel filter cartridge and install it onto the filter body.
2. Install the water level sensor (ECE).
3. Connect the water level sensor connector (ECE).
4. Bleed air from fuel filter. (Refer to page 4D—4.)
5. Check for fuel leakage.




76G04D-050

SEDIMENTER (GENERAL)

On-Vehicle Inspection


Check for water in the sedimenter. If present, drain the water. (Refer to page 4D—4.)



76G04D-051

Replacement

1. Remove the sedimenter from the body.
2. Apply fuel to a new O-ring, and install it onto the sedimenter body with water level sensor.




76G04D-052

WATER LEVEL SENSOR

Inspection

1. Remove the water level sensor.
(ECE)
Remove the water level sensor from the fuel filter.
(GENERAL)
Remove the water level sensor from the sedimenter body.




76G04D-053

2. Check the water level sensor for continuity with an ohmmeter. Replace if necessary.

ECE

Continuity : Pulled condition
No continuity: Pushed condition




76G04D-054

GENERAL

Continuity : Pushed condition
No continuity: Pulled condition

3. Apply fuel to a new O-ring and install it onto the sensor.
4. Install the water level sensor to the fuel filter (ECE) or the sedimenter (General).
5. Check for fuel leakage.

4D FUEL SYSTEM




76G04D-055

INJECTION PUMP

On-Vehicle Inspection

Fuel cut solenoid valve


1. Run the engine at idle.
2. Disconnect the solenoid valve connector, and let the engine stop.
3. If the engine does not stop, replace the fuel cut solenoid valve.



76G04D-056

Pick up coil

1. Disconnect the pick up coil connector.
2. Check for continuity of the coil using an ohmmeter.
3. Replace it if there is not continuity.



76G04D-057

Injection Timing Adjustment


Inspection

Check the injection timing. (Refer to page 4D—5.)

Injection timing

RF-CX: ATDC 1°


RF-N : TDC 0°



76G04D-058


Adjustment

1. Loosen the injection pump mounting nut.
2. Loosen the injection pump bracket bolt.



76G04D-059

3. Turn the crankshaft, and align the flywheel indicator pin at ATDC 1° (RF-CX), or TDC 0° (RF-N).




76G04D-060

4. Turn the injection pump until the dial indicator indicates **1 mm (0.04 in)**.

Note


Refer to page 4D—4 for initial setting of the dial indicator.



76G04D-061

Cam Height Inspection

1. Set the **SST** into the injection pump as for injection timing adjustment. (Refer to page 4D—4.)



76G04D-062


2. Turn the crankshaft clockwise and read the maximum difference of the indicator value, which gives the cam height.

Cam height: 2.2 mm (0.08 in)

4D FUEL SYSTEM


Removal and Installation

1. Remove in the sequence shown in the figure, referring to the removal note for specially marked parts.
2. Install in the reverse order of removal.



76G04D-063

- | | | |
|----------------------|--------------------------------------|-----------------------------------|
| 1. Accelerator cable | 5. Fuel cut solenoid valve connector | 8. Injection pump pulley lock nut |
| 2. Injection pipe | 6. Pick-up coil connector | 9. Injection pump |
| 3. Fuel hose | 7. Boost air hose (RF-CX) | |
| 4. Water hose | | |




76G04D-064

Removal note Injection pipe

Warning

- a) Catch leaking fuel with a rag when removing the injection pipes.
- b) Keep fire and open flame away from the fuel area.


Remove the injection pipes.



76G04D-065

Injection pump pulley

1. Put two 35—40 mm (1.3—1.6 in) long bolts through the injection pump pulley and affix them in the threaded holes of the injection pump bracket.
2. Loosen the injection pump pulley bolt.



76G04D-066

3. Separate the injection pump pulley from the injection pump shaft with the **SST**.

Steps after installation

1. After installation adjust the injection timing. (Refer to page 4D—24.)
2. Bleed air from the fuel line.
3. Check for fuel leakage.

76G04D-067


4D FUEL SYSTEM

Overhaul

Service point

1. For overhauling the injection pump, see the "Repair Service and Maintenance" manual prepared by the manufacturer of the pump.
2. If the inside of the injection pump is disassembled for maintenance, be sure to properly use the checking device such as the pump tester.


76G04D-068



63G04D-312

Manufacturer of Injection Pump:
Diesel Kiki Co., Ltd.

Construction of VE Injection Pump



63G04D-313

Injection Pump Characteristic (RF-CX)

VE-TYPE RF71 13 800C: 104749-0343 For RF-CX

☆ TEST OIL SAE Standard test oil (SEA 967C)

Fuel injection amount

Item	Pump speed (RPM)	Fuel injection amount (cm ³ /stroke)
Start	100	More than 55/1,000
	600	33.9—38.9/1,000
	1,000	48.9—50.9/1,000
	2,150	39.7—44.7/1,000
Full load	2,250	32.7—37.7/1,000
	2,550	8.0—15.0/1,000
	360	7.6—10.6/1,000
Idling		

Chamber pressure and timer stroke

Pump speed (RPM)	Chamber pressure (kg/cm ²)	Timer stroke (mm)
500		
1,250	4.5—5.1	2.7—3.9
1,500	5.2—5.8	4.3—4.9
2,150	6.8—7.4	7.6—8.8

Load sensing timer and overflowing quantity

Item		Fuel injection amount (cm ³ /stroke)
Load sensing timer	Start	37.2—39.2/1,000
	End	32.2—34.2/1,000
Overflowing quantity		41.0—85.0/1,000


*Checking condition

Pump speed: 1,500 rpm

Lever: Full load

Measurement

Measuring place	Dimension (mm)
KF	5.7—5.9
K	3.2—3.4
MS	1.6—1.8




Injection Pump Characteristic (RF-N)

VE-TYPE RF79 13 800A: 104748-0343 For RF-N ENGINE

☆ TEST OIL SAE Standard test oil (SEA 967C)


Fuel injection amount			Chamber pressure and timer stroke			Load sensing timer and overflowing quantity			Measurement	
Item	Pump speed (RPM)	Fuel injection amount (cm ³ /stroke)	Pump speed (RPM)	Chamber pressure (kg/cm ²)	Timer stroke (mm)	Item	Fuel injection amount (cm ³ /stroke)		Measuring place	Dimension (mm)
Start	100	More than 42/1,000	600	2.2—2.8	—	Load sensing timer	Start	26.7—29.7/1,000	KF	5.8—5.9
	600	29.0—33.0/1,000	1,375	4.4—5.0	3.9—4.5		End	14.6—17.6/1,000	K	3.2—3.4
	Full load	1,375	34.9—36.9/1,000	1,800	5.6—6.2	6.1—7.3	Overflowing quantity	46.3—90.3/1,000	MS	1.4—1.6
2,325		30.2—34.2/1,000	2,325	6.9—7.5	7.2—8.4					
		2,600	9.8—15.8/1,000				*Checking condition			
Idling	2,700	Max. 6.0/1,000				Pump speed: 1,375 rpm				
	360	8—12/1,000				Lever: Full load				



INJECTION NOZZLE


Removal

Remove in the sequence shown in the figure, referring to the removal note for the specially marked parts.



76G04D-071

1. Injection pipe bracket
2. Injection pipe
3. Fuel leak pipe
4. Fuel injection nozzle



76G04D-072


Removal note Injection pipe

Warning

- a) Catch leaking fuel leakage with a rag when removing the injection pipes.
- b) Keep fire and open flame away from the fuel area.

Remove the injection pipes.

4D FUEL SYSTEM



76G04D-073


Inspection

Injection starting pressure

1. Set the nozzle on the nozzle tester.
2. Bleed the air by pumping the nozzle tester handle several times.
3. Slowly lower the nozzle tester handle and check the pressure when injection starts.

Injection starting pressure:

13,200 kPa (135 kg/cm², 1,920 lb/in²) at 20°C (36°F) of fuel temperature




76G04D-074

4. If the injection starting pressure is higher than specification, increase the shim thickness. If the injection starting pressure is lower than specification, decrease the shim thickness.

Note


Adjusting shims are available in 0.05 mm (0.0197 in) thicknesses, from 1.0 mm (0.039 in) to 1.95 mm (0.077 in). When 0.05 mm (0.0197 in) is added, injection pressure increases approx. 490 kPa (5.0 kg/cm², 70 psi).



76G04D-075

Nozzle leakage


1. Apply **11,300 kPa (115 kg/cm², 1,640 psi)** pressure to the injection nozzle, and check for fuel leaks from the injection hole.
2. If fuel leaks, overhaul or replace the injection nozzle.



76G04D-076

Atomization (spray pattern)


1. Set the injection nozzle on the nozzle tester.
2. Bleed the air by operating the nozzle tester handle several times.
3. Lower the handle several times as quickly as possible so that a pulsating whistling sound is heard, and check the atomization.
 - (1) Uniform and proper atomization
 - (2) Incorrect injection angle and direction
4. If necessary, overhaul or replace the injection nozzle.



76G04D-077

Injection Nozzle Disassembly Disassemble the injection nozzle.

1. Nozzle holder
2. Adjusting shim
3. Pressure spring
4. Pressure pin
5. Distance piece
6. Nozzle
7. Retaining ring




76G04D-078

Cleaning

Clean the parts in clean test oil.

Injection Nozzle Inspection

1. Check the needle valve, nozzle body, and other parts for damage.
2. Hold the nozzle body upright and insert approximately two thirds of the needle valve, and check that the needle valve drops to the valve seat by its own weight.



76G04D-079


Injection Nozzle Assembly

1. Assemble the injection nozzle.

Tightening torque of nozzle body:

29—49 N·m (3.0—5.0 m·kg, 22—36 ft·lb)

2. Check the injection starting pressure, and atomization. (Refer to page 4D—32.)



76G04D-080

Injection Nozzle Installation

1. Install in the reverse order of removal, referring to the installation note.
2. Check for fuel leakage.

Installation note

Nozzle gasket


Install a new gasket with the red face toward the nozzle.

4D FUEL SYSTEM

FUEL TANK


Removal and Installation

1. Drain the fuel from the fuel tank.
2. Remove in the sequence shown in the figure, referring to the removal note for the specially marked parts.



76G04D-081

- | | | |
|-------------------------------|---------------------|------------------|
| 1. Fuel level gauge connector | 4. Joint hose | 7. Fuel tank |
| 2. Fuel main hose | 5. Ventilation hose | 8. Fuel tank pad |
| 3. Fuel return hose | 6. Breather hose | |



76G04D-082


Removal note

Fuel main and return hoses

1. Remove the service hole cover from the body.
2. Disconnect the fuel main and return hoses and plug them.

Warning

Keep fire and open flame away from the fuel area.




76G04D-083

Inspection

Fuel tank

Check the fuel tank for cracks or damage. Replace if necessary.



76G04D-084

Two way check valve

1. Disconnect the hose from the fuel tank.
2. Check that the air flows in both directions through the valve.
3. Replace the fuel vent hose if necessary.

Installation

1. Install in the reverse order of removal.
2. Bleed air from fuel line.
3. Check for fuel leakage.

76G04D-085