

1996 Mazda MPV Workshop Manual

©1995 Mazda Motor Corporation
PRINTED IN THE U.S.A. SEP '95
Form No. 1501-10-95I
Part No. 9999-95-038B-96

WARNING

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury and property damage increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Mazda-trained technicians in mind. This manual may be useful to non-Mazda trained technicians, but a technician with our service-related training and experience will be at less risk when performing servicing operations. However, all users of this manual are expected to know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Nonrecommended procedures and tools should include consideration for safety of the technician and continued safe operation of the vehicle.

Parts should be replaced with genuine Mazda replacement parts, not parts of lesser quality. Use of a nonrecommended replacement part should include consideration for safety of the technician and continued safe operation of the vehicle.

1996 Mazda MPV Workshop Manual

FOREWORD

For proper repair and maintenance, a thorough familiarization with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical—including photocopying and recording and the use of any kind of information storage and retrieval system—without permission in writing.

WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS

Title		Section
General Information		GI
Engine		B
Lubrication System		D
Cooling System		E
Fuel and Emission Control Systems		F
Engine Electrical System		G
Automatic Transmission	Electronically-Controlled	K1
	Transfer Case	K2
Propeller Shaft		L
Front and Rear Axles		M
Steering System		N
Braking System		P
Wheels and Tires		Q
Suspension		R
Body		S
Body Electrical System		T
Heater and Air Conditioner Systems		U

© 1995 Mazda Motor Corporation
PRINTED IN U.S.A. SEP. '95
Form No. 1501-10-95I
Part No. 9999-95-038B-96

VEHICLE IDENTIFICATION NUMBERS (VIN)

2WD WAGON
JM3 LV522*T0 800001—

4WD WAGON
JM3 LV523*T0 800001—

GENERAL INFORMATION

SAFETY INFORMATION	GI- 2	ELECTRICAL TROUBLESHOOTING	
LUBRICANTS	GI- 2	TOOLS	GI-13
JACKING POSITIONS	GI- 2	TEST LIGHT	GI-13
SAFETY STAND AND VEHICLE LIFT		JUMPER WIRE	GI-13
POSITIONS	GI- 2	VOLTMETER	GI-13
DYNAMOMETER	GI- 3	OHMMETER	GI-13
COMPRESSED AIR	GI- 3	ELECTRICAL PARTS	GI-14
HOW TO USE THIS MANUAL	GI- 3	BATTERY CABLE	GI-14
ADVISORY MESSAGES	GI- 3	CONNECTORS	GI-14
PREPARATION	GI- 3	TERMINALS	GI-15
REPAIR PROCEDURE	GI- 3	SENSORS, SWITCHES,	
SYMBOLS	GI- 4	AND RELAYS	GI-15
IDENTIFICATION NUMBER		WIRING HARNESS	GI-16
LOCATIONS	GI- 5	MAIN FUSE	GI-16
UNITS	GI- 6	INSTALLATION OF A RADIO	
ABBREVIATIONS	GI- 7	SYSTEM	GI-17
SAE STANDARDS	GI- 8	4-WHEEL DRIVE (4WD)	GI-17
FUNDAMENTAL PROCEDURES	GI-10	TOWING	GI-18
PROTECTION OF THE VEHICLE ..	GI-10	TRAILER TOWING	GI-19
PREPARATION OF TOOLS		WEIGHT LIMITS	GI-19
AND MEASURING EQUIPMENT ..	GI-10	TONGUE LOAD	GI-19
SPECIAL TOOLS	GI-10	PRE-DELIVERY INSPECTION	GI-20
REMOVAL OF PARTS	GI-10	PRE-DELIVERY INSPECTION	
DISASSEMBLY	GI-10	TABLE	GI-20
REASSEMBLY	GI-11	SCHEDULED MAINTENANCE	GI-21
ADJUSTMENTS	GI-12	SCHEDULED MAINTENANCE TABLE	
RUBBER PARTS AND TUBING	GI-12	(EXCEPT CANADA)	GI-21
HOSE CLAMPS	GI-12	SCHEDULED MAINTENANCE TABLE	
TORQUE FORMULAS	GI-12	(CANADA)	GI-29
WISE	GI-12		

SAFETY INFORMATION

LUBRICANTS

Avoid prolonged and repeated contact with petroleum-based oils. Used oil may irritate the skin, and can cause skin cancer and other skin disorders.

Wash thoroughly after working with oil. We recommend water-soluble hand cleaners. Do not use kerosene, gasoline, or any other solvent to remove oil from your skin.

If repeated or prolonged contact with oil is necessary, wear protective clothing. Soiled clothing, particularly those soiled with used oils and greases containing lead, should be cleaned at regular intervals.

JACKING POSITIONS


Warning

- **Improperly jacking a vehicle is dangerous. The vehicle can slip off the jack and cause serious injury. Use only the correct front and rear jacking positions and block the wheels.**

Use safety stands to support the vehicle after it has been lifted.


Front

At the center of the crossmember



Rear


At the center of the crossmember



SAFETY STAND AND VEHICLE LIFT POSITIONS


Front

Both sides of the vehicle



Rear

Both sides of the vehicle



DYNAMOMETER

When test-running a vehicle on a dynamometer:

- Place a fan, preferably a vehicle-speed proportional type, in front of the vehicle.
- Connect an exhaust gas ventilation unit.
- Cool the exhaust pipes with a fan.
- Keep the area around the vehicle uncluttered.
- Watch the water temperature gauge.

COMPRESSED AIR

When using compressed air to clean or remove parts:

- Wear protective eye wear.
- Hold a rag over the opening to prevent parts from shooting out.
- Take precautions so that people around you are not struck by flying debris.

HOW TO USE THIS MANUAL**ADVISORY MESSAGES**

You'll find several **Warnings**, **Cautions**, and **Notes** in this manual.

Warning

- A **Warning** indicates a situation in which serious injury or death could result if the warning is ignored.

Caution


- A **Caution** indicates a situation in which damage to the vehicle could result if the caution is ignored.

Note

- A **Note** provides added information that will help you to complete a particular procedure.

PREPARATION

This points out the needed **SSTs** for the service operation. It is best to gather all necessary **SSTs** before beginning work.

Example:**REPAIR PROCEDURE**

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.


Example:

SHOWS SPECIAL SERVICE TOOL (SST) FOR THE SERVICE OPERATION

SHOWS EXPENDABLE PARTS

SHOWS APPLICATION POINT OF OIL, ETC.

SHOWS RELATED PAGE FOR SERVICE



SHOWS TIGHTENING TORQUE SPECIFICATIONS

SHOWS TIGHTENING TORQUE UNITS

SHOWS VISUAL INSPECTION INFORMATION

*1: The numbers (①, etc.) refer to part identification and servicing procedures.


SYMBOLS

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.


Symbol	Meaning	Kind
	Apply oil	New engine oil or gear oil as appropriate
	Apply brake fluid	FMVSS116: DOT-3
	Apply automatic transaxle fluid	M-III or Dexron®II
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly

IDENTIFICATION NUMBER LOCATIONS


VEHICLE IDENTIFICATION NUMBER



AUTOMATIC TRANSMISSION MODEL AND NUMBER



ENGINE MODEL AND NUMBER



UNITS

Electrical current	A (ampere)
Electric potential	V (volt)
Electric power	W (watt)
Length	mm (millimeter) in (inch)
Negative pressure	kPa (kilo Pascal) mmHg (millimeters of mercury) inHg (inches of mercury)
Positive pressure	kPa (kilo Pascal) kgf/cm ² (kilogram force per square centimeter) psi (pounds per square inch)
Resistance	Ω (ohm)
Speed	revolution per minute
Torque	N·m (Newton meter) kgf·m (kilogram force per meter) kgf·cm (kilogram force per centimeter) ft·lbf (foot pound) in·lbf (inch pound)
Volume	L (liter) US qt (U.S. quart) Imp qt (Imperial quart) ml (milliliter) cc (cubic centimeter) cu in (cubic inch) fl oz (fluid ounce)
Weight	g (gram) oz (ounce)

Conversion to SI Units (Système International d'Unités)

All numerical values in this manual are based on SI units. Numbers shown in conventional units are converted from these values.

Rounding off

Converted values are rounded off to the same number of places as the SI unit value. For example, if the SI unit value is 17.2 and the value after conversion is 37.84, the converted value will be rounded off to 37.8.

Upper and lower limits

When the data indicates upper and lower limits, the converted values are rounded down if the SI unit value is an upper limit and rounded up if the SI unit value is a lower limit. Therefore, converted values for the same SI unit value may differ after conversion. For example, consider 2.7 kgf/cm² in the following specifications:

- 210—260 kPa { 2.1—2.7 kgf/cm² , 30—38 psi }
- 270—310 kPa { 2.7—3.2 kgf/cm² , 39—45 psi }

The actual converted values for 2.7 kgf/cm² are 264 kPa and 38.4 psi. In the top specification, 2.7 is used as an upper limit, so its converted values are rounded down to 260 and 38. In the bottom specification, 2.7 is used as a lower limit, so its converted values are rounded up to 270 and 39.

ABBREVIATIONS

ABDC	After bottom dead center
ABS	Antilock brake system
ACC	Accessories
AFW	Automatic freewheel
ALL	Automatic load leveling
AT	Automatic transmission
ATDC	After top dead center
ATF	Automatic transmission fluid
BAC	Bypass air control
BARO V	Barometric pressure signal voltage
BAROTCM	Barometric pressure signal (TCM)
BBDC	Before bottom dead center
B/L	Bi-level
BRK SW	Brake switch
BTDC	Before top dead center
CDCV	Canister drain cut valve
CM	Control module
CPU	Central processing unit
D	Drive
DEF	Defrost
DRL	Daytime running lights
EC-AT	Electronically controlled automatic transmission
ECT V	Engine coolant temperature signal voltage
E/L	Electrical load
EX	Exhaust
FAT	FAT terminal (data link connector)
FHO2S	Heated oxygen sensor (front)
FHO2SH	Heated oxygen sensor heater (front)
FTL V	Fuel tank level signal voltage
FTP	Fuel tank pressure
FTP V	Fuel tank pressure signal voltage
H/D	Heat/Def
HEAT	Heater
HI	High
HLA	Hydraulic lash adjuster
HU	ABS hydraulic unit
IACV	Idle air control valve
IAT V	Intake air temperature signal voltage
IATDC	Intake air temperature (dynamic chamber)
IATDC V	Intake air temperature signal voltage (dynamic chamber)
IC	Integrated circuit
IGN	Ignition
IG SW	Ignition switch
IGT	Ignition timing
IN	Intake
INJ	Fuel injection duration
INJ#1	Fuel injector (cylinder No.1)
INT	Intermittent
LH	Left hand
LO	Low
M	Motor
N	Neutral
OFF	Switch off
ON	Switch on
P	Park
PCV	Positive crankcase ventilation
PRC	Pressure regulator control
PRCV	PRC solenoid valve
PRGV	Purge solenoid valve
P/S	Power steering
R	Reverse
RABS	Rear-wheel antilock brake system
REC	Recirculate
RH	Right hand
RHO2S	Heated oxygen sensor (rear)
RLY	relay
RPM	Engine speed
SAS	Sophisticated air bag sensor
SST	Special service tool

ST	Start
SW	Switch
TAT	TAT terminal (data link connector)
TEN	TEN terminal (data link connector)
TDC	Top dead center
TNS	Tail-, parking, and license plate lights
TPCV	Tank pressure control valve
TP V	Throttle position sensor signal voltage
TR SW	Transmission range switch
VAF V	Volume air flow signal voltage
VRIS	Variable resonance induction system
VRISV1	VRIS solenoid valve No.1
VS	Vehicle speed
2WD	2-wheel drive
4WD	4-wheel drive

SAE STANDARDS

In accordance with new regulations, SAE (Society of Automotive Engineers) standard names and abbreviations are now used in this manual. The table below lists the names and abbreviations that have been used in Mazda manuals up to now and their SAE equivalents.

Previous Standard		SAE Standard		
Abbreviation	Name	Abbreviation	Name	Remark
—	Accelerator Pedal	AP	Accelerator Pedal	
—	Air Cleaner	ACL	Air Cleaner	
—	Air Conditioning	A/C	Air Conditioning	
—	Airflow Meter	VAF	Volume Air Flow Sensor	
—	Airflow Sensor	MAF	Mass Air Flow Sensor	
—	Alternator	GEN	Generator	
—	ATF Thermosensor	—	Transmission (Transaxle) Fluid Temperature Sensor	
—	Atmospheric Pressure	BARO	Barometric Pressure	
Vb	Battery Voltage	B+	Battery Positive Voltage	
—	Catalytic Converter	OC	Oxidation Catalytic Converter	
		TWC	Three-Way Catalytic Converter	
		WU-TWC	Warm Up Three-Way Catalytic Converter	#1
—	Circuit Opening Relay	FPR	Fuel Pump Relay	#2
—	Clutch Position	CPP	Clutch Pedal Position	
—	Crank Angle Sensor	CMP	Camshaft Position Sensor	
—	Crank Angle Sensor 2	CKP	Crankshaft Position Sensor	
—	Diagnosis Connector	DLC	Data Link Connector	
—	Diagnosis/Self-Diagnosis	OBD	On-Board Diagnostic	
—	Direct Ignition	DLI	Distributorless Ignition	
—	EC-AT Control Unit	TCM	Transmission (Transaxle) Control Module	
EGL	Electronic Gasoline Injection System	CIS	Continuous Fuel Injection System	
—	Electronic Spark Ignition	EI	Electronic Ignition	#3
ECU	Engine Control Unit	PCM	Powertrain Control Module	#4
		ECM	Engine Control Module	
—	Engine Modification	EM	Engine Modification	
—	Engine RPM Signal	—	Engine Speed Input Signal	
—	Evaporative Emission	EVAP	Evaporative Emission	
—	Exhaust Gas Recirculation	EGR	Exhaust Gas Recirculation	
—	Fan Control	FC	Fan Control	
—	Feedback System	CLS	Closed Loop System	
—	Flexible Fuel	FF	Flexible Fuel	
—	Fuel Pump	FP	Fuel Pump	
—	Fully Closed	CTP	Closed Throttle Position	
—	Fully Open	WOT	Wide Open Throttle	
—	Ground/Earth	GND	Ground	

#1: Directly connected to exhaust manifold.

#2: In some models, there is a fuel pump relay that controls pump speed. That relay is now called the fuel pump relay (speed).

#3: Controlled by the ECM (PCM).

#4: Device that controls engine and powertrain.


Previous Standard		SAE Standard		
Abbreviation	Name	Abbreviation	Name	Remark
—	IC Regulator	VR	Voltage Regulator	
—	Idle Speed Control	IAC	Idle Air Control	
—	Idle Switch	—	Closed Throttle Position Switch	
—	Igniter	ICM	Ignition Control Module	
—	Inhibitor Position	TR	Transmission (Transaxle) Range	
—	Intake Air Pressure	MAP	Manifold Absolute Pressure	
—	Intake Air Thermo	IAT	Intake Air Temperature	
—	Intercooler	CAC	Charge Air Cooler	
—	Knock Sensor	KS	Knock Sensor	
—	Line Pressure Solenoid Valve	—	Pressure Control Solenoid	
—	Lock-up Position	TCC	Torque Converter Clutch	
—	Malfunction Indicator Light	MIL	Malfunction Indicator Lamp	
—	Multipoint Fuel Injection	MFI	Multipoint Fuel Injection	
—	Open Loop	OL	Open Loop	
—	Overdrive	4GR	Fourth Gear	
—	Oxygen Sensor	HO2S	Heated Oxygen Sensor	With heater
		O2S	Oxygen Sensor	
—	Park/Neutral Range	PNP	Park/Neutral Position	
—	Power Steering Pressure	PSP	Power Steering Pressure	
—	Pulse Generator	—	Input/Turbine Speed Sensor	
—	Reed Valve	SAPV	Secondary Air Pulse Valve	
—	Secondary Air Injection System	PAIR	Pulsed Secondary Air Injection	Pulsed injection
		AIR	Secondary Air Injection	Inject with compressor
		SFI	Sequential Multipoint Fuel Injection	
—	Sequential Fuel Injection	SFI	Sequential Multipoint Fuel Injection	
—	Service Code(s)	DTC	Diagnostic Trouble Code(s)	
—	Spark Ignition	DI	Distributor Ignition	
—	Stoplight Switch	—	Brake Switch	
—	Test Mode	DTM	Diagnostic Test Mode	#5
—	Throttle Body	TB	Throttle Body	
—	Throttle Sensor	TP	Throttle Position Sensor	
—	Turbocharger	TC	Turbocharger	
—	Vehicle Speed Sensor	VSS	Vehicle Speed Sensor	
—	Vehicle Speed Sensor 1	—	Output Speed Sensor	
—	Water Thermo	ECT	Engine Coolant Temperature	
—	1-2 Shift Solenoid Valve	—	Shift Solenoid A	
	Shift A Solenoid Valve			
—	2-3 Shift Solenoid Valve	—	Shift Solenoid B	
	Shift B Solenoid Valve			
—	3-4 Shift Solenoid Valve	—	Shift Solenoid C	
—	3rd Gear	3GR	Third Gear	
—	—	—	Incorrect Gear Ratio	

#5: Diagnostic trouble codes depend on the diagnostic test mode.

FUNDAMENTAL PROCEDURES


PROTECTION OF THE VEHICLE

Always be sure to cover fenders, seats, and floor areas before starting work.




PREPARATION OF TOOLS AND MEASURING EQUIPMENT

Be sure that all necessary tools and measuring equipment are available before starting any work.




SPECIAL TOOLS

Use special tools when they are required.




REMOVAL OF PARTS


While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair. After removing the part, plug all holes and ports to prevent foreign material from entering.



DISASSEMBLY


If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.





1. Inspection of parts


When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.



2. Arrangement of parts

All disassembled parts should be carefully arranged for reassembly.

Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.




3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

Warning

- **Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.**



REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts.


If removed, these parts should be replaced with new ones:

- | | |
|----------------|-----------------|
| 1. Oil seals | 2. Gaskets |
| 3. O-rings | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts |

Depending on location:


1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.






ADJUSTMENTS

Use suitable gauges and testers when making adjustments.




RUBBER PARTS AND TUBING

Prevent gasoline or oil from getting on rubber parts or tubing.



HOSE CLAMPS

When reinstalling, position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.




TORQUE FORMULAS

When using a torque wrench-SST combination, the written torque must be recalculated due to the extra length that the SST adds to the torque wrench. Recalculate the torque by using the following formulas. Choose the formula that applies to you.

Torque Unit	Formula
N·m	$N \cdot m \times [L / (L + A)]$
kgf·m	$kgf \cdot m \times [L / (L + A)]$
kgf·cm	$kgf \cdot cm \times [L / (L + A)]$
ft·lbf	$ft \cdot lbf \times [L / (L + A)]$
in·lbf	$in \cdot lbf \times [L / (L + A)]$


A = The length of the SST past the torque wrench drive.

L = The length of the torque wrench.



WISE

When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.




ELECTRICAL TROUBLESHOOTING TOOLS

TEST LIGHT

The test light, as shown in the figure, uses a 12 V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

Caution

- Using a bulb over 3.4 W when checking the control module may damage the control module.




JUMPER WIRE

A jumper wire is used to create a temporary circuit. Connect the jumper wire between the terminals of a circuit to bypass a switch.


Caution

- Do not connect a jumper wire from the power source line to a body ground. This may cause burning or other damage to wiring harnesses or electronic components.



VOLTMETER

The DC voltmeter is used to measure circuit voltage. A voltmeter with a range of 15 V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.




OHMMETER

The ohmmeter is used to measure the resistance between two points in a circuit, and to check for continuity and short circuits.

Caution


- Do not connect the ohmmeter to any circuit to which voltage is applied. This will damage the ohmmeter.



ELECTRICAL PARTS

BATTERY CABLE

Before disconnecting connectors or removing electrical parts, disconnect the negative battery cable.




CONNECTORS

Data Link Connector

Insert the probe into the service hole when connecting a jumper wire to the data link connector.


Caution

- Inserting a jumper wire probe into the data link connector terminal may damage the terminal.




Disconnecting Connectors

When disconnecting two connectors, grasp the connectors, not the wires.




Connectors can be disconnected by pressing or pulling the lock lever as shown.




Locking Connector

When locking connectors, listen for a click that will indicate they are securely locked.

**Inspection**


1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wiring harness side.




2. Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wiring harness side.

Caution

- To prevent damage to the terminal, wrap a thin wire around the lead before inserting it into the terminal.


**TERMINALS****Inspection**

Pull lightly on individual wires to check that they are secured in the terminal.


**Replacement**

Use the appropriate tools to remove a terminal as shown. When installing a terminal, be sure to insert it until it locks securely.

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.

**SENSORS, SWITCHES, AND RELAYS**

Handle sensors, switches, and relays carefully. Do not drop them or strike them against other objects.




WIRING HARNESS Wiring Color Codes

Two-color wires are indicated by a two-color code symbol.

The first letter indicates the base color of the wire and the second the color of the stripe.

CODE	COLOR	CODE	COLOR
B	Black	O	Orange
BR	Brown	P	Pink
G	Green	R	Red
GY	Gray	V	Violet
L	Blue	W	White
LB	Light Blue	Y	Yellow
LG	Light Green	—	—



MAIN FUSE

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the main fuse block cover.
3. Remove the main fuse block mounting nuts.
4. Remove the main fuse mounting bolts.
5. Remove the MAIN fuse.
6. Install in the reverse order of removal.

INSTALLATION OF A RADIO SYSTEM

If a radio system is installed improperly or if a high-powered type is used, the CIS and other systems may be affected.

When the vehicle is to be equipped with a radio, observe the following precautions:


1. Install the antenna at the farthest point from control modules.
2. Install the antenna feeder as far as possible away from the control module harnesses (**at least 30 cm { 11.8 in }**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered radio system.




4-WHEEL DRIVE (4WD)

1. Shifting from 2WD to 4WD must be done **below 120 km/h { 65 MPH }**.
2. Shifting from 4WD to 2WD must be done with the center differential in **FREE** mode.
3. Shifting shock may occur when shifting 2WD↔4WD while turning tight circle.
4. Shifting 2WD↔4WD may not be completed if shift is made while the vehicle is stopped. Drive the vehicle to complete the shift.
5. Shifting 2WD↔4WD may take extra time during acceleration or while ascending grades. It is a good practice to release the accelerator slightly when shifting.
6. Shifting 2WD↔4WD may take extra time in extremely cold weather because of the high viscosity of the transfer case oil.

TOWING



WHEEL DOLLIES



4WD MODELS:
SET CENTER DIFFERENTIAL
UNLOCKED AND DRIVING MODE
TO 2WD.



AUTOMATIC TRANSMISSION:
DO NOT EXCEED 56 km/h { 35 mph } OR
56 km { 35 miles }.

Proper towing equipment is necessary to prevent damage to the vehicle.

Laws and regulations applicable to vehicles in tow must always be observed.

As a general rule, towed vehicles should be pulled with the driving wheels off the ground. If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.

With either automatic or manual transmission:

1. Set the ignition switch in the ACC position.
2. Place the selector lever or shift lever in N (Neutral).
3. Release the parking brake.

Caution

- Do not tow the vehicle backward with driving wheels on the ground. This may cause internal damage to the transmission.


Caution

- Don't use the hook loops under the front and rear for towing. They are designed ONLY for tying down the vehicle when it's being transported. Using them for towing will damage the bumper.

Caution


- The power assist for the brakes and steering are inoperable while the engine is off.
- Do not use the tie down hook under the front or rear of the vehicle for towing. These hooks are designed ONLY for transport tie down. If tie down hook are used for towing the front or rear skirt and bumper will be damaged.

FRONT




TIE DOWN HOOKS

REAR
2WD



TIE DOWN HOOKS

4WD



TOWING HOOK

Trailer Towing Load Table

kg { lb }

Model	Vehicle equipment	Max. TTW	Max. GCWR	Max frontal area
2WD	With towing package	1,950 { 4,300 }	3,674 { 8,100 }	4.65 m ² { 50 ft ² }
	Without towing package	1,179 { 2,600 }	2,903 { 6,400 }	2.97 m ² , { 32 ft ² }
4WD	With towing package	1,814 { 4,000 }	3,688 { 8,130 }	4.65 m ² { 50 ft ² }
	With towing package	1,905 { 4,200 }	3,688 { 8,130 }	2.97 m ² { 32 ft ² }
	Without towing package	1,179 { 2,600 }	3,053 { 6,730 }	

Towing package (if equipped): The optional towing package includes the Automatic load Leveling (ALL) system, an automatic transmission oil cooler, a heavy-duty cooling fan, and a standard size spare tire. Vehicles with the towing package can tow a heavier trailer and carry more cargo weight than standard equipped vehicles.

TTW: Total trailer Weight. (TTW: Sum of weights of the trailer, its cargo load, trailer hitch, vehicle passengers, and load)

GCWR: Gross combined Weight Rating.

TRAILER TOWING

WEIGHT LIMITS

Before towing, make sure the total trailer weight, gross combined weight rating, gross axle weight ratings, trailer load, and trailer tongue load are all within the prescribed limits.

- The total trailer weight is the sum of the weights of the trailer load (trailer weight plus cargo), trailer hitch, vehicle passengers, and vehicle load. Never allow the total trailer weight to exceed the specifications in the Trailer Towing Load Table.
- The maximum GCWR (Gross Combined Weight Rating) is the combined weight of the trailer and load plus towing vehicle (including trailer hitch, vehicle passengers, and load). The maximum GCWR must not exceed the specifications in the Trailer Towing Load Table.

Calculating the maximum permissible trailer load

The maximum permissible trailer load is the value obtained by subtracting the towing vehicle weight (including trailer hitch, vehicle passengers, and vehicle load) from the Max GCWR in the Trailer Towing Load Table. In a high altitude operation environment, a gasoline engine loses power at a rate of 3% to 4% per 304 m { 1,000 ft } elevation. For these high altitude conditions, a reduction in gross vehicle weight and gross combined weight is recommended. Such a reduction will result in improved vehicle performance.

Warning

- Attempting to tow loads greater than those specified may cause serious handling and performance problems that could result in personal injury and/or vehicle damage.

TONGUE LOAD

Trailer tongue load is considered part of the vehicle passenger, luggage, and gear load.


The trailer tongue load must be 10—15 % of the trailer load (sum of the weights of the trailer and cargo.) Always try to load the trailer with the weight about 60 % toward the front and 40 % toward the rear. Never load the trailer with more weight in the rear than in the front.

The front and rear GAWR (Gross Axle Weight Rating) and the GVWR (Gross Vehicle Weight Rating) must not be exceeded because vehicle handling, braking, and performance will be adversely affected.

The GAWR and GVWR values are found on the vehicle's Motor Vehicle Safety Certification label posted on the driver side door pillar and also in section 7 of the Owner's Manual.

Note

- The total trailer weight and tongue load can be determined by weighing the trailer, as illustrated, on platform scales located at, for example, a highway weighing station, trucking company, junkyard, etc.



**THIS PAGE
INTENTIONALLY
LEFT BLANK**

SCHEDULED MAINTENANCE

SCHEDULED MAINTENANCE TABLE (EXCEPT CANADA)

Schedule 1 (Normal driving conditions):

The vehicle is mainly operated where none of the "unique driving conditions" apply.

Schedule 2 (Unique driving conditions):

- Repeated short distance driving
- Driving in dusty conditions
- Driving with extended use of brakes
- Driving in areas where road salt or other corrosive materials are used
- Driving on rough or muddy roads
- Extended periods of idling or low-speed operation
- Driving for long prolonged periods in cold temperatures or extremely humid climates

Schedule 1 (Normal driving conditions)

Chart symbols:

I : Inspect and repair, clean, or replace if necessary.

R : Replace

L : Lubricate

Remarks:

- After 48 months or 60,000 miles { 96,000 km }, continue to follow the described maintenance at the recommended intervals.
- *1 This maintenance is required for all states except California.
However, we recommend that it also be performed on California vehicles.
- *2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

Schedule 1 (Normal driving conditions)

Maintenance Interval	Number of months or miles { km }, whichever comes first										Service data and inspection point	Page	
	Months	6	12	18	24	30	36	42	48				
	Maintenance Item × 1,000 Km × 1,000 Miles	7.5	15	22.5	30	37.5	45	52.5	60				
ENGINE													
Engine oil	R	R	R	R	R	R	R	R	R	R	R	Oil pan capacity: 4.5 L { 4.8 US qt , 4.0 Imp qt }	D-4
Oil filter	R	R	R	R	R	R	R	R	R	R	R	0.22 L { 0.23 US qt , 0.19 Imp qt }	D-4
Drive belts (tension)					I						I	• Cracks or damage • Tension	B-4
Engine timing belt (except California)												Replace every 60,000 miles { 96,000 km }	B-7
Engine timing belt (California)												Inspect at 60,000 miles { 96,000 km } and again at 90,000 miles { 144,000 km }*2 Replace every 105,000 miles { 168,000 km }	
PCV valve											I*2	Function	F-28
Hoses and tubes for emission												Replace every 80,000 miles { 128,000 km }	F-23
AIR CLEANER													
Air cleaner element					R						R	—	F-5
IGNITION SYSTEM													
Spark plugs					R						R	• Plug gap: 1.0—1.1 mm { 0.040—0.043 in } • Recommended spark plugs: NGK BKR5E-11 BKR6E-11 NIPPONDENSO K16PR-U11 K20PR-U11	G-3
Initial ignition timing											I*1	Ignition timing BTDC 10—12° (11 ± 1°)	F-3

Schedule 1 (Normal driving conditions) (Cont'd)

Maintenance Interval	Number of months or miles { km }, whichever comes first										Service data and inspection point	Page	
	Months	6	12	18	24	30	36	42	48				
	Maintenance Item × 1,000 Km × 1,000 Miles	12	24	36	48	60	72	84	96				
FUEL SYSTEM													
Idle speed			I*2				I*2					Idle speed 760—800 (780 ± 20) rpm—AT (P range)	F-3
Fuel filter											R*1	—	F-15
Fuel lines and hoses					I*2						I*1	Fittings, connections and components for leaks	F-9 F-23
Fuel hoses (California)							Inspect every 105,000 miles { 168,000 km }						
COOLING SYSTEM													
Cooling system					I						I	• Hoses for cracks or wear • Coolant level	E-5
Engine coolant					Replace at first 45,000 miles { 72,000 km } or 36 months; after that, every 30,000 miles { 48,000 km } or 24 months								E-5
CHASSIS AND BODY													
Brake lines, hoses, and connections					I						I	Proper attachment and connections	P-6
Brake fluid					R						R	Brake fluid: FMVSS 116 DOT-3	P-3
Disc brakes					I						I	• Disc plate thickness: Front: 26.0 mm { 1.02 in }—Minimum Rear: 16.0 mm { 0.63 in }—Minimum • Pad thickness: Front: 2.0 mm { 0.08 in }—Minimum Rear: 1.0 mm { 0.04 in }—Minimum	P-18 P-23 P-16 P-20

Schedule 1 (Normal driving conditions) (Cont'd)

Maintenance Interval	Number of months or miles { km }, whichever comes first										Service data and inspection point	Page		
	Months	6	12	18	24	30	36	42	48					
	Maintenance Item × 1,000 Km × 1,000 Miles	7.5	15	22.5	30	37.5	45	52.5	60					
CHASSIS AND BODY														
Automatic transmission fluid												R	• Replacement fluid capacity: Approx. 4.0 L { 4.2 US qt, 3.5 Imp qt }	K1-30
Steering operation and linkages					I							I	• Free play: 0—30 mm { 0—1.18 in } • Operation and looseness • Fluid leakage or oozing	—
Front suspension ball joints					I							I	Damage, looseness, and grease leakage	R-16 R-18
Front axle oil (4WD) Rear axle oil												R	Oil capacity Front: 1.7 L { 1.8 US qt, 1.5 Imp qt } Rear: 1.5 L { 1.6 US qt, 1.3 Imp qt }	M-36 M-58
Transfer case oil (4WD)												R	Oil capacity: 1.5 L { 1.6 US qt, 1.3 Imp qt }	K2-29
Drive shaft dust boots (4WD)					I							I	Cracks, grease leakage, and looseness of band	M-24
Bolts and nuts on chassis and body					I							I	Retighten all loose bolts and nuts	—
Exhaust system heat shields					I							I	Insulator clearance to body and exhaust system	F-22
All locks and hinges					L	L	L	L	L	L	L	L	Check for damage	S-6, 7, 9, 10
AIR CONDITIONER SYSTEM (IF EQUIPPED)														
A/C compressor operation					I							I	—	—

Schedule 2 (Unique driving conditions)**Chart symbols:**

- I** : Inspect and repair, clean, or replace if necessary.
(Inspect, and if necessary replace...Air cleaner element JE engine only)
- R** : Replace
- L** : Lubricate

Remarks:

- After 48 months or 60,000 miles { 96,000 km }, continue to follow the described maintenance at the recommended intervals.
 - *1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
 - *2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

Schedule 2 (Unique driving conditions) (Cont'd)

Maintenance Interval Maintenance Item	Number of months or miles { km }, whichever comes first														Service data and inspection point	Page			
	Months	4	8	12	16	20	24	28	32	36	40	44	48						
	× 1,000 Km	8	16	24	32	40	48	56	64	72	80	88	96						
	× 1,000 Miles	5	10	15	20	25	30	35	40	45	50	55	60						
FUEL SYSTEM																			
Idle speed				I*2													Idle speed 760—800 (780 ± 20) rpm—AT (P range)	F-3	
Fuel filter										I*2									F-15
Fuel lines and hoses																		Fittings, connections and components for leaks	F-9 F-23
Fuel hoses (California)																			
Inspect every 105,000 miles { 168,000 km }																			
COOLING SYSTEM																			
Cooling system																		• Hoses for cracks or wear • Coolant level	E-5
Engine coolant																			E-5
CHASSIS AND BODY																			
Brake lines, hoses, and connections																		Proper attachment and connections	P-6
Brake fluid																		Brake fluid: FMVSS 116 DOT-3	P-3
Disc brakes																		• Disc plate thickness: Front: 26.0 mm { 1.02 in }—Minimum Rear: 16.0 mm { 0.63 in }—Minimum • Pad thickness: Front: 2.0 mm { 0.08 in }—Minimum Rear: 1.0 mm { 0.04 in }—Minimum	P-18 P-23 P-16 P-20

Schedule 2 (Unique driving condition) (Cont'd)

Maintenance Interval	Number of months or miles { km }, whichever comes first													Service data and inspection point	Page	
	Months	4	8	12	16	20	24	28	32	36	40	44	48			
	Maintenance Item	× 1,000 Km	8	16	24	32	40	48	56	64	72	80	88			96
	× 1,000 Miles	5	10	15	20	25	30	35	40	45	50	55	60			
CHASSIS AND BODY																
Steering operation and linkages							I							I	<ul style="list-style-type: none"> • Free play: 0—30 mm { 0—1.18 in } • Operation and looseness • Fluid leakage or oozing 	—
Front suspension ball joints							I							I	Damage, looseness and grease leakage	R-16 R-18
Front axle oil (4WD) Rear axle oil							R							R	Oil capacity Front: 1.7 L { 1.8 US qt, 1.5 Imp qt } Rear: 1.5 L { 1.6 US qt, 1.3 Imp qt }	M-36 M-58
Automatic transmission fluid							R							R	Replacement fluid capacity: Approx. 4.0 L { 4.2 US qt, 3.5 Imp qt }	K1-30
Transfer case oil (4WD)							R							R	Oil capacity: 1.5 L { 1.6 US qt, 1.3 Imp qt }	K2-29
Drive shaft dust boots (4WD)							I							I	Cracks, grease leakage and looseness of band	M-24
Bolts and nuts on chassis and body				I			I							I	Retighten all loose bolts and nuts	—
Exhaust system heat shields							I							I	Insulator clearance to body and exhaust system	F-22
All locks and hinges	L	L	L	L	L	L	L	L	L	L	L	L	L	L	Check for damage	S-6,7, 9, 10
AIR CONDITIONER SYSTEM (IF EQUIPPED)																
A/C compressor operation				I			I							I	—	—

SCHEDULED MAINTENANCE**SCHEDULED MAINTENANCE TABLE (CANADA)****Schedule****Chart symbols:**

- I** : Inspect and repair, clean, or replace if necessary.
 (Inspect, and if necessary replace...Air cleaner element JE engine only)
- R** : Replace
- L** : Lubricate
- Rt** : Rotation (tires)

Remarks:

After 60 months or 60,000 miles { 96,000 km }, continue to follow the described maintenance at the recommended intervals.

*1: Replacement of the timing belt is required every 60,000 miles { 96,000 km }.

Failure to replace this belt may result in damage to the engine.

*2: This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

Schedule (Cont'd)

Maintenance Interval	Number of months or miles { km }, whichever comes first														Service data and inspection point	Page	
	Months	5	10	15	20	25	30	35	40	45	50	55	60				
	Maintenance Item	8	16	24	32	40	48	56	64	72	80	88	96				
	× 1,000 Km	5	10	15	20	25	30	35	40	45	50	55	60				
	× 1,000 Miles	5	10	15	20	25	30	35	40	45	50	55	60				
ENGINE																	
Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	Oil pan capacity: 4.5 L { 4.8 US qt., 4.0 Imp qt }	D-4
Oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	Oil filter capacity 0.22 L { 0.23 US qt., 0.19 Imp qt }	D-4
Tension of all drive belts		I	I	I	I	I	I	I	I	I	I	I	I	I	I	• Cracks or damage • Tension	B-4
Engine timing belts *1															R		B-7
FUEL SYSTEM																	
Idle speed				I						I					I	• Idle speed 760—800 (780 ± 20) rpm—AT (P range)	F-3
Fuel filter							R								R		F-15
Fuel lines and hoses											I*2				I	• Fittings, connections and components for leaks	F-9 F-23
PCV valve *2															I	Function	F-28
Emission hoses and tubes															I		F-23
AIR CLEANER																	
Air cleaner element				I						R					R		F-5

Schedule (Cont'd)

Maintenance Interval	Number of months or miles { km }, whichever comes first												Service data and inspection point	Page								
	Months	5	10	15	20	25	30	35	40	45	50	55			60							
	Maintenance Item × 1,000 Km × 1,000 Miles	8	16	24	32	40	48	56	64	72	80	88			96							
IGNITION SYSTEM																						
Spark plugs																	<ul style="list-style-type: none"> • Plug gap: 1.0—1.1 mm { 0.040—0.043 in } • Recommended spark plugs: <table border="1" style="margin-left: 20px;"> <tr> <td>NGK</td> <td>BKR5E-11 BKR6E-11</td> </tr> <tr> <td>NIPPONDENSO</td> <td>K16PR-U11 K20PR-U11</td> </tr> </table>	NGK	BKR5E-11 BKR6E-11	NIPPONDENSO	K16PR-U11 K20PR-U11	G-3
NGK	BKR5E-11 BKR6E-11																					
NIPPONDENSO	K16PR-U11 K20PR-U11																					
COOLING SYSTEM																						
Engine coolant level and strength		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	E-5					
Cooling system for leaks																	E-5					
Engine coolant																	E-5					
CHASSIS AND BODY																						
Brake lines, and hoses																	P-6					
Brake fluid							R										P-3					
Disc brakes																	<ul style="list-style-type: none"> • Disc plate thickness: Front: 26.0 mm { 1.02 in }—Minimum Rear: 16.0 mm { 0.63 in }—Minimum • Pad thickness: Front: 2.0 mm { 0.08 in }—Minimum Rear: 1.0 mm { 0.04 in }—Minimum 	P-18 P-23 P-16 P-20				
Automatic transmission fluid level																	K1-30					

Schedule (Cont'd)

Maintenance Interval	Number of months or miles { km }, whichever comes first												Service data and inspection point	Page										
	Months	5	10	15	20	25	30	35	40	45	50	55			60									
	Maintenance Item	8	16	24	32	40	48	56	64	72	80	88			96									
CHASSIS AND BODY																								
Automatic transmission fluid							R							R	• Replacement fluid capacity Approx. 4.0 L { 4.2 US qt , 3.5 Imp qt }	K1-30								
Oil level in differential and transfer case (in models so equipped)															• Oil type Front differential Above -18 °C { 0 °F }: API GL-5, SAE 90 Below -18 °C { 0 °F }: API GL-5, SAE 80W Rear differential Above -18 °C { 0 °F }: API GL-5, SAE 90 Below -18 °C { 0 °F }: API GL-5, SAE 80W • Transfer case API service GL-4 or GL-5, SAE 75W-90	M-36 M-57								
Front differential oil (4WD)							R							R	Oil capacity 1.7 L { 1.8 US qt , 1.5 Imp qt }	M-36								
Rear differential oil							R							R	Oil capacity 1.5 L { 1.6 US qt , 1.3 Imp qt }	M-58								
Transfer case oil (4WD)							R							R	Oil capacity 1.5 L { 1.6 US qt , 1.3 Imp qt }	K2-29								
Driveshaft dust boots (4WD)							I							I	—	M-26								
Brake fluid level							I							I	Fluid specification FMVSS 116 DOT-3	—								
Tire inflation pressure and tire wear															<table border="1"> <tr> <th>Tire size</th> <th>Tires air pressure</th> </tr> <tr> <td>P195/75R15</td> <td>240 kPa</td> </tr> <tr> <td>P215/65R15</td> <td>{ 2.4 kgf/cm² , 35 psi }</td> </tr> <tr> <td>P215/70R15</td> <td>220 kPa { 2.2 kgf/cm² , 32 psi }</td> </tr> </table>	Tire size	Tires air pressure	P195/75R15	240 kPa	P215/65R15	{ 2.4 kgf/cm ² , 35 psi }	P215/70R15	220 kPa { 2.2 kgf/cm ² , 32 psi }	Q-2
	Tire size	Tires air pressure																						
	P195/75R15	240 kPa																						
P215/65R15	{ 2.4 kgf/cm ² , 35 psi }																							
P215/70R15	220 kPa { 2.2 kgf/cm ² , 32 psi }																							
Tires			Rt				Rt							Rt	—	Q-5								
Power steering fluid level							I							I	Fluid specification ATF Dexron ®II or M-III	N-37								
Steering operation and linkage (Includes four wheel alignment)							I							I	—	N-6 R-7								
Suspension components front and rear							I							I	—	—								
All chassis and body nuts and bolts							I							I	—	—								

Schedule (Cont'd)

Maintenance Interval Maintenance Item	Number of months or miles { km }, whichever comes first														Service data and inspection point	Page	
	Months	5	10	15	20	25	30	35	40	45	50	55	60	60			
	× 1,000 Km	8	16	24	32	40	48	56	64	72	80	88	96				
× 1,000 Miles	5	10	15	20	25	30	35	40	45	50	55	60	60				
CHASSIS AND BODY																	
Exhaust system heat shields							I							I			—
All locks and hinges	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	S-6, 7, 9, 10
Washer fluid level	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	—
Function of all lights	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	—
AIR CONDITIONER SYSTEM (IF EQUIPPED)																	
A/C compressor operation		I			I		I		I		I		I		I		—

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

ENGINE


OUTLINE	B- 2
SPECIFICATIONS	B- 2
TROUBLESHOOTING GUIDE	B- 2
DRIVE BELT	B- 4
PREPARATION	B- 4
INSPECTION / ADJUSTMENT	B- 4
COMPRESSION	B- 6
INSPECTION	B- 6
TIMING BELT	B- 7
PREPARATION	B- 7
REMOVAL / INSTALLATION	B- 7
CYLINDER HEAD GASKET	B-12
REPLACEMENT	B-12
HLA	B-15
REMOVAL / INSTALLATION	B-15
HLA TROUBLESHOOTING GUIDE	B-17
FRONT OIL SEAL	B-18
REPLACEMENT	B-18
REAR OIL SEAL	B-19
PREPARATION	B-19
REPLACEMENT	B-19
ENGINE	B-20
PREPARATION	B-20
REMOVAL / INSTALLATION	B-20
ENGINE STAND MOUNTING/DISMOUNTING	B-24
PREPARATION	B-24
PROCEDURE	B-24
DISASSEMBLY / ASSEMBLY	B-26
PREPARATION	B-26
AUXILIARY PARTS	B-28
TIMING BELT	B-30
CYLINDER HEAD	B-34
CYLINDER BLOCK (EXTERNAL PARTS)	B-41
CYLINDER BLOCK (INTERNAL PARTS)	B-45
INSPECTION / REPAIR	B-54
PREPARATION	B-54
CYLINDER HEAD	B-54
VALVE MECHANISM	B-55
CAMSHAFT	B-59
ROCKER ARM AND ROCKER ARM SHAFT	B-60
HLA	B-60
CYLINDER BLOCK	B-60
PISTON, PISTON RING, AND PISTON PIN	B-62
CONNECTING ROD	B-63
CRANKSHAFT	B-63
TIMING BELT AUTO TENSIONER	B-64

OUTLINE

SPECIFICATIONS

Item		Engine	JE
Type			Gasoline, 4-cycle
Cylinder arrangement and number			60°-V configuration, 6-cylinder
Combustion chamber			Pentroof
Valve system			OHC, belt-driven
Displacement		ml { cc , cu in }	2,954 { 2,954 , 180.2 }
Bore × stroke		mm { in }	90.0 × 77.4 { 3.54 × 3.05 }
Compression ratio			8.5 : 1
Compression pressure		kPa { kgf/cm ² , psi } - rpm	1,128 { 11.5 , 164 } - 300
Valve timing	IN	Open BTDC	9 °
		Close ABDC	53 °
	EX	Open BBDC	51 °
		Close ATDC	11 °
Valve clearance		IN mm { in }	0 { 0 } : Maintenance-free
		EX mm { in }	0 { 0 } : Maintenance-free

Cylinder Arrangement



TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
Difficult starting	Malfunction of engine-related components Burned valve Worn piston, piston ring, or cylinder Failed cylinder head gasket	Replace Replace or repair Replace	B-55 B-62 B-12
	Malfunction of fuel system	Refer to section F	
	Malfunction of electrical system	Refer to section G	
Poor idling	Malfunction of engine-related components Malfunction of HLA* Poor valve-to-valve seat contact Failed cylinder head gasket	Replace Repair or replace Replace	B-15 B-57 B-12
	Malfunction of fuel system	Refer to section F	

* Tappet noise may occur if the engine is not operated for an extended period. The noise should disappear after the engine has reached normal operating temperature. (HLA troubleshooting guide: Refer to page B-17.)

Problem	Possible Cause	Action	Page
Insufficient power	Insufficient compression Malfunction of HLA* Compression leakage from valve seat Stuck valve Weak or broken valve spring Damaged cylinder head gasket Cracked or distorted cylinder head Stuck, damaged, or worn piston ring Cracked or worn piston	Replace Repair Replace Replace Replace Replace Replace Replace	B-15 B-57 B-55 B-58 B-12 B-54 B-62 B-62
	Malfunction of fuel system	Refer to section F	
	Others Dragging brakes Wrong size tires	Refer to section P Refer to section Q	
Abnormal combustion	Malfunction of engine-related components Malfunction of HLA* Stuck or burned valve Weak or broken valve spring Carbon accumulation in combustion chamber	Replace Replace Replace Eliminate carbon	B-15 B-55 B-58 —
	Malfunction of fuel system	Refer to section F	
Excessive oil consumption	Oil working up Worn piston ring groove or stuck piston ring Worn piston or cylinder	Replace Replace or repair	B-62 B-62
	Oil working down Worn valve seal Worn valve stem or guide	Replace Replace	B-36 B-55
	Oil leakage	Refer to section D	
Engine noise	Crankshaft- or bearing-related parts Excessive main bearing oil clearance Main bearing heat-damaged Excessive crankshaft end play Excessive connecting rod bearing oil clearance Connecting rod bearing heat-damaged	Replace or repair Replace Replace or repair Replace or repair Replace	B-47 B-47 B-49 B-52 B-52
	Piston-related parts Worn cylinder Worn piston or piston pin Damaged piston ring Bent connecting rod	Replace or repair Replace Replace Replace	B-60 B-62 B-62 B-63
	Valve-related parts Malfunction of HLA* Broken valve spring Excessive valve guide clearance Malfunction of timing belt auto tensioner	Replace Replace Replace Replace	B-15 B-58 B-55 B-64
	Malfunction of cooling system	Refer to section E	
	Malfunction of fuel system	Refer to section F	
	Others Malfunction of water pump bearing Improper drive belt tension Malfunction of generator bearing Exhaust gas leakage	Replace Adjust Replace Repair	— B-4 — —


* Tappet noise may occur if the engine is not operated for an extended period. The noise should disappear after the engine has reached normal operating temperature. (HLA troubleshooting guide: Refer to page B-17.)




Warning

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

DRIVE BELT

PREPARATION SST

<p>49 9200 020A</p> <p>Tension gauge, belt</p>		<p>For inspection of drive belt tension</p>
--	---	---



INSPECTION / ADJUSTMENT

Inspection

1. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure **98 N { 10 kgf , 22 lbf }** midway between the specified pulleys.


Deflection

mm { in }

Drive belt	*New	Used	Limit
Generator	9—10 { 0.36—0.39 }	10—12 { 0.40—0.47 }	18 { 0.71 }
P/S oil pump	7.0—7.5 { 0.28—0.29 }	7.5—8.2 { 0.30—0.32 }	13.5 { 0.53 }
A/C compressor	4.0—4.5 { 0.16—0.17 }	4.5—5.5 { 0.18—0.21 }	8.5 { 0.33 }

*A belt that has been on a running engine for less than five minutes.

2. If the deflection is not within the specification, adjust it. (Refer to page B-5.)



Drive Belt Tension Check

1. Belt tension can be checked in place of belt deflection. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the **SST**, check the belt tension between any two pulleys.

Tension

N { kgf , lbf }

Drive belt	*New	Used	Limit
Generator	550—637 { 56—65 , 124—143 }	461—549 { 47—56 , 104—123 }	265 { 27 , 59 }
P/S oil pump	344—382 { 35—39 , 77—85 }	295—333 { 30—34 , 66—74 }	245 { 25 , 55 }
A/C compressor	540—617 { 55—63 , 121—138 }	452—539 { 46—55 , 102—121 }	245 { 25 , 55 }


*A belt that has been on a running engine for less than five minutes.

2. If the tension is not within the specification, adjust it. (Refer to below.)

Adjustment

Generator

1. Loosen generator bolts (A) and (B).
2. Lever the generator outward and apply tension to the belt.




Tightening torque

- (A): 19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }
- (B): 38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

P/S oil pump

Loosen the locknut and adjust the belt deflection by turning the adjusting bolt.




Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

A/C compressor

Loosen the locknut and adjust the belt deflection by turning the adjusting bolt.




Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

COMPRESSION

INSPECTION

1. Verify that the battery is fully charged. Recharge it if necessary. (Refer to section G.)
2. Warm up the engine to the normal operating temperature.
3. Turn it off for about 10 minutes to allow the exhaust manifold to cool.
4. Remove the all spark plugs.
5. Disconnect the distributor connector.
6. Install a compression gauge to the No.1 spark plug hole.
7. Fully depress the accelerator pedal and crank the engine.
8. Record the maximum gauge reading.
9. Check each cylinder as above.



Compression

	kPa { kgf/cm ² , psi }-rpm
Standard	1,128 { 11.5 , 164 }-300
Minimum	834 { 8.5 , 121 }-300
Maximum difference between cylinders	196 kPa { 2.0 kgf/cm ² , 28 psi }

10. If the compression in one or more cylinders is low, pour a small amount of engine oil into the cylinder and re-check the compression.
 - (1) If the compression increases, the piston, piston rings, or cylinder wall may be worn.
 - (2) If the compression stays low, the valve may be stuck or improperly seated.
 - (3) If the compression in adjacent cylinders stays low, the cylinder head gasket may be damaged or the cylinder head distorted.
11. Connect the distributor connector.
12. Install the all spark plugs.

Tightening torque:

15—22 N·m { 1.5—2.3 kgf·m , 11—16 ft·lbf }

TIMING BELT


PREPARATION
SST

B


49 S120 710		For removal / installation of crankshaft pulley flange
Holder, coupling flange		

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order or removal, referring to **Installation Note**.
5. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to section E.)
6. Connect the negative battery cable.
7. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F.)




- | | |
|-------------------------------------|-----------------------------------|
| 1. High-tension lead and spark plug | 8. Upper radiator hose |
| 2. Fresh-air duct | 9. Timing belt cover |
| 3. Cooling fan and radiator cowling | Installation Note page B-10 |
| 4. Drive belt | 10. Timing belt |
| 5. A/C compressor idler pulley | Removal Note below |
| 6. Crankshaft pulley | Installation Note page B- 9 |
| Removal Note below | 11. Upper idler pulley |
| Installation Note page B-11 | 12. Timing belt auto tensioner |
| 7. Coolant bypass hose | Installation Note page B- 9 |



Removal Note
Crankshaft pulley


1. Mount the **SST** on the crankshaft pulley to hold the crankshaft.
2. Remove the crankshaft pulley bolt.



Caution


- The crankshaft position sensor rotor is on the rear of the crankshaft pulley, and can be damaged easily.

3. Remove the crankshaft pulley.



Timing belt

1. Install the crankshaft pulley lock bolt and hand tighten it.
2. Turn the crankshaft to align the timing marks on the pulleys.




3. Mark the timing belt rotation for proper reinstallation.
4. Remove the timing belt.

Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

5. Remove the crankshaft pulley lock bolt.



Installation Note

Timing belt auto tensioner

1. Set a plain washer at the bottom of the tensioner body to prevent damage to the body plug.

B



Caution

- Pressing the tensioner rod with more than 9,807 N { 1,000 kgf , 2,200 lbf } can damage the tensioner spring.

2. Press in the tensioner rod slowly by using a press.
3. Insert a pin to hold the tensioner rod in the body as shown.
4. Install the auto tensioner to the cylinder block.


Tightening torque:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }



Timing belt


1. Install the crankshaft pulley lock bolt and hand tighten it.




2. Turn the camshaft pulleys clockwise and align the timing marks.

Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.



3. Position the timing belt in the original direction, and hang it on each pulley in the order shown.




4. Install the upper idler pulley.


Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

5. Turn the crankshaft clockwise twice and align the timing marks.
6. Check that the timing marks are correctly aligned. If not, repeat steps 2—5.




7. Remove the pin from the auto tensioner.
8. Turn the crankshaft clockwise twice and align the timing marks.
9. Reconfirm that the timing marks are correctly aligned.




10. Check the timing belt deflection by applying moderate pressure **98 N { 10 kgf , 22 lbf }** midway between the timing belt pulley and the auto tensioner. If not correct, repeat the adjustment from step 4.

Timing belt deflection: 5—7 mm { 0.20—0.27 in }



11. Remove the crankshaft pulley lock bolt.




Timing belt cover

1. Install the timing belt covers along with new gaskets.
2. Tighten the bolts in the order shown.

Tightening torque

M6: 7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }

M10: 38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }



Crankshaft pulley

Caution

- The crankshaft position sensor rotor is on the rear of the crankshaft pulley, and can be damaged easily.

1. Install the crankshaft pulley and hand tighten the pulley lock bolt.
2. Mount the **SST** on the crankshaft pulley to hold the crankshaft.
3. Tighten the crankshaft pulley lock bolt.

Tightening torque: 157—166 N·m
{ 16.0—17.0 kgf·m , 116—122 ft·lbf }


CYLINDER HEAD GASKET

REPLACEMENT


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F.

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E.)
3. Remove the timing belt. (Refer to page B-7.)
4. Remove the intake manifold assembly. (Refer to section F.)
5. Remove in the order shown in the figure, referring to **Removal Note**.
6. Install in the reverse order of removal, referring to **Installation Note**.
7. Install the intake manifold assembly. (Refer to section F.)
8. Install the timing belt. (Refer to page B-7.)
9. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to section E.)
10. Connect the negative battery cable.
11. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F.)
12. Check the compression. (Refer to page B-6.)




- | | |
|---|---|
| 1. Cylinder head cover
Installation Note page B-14 | 6. Seal plate |
| 2. Center exhaust pipe insulator | 7. Cylinder head
Removal Note below
Installation Note below |
| 3. Center exhaust pipe | 8. Cylinder head gasket |
| 4. Exhaust manifold insulator | |
| 5. Exhaust manifold | |



**Removal Note
Cylinder head**

1. Loosen the cylinder head bolts in two or three steps in the order shown.
2. Remove the cylinder head.




**Installation Note
Cylinder head**


1. Measure the amount of oil control plug projection from the deck of the cylinder block.

Projection: 5.3—5.7 mm { 0.209—0.224 in }

2. Apply clean engine oil to new O-rings; and install them to the oil control plugs.




3. Thoroughly remove all dirt, oil, and other material from the top of the cylinder block.
4. Turn the crankshaft clockwise and apply engine oil to the cylinder walls.
5. Place a new cylinder head gasket on the left bank with the L mark facing upward.
6. Place a new cylinder head gasket on the right bank with the R mark facing upward.




7. Install the cylinder head to the cylinder block.
8. Tighten the cylinder head bolts.
(1) Before installation, measure each bolt length. Replace if necessary.

Length	IN : 107.7—108.3 mm { 4.25—4.26 in }
	EX : 137.7—138.3 mm { 5.43—5.44 in }
Maximum	IN : 109 mm { 4.29 in }
	EX : 139 mm { 5.47 in }



(2) Tighten the bolts in the order shown.


Tightening torque: 17.2—22.0 N·m
 { 1.75—2.25 kgf·m , 12.7—16.2 ft·lbf }



(3) Put a paint mark on each bolt head.

(4) Using the mark as a reference, tighten the bolts 85°—95° in the sequence shown.

(5) Retighten each bolt another 85°—95° in the sequence shown.



Cylinder head cover

1. Remove all old silicone sealant from the cylinder head and cylinder head cover.
2. Coat a new gasket with silicone sealant, and install it onto the cylinder head cover.
3. Install the cylinder head cover along with new seal washers.

Tightening torque:

3.5—4.4 N·m { 35—45 kgf·cm , 31—39 in·lbf }


HLA

REMOVAL / INSTALLATION

Caution


- Removal and installation of the HLA must be carried out only when the problem cannot be solved by the HLA troubleshooting guide. (Refer to page B-17.)

1. Disconnect the negative battery cable.
2. Remove the air intake hose and dynamic chamber. (Refer to section F.)
3. Remove the timing belt. (Refer to page B-7.)
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the dynamic chamber and air intake hose. (Refer to section F.)
7. Install the timing belt. (Refer to page B-7.)
8. Fill the engine with the specified amount and type of engine oil. (Refer to section D.)
9. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to section E.)
10. Connect the negative battery cable.
11. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F.)
12. Turn off the engine and check the drive belt deflection. (Refer to page B-4.)
13. Perform a road test.
14. Recheck the engine oil and coolant levels.



- 1. Distributor
Removal / Installation section G
- 2. Cylinder head cover
Installation Note page B-14
- 3. Rocker arm and rocker arm shaft assembly
Removal Note below
Installation Note below


- 4. HLA
Removal Note below
Installation Note below



Removal Note

Rocker arm and rocker arm shaft assembly

- 1. Loosen the bolts in two or three steps in the order shown.
- 2. Remove the rocker arm and rocker arm shaft assembly together with the bolts. Do not mix up the parts of the rocker arm and rocker arm shaft assembly.




HLA

Caution

- Do not remove the HLA unless necessary because oil leakage will occur if the O-ring is damaged.


Remove the HLA by hand. If this is difficult, remove it with pliers.



Installation Note

HLA


- 1. Pour engine oil into the oil reservoir in the rocker arm.
- 2. Apply engine oil to the HLA.
- 3. Carefully install the HLA into the rocker arm.



Rocker arm and rocker arm shaft assembly

Caution

- Be careful that the rocker arm shaft spring does not get caught between the shaft and mounting boss during installation.







1. Install the rocker arm and rocker arm shaft assembly.
2. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

18—26 N·m { 1.8—2.7 kgf·m , 14—19 ft·lbf }

HLA TROUBLESHOOTING GUIDE

Problem	Possible cause	Action
1. Noise when engine is first started after oil is changed.	Oil leakage in oil passage or in HLA	Run engine at 2,000—3,000 rpm. If noise stops within 20 minutes*, HLA is normal. If not, replace HLA. * Time required for engine oil to circulate within HLA includes tolerance for engine oil condition and ambient temperature.
2. Noise when engine is started after setting one day or more.		
3. Noise when engine is started after new HLA is installed.	Oil leakage in HLA	
4. Noise during idle after warm up.	Insufficient oil pressure	Check oil pressure. If lower than specification, check for cause. (Refer to section D)
	Faulty HLA	Press down HLA by hand. If it does not move, HLA is normal. If it moves, replace HLA. Measure valve clearance. If more than 0.15 mm { 0.0059 in }, replace HLA. 
5. Noise during idle after high speed running.	Incorrect oil amount	Check oil level. Drain or add oil as necessary.
	Deteriorated oil	Check oil quality. If deteriorated, replace with specified type and amount of oil.



FRONT OIL SEAL

REPLACEMENT

1. Disconnect the negative battery cable.
2. Remove the timing belt. (Refer to page B-7.)
3. Remove the timing belt pulley.
4. Remove the key.
5. Cut the oil seal lip by using a razor knife.
6. Remove the oil seal by using a screwdriver protected with a rag.
7. Apply clean engine oil to the new oil seal.
8. Push the oil seal slightly in by hand.
9. Tap the oil seal in evenly by using a pipe and a hammer.

Note


- Oil seal outer diameter: 55.0 mm { 2.17 in }
- Oil seal inner diameter: 43.0 mm { 1.69 in }

10. Install the timing belt pulley, aligning the key groove.
11. Insert the key with the tapered side toward to the oil pump body.
12. Install the timing belt. (Refer to page B-7.)
13. Connect the negative battery cable.
14. Start the engine and check the ignition timing. (Refer to section F.)

REAR OIL SEAL


PREPARATION

SST


<p>49 G019 017</p> <p>Installer, oil seal</p>		<p>For installation of rear oil seal</p>
---	---	--

REPLACEMENT

1. Disconnect the negative battery cable.
2. Remove the transmission assembly. (Refer to section K.)
3. Remove the drive plate. (Refer to section K.)



4. Cut the oil seal lip by using a razor knife.
5. Remove the oil seal by using a screwdriver protected with a rag.




6. Apply clean engine oil to the new oil seal.
7. Push the oil seal slightly in by hand.
8. Tap the oil seal in evenly by using the **SST** and a hammer.
9. Install the drive plate. (Refer to section K.)
10. Install the transmission assembly. (Refer to section K.)
11. Connect the negative battery cable.

ENGINE

PREPARATION

SST

<p>49 G032 354</p> <p>Adjust wrench</p> 	<p>For removal / installation of P/S oil pump</p>
---	---

REMOVAL / INSTALLATION

Procedure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on section F.
- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.


Caution

- Cover the fuel hoses with a rag because fuel will spray out when disconnected.


Note

- Plug the disconnected fuel hoses to prevent fuel leakage.


1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E.)
3. Remove the hood.
4. Drain the transmission oil. (Refer to section K.)
5. Remove in the order shown in the figure, referring to **Removal Note**.
6. Install in the reverse order of removal, referring to **Installation Note**.
7. Fill the transmission with the specified amount and type of transmission oil. (Refer to section K.)
8. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to section E.)
9. Install the hood.
10. Connect the negative battery cable.
11. Start the engine and
 - (1) check the engine oil, transmission oil, and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F.)
12. Turn off the engine and check the drive belt deflection. (Refer to page B-4.)
13. Perform a road test.
14. Recheck the engine oil, transmission oil, and engine coolant levels.




- | | |
|-----------------------------------|---------------------------------------|
| 1. Fresh-air duct | 11. Cooling fan and water pump pulley |
| 2. Drive belt | 12. Heater hose |
| 3. Splash shield | 13. Solenoid and bracket |
| 4. Upper and lower radiator hose | 14. Front pipe |
| 5. Oil cooler hose | 15. Accelerator cable |
| 6. Radiator cowl | Adjustment section F |
| 7. Radiator | 16. Engine mount |
| 8. Air cleaner and air duct | 17. Engine assembly |
| 9. P/S oil pump | Removal Note page B-22 |
| Removal Note page B-22 | Installation Note page B-23 |
| Installation Note page B-23 | |
| 10. A/C compressor | |
| Removal Note page B-22 | |

**Removal Note****P/S oil pump**


1. Remove the P/S oil pump pulley by using the **SST**.



2. Remove the P/S oil pump with the hoses still connected to them; secure the pump and compressor as shown in the figure.

**A/C compressor**

Remove the A/C compressor with the hoses still connected to them; secure the pump and compressor as shown in the figure.


**Engine assembly**

1. Install the front engine hanger. (JE48 10 561A)

Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

2. Set the chain block.
3. Remove the engine mount nuts.
4. Suspend the engine assembly horizontally.
5. Removal the engine in the engine compartment being careful not to damage the piping.

**Installation Note****Engine assembly**


1. Suspend the engine assembly.
2. Slowly lower the engine. Keep it from swinging or bumping into components in the engine compartment.

3. Tighten the engine mount nuts.

Tightening torque:

35—49 N·m { 3.5—5.0 kgf·m , 26—36 ft·lbf }

4. Removal the front engine hanger. (JE48 10 561A)

**P/S oil pump**

1. Install the P/S oil pump.

Tightening torque:

32—46 N·m { 3.2—4.7 kgf·m , 24—33 ft·lbf }










2. Install the P/S oil pump pulley by using the SST.


Tightening torque:

40—58 N·m { 4.0—6.0 kgf·m , 29—43 ft·lbf }

ENGINE STAND MOUNTING/DISMOUNTING


PREPARATION SST

<p>49 0107 680A Engine stand</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 1A0 Hanger set, engine stand</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L010 101 Plate (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 102 Arms (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L010 103 Hooks (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 104 Nuts (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L010 105 Bolts (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 106 Bolts (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L010 111 Attachment and bolt (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>—</p>	<p>—</p>




PROCEDURE Mounting

1. Remove the engine mount (RH).
2. Remove the generator and P/S oil pump bracket.
3. Install the **SST** (arms) as shown and hand tighten the **SST** (bolts).



4. Assemble the **SST** (bolts, nuts, hooks, and plate) in the specified positions marked A, C, and F.
5. Install the **SST** assembly to the respective arms.




6. Adjust the **SST** (bolts) so that less than 20 mm { 0.79 in } of thread is exposed.
7. Make the **SST** (plate and arms) parallel by adjusting the **SST** (bolts and nuts).
8. Tighten the **SST** (bolts and nuts) to affix the **SST** firmly.
9. Install the engine on the **SST** (engine stand).

Warning

- Although the engine stand has a self-locking brake system, there is a possibility that the brake may not be effective in the following situations:

1. When the engine is held in an unbalanced position.
2. While rotating the engine, if it passes through an unbalanced position.

Either of these situations could lead to sudden, rapid movement of the engine and mounting stand handle and cause serious injury. Never keep the engine in an unbalanced position, and always hold the rotating handle firmly when turning the engine.




Dismounting

1. Remove the engine from the **SST** (engine stand).
2. Remove the **SST** (plate and arms) from the engine. (Refer to page B-24.)
3. Install the generator and P/S oil pump bracket.

Tightening torque:


38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }



4. Install the engine mount (RH).

















Tightening torque:












40—56 N·m { 4.0—5.8 kgf·m , 29—41 ft·lbf }



DISASSEMBLY / ASSEMBLY

PREPARATION SST

<p>49 L011 0A0B</p> <p>Piston pin setting tool set</p> 	<p>For removal / installation of piston pins</p>	<p>49 L011 001</p> <p>Support block body (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>
<p>49 L011 002</p> <p>Support block head (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>	<p>49 L011 004</p> <p>Screw (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>
<p>49 L011 005</p> <p>Stopper bolt (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>	<p>49 L011 006</p> <p>Puller & installer (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>
<p>49 L011 009</p> <p>Guide (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>	<p>49 L011 010</p> <p>Centering tool (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>
<p>49 L011 011</p> <p>Holder (Part of 49 L011 0A0B)</p> 	<p>For removal / installation of piston pins</p>	<p>49 E011 1A0</p> <p>Ring gear brake set</p> 	<p>For prevention of engine rotation</p>
<p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p> 	<p>For prevention of engine rotation</p>	<p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p> 	<p>For prevention of engine rotation</p>
<p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p> 	<p>For prevention of engine rotation</p>	<p>49 L012 0A0</p> <p>Installer set, valve seal, & valve guide</p> 	<p>For installation of valve seals</p>
<p>49 L012 001</p> <p>Installer (Part of 49 L012 0A0)</p> 	<p>For installation of valve seals</p>	<p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p> 	<p>For installation of valve seals</p>

49 L012 005 Spacer (Part of 49 L012 0A0)		For installation of valve seals	49 0636 100B Arm, valve spring lifter		For removal / installation of valves
49 B012 0A2 Pivot		For removal / installation of valves	49 B012 012 Body (Part of 49 B012 0A2)		For removal / installation of valves
49 B012 013 Foot (Part of 49 B012 0A2)		For removal / installation of valves	49 B012 014 Lock nut (Part of 49 B012 0A2)		For removal / installation of valves
49 H012 010 Box wrench		For removal / installation of camshaft pulley	49 G019 017 Installer, oil seal		For installation of rear oil seal
49 G034 2A0 Replace set, rubber bush		For installation of front oil seal/ camshaft oil seal	49 G034 202 Support block (Part of 49 G034 2A0)		For installation of front oil seal/ camshaft oil seal
49 S120 170 Remover, valve seal		For removal of valve seals	—	—	—

1. Code or arrange all identical parts (such as pistons, piston rings, connecting rods, and valve springs etc.) so that they can be reinstalled in the cylinder from which they were removed.
2. Clean the parts by using a steam cleaner. Blower dry with compressed air.
3. Clean all parts before reinstallation.
4. Apply clean engine oil to all sliding and rotating parts.
5. Replace plain bearings if they are peeled, burned, or otherwise damaged.
6. Tighten all bolts and nuts to the specified torque.

Warning


- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

AUXILIARY PARTS

1. Remove the oil drain plug and drain the engine oil. After draining the engine oil, install the oil drain plug.


Tightening torque: 30—41 N·m { 3.0—4.2 kgf·m , 22—30 ft·lbf }

2. Remove the intake manifold assembly. (Refer to section F.)
3. Disassemble in the order shown in the figure.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.
5. Install the intake manifold assembly. (Refer to section F.)



1. Engine mount (LH)
2. P/S idler pulley and bracket
3. A/C idler pulley and compressor bracket
4. Engine hanger
5. Water inlet pipe
6. Water bypass hose


7. Distributor
Assembly Note page B-29
8. Exhaust manifold insulator
9. Exhaust manifold assembly
10. Dipstick
11. Oil filter assembly

**Assembly Note****Distributor**

1. Apply clean engine oil to the new O-ring, and position it on the distributor.
2. Apply clean engine oil to the drive gear, and match the matching marks as shown.
3. Install the distributor into the cylinder head with the marks facing straight up.
4. Hand tighten the distributor mounting bolt.


TIMING BELT

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|-----------------------|-----------------|
| 1. Crankshaft pulley | |
| Disassembly Note | page B-31 |
| Assembly Note | page B-33 |
| 2. Timing belt cover | |
| Assembly Note | page B-32 |
| 3. Upper idler pulley | |

- | | |
|-------------------------------|-----------------|
| 4. Timing belt | |
| Disassembly Note | page B-31 |
| Assembly Note | page B-31 |
| 5. Timing belt auto tensioner | |
| Assembly Note | page B-31 |
| 6. Lower idler pulley | |
| 7. Tensioner pulley | |




Disassembly Note Crankshaft pulley

1. Hold the drive plate by using the SST.

Caution

- The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.

2. Remove the crankshaft pulley lock bolt.
3. Remove the crankshaft pulley.




Timing belt

1. Mark the timing belt rotation for proper reinstallation if it is reused.
2. Remove the timing belt.

Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.



Assembly Note

Timing belt auto tensioner

1. Set a plain washer at the bottom of the tensioner body to prevent damage to the body plug.


Caution

- Pressing the tensioner rod with more than 9,807 N { 1,000 kgf , 2,200 lbf } can damage the tensioner spring.

2. Press in the tensioner rod slowly by using a press.


3. Insert a pin to hold the tensioner rod in the body as shown.

4. Install the timing belt auto tensioner to the cylinder block.








Tightening torque:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }



Timing belt

1. Install the crankshaft pulley lock bolt and hand tighten it.
2. Verify that the timing marks on the pulleys are aligned.



Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

3. Position the timing belt in the original direction, and hang it on each pulley in the order shown.

4. Install the upper idler pulley.

Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

5. Turn the crankshaft clockwise twice and align the timing marks.
6. Check that the timing marks are correctly aligned. If not, repeat steps 3—6.

7. Remove the pin from the auto tensioner.
8. Turn the crankshaft clockwise twice and align the timing marks.
9. Reconfirm that the timing marks are correctly aligned.

10. Check the timing belt deflection by applying moderate pressure **98 N { 10 kgf , 22 lbf }** midway between the timing belt pulley and the auto tensioner. If not correct, repeat the adjustment starting from step 4 above.

Timing belt deflection: 5—7 mm { 0.20—0.27 in }


Timing belt cover

1. Install the timing belt covers with new gaskets.
2. Tighten the bolts in the order shown.


Tightening torque

M6: 7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }

M10: 38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

**Crankshaft pulley**

1. Hold the drive plate by using the SST.



2. Remove the crankshaft pulley lock bolt.

Caution

- The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.


3. Install the crankshaft pulley onto the crankshaft.

4. Tighten the crankshaft pulley lock bolt.


Tightening torque: 157—166 N·m
{ 16.0—17.0 kgf·m , 116—122 ft·lbf }

CYLINDER HEAD


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Cylinder head cover Assembly Note page B-40	12. Distributor drive gear Assembly Note page B-38
2. Distributor spacer	13. Cylinder head Disassembly Note page B-35 Inspection page B-54 Assembly Note page B-37
3. Brind cover	14. Cylinder head gasket Assembly Note page B-37
4. PCV valve	15. Valve keeper Disassembly Note page B-35 Assembly Note page B-37
5. Camshaft pulley Disassembly Note page B-35 Assembly Note page B-39	16. Upper valve spring seat
6. Seal plate	17. Outer and inner valve spring Inspection page B-58 Assembly Note page B-36
7. Rocker arm and rocker arm shaft Disassembly Note page B-35 Inspection page B-60 Assembly Note page B-39	18. Lower valve spring seat
8. HLA Disassembly Note page B-35 Inspection page B-60 Assembly Note page B-38	19. Valve Inspection page B-55
9. Camshaft oil seal Assembly Note page B-38	20. Valve seal Disassembly Note page B-36 Assembly Note page B-36
10. Thrust plate	
11. Camshaft Disassembly Note page B-35 Inspection page B-59 Assembly Note page B-38	

**Disassembly Note****Camshaft pulley**

Loosen the camshaft pulley lock bolt by using the SST.


**Rocker arm and rocker arm shaft**

1. Loosen the bolts in two or three steps in the order shown.
2. Identify the rocker arm and rocker arm shaft assembly parts so that they can be reinstalled in the same locations from which they were removed.
3. Remove the rocker arm and rocker arm shaft assembly together with the bolts.

**HLA****Caution**

- The HLA must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.


Remove the HLA only for inspection. Remove by hand or use pliers protected with a rag.

**Camshaft**


Before removing the thrust plate, measure the camshaft end play. (Refer to page B-60.)

Cylinder head

1. Loosen the cylinder head bolts in two or three steps in the order shown.
2. Remove the cylinder head bolts.
3. Remove the cylinder heads.


**Valve keeper**

1. Set the SST against the upper valve spring seat as shown.
2. Compress the spring and remove the valve keepers.



Valve seal

Remove the valve seal by using the SST.



Assembly Note


Valve seal

1. Assemble the SST as shown so that depth **L** is specified.


Depth L

IN : 17.8—18.6 mm { 0.701—0.732 in }


EX : 24.2—25.0 mm { 0.953—0.984 in }



2. Install the valve seal onto the valve guide.
3. Install the SST onto the valve seal.




4. Tap the valve seal in until the SST contacts the cylinder head.




Outer and inner valve spring

1. Install the lower spring seat.
2. Install the valve.
3. Install the outer valve spring with the closer pitch toward the cylinder head.
4. Install the inner valve spring.
5. Install the upper spring seat.

**Valve keeper**


1. Compress the valve spring with the **SST**; then install the valve keepers.
2. Tap the end of the valve stem lightly two or three times with a plastic hammer to confirm that the valve keepers are all fully seated.

**Cylinder head gasket**


1. Measure the amount of oil control plug projection from the deck of the cylinder block.

Projection: 5.3—5.7 mm { 0.209—0.224 in }

2. Apply clean engine oil to the new O-rings and install them to the oil control plug.



3. Thoroughly remove all dirt, oil, and other material from the top of the cylinder block.
4. Turn the crankshaft clockwise and apply engine oil to the cylinder walls.
5. Place a new cylinder head gasket on the left bank with the L mark facing upward.
6. Place a new cylinder head gasket on the right bank with the R mark facing upward.

**Cylinder head**


1. Install the cylinder head to the cylinder block.
2. Tighten the cylinder head bolts.
 - (1) Before installation, measure each bolt length. Replace if necessary.

Length IN: 107.7—108.3 mm { 4.25—4.26 in }

EX: 137.7—138.3 mm { 5.43—5.44 in }

Maximum IN: 109 mm { 4.29 in }


EX: 139 mm { 5.47 in }




- (2) Tighten the bolts in the order shown.

Tightening torque:

17.2—22.0 N·m { 1.75—2.25 kgf·m , 12.7—16.2 ft·lbf }




- (3) Put a paint mark on each bolt head.
- (4) Using the mark as a reference, tighten the bolts by turning each 85° — 95° in the sequence shown.
- (5) Further tighten each bolt by turning another 85° — 95° .



Distributor drive gear

1. Remove all old sealant from the drive gear.
2. Apply silicone sealant to the shaded area shown.
3. Seat the drive gear fully onto the left camshaft.




Camshaft

1. Apply clean engine oil to the journals, lobes, and bearings.
2. Set the camshaft into the cylinder head.
3. Install the thrust plate.


Tightening torque:

7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }








Camshaft oil seal

1. Apply clean engine oil to the lip of the new camshaft oil seal.
2. Push the oil seals slightly in by hand.
3. Tap the oil seal in evenly by using the **SST** and a hammer.



HLA

1. Pour engine oil into the oil reservoir in the rocker arm.
2. Apply clean engine oil to the HLA.
3. Carefully install the HLA into the rocker arm.



Rocker arm and rocker arm shaft

The intake side shaft has twice as many oil holes as the exhaust side shaft.

1. Apply clean engine oil to the rocker arm shafts and rocker arm bearing surface.
2. Assemble the rocker arm and rocker arm shaft assembly as shown in the figure.

3. Install the rocker arm and rocker arm shaft assembly.
4. Verify that the rocker arm shaft spring is not caught between the rocker arm shaft and the mounting boss.

5. Tighten the bolts in two or three steps in the order shown.


Tightening torque:

18—26 N·m { 1.8—2.7 kgf·m , 14—19 ft·lbf }

Camshaft pulley

1. Verify that the camshaft keys face upward as shown.


2. Install the camshaft pulleys with the **L** mark (left bank) or the **R** mark (right bank) face upward as shown.



3. Tighten the camshaft pulley by using the SST.

Tightening torque:

71—80 N·m { 7.2—8.2 kgf·m , 53—59 ft·lbf }



Cylinder Head Cover


1. Remove all old silicone sealant from the cylinder head and cover.
2. Coat a new gasket with silicone sealant, and install it onto the cylinder head cover.
3. Install the cylinder head cover with new seal washers.

Tightening torque:


3.5—4.4 N·m { 35—45 kgf·cm , 31—39 in·lbf }

CYLINDER BLOCK (EXTERNAL PARTS)


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of assembly, referring to **Assembly Note**.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Backing plate, drive plate, adapter
Disassembly Note page B-42
Assembly Note page B-44 2. End plate 3. Oil pan
Disassembly Note page B-42
Assembly Note page B-44 4. Oil strainer 5. Rear cover
Assembly Note page B-43 6. Rear oil seal
Disassembly Note page B-42
Assembly Note page B-43 | <ol style="list-style-type: none"> 7. Thermostat assembly 8. Water pump 9. Timing belt pulley 10. Oil pump
Assembly Note page B-43
Disassembly / Inspection /
Assembly section D 11. Front oil seal
Disassembly Note page B-42
Assembly Note page B-42 |
|---|---|


**Disassembly Note****Backing plate, drive plate, adapter**

1. Hold the drive plate by using the SST.
2. Remove the drive plate bolts.
3. Remove the backing plate, drive plate, and adapter.
4. Remove the SST.


**Oil pan****Caution**

- Pry tools can easily scratch the oil pan and cylinder block contact surfaces. prying off the oil pan can also easily bend the oil pan flange.


1. Remove the oil pan mounting bolts.
2. Insert a screwdriver between the oil pan and the cylinder block to separate them.

**Rear oil seal**


Remove the oil seal using a screwdriver protected with a rag.

**Front oil seal**

Remove the oil seal using a screwdriver protected with a rag.

**Assembly Note****Front oil seal**


1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal into the oil pump body by hand.
3. Press the oil seal into the oil pump body by using the SST.

**Oil pump**


1. Install the oil pump with a new gasket.

Tightening torque:


19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }



2. Cut away the portion of the gasket that projects from the body toward the oil pan side.

**Rear oil seal**


1. Apply clean engine oil to the lip of new oil seal.
2. Push the oil seal into the rear cover by hand.
3. Press the oil seal into the rear cover by using the **SST**.

**Rear cover**


1. Install the rear cover and a new gasket.

Tightening torque:

7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }



2. Cut away the portion of the gasket that projects from the body toward the oil pan side.




Oil pan

1. Remove the old sealant from the oil pan bolts and bolt holes in the cylinder block.

Caution


- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.



2. Apply silicone sealant and install oil pan.
3. Apply silicone sealant to the oil pan along the inside of the bolt holes, overlap the ends, and install the oil pan within five minutes.
4. Tighten the oil pan bolts.

Tightening torque:

6.9—9.80 N·m { 70—100 kgf·cm , 61—86 in·lbf }



Backing plate, drive plate, adapter


Install, and tighten the backing plate, adapter, drive plate, and plate by using the SST.

Tightening torque:


103—109 N·m { 10.5—11.2 kgf·m , 76.0—81.0 ft·lbf }

CYLINDER BLOCK (INTERNAL PARTS)

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




<ol style="list-style-type: none"> 1. Connecting rod cap Disassembly Note page B-46 Assembly Note page B-52 2. Lower connecting rod bearing 3. Piston and connecting rod assembly Disassembly Note page B-46 Assembly Note page B-51 4. Upper connecting rod bearing 5. Piston ring Disassembly Note page B-46 Inspection page B-62 Assembly Note page B-51 6. Piston pin Disassembly Note page B-46 Inspection page B-63 	<ol style="list-style-type: none"> 7. Connecting rod Inspection page B-63 Assembly Note page B-50 8. Piston Inspection page B-62 9. Main bearing cap Disassembly Note page B-47 Assembly Note page B-47 10. Lower main bearing and lower thrust bearing 11. Crankshaft Inspection page B-63 12. Upper main bearing and upper thrust bearing 13. Oil baffle plate Assembly Note page B-47 14. Cylinder block Inspection page B-60
---	--




Disassembly Note Connecting rod cap

Before removing the connecting rod caps, measure the connecting rod side clearance. (Refer to page B-52.)




Piston and connecting rod assembly

1. Before removing the piston and connecting rod assembly, measure the connecting rod bearing oil clearance by using Plastigage. (Refer to page B-52.)
2. Remove the Plastigage from journals and bearings.



Piston ring

Remove the piston rings by using a piston ring expander (commercially available).




Piston pin

Caution






- The connecting rods must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.

1. Before disassembling the piston and connecting rod, check the oscillation torque as shown. If the large end does not drop by its own weight, replace the piston or the piston pin.



Note

- Mark the connecting rods to show their original positions.
2. Assemble the SST as shown.



3. Insert the **SST No.2** into the piston pin as shown and fully screw in the **SST No.1**.

4. Mount the piston and connecting rod on the **SST** as shown.
5. Verify that the **SST** fits squarely into the piston before pressing.
6. Press out the piston pin.
While removing the piston pin, check the pressure. If it is lower than **4,903 N { 500 kgf , 1,100 lbf }**, replace the piston pin or connecting rod.

Main bearing cap

1. Before removing the main bearing cap, measure the crankshaft end play. (Refer to page B-49.)
2. After removing the main bearing cap, measure the main journal oil clearance. (Refer to below.)

Assembly Note

Oil baffle plate

Apply locking agent to the baffle plate screws; then install the baffle plate to the cylinder block.

Tightening torque:


7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }

Main bearing cap


1. Before installing the crankshaft, inspect the main bearing oil clearances as described.

Oil clearance inspection

- (1) Remove any foreign material and oil from the journals and bearings.
- (2) Install the upper main bearings and thrust bearings.
- (3) Install the grooved upper main bearings.
- (4) Install the thrust bearings so that the oil groove contacts the crankshaft.




- (5) Set the crankshaft in the cylinder block.
- (6) Position Plastigage on top of the journals in the axial direction.




- (7) Install the main bearing caps along with the lower main bearings according to the cap number and ◁ mark.
- (8) Tighten the bolts in two or three steps in the order shown.

Tightening torque:

17.2—22.0 N·m { 1.75—2.25 kgf·m , 12.7—16.2 ft·lbf }




- (9) Put a paint mark on each bolt head.
- (10) Using this mark as a reference, tighten the bolts by turning each **85°—95°** in the sequence.
- (11) Further tighten each bolt by turning another **40°—50°**.




- (12) Do not rotate the crankshaft when measuring the oil clearances.
- (13) Remove the main bearing caps, and measure the Plastigage at each journal at the widest point for the smallest clearance, and at the narrowest point for the largest clearance.
- (14) If the oil clearance exceeds the maximum, grind the crankshaft and use the undersize main bearings. (Refer to page B1-64.)

Oil clearance: 0.025—0.037 mm { 0.0010—0.0014 in }
Maximum: 0.08 mm { 0.0031 in }




2. Apply clean engine oil to the main bearings, thrust bearings and main journals.
3. Install the crankshaft and the main bearing caps according to the cap number and ◁ mark.




4. Tighten the main bearing cap bolts.
 (1) Measure each bolt length. Replace if necessary.

Length: 84.7—85.3 mm { 3.34—3.35 in }
Maximum: 85.5 mm { 3.37 in }




- (2) Tighten the bolts in two or three steps in the order shown.

Tightening torque:
 17.2—22.0 N·m { 1.75—2.25 kgf·m , 12.7—16.2 ft·lbf }




- (3) Put a paint mark on each bolt head.
 (4) Using this mark as a reference, tighten the bolts by turning each 85° — 95° in the sequence.
 (5) Further tighten each bolt by turning another 40° — 50° .
 (6) Verify that the crankshaft rotates smoothly by hand.



5. Inspect the crankshaft end play.

End play: 0.080—0.282 mm { 0.0032—0.0111 in }
Maximum: 0.30 mm { 0.0118 in }



6. If the end play exceeds the maximum, grind the crankshaft and install an oversize thrust bearing or replace the crankshaft and thrust bearing.

Thrust bearing width

Standard:


2.000—2.050 mm { 0.0788—0.0807 in }

0.25 mm { 0.01 in } **oversize:**

2.125—2.175 mm { 0.0837—0.0856 in }

0.50 mm { 0.02 in } **oversize:**


2.250—2.300 mm { 0.0886—0.0905 in }




Connecting rod

1. Measure each connecting rod bolt length. Replace the connecting rod assembly if necessary.

Length: 66.7—67.3 mm { 2.63—2.64 in }
Maximum: 67.5 mm { 2.66 in }




2. Assemble the **SST** as shown.




3. Set the stopper bolt so that depth **L** is as specified.

Depth L: 61.35—61.5 mm { 2.416—2.421 in }

4. Tighten the locknut.



5. Insert the **SST** No.2 into the piston pin as shown and fully screw in the **SST** No.1.
6. Apply clean engine oil to the piston pin.
7. Set the piston on the **SST** with the **R** mark or **L** mark facing upward.
8. Verify that the **SST** fits squarely into the piston before pressing.








9. Press the piston pin into the piston and connecting rod until the **SST** contacts the stopper bolt.
10. While inserting the piston pin, check the pressure force. If it is less than the specification, replace the piston pin or the connecting rod.

Pressure force:

4,904—14,709 N { 500—1,500 kgf , 1,100—3,300 lbf }

11. Check the connecting rod oscillation torque. (Refer to page B-46.)



Piston ring

1. Install the three-piece oil rings on the pistons.
 - (1) Apply clean engine oil to the oil ring spacer and rails.
 - (2) Install the oil ring spacer so that the opening faces upward.
 - (3) Install the upper rail and lower rail.

Caution

- If reusing an oil ring, it must be reinstalled in the same place and face the same direction as when removed. If this is not done, it can cause premature and uneven wear.

Note

- The upper and lower rails are the same. They can be installed with either face upward.
2. Verify that the spacer tang separates the rails, and that the rails turn smoothly in both directions.
 3. Using a piston ring expander, install the second ring with the scraper face downward.
 4. Using a piston ring expander, install the top ring.
 5. Apply clean engine oil to the second and top piston rings.



6. Position the opening of each ring as shown.

Piston and connecting rod assembly

1. There are three standard cylinder bore and matching piston sizes. The pistons and bores must agree if installing new pistons in a standard size bore.

Cylinder block	Piston
A	A
No mark	No mark
C	C

2. The pistons and cylinder block are marked as shown in the figures. Refer to the charts for piston and bore sizes.



Cylinder block (Bore size)

mm { in }


Mark	Size
A	90.015—90.022 { 3.5439—3.5441 }
No mark	90.007—90.015 { 3.5436—3.5438 }
C	90.000—90.007 { 3.5433—3.5435 }

Piston (Measured at 90 ° to pin bore axis and 22.0 mm { 0.866 in } below oil ring groove)

mm { in }

Mark	Size
A	89.971—89.990 { 3.5422—3.5429 }
No mark	89.965—89.983 { 3.5420—3.5426 }
C	89.958—89.977 { 3.5417—3.5423 }

3. Apply clean engine oil to the cylinder walls, piston, and piston rings.
4. Check the piston rings for the end gap alignment.
5. Insert each piston assembly into the cylinder block with the **L** mark (left bank) or the **R** mark (right bank) facing the front of the engine. Use a piston installer tool to install.




Connecting rod cap


1. Check the connecting rod bearing oil clearances using the same procedure as for the main bearing oil clearance.
2. Align the marks on the cap and the connecting rod when installing the connecting rod cap.
 - (1) Tighten the nuts.

Tightening torque:

27.0—31.8 N·m { 2.75—3.25 kgf·m , 19.9—23.5 ft·lbf }



- (2) Put a paint mark on each nut head.
- (3) Using the paint mark as a reference, tighten the nuts **82.5°—97.5°**.




3. If the oil clearance exceeds the maximum, grind the crankshaft and use undersize bearings. (Refer to page B-64.)

Oil clearance:

0.023—0.064 mm { 0.0010—0.0025 in }

Maximum: 0.10 mm { 0.004 in }




4. Check each connecting rod side clearance.

Side clearance:


0.178—0.330 mm { 0.0071—0.0129 in }

Maximum: 0.40 mm { 0.016 in }

If the clearance exceeds the maximum, replace the connecting rod and cap.




5. Apply clean engine oil to the crankpin journal and connecting rod bearing.
6. Install the connecting rod cap with the alignment marks aligned.



7. Tighten the connecting rod cap nuts.
(1) Tighten the nuts.

Tightening torque:

27.0—31.8 N·m { 2.75—3.25 kgf·m , 19.9—23.5 ft·lbf }








- (2) Put a paint mark on each nut head.
(3) Using the paint mark as a reference, tighten the nuts **82.5°—97.5°**.
(4) Verify that the crankshaft rotates smoothly by hand.


INSPECTION / REPAIR

PREPARATION

SST

<p>49 0249 010A</p> <p>Remover & installer, valve guide</p> 	<p>For removal of valve guides</p>	<p>49 L012 0A0</p> <p>Installer set, valve seal & valve guide</p> 	<p>For installation of valve guides</p>
<p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p> 	<p>For installation of valve guides</p>	<p>49 L012 003</p> <p>Installer (Part of 49 L012 0A0)</p> 	<p>For installation of valve guides</p>
<p>49 L012 004</p> <p>Nut (Part of 49 L012 0A0)</p> 	<p>For installation of valve guides</p>	<p>—</p>	<p>—</p>






1. Clean all parts, being sure to remove all gasket fragments, dirt, oil or grease, carbon, moisture residue, and other foreign materials.
2. Inspection and repairs must be performed in the order specified.



CYLINDER HEAD

1. Inspect the cylinder head for damage, cracks, and leakage of water or oil. Replace if necessary.
2. Using a straightedge, measure the cylinder head for distortion in the six directions as shown.

Distortion: 0.10 mm { 0.004 in } max.



3. Inspect for the following and repair or replace.
 - (1) Sunken valve seats
 - (2) Damaged intake and exhaust manifold contact surfaces
 - (3) Excessive camshaft oil clearances and end play
4. If the cylinder head distortion exceeds the specification, grind the cylinder head surface.

Grinding: 0.15 mm { 0.006 in } max.

5. If the cylinder head height is not within the specification, replace it.

Height: 125.25—125.35 mm { 4.932—4.935 in }

6. Using a straightedge, measure the manifold contact surface distortion in the six directions as shown.

Distortion: 0.10 mm { 0.004 in } max.

7. If distortion exceeds the specification, grind the surface or replace the cylinder head.

Grinding: 0.15 mm { 0.006 in } max.

VALVE MECHANISM

Valve and Valve Guide

1. Inspect each valve for the following. Replace or resurface if necessary.
 - (1) Damaged or bent stem
 - (2) Roughness or damage to face
 - (3) Damage or uneven wear of stem tip
2. Check the valve head margin thickness. Replace the valve if necessary.

Margin thickness

IN: 0.75—1.25 mm { 0.030—0.049 in }

EX: 1.2—1.8 mm { 0.048—0.070 in }

3. Measure the valve length. Replace the valve if necessary.

Length

Standard

IN: 121.31 mm { 4.7760 in }

EX: 122.63 mm { 4.8279 in }

Minimum

IN: 120.91 mm { 4.7602 in }


EX: 122.23 mm { 4.8122 in }

4. Measure the valve stem diameter in X and Y directions at three points (A, B and C) as shown. Replace the valve if necessary.

Diameter

IN: 6.970—6.985 mm { 0.2745—0.2750 in }

EX: 8.025—8.040 mm { 0.3160—0.3165 in }



5. Measure the valve guide inner diameter in X and Y directions at three points (A, B and C) as shown. Replace the guide if necessary.

Inner diameter

IN: 7.01—7.03 mm { 0.2752—0.2767 in }
EX: 8.07—8.09 mm { 0.3178—0.3185 in }

6. Measure the valve stem-to-guide clearance.

(1) Method No.1



Subtract the valve stem outer diameter from the inner diameter of the corresponding valve guide.

(2) Method No.2

Measure the valve stem play at a point close to the valve guide with the valve lifted slightly off the valve seat.

Clearance

IN: 0.025—0.060 mm { 0.0010—0.0023 in }
EX: 0.030—0.065 mm { 0.0012—0.0025 in }
Maximum: 0.20 mm { 0.008 in }




7. If the clearance exceeds the maximum, replace the valve and/or valve guide.

8. Measure each valve guide projection height (dimension (A) in the figure). Replace the guide if necessary.

Height

IN: 13.2—13.8 mm { 0.520—0.543 in }
EX: 19.6—20.2 mm { 0.772—0.795 in }





Replacement of Valve Guide

Although the intake and exhaust valve guides are different, use the exhaust valve guide to replace the intake valve guide.

Removal

Remove the valve guide from the combustion chamber side by using the SST.




**Installation**

1. Assemble the **SST** so that depth **L** is as specified.


Depth L

IN: 13.2—13.8 mm { 0.520—0.543 in }
EX: 19.6—20.2 mm { 0.772—0.795 in }


2. Tighten the locknut.




3. Tap the valve guide in from the side opposite the combustion chamber until the **SST** contacts the cylinder head.
4. Verify that the valve guide projection height is within the specification. (Refer to page B-56.)
5. If not, repeat steps 1—4.

**Valve Seat**

1. Inspect the contact surface of the valve seat and valve face for the following:
 - (1) Roughness
 - (2) Damage
2. If necessary, resurface the valve seat with a 45° valve seat cutter and/or resurface the valve face.




3. Apply a thin coat of prussian blue to the valve face.
4. Check the valve seating by pressing the valve against the seat.
 - (1) If blue does not appear 360° around the valve face, replace the valve.
 - (2) If blue does not appear 360° around the valve seat, resurface the seat.




5. Measure the seat contact width.

Width: 1.2—1.6 mm { 0.048—0.062 in }



- (1) If the valve seating position on the valve face is too high, correct the valve seat with a 65° cutter.
 - (2) If the valve seating position on the valve face is too low, correct the valve seat with a 35° (IN) or 15° (EX) cutter.
6. Seat the valve to the valve seat with a lapping compound.



7. Check the sinking of the valve seat.
Measure the protruding length (dimension L) of the valve stem.

Dimension L


IN: 50.5 mm { 1.988 in }

EX: 49.5 mm { 1.949 in }

- (1) If L is as below, it can be used as it is.

IN: 50.5—51.0 mm { 1.989—2.007 in }


EX: 49.5—50.0 mm { 1.949—1.968 in }



- (2) If L is more than below, replace the cylinder head.

IN: 51.1 mm { 2.012 in }

EX: 50.1 mm { 1.972 in }



Valve Spring

1. Inspect each valve spring for cracks and damage.
2. Check the free length and out-of-square. Replace if necessary.


Free length and out-of-square


mm { in }

		Outer		Inner	
Free length	Standard	IN	50.9 { 2.004 }	46.73 { 1.840 }	
		EX	58.33 { 2.296 }	53.14 { 2.092 }	
	Minimum	IN	①	②	
		EX	③	④	
Maximum out-of-square		IN	1.78 { 0.070 }	1.63 { 0.064 }	
		EX	2.04 { 0.080 }	1.86 { 0.073 }	

N { kgf , lbf }/mm { in }


- ① 138—147 { 14.0—15.05 , 31—33 } with a set load of 44.0 { 1.732 }
- ② 93—99 { 9.4—10.11 , 21—22 } with a set load of 39.5 { 1.555 }
- ③ 232—261 { 23.56—26.66 , 52—58 } with a set load of 45.0 { 1.772 }
- ④ 148—166 { 15.01—16.99 , 33—37 } with a set load of 40.5 { 1.594 }



**CAMSHAFT**

1. Set the front and rear journals on V-blocks. Measure the camshaft runout. Replace if necessary.

Runout: 0.03 mm { 0.0012 in } max.




2. Inspect the cam for wear and damage. Replace if necessary.
3. Measure the cam lobe height at the two points shown.

Height

IN: 41.054 mm { 1.6163 in }
EX: 41.293 mm { 1.6257 in }

Minimum

IN: 40.854 mm { 1.6084 in }
EX: 41.093 mm { 1.6178 in }



4. Measure the journal diameters in X and Y directions at the two points (A and B) shown.


Diameter**No.1 and No.4:**

48.923—48.938 mm { 1.9261—1.9266 in }

No.2 and No.3:

48.915—48.935 mm { 1.9258—1.9265 in }

Out-of-round: 0.03 mm { 0.0012 in } max.



5. Measure the camshaft and cylinder head oil clearance.
 - (1) Remove any oil or dirt from the journals and the camshaft bore.
 - (2) Measure the camshaft bore diameter.

Diameter: 49.015—49.035 mm { 1.9298—1.9305 in }

- (3) Subtract the journal diameter from the bore diameter.

Oil clearance**No.1 and No.4:**


0.077—0.112 mm { 0.0031—0.0044 in }

No.2 and No.3:

0.080—0.120 mm { 0.0031—0.0047 in }


Maximum: 0.15 mm { 0.006 in }

- (4) If the clearance exceeds the maximum, replace the camshaft or cylinder head.



- Install the thrust plate and measure the camshaft end play. If it exceeds the maximum, replace the thrust plate or camshaft.


End play: 0.05—0.18 mm { 0.0020—0.0070 in }
Maximum: 0.20 mm { 0.008 in }



ROCKER ARM AND ROCKER ARM SHAFT

- Check for wear and damage to the contact surfaces of the rocker arm shaft and the rocker arm. Replace if necessary.
- Check the oil clearance between the rocker arm and rocker arm shaft. Replace if necessary.
 - Measure the rocker arm inner diameter.

Diameter: 19.000—19.033 mm { 0.7481—0.7493 in }




- Measure the rocker arm shaft diameter.

Diameter: 18.959—18.980 mm { 0.7465—0.7472 in }

- Subtract the rocker arm shaft diameter from the inner diameter.

Oil clearance:


0.020—0.074 mm { 0.0008—0.0029 in }
Maximum: 0.10 mm { 0.004 in }



HLA

Check the HLA face for wear and damage. Replace if necessary.


Remove the HLA only for inspection. Remove by hand or use pliers protected by a rag.



CYLINDER BLOCK

- Check the cylinder block. Repair or replace if necessary.
 - Leakage damage
 - Cracks
 - Scoring of wall
- Measure the distortion of the top surface of the cylinder block in the seven directions as shown.


Distortion: 0.15 mm { 0.006 in } max.



3. If the distortion exceeds the specification, repair by grinding or replace the cylinder block.

Height: 220.0 mm { 8.66 in }

Grinding: 0.20 mm { 0.008 in } max.




4. Measure the cylinder bore in X and Y directions at three points (A, B, and C) in each cylinder as shown.

Cylinder bore

Base the boring diameter on the diameter of an oversize piston. All cylinders must be the same diameter.


mm { in }

Size	Bore	Diameter
Standard		90.000—90.022 { 3.5433—3.5441 }
0.25 { 0.01 } oversize		90.250—90.272 { 3.5532—3.5540 }
0.50 { 0.02 } oversize		90.500—90.522 { 3.5630—3.5638 }




- (1) If the cylinder bore exceeds the maximum, rebore the cylinder to oversize.
- (2) If the difference between the measurements A and C exceeds the maximum taper, rebore the cylinder to oversize.

Taper: 0.019 mm { 0.0007 in } max.




- (3) If the difference between the measurements X and Y exceeds the maximum out-of-round, rebore the cylinder to oversize.

Out-of-round: 0.019 mm { 0.0007 in } max.



5. If the upper part of the cylinder wall shows uneven wear, remove the ridge with a ridge reamer.



PISTON, PISTON RING, AND PISTON PIN


Piston

1. Inspect the outer circumferences of all pistons for seizure or scoring. Replace if necessary.
2. Measure the outer diameter of each piston at a right angle **90°** to the piston pin, **22 mm { 0.866 in }** below the oil ring groove lower edge.

Piston diameter

mm { in }


Size	Bore	Diameter
Standard		89.958—89.990 { 3.5417—3.5429 }
0.25 { 0.01 } oversize		90.208—90.240 { 3.5515—3.5527 }
0.50 { 0.02 } oversize		90.458—90.490 { 3.5614—3.5625 }



3. Measure the piston-to-cylinder clearance.

Clearance: 0.023—0.051 mm { 0.0010—0.0020 in }
Maximum: 0.15 mm { 0.006 in }

4. If the clearance exceeds the maximum, replace the piston or rebore the cylinders to fit oversize pistons.
5. If the piston is replaced, the piston rings must also be replaced.




Piston and Piston ring

1. Measure the piston ring-to-ring land clearance around the entire circumference by using a new piston ring.

Clearance (Top and Second):
0.03—0.07 mm { 0.0012—0.0027 in }
Maximum: 0.15 mm { 0.006 in }


2. If the clearance exceeds the maximum, replace the piston.
3. Inspect the piston rings for damage, abnormal wear, or breakage. Replace if necessary.
4. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.




5. Measure each piston ring end gap with a feeler gauge. Replace if necessary.

End gap


Top : 0.20—0.35 mm { 0.008—0.013 in }
Second : 0.15—0.30 mm { 0.006—0.011 in }
Oil rail : 0.20—0.70 mm { 0.008—0.027 in }
Maximum: 1.0 mm { 0.039 in }



**Piston and Piston Pin**

1. Measure the piston pin hole diameter in X and Y directions at four points (A, B, C and D).

Diameter: 22.988—23.000 mm { 0.9051—0.9055 in }




2. Measure the piston pin diameter in X and Y directions at four points (A, B, C and D).

Diameter: 22.974—22.980 mm { 0.9045—0.9047 in }

3. Calculate the related piston pin-to-piston clearance.

Clearance: 0.008—0.026 mm { 0.0004—0.0010 in }

4. If the clearance exceeds the specification, replace the piston and/or piston pin.

**CONNECTING ROD**

1. Measure the connecting rod small end bore.

Diameter: 22.943—22.961 mm { 0.9033—0.9039 in }

2. Calculate the interference between the small end bore and piston pin.

**Interference:
0.013—0.037 mm { 0.0005—0.0014 in }**

3. Measure each connecting rod for bend. Replace the connecting rod if necessary.

Bend: 0.08 mm { 0.0031 in }/50 mm { 1.9685 in } max.


Distortion:

0.18 mm { 0.0071 in }/50 mm { 1.9685 in } max.

Length (Center to Center):


146.25—146.35 mm { 5.758—5.761 in }


4. If the connecting rod is replaced, the connecting rod cap, bolts, and nuts must also be replaced because they are a matched set.

**CRANKSHAFT**

1. Check the journals and pins for damage, scoring, or oil hole clogging.
2. Set the crankshaft on V-blocks.
3. Measure the crankshaft runout at the center journal. Replace if necessary.

Runout: 0.03 mm { 0.0012 in } max.





4. Measure each journal diameter in X and Y directions at two points as shown.

Main journal

Diameter:

61.937—61.955 mm { 2.4385—2.4391 in }

Out-of-round: 0.05 mm { 0.0020 in } max.

Crankpin journal

Diameter:

52.940—52.955 mm { 2.0843—2.0848 in }

Out-of-round: 0.05 mm { 0.0020 in } max.

5. If the diameter is less than the specification, grind the journals to match an undersize bearing.

Undersize bearing: 0.25 mm { 0.01 in }

Main journal diameter undersize

mm { in }

Bearing size	Journal diameter
0.25 { 0.01 } undersize	61.687—61.705 { 2.4287—2.4293 }




Crankpin journal diameter undersize

mm { in }

Bearing size	Journal diameter
0.25 { 0.01 } undersize	52.690—52.705 { 2.0745—2.0749 }

Caution

- Do not remove the fillet roll area when grinding.



TIMING BELT AUTO TENSIONER

Check the tensioner rod projection. Replace if necessary.

Projection (free length): 12—14 mm { 0.48—0.55 in }

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

LUBRICATION SYSTEM


OUTLINE	D-2
SPECIFICATIONS	D-2
TROUBLESHOOTING GUIDE	D-2
OIL PRESSURE	D-3
PREPARATION	D-3
INSPECTION	D-3
ENGINE OIL	D-4
INSPECTION	D-4
REPLACEMENT	D-4
OIL FILTER	D-5
REPLACEMENT	D-5
OIL PAN	D-6
REMOVAL / INSTALLATION	D-6
OIL PUMP	D-9
PREPARATION	D-9
DISASSEMBLY / INSPECTION / ASSEMBLY	D-9

OUTLINE

SPECIFICATIONS

Item		Engine	JE
Lubrication system			Force-fed type
Oil pump	Type		Trochoid gear
	Relief pressure	kPa { kgf/cm ² , psi }	383—480 { 3.9—4.9 , 56—69 }
Oil filter	Type		Full-flow, paper element
	By-pass pressure differential	kPa { kgf/cm ² , psi }	79—117 { 0.8—1.2 , 12—17 }
Oil pressure switch activation pressure		kPa { kgf/cm ² , psi }	2—24 { 0.02—0.25 , 0.29—3.55 }
Oil capacity	Total (dry engine)	L { US qt , Imp qt }	5.2 { 5.5 , 4.6 }
	Oil replacement	L { US qt , Imp qt }	4.5 { 4.8 , 4.0 }
	Oil and oil filter replacement	L { US qt , Imp qt }	4.8 { 5.1 , 4.2 }
	Engine oil		API Service SG, SH (ECII) ILSAC

Recommended SAE Viscosity



Anticipated ambient temperature range before succeeding oil change, °C { °F }

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
Engine hard starting	Improper engine oil	Replace	D-4
	Insufficient engine oil	Add oil	D-4
Excessive oil consumption	Oil working up or down	Refer to section B	D-6
	Oil leakage	Repair	
Oil pressure drop	Insufficient oil	Add oil	D-4
	Oil leakage	Repair	D-4
	Worn and/or damaged oil pump rotor	Replace	D-9, 10
	Worn plunger (inside oil pump) or weak spring	Replace	D-11
	Clogged oil strainer	Clean	—
	Excessive main bearing or connecting rod bearing clearance	Refer to section B	
Warning light illuminates while engine is running	Oil pressure drop	As described above	—
	Malfunction of oil pressure switch	Refer to section T	
	Malfunction of electrical system	Refer to section T	


Warning




- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

OIL PRESSURE

PREPARATION

SST

<p>49 0187 280</p> <p>Gauge, oil pressure</p>		<p>For inspection of oil pressure</p>
---	---	---



INSPECTION

1. Remove the oil pressure switch.

2. Screw the **SST** into the oil pressure switch installation hole.
3. Warm up the engine to normal operating temperature.
4. Run the engine at the specified speed, and note the gauge readings.

Oil pressure

1,000 rpm:

89—245 kPa { 0.9—2.5 kgf/cm² , 13—35 psi }

3,000 rpm:


363—519 kPa { 3.7—5.3 kgf/cm² , 53—75 psi }

5. If the pressure is not as specified, check for the cause and repair as necessary.
6. Apply silicone sealant to the oil pressure switch threads as shown.
7. Remove the **SST** and install the oil pressure switch.

Tightening torque:

12—17 N·m { 1.2—1.8 kgf·m , 9—13 ft·lbf }

8. Start the engine and check for oil leaks.



ENGINE OIL

INSPECTION

1. Position the vehicle on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil if necessary.


Note

- The distance between the L and F marks on the dipstick represents 1.0 L { 1.1 US qt , 0.9 Imp qt }.

REPLACEMENT

Warning

- When the engine and the engine oil are hot, they can badly burn. Don't burn yourself with either.
- A vehicle that is lifted but not securely supported on safety stands is dangerous. It can slip or fall, causing death or serious injury. Never work around or under a lifted vehicle if it is not securely supported on safety stands.
- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.



1. Remove the oil filler cap and the oil drain plug.
2. Drain the oil into a container.
3. Install the oil drain plug.

Tightening torque:

30—41 N·m { 3.0—4.2 kgf·m , 22—30 ft·lbf }



4. Refill the engine with the specified type and amount of engine oil.

Oil capacity

L {US qt, Imp qt}

Total (dry engine)	5.2 { 5.5 , 4.6 }
Oil replacement	4.5 { 4.8 , 4.0 }
Oil and oil filter replacement	4.8 { 5.1 , 4.2 }

5. Refit the oil filler cap.
6. Run the engine and check for oil leaks.
7. Check the oil level and add oil if necessary.



OIL FILTER

REPLACEMENT

1. Remove the oil filter by using a wrench.
2. Use a clean rag to wipe off the mounting surface on the engine.
3. Apply clean engine oil to the rubber seal of the new filter.
4. Install the oil filter until the rubber seal contacts the base, and then tighten the filter 1 and 1/6 turns by using the wrench.
5. Start the engine and inspect for leaks around the filter seal.
6. Check the oil level and add oil if necessary.


D

OIL PAN

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine oil. (Refer to page D-4.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Fill with the specified amount and type of engine oil. (Refer to page D-4.)
6. Start the engine and check for oil leaks.
7. Check the oil level and add oil if necessary.

4×2




N-m { kgf-m , ft-lbf }

1. Splash shield
2. Gusset plate

3. Oil pan
Removal Note page D-8
Installation Note page D-8
4. Drain plug

4x4

D



Before removing the parts below, suspend the engine slightly.

- | | |
|-----------------------------|----------------------------------|
| 1. Splash shield | 6. Oil cooler hose and pipe |
| 2. Fresh-air duct | 7. Stabilizer bracket |
| 3. Fan cowling | 8. Oil pan |
| 4. Engine mount | Removal Note page D-8 |
| Removal Note page D-8 | Installation Note page D-8 |
| 5. Transmission lower mount | 9. Drain plug |
| Removal Note page D-8 | |


Removal Note**Engine mount (4 × 4)**

1. Install the front engine hanger (JE48 10 561A).


Tightening torque:

32—46 N·m { 3.2—4.7 kgf·m , 24—33 ft·lbf }

2. Suspend the engine. Remove the engine mount nuts and lift the engine to gain removal clearance.

**Transmission lower mount (4 × 4)**

Support the transmission with a transmission jack before removing the transmission lower mount.


**Oil pan**

1. Remove the oil pan mounting bolts.

Caution

- Pry tools can easily scratch the oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange.

2. Insert a screwdriver between the oil pan and the cylinder block to separate them.
3. Remove the oil pan.

**Installation Note****Oil pan**

1. Apply silicone sealant to the oil pan along the inside of the bolt holes, overlap the ends, and install the oil pan within five minutes.

Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.

2. Tighten the oil pan bolts.



Tightening torque:

6.9—9.8 N·m { 70—100 kgf·cm , 61—86 in·lbf }

OIL PUMP

PREPARATION


SST

<p>49 G034 2A0</p> <p>Replacer set, rubber bush</p> 	<p>For installation of front oil seal</p>	<p>49 G034 202</p> <p>Support block (Part of 49 G034 2A0)</p> 	<p>For installation of front oil seal</p>
---	---	---	---

D


DISASSEMBLY / INSPECTION / ASSEMBLY

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Pump cover
2. Outer rotor
3. Inner rotor
4. Pressure relief valve

5. Oil seal
Disassembly Note page D-10
Assembly Note page D-11
6. Oil pump body


**Disassembly Note****Oil seal**

Remove the oil seal by using a screwdriver protected with a rag.

**Inspection**

1. Check the following and replace any faulty parts.
 - (1) Distorted or damaged oil pump body or cover
 - (2) Worn or damaged plunger
 - (3) Weak or broken plunger spring

Free length: 46.4 mm { 1.827 in }




2. Measure the following clearances.

Side clearance


Standard: 0.035—0.085 { 0.0014—0.0033 in }

Maximum: 0.13 mm { 0.0051 in }

**Tooth tip clearance**


Standard: 0.04—0.20 mm { 0.0016—0.0078 in }

Maximum: 0.24 mm { 0.0094 in }

**Outer rotor to pump body**

Standard: 0.010—0.196 mm { 0.0004—0.0077 in }

Maximum: 0.23 mm { 0.0091 in }

**Assembly Note****Oil seal**

1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Press the oil seal into the oil pump body by using the **SST**.

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

COOLING SYSTEM

OUTLINE	E-2
SPECIFICATIONS	E-2
TROUBLESHOOTING GUIDE	E-2
ENGINE COOLANT	E-3
PREPARATION	E-3
INSPECTION	E-3
REPLACEMENT	E-4
RADIATOR CAP	E-6
PREPARATION	E-6
INSPECTION	E-6
RADIATOR	E-7
REMOVAL / INSTALLATION	E-7
THERMOSTAT	E-8
REMOVAL / INSPECTION / INSTALLATION	E-8
WATER PUMP	E-9
REMOVAL / INSTALLATION	E-9
COOLING FAN	E-9
INSPECTION	E-9

OUTLINE

SPECIFICATIONS




Item		Engine	JE
Cooling system			Water-cooled, forced circulation
Coolant capacity		L { US qt , Imp qt }	9.4 { 9.9 , 8.3 }
Water pump	Type		Centrifugal
	Water seal		Unified mechanical seal
Thermostat	Type		Wax, bottom-bypass
	Opening temperature	°C { °F }	81.5—84.5 { 179—184 }
	Full-open temperature	°C { °F }	96 { 205 }
	Full-open lift	mm { in }	9.0 { 0.35 } min.
Radiator	Type		Corrugated fin
	Cap valve opening pressure	kPa { kgf/cm ² , psi }	74—102 { 0.75—1.05 , 10.7—14.9 }
Cooling fan	Type		Thermo-modulated
	Switching temperature OFF→ON	°C { °F }	82—88 { 180—190 } linear
	Number of blades		7
	Outer diameter of blade	mm { in }	430 { 16.9 }

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
Overheating	Insufficient coolant	Add	E-3
	Coolant leakage	Repair	—
	Radiator fins clogged	Repair	—
	Radiator cap malfunction	Replace	E-6
	Cooling fan malfunction	Replace	E-9
	Thermostat malfunction	Replace	E-8
	Water passage clogged	Clean	E-4
	Water pump malfunction	Replace	E-9
Corrosion	Impurities in coolant	Replace	E-3

ENGINE COOLANT

PREPARATION
SST

<p>49 9200 145</p> <p>Adapter set, radiator cap tester</p> 	<p>For inspection of cooling system</p>	<p>49 9200 146</p> <p>Adapter B (Part of 49 9200 145)</p> 	<p>For inspection of cooling system</p>
<p>49 9200 147</p> <p>Adapter A (Part of 49 9200 145)</p> 	<p>For inspection of radiator cap valve</p>	<p>—</p>	<p>—</p>

E

INSPECTION

Warning

- Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.
- Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.
- When you're sure all the pressure is gone, press down on the cap—still using a cloth—turn it, and remove it.

Coolant Level (Engine cold)

1. Check that the coolant level is near the radiator inlet port.
2. Check that the coolant level in the coolant reservoir is between the F and L marks. Add coolant if necessary.

Note

- The distance between the L and F marks on the coolant reservoir represents 0.55 L { 0.6 US qt , 0.5 Imp qt }.



Coolant Leakage


1. Remove the radiator cap.
2. Connect a radiator tester and the SST to the radiator inlet port.

Caution

- Applying more than 103 kPa { 1.05 kgf/cm² , 14.9 psi } can damage the hoses, fittings, and other components, and cause leaks.

3. Apply 103 kPa { 1.05 kgf/cm² , 14.9 psi } pressure to the system.
4. Verify that the pressure is held. If not, check for coolant leakage.





Coolant Protection

Caution

- The engine has aluminum parts that can be damaged by alcohol or methanol antifreeze. Do not use alcohol or methanol in the cooling system. Use only ethylene-glycol-based coolant.
- Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.

1. Measure the coolant temperature and specific gravity with a thermometer and a hydrometer.
2. Determine the coolant protection by referring to the graph shown.
3. If the coolant protection is not proper, add water or coolant as necessary.

Antifreeze solution mixture percentage

Coolant protection	Volume percentage		Gravity at 20 °C { 68 °F }
	Water	Coolant	
Above -16 °C { 3 °F }	65	35	1.054
Above -26 °C { -15 °F }	55	45	1.066
Above -40 °C { -40 °F }	45	55	1.078


REPLACEMENT

Draining

Warning

- Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It can also damage the engine and cooling system.
- Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.
- When you're sure all the pressure is gone, press down on the cap—still using a cloth—turn it, and remove it.

1. Remove the radiator cap.
2. Loosen the radiator drain plug by hand.
3. Drain the coolant into a container.




4. Flush the cooling system with water until all traces of color are gone.
5. Let the system drain completely.
6. Tighten the drain plug by hand.

Refilling

Use the proper amount and mixture of ethylene-glycol-based coolant. (Refer to Coolant Protection, page E-4.)

1. Slowly pour the coolant into the radiator up to the coolant filler port.

Filling pace: 2 L { 2.1 US qt , 1.8 Imp qt }/min. max.





2. Fill the coolant reservoir up to the F mark.
3. Fully install the radiator cap.
4. Start the engine and let it idle until it warms up.
5. If the temperature increases beyond normal, there is excessive air in the system. Stop the engine and allow it to cool; then repeat steps 1—3.
6. Run the engine at 2,200—2,800 rpm for five seconds; repeat several times.
7. Stop the engine and allow it to cool.

Warning

- **Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.**
 - **Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.**
 - **When you're sure all the pressure is gone, press down on the cap—still using a cloth—turn it, and remove it.**
8. Remove the radiator cap and check the coolant level. If the coolant level has dropped, repeat the procedure from step 1.


RADIATOR CAP

PREPARATION
SST


<p>49 9200 145</p> <p>Adapter set, radiator cap tester</p> 	<p>For inspection of radiator cap</p>	<p>49 9200 147</p> <p>Adapter A (Part of 49 9200 145)</p> 	<p>For inspection of radiator cap</p>
--	---	---	---

Warning

- Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.
- Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.
- When you're sure all the pressure is gone, press down on the cap—still using a cloth—turn it, and remove it.

**INSPECTION****Radiator Cap Valve**

1. Remove the radiator cap.
2. Attach the radiator cap to a radiator cap tester with the SST. Apply pressure gradually to **74—102 kPa** { **0.75—1.05 kgf/cm²** , **10.7—14.9 psi** }.
3. Verify that the pressure is held at least **10 seconds**.

**Negative Pressure Valve**


1. Pull the negative pressure valve to open it. Verify that it closes completely when released.
2. Check for damage on the contact surfaces and for cracked or deformed seal packing.
3. Replace the radiator cap if necessary.

RADIATOR

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E-4.)
3. Remove the fresh-air duct. (Refer to section F.)
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal.
6. Install the fresh-air duct. (Refer to section F.)

E



1. Upper and lower radiator hoses
2. Coolant reservoir hose
3. Oil cooler hose

4. Radiator cowling
5. Radiator


Steps After Installation

1. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Check the ATF level and add ATF if necessary. (Refer to section K.)
3. Check the ATF and coolant leaks.

THERMOSTAT


REMOVAL / INSPECTION / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E-4.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Lower radiator hose
2. Thermostat cover

3. Thermostat
Inspection below



Inspection

Check the thermostat and replace if necessary.

1. Check the O-ring for damage.
2. Visually check that the valve is airtight.
3. Place the thermostat and a thermometer in water. Heat the water and check the following.

Initial-opening temperature:
 81.5—84.5 °C { 179—184 °F }
Full-open temperature: 96 °C { 205 °F }
Full-open lift: 9.0 mm { 0.35 in } min.

Steps After Installation


1. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Start the engine and check for coolant leaks.

WATER PUMP

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Turn the crankshaft so that the No.1 cylinder is at TDC of compression.
3. Drain the engine coolant. (Refer to page E-4.)
4. Remove the timing belt. (Refer to section B.)
5. Remove in the order shown in the figure.
6. Install in the reverse order of removal.

E




1. Water pump

Inspect for cracks, damaged mounting surface, bearing condition, and leakage. If the water pump is damaged, replace it. Do not repair it.

2. Water pump gasket

Steps After Installation

1. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Start the engine and check for coolant leaks.



COOLING FAN

INSPECTION

1. Inspect the following items. Replace if necessary.
 - (1) Fluid leakage from the fan-drive clutch
 - (2) Deformation of the bimetal
 - (3) Excessive play of the cooling fan bearing
 - (4) Grease leakage from the cooling fan bearing
2. While the engine is warm, turn the cooling fan by hand and check that resistance is felt. Replace the cooling fan-drive clutch if necessary.









Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.


FUEL AND EMISSION CONTROL SYSTEMS

ENGINE TUNE-UP	F- 2	CONTROL SYSTEM	F- 29
PREPARATION	F- 2	PREPARATION	F- 29
ADJUSTMENT	F- 2	STRUCTURAL VIEW	F- 30
INTAKE-AIR SYSTEM	F- 5	ENGINE CONTROL MODULE	
COMPONENT PARTS	F- 5	(ECM)	F- 31
AIR VALVE	F- 6	MASS AIR FLOW SENSOR	F- 37
IDLE AIR CONTROL VALVE	F- 7	CAMSHAFT POSITION SENSOR ..	F- 38
SHUTTER VALVE ACTUATOR	F- 7	CRANKSHAFT POSITION	
VACUUM CHAMBER	F- 7	SENSOR	F- 39
VRIS SOLENOID VALVE	F- 7	THROTTLE POSITION SENSOR ..	F- 40
ACCELERATOR PEDAL	F- 8	ENGINE COOLANT TEMPERATURE	
ACCELERATOR CABLE	F- 8	SENSOR	F- 42
FUEL SYSTEM	F- 9	INTAKE AIR TEMPERATURE SENSOR	
COMPONENT PARTS	F- 9	(DYNAMIC CHAMBER)	F- 43
PRECAUTION	F-10	HEATED OXYGEN SENSOR	F- 43
SYSTEM INSPECTION	F-11	FUEL TANK PRESSURE SENSOR	F- 44
FUEL TANK	F-13	POWER STEERING PRESSURE	
FUEL FILTER		SWITCH	F- 45
(HIGH PRESSURE SIDE)	F-15	MAIN RELAY	F- 45
FUEL PUMP	F-15	ON-BOARD DIAGNOSTIC SYSTEM .	F- 46
FUEL PUMP RELAY	F-18	PREPARATION	F- 46
PRESSURE REGULATOR	F-19	DIAGNOSTIC TROUBLE CODE	
PRC SOLENOID VALVE		NUMBER	F- 46
(No.1, No.2)	F-20	TROUBLESHOOTING GUIDE	F- 79
FUEL INJECTOR	F-20	RELATIONSHIP CHART	F- 79
EXHAUST SYSTEM	F-22	ENGINE CONTROL OPERATION	
COMPONENT PARTS	F-22	CHART	F- 80
EMISSION SYSTEM	F-23	HOW TO USE THIS SECTION	F- 84
COMPONENTS PARTS	F-23	DIAGNOSTIC INDEX	F- 86
CATCH TANK	F-25	SYMPTOM TROUBLESHOOTING .	F- 88
PURGE SOLENOID VALVE	F-25	SYSTEM INSPECTION	F-139
CHARCOAL CANISTER	F-25	PREPARATION	F-139
CUT VALVE	F-26	IDLE AIR CONTROL INSPECTION	F-139
TANK PRESSURE CONTROL VALVE		VRIS INSPECTION	F-140
(TPCV)	F-26	PRESSURE REGULATOR CONTROL	
CHECK VALVE	F-26	INSPECTION	F-141
SEPARATOR	F-27	PURGE CONTROL INSPECTION ..	F-143
CANISTER DRAIN CUT VALVE		A/C CUT CONTROL INSPECTION .	F-144
(CDCV)	F-28		
PCV VALVE	F-28		

ENGINE TUNE-UP






PREPARATION SST

<p>49 B019 9A0</p> <p>System Selector</p> 	<p>For inspection of ignition timing and idle speed</p>	<p>49 T088 0A0</p> <p>NGS set</p> 	<p>For inspection of ignition timing and idle speed</p>
<p>49 T088 010B</p> <p>Program Card</p> 	<p>For inspection of ignition timing and idle speed</p>	<p>49 D088 008A</p> <p>Instruction Manual</p> 	<p>For inspection of ignition timing and idle speed</p>
<p>49 T088 002</p> <p>Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For inspection of ignition timing and idle speed</p>	<p>49 T088 001</p> <p>Control Unit (Part of 49 T088 0A0)</p> 	<p>For inspection of ignition timing and idle speed</p>
<p>49 T088 004</p> <p>NGS OBD II Adapter (Part of 49 T088 0A0)</p> 	<p>For inspection of ignition timing and idle speed</p>	<p>49 T088 006</p> <p>Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For inspection of ignition timing and idle speed</p>



ADJUSTMENT Preparation

1. Warm up the engine to normal operating temperature.
2. Shift the transmission into P position.
3. Turn off all loads.
 - Headlight
 - Blower motor
 - Rear window defroster
 - Power steering
4. Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard and select the "PID/DATA MONITOR AND RECORD" function.
5. Select "RPM" on the NGS display.



Ignition Timing

1. Perform "Preparation". (Refer to page F-2.)
2. Connect a timing light to the high-tension lead No.1.
3. Connect the **SST** (System Selector) to the data link connector.
4. Set switch (A) to position 1.
5. Set the test switch to SELF TEST.
6. Verify that the idle speed is within the specification; if not, adjust it.

Specification: 500—900 rpm

7. Verify that the timing mark (yellow) is within the specification.

Specification: BTDC 10—12° (11 ± 1°)

8. If not as specified, loosen the distributor lock bolts and turn the distributor to make the adjustment.
9. Tighten the distributor lock bolts to the specified torque.

Tightening torque:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }

10. Disconnect the **SST** (System Selector).
11. Verify that the timing mark (yellow) is within the specification.

Specification: ATDC 2—BTDC 34°

Idle Speed

1. Perform "Preparation". (Refer to page F-2.)
2. Connect the **SST** (System Selector) to the data link connector.
3. Set switch (A) to position 1.
4. Set the test switch to SELF TEST.
5. Verify that the idle speed is within the specification.

Specification: 760—800 (780 ± 20) rpm

Caution

- The throttle adjusting screw is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.

6. If not within the specification, adjust the idle speed by turning the air adjusting screw.
7. Disconnect the **SST** (System Selector).

Idle-up Speed

1. Perform "Preparation". (Refer to page F-2.)
2. Verify that the idle speed is within the specification.

Specification: 760—800 (780 ± 20) rpm

3. If not as specified, adjust the idle speed.
(Refer to page F-3.)
4. Check the idle speed with the following load conditions.


Specification

Load condition	Idle speed (rpm)
Fan switch ON at max. speed	730—830
Headlight switch ON	730—830
Rear window defroster switch ON	730—830
P/S ON	730—830
A/C ON	750—850

Note

- Excludes temporary idle speed drop just after the electrical loads are turned on.
5. If not as specified with all load conditions, inspect the idle air control valve. (Refer to page F-7.)
If not as specified with some load condition, check related input switches, harnesses and connectors.


- 1. Fresh-air duct
- 2. Air intake hose
- 3. Air cleaner
- 4. Mass air flow sensor
- 5. Accelerator cable
Inspection / Adjustment page F-8
- 6. Throttle body
- 7. BAC valve
Inspection below
- 8. VRIS solenoid valve
Inspection page F-7
- 9. PRC solenoid valve No.1
- 10. PRC solenoid valve No.2
- 11. VRIS shutter valve actuator
Inspection page F-7
- 12. Dynamic chamber
Installation note below
- 13. Fuel distributor
- 14. Water outlet pipe
- 15. Intake manifold
Installation note below



Installation note


Dynamic chamber

Face the bead of the gasket as shown, and install the dynamic chamber.



Intake manifold

1. Face the bead of the gasket toward the intake manifold as shown, and install the intake manifold.




- 2. Install the intake manifold washers with the white paint mark upward.
- 3. Tighten the nuts to the specification in two steps in the sequence shown in the figure.

Tightening torque

Intake manifold and delivery pipes:


19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }



AIR VALVE

Inspection

- 1. Remove the BAC valve. (Refer to page F-5.)
- 2. Circulate water in the BAC valve coolant passage to cool the air valve.
- 3. Circulate hot water in the BAC valve coolant passage and verify that the air valve operates.
- 4. If not, replace the BAC valve.




IDLE AIR CONTROL VALVE

Inspection

1. Verify that the ignition switch is OFF.
2. Disconnect the idle air control valve connector.
3. Measure the resistance of the idle air control valve by using an ohmmeter.

Specification: 10.7—12.3 Ω [20 °C { 68 °F }]


4. If not as specified, replace the BAC valve.
(Refer to page F-5.)



SHUTTER VALVE ACTUATOR

Inspection


1. Connect a vacuum pump to the shutter valve actuator as shown.
2. Apply vacuum of 4.0 kPa { 30 mmHg } and verify that the rod is pulled into the actuator.
3. Apply vacuum of 25.3 kPa { 190 mmHg } and verify that the actuator opens completely (rod fully pulled in).
4. If not as specified, replace the shutter valve actuator.
(Refer to page F-5.)




VACUUM CHAMBER

Inspection

1. Remove the vacuum chamber.
2. Visually inspect the outer surface for damage.



3. Blow air from port (A) and verify that there is no airflow.
4. Blow air from port (B) and verify that there is airflow.
5. If not as specified, replace the vacuum chamber.



VRIS SOLENOID VALVE

Inspection

1. Remove the VRIS solenoid valve.
(Refer to page F-5.)
2. Check for airflow between ports of the solenoid valve.

○—○: Continuity ○—○: Airflow B+: Battery positive voltage


Step	Terminal		Port		
	A	B	A	B	C
1	○—○	○—○		○—○	○—○
2	B+	Ground	○—○	○—○	

3. If not as specified, replace the VRIS solenoid valve.

ACCELERATOR PEDAL


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N-m { kgf-m , ft-lbf }

- | | |
|---|----------------------|
| 1. Accelerator cable
Inspection / Adjustment below | 3. Retainer |
| 2. Actuator cable (with cruise control) | 4. Accelerator pedal |



ACCELERATOR CABLE

Inspection / Adjustment

1. Verify that the throttle valve is at the closed throttle position.
2. Measure the free play of the accelerator cable.


Free play: 1—3 mm { 0.04—0.11 in }

3. If not as specified, adjust by turning locknut (A).
4. Depress the accelerator pedal to the floor and check that the throttle valve is fully opened. Adjust with bolt (B), if necessary.

FUEL SYSTEM

COMPONENT PARTS

This system supplies the necessary fuel for combustion at a constant pressure to the fuel injectors. Fuel is metered and injected into intake manifold according to the injection control signals from the engine control module. It consists of the fuel tank, the fuel pump, the fuel filters, the delivery pipe, the pulsation damper, the pressure regulator, the fuel injectors, and the fuel pump relay.



- 1. Fuel tank
- 2. Fuel pump
- 3. Fuel hose protect
- 4. Fuel hose
- 5. Evaporative hose

- 6. Delivery pipe
- 7. Pressure regulator
- 8. Fuel injector
- 9. Fuel pump relay


PRECAUTION**Fuel Pressure Release and Servicing Fuel System****Warning**

- **Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.**


Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".**

**Fuel Line Safety Procedures**

1. Release the fuel pressure before disconnecting a fuel line.
 - (1) Start the engine.
 - (2) Disconnect the fuel pump relay connector.
 - (3) After the engine stalls, turn the ignition switch to OFF.
 - (4) Connect the fuel pump relay connector.
2. Avoid leakage.
 - (1) When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 - (2) Plug the hoses after removal.
3. Install hose clamps to secure the fuel pressure gauge connections.

**Priming Fuel System**

After the fuel pressure has been released for repairs or inspection, the system must be primed to avoid excessive cranking when the engine is first started. Follow the steps below.


1. Connect the data link connector terminals F/P and GND with a jumper wire.
2. Turn the ignition switch to ON for **approx. 10 sec.** and check for fuel leaks.
3. Turn the ignition switch to OFF and remove the jumper wire.

SYSTEM INSPECTION


Fuel System Pressure Drop

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.



1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and the delivery pipe.
3. Connect the negative battery cable.



4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure after **5 min.**

Fuel pressure:


More than 147 kPa { 1.5 kgf/cm² , 21 psi }

8. If not as specified, perform the following inspection.
 - Fuel pump fuel pressure drop (Refer to page F-15.)
 - Pressure regulator fuel pressure drop (Refer to page F-19.)
 - Fuel injector fuel leakage (Refer to page F-21.)


Fuel Line Pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.



1. Disconnect the negative battery cable.
2. Install the fuel pressure gauge between the fuel filter and the pulsation damper.
3. Connect the negative battery cable.



4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON.
6. Measure the fuel line pressure.

Fuel line pressure:

265—313 kPa { 2.7—3.2 kgf/cm² , 39—45 psi }

- Low pressure— Check fuel pump maximum pressure.
(Refer to page F-16.)
- High pressure— Replace the pressure regulator.
(Refer to page F-20.)


FUEL TANK

Removal / Inspection / Installation


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.
- Repairing a fuel tank that has not been properly steam cleaned can be dangerous. Explosion or fire may cause death or serious injury. Always properly steam clean a fuel tank before repairing it.

1. Drain the fuel from the fuel tank.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Drain plug
2. Pipe protect
3. Under guard
4. Tank strap
5. Fuel tank
6. Fuel hose
7. Fuel hose bracket
8. Fuel hose protect
9. Fuel filler cap
10. Dust cover
11. Fuel filler hose
12. Evaporative hose




Installation note

Fuel hose, evaporative hose, breather hose

- Push the ends of the fuel hoses, evaporative hose, and breather hose onto the respective fittings.

Specification: 25—30 mm { 0.99—1.18 in }

- Install the clip on the fuel hoses with its tongues facing upward.
- Install the clip on the evaporative hose and breather hose as shown.
- Be sure the hoses are not bent or twisted.




Joint hose

- Push the ends of the joint hose onto the fitting.

Specification: 35—40 mm { 1.38—1.57 in }

- Install the clamp on the joint hose. Position the clamp so that paint mark (A) is visible under it as shown.
- Install the joint hose onto the fuel filler pipe. Align paint marks (B) on the hose and on the pipe.
- Be sure the hose is not bent or twisted.



FUEL FILTER (HIGH PRESSURE SIDE)

Replacement

The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F-10.**

1. Disconnect the fuel hoses from the fuel filter.
2. Remove the fuel filter and bracket.
3. Install in the reverse order of removal.
4. Verify that the fuel hoses are pushed fully onto the fuel filter nipples.


FUEL PUMP

Inspection


Fuel pressure drop

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F-10.**



1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge to the outlet of the fuel filter and plug the outlet of the fuel pressure gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.








4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure after **5 min.**.

Fuel pressure:

More than 343 kPa { 3.5 kgf/cm² , 50 psi }

8. If not as specified, replace the fuel pump.



Fuel pump maximum pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge to the outlet of the fuel filter and plug the outlet of the fuel pressure gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON to operate the fuel pump.
6. Measure the fuel pump maximum pressure.

Fuel pump maximum pressure:

442—637 kPa { 4.5—6.5 kgf/cm² , 64—92 psi }

7. Turn the ignition switch OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.

Fuel pump continuity

1. Remove the No.2 rear seat.
2. Lift up the rear floormat.
3. Remove the fuel pump cover.
4. Disconnect the fuel pump connector, and check for continuity between fuel pump connector (pump side) terminals C and D.
5. If there is no continuity, replace the fuel pump. (Refer to below.)

Removal / Installation


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.


1. Remove the No.2 rear seat.
2. Lift up the rear floormat.
3. Remove the fuel pump cover.
4. Disconnect the fuel pump connector.
5. Disconnect the fuel hoses.
6. Remove the fuel pump and fuel tank gauge unit assembly.
7. Use a new rubber seal, and install in the reverse order of removal.

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|------------------------------------|--------------------------------|
| 1. Mounting rubber | 4. Mount |
| 2. Fuel filter (low pressure side) | 5. Fuel hose |
| 3. Fuel pump | Assembly Note below |
| Assembly Note below | 6. Seal rubber |
| | 7. Fuel tank gauge sender unit |




Assembly Note

1. Do not apply excessive side force when pushing the fuel hose onto the fuel pump nipple.
2. Install the clamps as shown.



3. Install the pump side fuel hose clamp and terminals in the range and direction shown in the figure.



FUEL PUMP RELAY



Inspection

1. Remove the fuel pump relay. (Refer to below.)
2. Check for continuity between terminals of the fuel pump relay by using an ohmmeter.

○—○: Continuity B+: Battery positive voltage


Step \ Terminal	A	B	C	E
1	○—○	○—○		
2	B+	Ground	○—○	○—○

3. If not as specified, replace the fuel pump relay.



Removal / Installation

1. Lift up the floor mat in front of the passenger's seat.
2. Remove the protector cover.
3. Remove the fuel pump relay.
4. Install in the reverse order of removal.


**PRESSURE REGULATOR****Inspection****Fuel line pressure****Warning**

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and pulsation damper.
3. Connect the negative battery cable.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.

Fuel line pressure:

206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }

**Fuel pressure drop****Warning**


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and the pulsation damper.
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure for **5 min.**

Fuel pressure:

More than 147 kPa { 1.5 kgf/cm² , 21 psi }

8. If not as specified, replace the pressure regulator.



PRC SOLENOID VALVE (No.1, No.2)

Inspection

1. Remove the PRC solenoid valve. (Refer to page F-5.)
2. Check for airflow between ports of the solenoid valve.

○—○: Continuity ○—○: Airflow B+: Battery positive voltage

Step	Terminal		Port		
	A	B	A	B	C
1	B+	Ground	○—○		
2	○—○	○—○		○—○	

3. If not as specified, replace the PRC solenoid valve.


FUEL INJECTOR

Removal / Installation

Warning


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Pressure regulator
2. Delivery pipe

3. Fuel injector




**Inspection
Resistance**

1. Remove the fuel injector. (Refer to page F-20.)
2. Check resistance of the fuel injector with an ohmmeter.

Resistance: 12—16 Ω

3. If not as specified, replace the fuel injector.




Fuel leakage test


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

1. Fasten the fuel injectors firmly to the delivery pipe. (Refer to page F-20.)




2. Connect the data link connector terminals F/P and GND with a jumper wire. Keep the delivery pipe level. Turn the ignition switch to ON.
3. Check for fuel leaks. If there is more than one drop per minute, replace the fuel injector.
4. Turn the ignition switch to OFF and remove the jumper wire.



Installation Note

1. Use new fuel injector O-rings.
2. Apply a small amount of engine oil to the O-rings before installing.



3. Check for leaks in the fuel lines.

EXHAUST SYSTEM


COMPONENT PARTS

Inspection

1. Start the engine and check for exhaust gas leakage from each exhaust system components.
2. If leakage is found, repair or replace as necessary.

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




- | | |
|---|--|
| 1. After-silencer | 6. Three way catalytic converter (pre) |
| 2. Main silencer | 7. Exhaust manifold insulator |
| 3. Heated oxygen sensor (rear) | 8. Insulator |
| Inspection page F-43 | 9. Center exhaust pipe |
| 4. Three way catalytic converter (Main) | 10. Exhaust manifold |
| 5. Heated oxygen sensor (front) | |
| Inspection page F-43 | |

EMISSION SYSTEM

COMPONENTS PARTS



(IN ENGINE COMPARTMENT)



(IN RIGHT REAR SIDE TRIM B)



TANK PRESSURE CONTROL VALVE (TPCV)


(FUEL TANK FRONT SIDE)

CHARCOAL CANISTER

CUT VALVE


FUEL TANK PRESSURE SENSOR





CATCH TANK Replacement

1. Slide the catch tank out of the bracket.
2. Disconnect the three hoses.
3. Remove the catch tank.
4. Install in the reverse order of removal.




PURGE SOLENOID VALVE Inspection (On-vehicle)

1. Warm up the engine to normal operating temperature.
2. Run the engine at idle.
3. Disconnect the vacuum hose from the charcoal canister and check that there is no vacuum.
4. If not as specified, disconnect the vacuum hose from the solenoid valve.
5. Blow through the solenoid valve from hose (A) and check that air does not flow from (B).
6. If not as specified, replace the solenoid valve.


CHARCOAL CANISTER Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Pipe protector
2. Charcoal canister bracket

3. Charcoal canister



Inspection

1. Remove the charcoal canister. (Refer to page F-25.)
2. Plug the charcoal canister vent side port and purge solenoid valve side port.
3. Blow air into the charcoal canister and verify that no air leaks.
4. If air leaks, replace the charcoal canister.




CUT VALVE

Inspection

1. Remove the cut valve. (Refer to page F-27.)
2. Blow air into the valve and check for the airflow.


Blow air into port (A) while holding valve horizontally	Air flow
Blow air into port (A) while holding valve tilted	No air flow



TANK PRESSURE CONTROL VALVE (TPCV)

Inspection

1. Remove the TPCV. (Refer to page F-27.)
2. Apply pressure or vacuum to port (A) of the valve by using a vacuum pump, and check for the airflow.



Specification


Condition	kPa { mmHg, inHg }	Airflow
Pressure	Below 1.96 { 1.47, 0.06 }	No
	Above 9.81 { 7.36, 0.29 }	Yes
Vacuum	Below 9.81 { 7.36, 0.29 }	Yes

3. Apply battery positive voltage to the valve connector and apply pressure to port (A), and verify that air flows smoothly.
4. If not as specified, replace the TPCV.

CHECK VALVE


Inspection

1. Remove the check valve (two-way). (Refer to page F-24.)
2. Blow air into port (B) and verify that air smoothly flows from port (C).
3. Blow air into port (C) and verify that air smoothly flows from port (A).
4. If not as specified, replace the check valve (two-way).




SEPARATOR**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Tank pressure control valve
2. Cut valve

3. Fuel tank pressure sensor
4. Separator



Inspection

1. Pull back the right rear side trim B. (Right side)
2. Remove the cover.
3. Visually check the separator for cracks or leaking.
4. Replace it if necessary.



CANISTER DRAIN CUT VALVE (CDCV)


Inspection

1. Remove the valve. (Refer to page F-24.)
2. Check for airflow between ports of the solenoid valve.

○—○: Continuity ○—○: Airflow B+: Battery positive voltage

Step	Terminal		Port	
	A	B	A	B
1	○—○	○—○	○—○	○—○
2	B+	Ground		


3. If not as specified, replace the canister drain cut valve.



PCV VALVE

Inspection












1. Warm up the engine to the normal operating temperature and run it at idle.
2. Disconnect the PCV valve with the ventilation hose from the cylinder head cover.
3. Block the valve opening and check that there is vacuum. Replace the valve, if necessary.




4. Remove the PCV valve.
5. Blow through the valve from port (A) and verify that air comes out of port (B).
6. Blow through the valve from port (B) and verify that no air comes out of port (A).
7. Replace the PCV valve if necessary.

CONTROL SYSTEM


PREPARATION
SST

<p>49 9200 162A</p> <p>Monitor, Engine Signal</p> 	<p>For inspection of ECM terminal voltage</p>	<p>49 T018 902</p> <p>Adapter harness</p> 	<p>For inspection of ECM terminal voltage</p>
<p>49 F018 903</p> <p>Sheet</p> 	<p>For inspection of ECM terminal voltage</p>	<p>49 D088 008</p> <p>Harness adapter, Power</p> 	<p>For inspection of ECM terminal voltage</p>
<p>49 T088 0A0</p> <p>NGS set</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>	<p>49 T088 008A</p> <p>Instruction manual</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>
<p>49 T088 010B</p> <p>Program Card</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>	<p>49 T088 001</p> <p>Control Unit (Part of 49 T088 0A0)</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>
<p>49 T088 002</p> <p>Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>	<p>49 T088 004</p> <p>NGS OBD II Adapter (Part of 49 T088 0A0)</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>
<p>49 T088 006</p> <p>Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For inspection of ECM terminal voltage and input/output devices</p>	<p>—</p>	<p>—</p>


STRUCTURAL VIEW



- | | |
|---|-----------|
| 1. Engine control module | |
| Removal / Installation | page F-31 |
| Inspection | page F-31 |
| 2. Mass air flow sensor | |
| System inspection | page F-37 |
| Inspection | page F-38 |
| 3. Camshaft position sensor | |
| System inspection | page F-38 |
| 4. Crankshaft position sensor | |
| Inspection | page F-39 |
| Replacement | page F-39 |
| 5. Throttle position sensor | |
| Inspection | page F-40 |
| Adjustment | page F-41 |
| Replacement | page F-42 |
| 6. Engine coolant temperature sensor | |
| Inspection | page F-42 |
| 7. Intake air temperature sensor
(Dynamic chamber) | |
| Inspection | page F-43 |
| 8. Heated oxygen sensor | |
| System inspection | page F-43 |
| Inspection | page F-44 |
| 9. Fuel tank pressure sensor | |
| Inspection | page F-44 |
| 10. Power steering pressure switch | |
| Inspection | page F-45 |
| 11. Main relay | |
| System inspection | page F-45 |
| Inspection | page F-45 |



**ENGINE CONTROL MODULE (ECM)****Removal / Installation**

1. Remove the scuff plate (right side) and front side trim (right side).
2. Lift up the front mat.
3. Remove the protector cover.
4. Disconnect the engine control module connector.
5. Remove the engine control module.
6. Install in the reverse order of removal.

**Inspection****Caution**

- The ECM terminal voltages vary with change in measuring conditions and vehicle conditions. Always carry out a total inspection of the input systems, output systems, and ECM to determine the cause of trouble. Otherwise, a wrong diagnosis will be made.

1. Disconnect the negative battery cable.
2. Remove the ECM.
3. Connect the **SST** (Adapter harness) to the ECM.
4. Connect the **SSTs** (Monitor, Engine Signal and Harness adapter, power) to the **SST** (Adapter harness). Use connector A of the adapter harness for ECM terminals 1A through 1V and 3A through 3P. Use connector B for ECM terminals 2A through 2L and 4A through 4Z.
5. Place the **SST** (Sheet) on the **SST** (Monitor, Engine Signal).
6. Measure the voltage at each ECM terminal by switching the selector switch and the monitor switch.
7. If any incorrect voltage is detected, check related systems, wiring harnesses and connectors referring to the possible malfunction in the terminal voltage list.

**Caution**

- Disconnecting the connectors of the ECM and the **SST** (Adapter harness) while the battery is connected can damage the ECM and the **SST** (Monitor, Engine Signal). Disconnect the negative battery cable and the **SST** (Harness adapter, power) before disconnecting the connectors.
- Applying voltage to terminals A and B of the **SST** (Monitor, Engine Signal) can damage the **SST** (Monitor, Engine Signal).

Note

- The indicator lights of the **SST** (Monitor, Engine Signal), provided for confirmation of the voltmeter range, is also used for detection of the pulse such as the fuel injector control signal, which is difficult to detect by using the voltmeter.
- Terminals A and B of the **SST** (Monitor, Engine Signal) are for connection of an external instrument. By connecting an external instrument such as a circuit tester or an oscilloscope, various inspections in addition to the measurement of the ECM terminal voltages are made possible.

Terminal voltage (Reference)

B+: Battery positive voltage

4Y	4W	4U	4S	4Q	4O	4M	4K	4I	4G	4E	4C	4A	3O	3M	3K	3I	3G	3E	3C	3A	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
4Z	4X	4V	4T	4R	4P	4N	4L	4J	4H	4F	4D	4B	3P	3N	3L	3J	3H	3F	3D	3B	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

Terminal	Signal	Connection to	Test condition		Voltage (V)	Possible malfunction
1A	—	—	—		—	—
1B	—	—	—		—	—
1C	Start	Ignition switch (START)	While cranking		Approx. 10	• ECM terminal 1C — Ignition switch harness
			Ignition switch ON		0	
1D	Serial communication signal	Data link connector 2 terminal KLN	Carry out inspection according to diagnostic trouble code Diagnostic trouble code output is a part of serial communication Judgement by terminal voltage is not possible		—	• On-board diagnostic system
1E	MIL	Malfunction indicator lamp	Malfunction indicator lamp OFF		B+	• ECM terminal 1E — MIL
			Malfunction indicator lamp ON		Below 1.0	
1F	—	—	—		—	—
1G	A/C control	A/C relay	Idle	A/C operating	Below 1.0	• A/C relay
				A/C stop	B+	
1H	—	—	—		—	—
1I	Diagnostic test mode	Data link connector (Terminal TEN)	Ignition switch ON	Open terminal TEN	B+	• ECM terminal 1I — Data link connector terminal TEN harness
				Short terminal TEN	Below 1.0	
1J	—	—	—		—	—
1K	Barometric pressure	TCM	Ignition switch ON		repeat B+ and 0	• ECM terminal 1K — TCM terminal 2G harness
1L	Load/No load distinction	Transmission range switch	Ignition switch ON	Other than park/neutral position	B+	• Transmission range switch (Refer to section K1)
				Park/neutral position	Below 1.0	
1M	Vehicle speed	Vehicle speed sensor	Ignition switch ON		0 or 5.0	• Vehicle speed sensor (Refer to section T)
			Driving		Approx. 2.5	
1N	4WD distinction	Ground (4WD)	Constant		Below 1.0	• ECM terminal 1N harness (Open)
		— (2WD)	Constant		B+	

B+: Battery positive voltage

Terminal	Signal	Connection to	Test condition		Voltage (V)	Possible malfunction
1O	A/C	A/C amplifier	Idle	A/C switch ON and fan switch ON	Below 1.0	<ul style="list-style-type: none"> A/C amplifier (Refer to section U)
				A/C switch OFF	B+	
1P	Electrical load	CPU	Ignition switch ON	Electrical load OFF	B+	<ul style="list-style-type: none"> Headlight switch DRL relay Rear window defroster relay Fan switch (Refer to section U)
				Electrical load ON*	Below 1.0	
1Q	Brake	Brake switch	Brake pedal released		Below 1.0	<ul style="list-style-type: none"> Brake switch (Refer to section T)
			Brake pedal depressed		B+	
1R	—	—	—	—	—	—
1S	—	—	—	—	—	—
1T	Heated oxygen sensor (front) heater control	Heated oxygen sensor (front)	Ignition switch ON		B+	<ul style="list-style-type: none"> Heated oxygen sensor (Refer to page F-43)
			Idle		Below 1.0	
1U	—	—	—	—	—	—
1V	—	—	—	—	—	—
2A	—	—	—	—	—	—
2B	—	—	—	—	—	—
2C	Evaporative check	Tank pressure control valve/canister drain cut valve	Ignition switch ON		B+	<ul style="list-style-type: none"> Tank pressure control valve (Refer to page F-26) Canister drain cut valve (Refer to page F-28)
			Diagnosis executed		Below 1.0	
2D	—	—	—	—	—	—
2E	—	—	—	—	—	—
2F	—	—	—	—	—	—
2G	TCM diagnostic test mode	TCM	Ignition switch ON	Open terminal TEN	B+	<ul style="list-style-type: none"> ECM terminal 2G — TCM terminal 2K harness
				Short terminal TEN	Below 1.0 or repeat B+ and 0	
2H	On-board diagnostic system signal input (From TCM)	TCM	Ignition switch ON (Terminal TEN ground)	No diagnostic trouble code output	repeat B+ and 0	<ul style="list-style-type: none"> ECM terminal 2H — TCM terminal 2N harness
				Diagnostic trouble code output	B+	
2I	—	—	—	—	—	—
2J	—	—	—	—	—	—
2K	Heated oxygen sensor (rear)	Heated oxygen sensor (rear)	Ignition switch ON		Below 1.0	<ul style="list-style-type: none"> Heated oxygen sensor (Refer to page F-43)
			Idle	Engine cold	Below 0.5	
				After warms up	0—1.0	
2L	Fuel level	Fuel gauge sender unit	Ignition switch ON	Full fuel	Approx. 0	<ul style="list-style-type: none"> Fuel gauge sender unit (Refer to section T)
				Low fuel	Approx. 3.0	
3A	Fuel tank pressure	Fuel tank pressure sensor	Ignition switch ON	Fuel tank pressure 0 kPa { 0 mmHg , 0 inHg }	Approx. 2.5	<ul style="list-style-type: none"> Fuel tank pressure sensor (Refer to page F-44)

*: When all following conditions are satisfied

- Fan switch ON at 2nd or higher, rear window defroster switch ON, headlights ON

B+: Battery positive voltage


Terminal	Signal	Connection to	Test condition		Voltage (V)	Possible malfunction
3B	Mass air flow sensor (VGP)	Mass air flow sensor	Idle		1.0—2.0	• Mass air flow sensor (Refer to page F-37)
3C	Heated oxygen sensor (front)	Heated oxygen sensor (front)	Ignition switch ON		Below 1.0	• Heated oxygen sensor (Refer to page F-43)
			Idle	Engine cold	Below 0.5	
				After warms up	0—1.0	
			Acceleration (After warms up)		0.5—1.0	
Deceleration (After warms up)		0—0.5				
3D	—	—	—		—	—
3E	Engine coolant temperature	Engine coolant temperature sensor	Ignition switch ON	Engine coolant temp 20 °C { 68 °F }	Approx. 2.4	• Engine coolant temperature sensor (Refer to page F-42)
				After warms up	Approx. 0.4	
3F	Throttle position sensor (TVO)	Throttle position sensor	Ignition switch ON	Closed throttle position	0.1—1.1	• Throttle position sensor (Refer to page F-40) • ECM terminal 3I voltage
				Wide open throttle	2.8—4.5	
3G	DRL (CANADA)	DRL relay	Daytime running light ON		Below 2.0	• DRL relay (Refer to section T)
			Daytime running light OFF		B+	
3H	—	—	—		—	—
3I	Constant voltage (Vref)	Throttle position sensor Fuel tank pressure sensor	Ignition switch ON		Approx. 5.0	• ECM terminal 4B voltage
3J	—	—	—		—	—
3K	Intake-air temperature	Intake air temperature sensor (In mass air flow sensor)	Ignition switch ON	Intake-air temperature 20 °C { 68 °F }	Approx. 2.4	• Intake air temperature sensor (Refer to page F-38)
3L	Closed throttle position	Closed throttle position switch (In throttle position sensor)	Ignition switch ON	Accelerator pedal released	Below 1.0	• Throttle position sensor (Refer to page F-40) • ECM terminal 3I voltage
				Accelerator pedal depressed	B+	
3M	Intake air temperature	Intake air temperature sensor (dynamic chamber)	Ignition switch ON	Intake air temperature 20 °C { 68 °F }	Approx. 3.0	• Intake air temperature sensor (dynamic chamber) (Refer to page F-43)
3N	—	—	—		—	—
3O	Analogue sensor ground	Ground	Constant		Below 1.0	• ECM terminal 3O harness (Open)
3P	Power steering pressure	Power steering pressure switch	Ignition switch ON		B+	• Power steering pressure switch (Refer to page F-45)
			Idle	P/S not operating		
P/S operating		Below 1.0				

B+: Battery positive voltage

Terminal	Signal	Connection to	Test condition	Voltage (V)	Possible malfunction	
4A	ECM ground	Ground	Constant	Below 1.0	• ECM terminal 4A harness (Open)	
4B	Power supply	Main relay	Ignition switch OFF	Below 1.0	• Main relay (Refer to page F-45)	
			Ignition switch ON	B+		
4C	Fuel injector ground	Ground	Constant	Below 1.0	• ECM terminal 4C harness (Open)	
4D	Output device ground	Ground	Constant	Below 1.0	• ECM terminal 4D harness (Open)	
4E	NE \ominus	Crankshaft position sensor	Constant	0	• Crankshaft position sensor (Refer to page F-39)	
4F	—	—	—	—	—	
4G	SGC	Camshaft position sensor (In distributor)	Ignition switch ON	0 or Approx. 5.0	Camshaft position sensor (Refer to page F-38)	
			Idle	Approx. 2.5		
4H	NE \oplus	Crankshaft position sensor	Ignition switch ON	0	• Crankshaft position sensor (Refer to page F-39)	
			Idle	Approx. 0		
4I	Back-up power supply	Battery	Constant	B+	• ECM terminal 4I — Battery harness and connector	
4J	Pressure regulator control	PRC solenoid valve No.1	Idle (Hot condition)	Below 1.0	• PRC solenoid valve No.1 (Refer to page F-20)	
			Other	B+		
4K	VRIS control	VRIS solenoid valve	Ignition switch ON	B+	• VRIS solenoid valve (Refer to page F-7)	
			Engine speed	3625—5125 rpm		B+
				Others		Below 1.0
4L	Pressure regulator control	PRC solenoid valve No.2	Idle (Hot condition)	Below 1.0	• PRC solenoid valve No.2 (Refer to page F-20)	
			Other	B+		
4M	—	—	—	—	—	
4N	IGT control	Ignition control module (Distributor)	Ignition switch ON	Approx. 0	• Ignition control module (Refer to section G)	
			Idle	Approx. 0.5		
4O	—	—	—	—	—	
4P	—	—	—	—	—	
4Q	Idle air control	Idle air control valve	Ignition switch ON	B+	• Idle air control valve (Refer to page F-7)	
			Idle (After warms up)	Approx. 10		
4R	Engine speed	Tachometer TCM	Ignition switch ON	Approx. 10	• ECM terminal 4R — TCM terminal 1G harness	
			Idle	Approx. 8		
4S	Fuel pump control	Fuel pump relay	Ignition switch ON	B+	• Fuel pump relay (Refer to page F-18)	
			Cranking	Below 1.0		
			Idle			
4T	Purge control	Purge solenoid valve	Ignition switch ON	B+	• Purge solenoid valve (Refer to page F-25)	
			Idle			

B+: Battery positive voltage

Terminal	Signal	Connection to	Test condition	Voltage (V)	Possible malfunction
4U	Fuel injector control No.1	Fuel injector (No.1 cylinder)	Ignition switch ON/Idle	B+	<ul style="list-style-type: none"> Fuel injector (Refer to page F-21)
4V	Fuel injector control No.2	Fuel injector (No.2 cylinder)			
4W	Fuel injector control No.3	Fuel injector (No.3 cylinder)			
4X	Fuel injector control No.4	Fuel injector (No.4 cylinder)			
4Y	Fuel injector control No.5	Fuel injector (No.5 cylinder)			
4Z	Fuel injector control No.6	Fuel injector (No.6 cylinder)			






Using SST (NGS)

1. In the passenger compartment, connect the **SST (NGS)**, to the data link connector 2 located under the driver side dashboard.
2. Referring to the NGS operational manual, select the "PID/DATA MONITOR AND RECORD" function.
3. Referring to the 1996 Service Highlights, inspect each ECM input/output signal.

Note

- The "PID/DATA MONITOR AND RECORD" function is to monitor the calculation value of input/output signals in the ECM. Deviation in the value does not always indicate malfunction in the related input/output devices (sensors and solenoids).
4. If normal output signal cannot be detected when all input signals are normal, replace the ECM. (Refer to page F-31.)





MASS AIR FLOW SENSOR

System Inspection

1. Check the mass air flow sensor for damage and cracks.
2. Remove the ECM. (Refer to page F-31.)
3. Connect the **SSTs** (Monitor, Engine Signal and Adapter Harness) to the ECM.
4. Measure the voltage at the ECM terminals as shown in the table.

Specification

Terminal	Ignition switch ON	Idle
3B	Approx 1.0 V	1.0—2.0 V
4A	Below 1.0 V	Below 1.0 V

5. If not as specified, inspect following.



Harness continuity

- Between ECM terminal 3B and mass air flow sensor terminal B
- Between ECM terminal 4A and mass air flow sensor terminal E
- Between main relay terminal D and mass air flow sensor terminal A

Terminal voltage

- Mass air flow sensor terminal A: Battery positive voltage

6. If there is incorrect terminal voltage or harness continuity, replace the mass air flow sensor. (Refer to page F-5.)



Using SSTs (NGS)

1. Check the mass air flow sensor for damage and cracks.
2. Warm up the engine to normal operating temperature.
3. Shift the selector lever to P.
4. Turn off all electric loads.
 - Headlight
 - Blower motor
 - Rear window defroster
 - Power steering
5. Wait until the cooling fan stops.
6. Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
7. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display.
8. Select "MAF V" on the NGS display. NGS measures and shows the voltage.

Specification

	Ignition switch ON	Idle
Voltage (V)	Approx. 1.0	1.0—2.0

9. If not as specified, perform following inspection.
 - Harness continuity
 - Between ECM terminal 3B and mass air flow sensor terminal B
 - Between ECM terminal 4A and mass air flow sensor terminal E
 - Between main relay terminal D and mass air flow sensor terminal A
 - Terminal voltage
 - Mass air flow sensor terminal A voltage: Battery positive voltage
10. If there is incorrect terminal voltage or harness continuity, replace the mass air flow sensor. (Refer to page F-5.)


Note

- The scan tool shows the mass air flow rate and load value.

Specification

Engine speed (rpm)	Intake mass air flow (g/s)	Load (%)
Idle at 730—830	3.9—5.7	17.2—22.0
2,500*	11.3—14.8	15.4—19.4

* No load, in neutral or park



Inspection

Intake air temperature sensor

1. Disconnect the mass air flow sensor connector.
2. Measure the resistance between terminals C and D by using an ohmmeter.

Specification: 2.21—2.69 kΩ [20 °C { 68 °F }]

3. If not as specified, replace the mass air flow sensor. (Refer to page F-5.)



CAMSHAFT POSITION SENSOR

System Inspection

1. Remove the distributor. (Refer to section G.)
2. Remove the ECM. (Refer to page F-31.)
3. Connect the **SSTs** (Monitor, Engine signal and Adapter Harness) to the ECM.
4. Turn the ignition switch to ON.
5. Rotate the distributor drive by hand and check the output signal.

Specification

Signal	Terminal	Voltage
SGC	4G	Approx. 5 V (1 pulse/rev)



6. If not as specified, inspect following.


Harness continuity

- Between ECM terminal 4G and distributor (6-pin) terminal D
- Between ECM terminal 4A and distributor (6-pin) terminal A
- Between main relay terminal D and distributor (6-pin) terminal B

Terminal voltage

- Distributor (6-pin) terminal B: Battery positive voltage

7. If there is incorrect terminal voltage or harness continuity, replace the distributor. (Refer to section G.)



CRANKSHAFT POSITION SENSOR

Inspection

Resistance

1. Disconnect the crankshaft position sensor connector.
2. Measure the resistance between terminals A and B by using an ohmmeter.

Specification: 950—1250 Ω [20 °C { 68 °F }]


3. If not as specified, replace the crankshaft position sensor.

Air gap

1. Measure the air gap between crankshaft pulley and crankshaft position sensor by using a feeler gauge.


Specification: 0.5—1.5 mm { 0.020—0.059 in }

2. If not as specified, replace the crankshaft pulley or the crankshaft position sensor. (Refer to below.)



Replacement

1. Disconnect the negative battery cable.
2. Disconnect the crankshaft position sensor connector.
3. Remove the crankshaft position sensor.
4. Install in the reverse order of removal.




THROTTLE POSITION SENSOR

Inspection


Closed throttle position switch

1. Verify that the throttle valve is at the closed throttle position.
2. Disconnect the throttle position sensor connector.
3. Check for continuity between throttle position sensor connector terminals C and D by using an ohmmeter.
4. If no continuity, adjust the throttle position sensor.
5. Insert a 0.50 mm {0.020 in} feeler gauge between the throttle adjusting screw (TAS) and the throttle lever. Verify that there is no continuity.
6. If there is continuity, adjust the throttle position sensor. (Refer to page F-41.)



Throttle position sensor

1. Remove the ECM. (Refer to page F-31.)
2. Connect the SSTs (Monitor, Engine Signal and Adapter Harness) to the ECM.
3. Verify that the throttle valve is closed throttle position.
4. Turn the ignition switch to ON.
5. Measure the ECM terminal 3F voltage by using a voltmeter.




Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

6. If not as specified, adjust the throttle position sensor. (Refer to page F-41.)



Using SSTs (NGS)

1. Connect the SSTs (NGS) to the data link connector 2 located under the driver side dashboard.
2. Verify that the throttle valve is at the closed throttle position.
3. Turn the ignition switch to ON.
4. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display.
5. Select "TP V" on the NGS display. NGS measures and shows the voltage.


Specification



Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

6. If not as specified, adjust the throttle position sensor. (Refer to page F-41.)





Adjustment

Caution

- The throttle position sensor is adjusted at the factory before shipment. Unnecessarily adjustment will negatively effect the engine performance.
- Adjusting the throttle position sensor by using the throttle adjusting screw (TAS) will negatively effect the engine performance.

1. Verify that the throttle valve is at the closed throttle position.
2. Disconnect the throttle position sensor connector.
3. Loosen the attaching screws.
4. Insert a feeler gauge between the throttle adjusting screw (TAS) and the throttle lever. Adjust the continuity between the closed throttle position switch terminals C and D by using an ohmmeter.



Specification

Clearance	Continuity
0.15 mm { 0.006 in }	Yes
0.50 mm { 0.020 in }	No

5. Tighten the attaching screws.

Tightening torque:

1.6—2.3 N·m { 16—24 kgf·cm , 14—20 in·lbf }



6. If using the **SSTS** (Monitor, Engine Signal and Adapter Harness), do as follows.
 - (1) Remove the ECM. (Refer to page F-31.)
 - (2) Connect the **SSTS** (Monitor, Engine Signal and Adapter Harness) to the ECM.
 - (3) Verify that the throttle valve is at the closed throttle position.
 - (4) Turn the ignition switch to ON.
 - (5) Rotate the throttle link by hand and verify that the ECM terminal 3F voltage is as specified.





Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

- (6) If not as specified, replace the throttle position sensor.



7. If using the **SSTs** (NGS), do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
 - (2) Verify that the throttle valve is at the closed throttle position.
 - (3) Turn the ignition switch to ON.
 - (4) Select the "PID/DATA MONITOR AND RECORD" function of the NGS display.
 - (5) Select "TP V" on the NGS display. NGS measures and shows the voltage.

Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

- (6) If not specified, replace the throttle position sensor.

Replacement

1. Disconnect the throttle position sensor connector.
2. Remove the attaching screws.
3. Remove the throttle position sensor.
4. Verify that the throttle valve is at the closed throttle position.
5. Open the throttle valve slightly and catch the tang of the throttle body on the throttle position sensor plastic tabs. Align tang A on throttle body with tab A on throttle position sensor. Note tangs on the throttle body mate with the tab on the throttle position sensor on the side of the tab without a slot.
6. Position the throttle position sensor on the throttle body so that the mounting holes align.
7. Install and hand tighten the attaching screws.
8. Release the throttle.
9. Adjust the throttle position sensor output voltage and closed throttle position switch. (Refer to page F-41.)

ENGINE COOLANT TEMPERATURE SENSOR

Inspection

1. Remove the engine coolant temperature sensor.
2. Place the sensor in water with a thermometer, and heat the water gradually.
3. Measure the resistance of the sensor by using an ohmmeter.


Spcification

Temperature (°C { °F })	Resistance (kΩ)
20 { 68 }	2.2—2.7
80 { 176 }	0.29—0.35

4. If not as specified, replace the engine coolant temperature sensor.

Tighting torque:

16—23 N·m { 1.6—2.4 kgf·m , 12—17 ft·lbf }



INTAKE AIR TEMPERATURE SENSOR (DYNAMIC CHAMBER)

Inspection

1. Remove the intake air temperature sensor (dynamic chamber).
2. Place the sensor in water with a thermometer, and heat the water gradually.
3. Measure the resistance of the sensor by using an ohmmeter.


Specification

Temperature (°C { °F })	Resistance (kΩ)
25 { 77 }	30—36
85 { 185 }	3.3—3.7

4. If not as specified, replace the intake air temperature sensor.

Tightening torque:

7.9—11.7 N·m { 80—120 kgf·cm , 70—104 in·lbf }



HEATED OXYGEN SENSOR

System Inspection

1. Remove the ECM. (Refer to page F-31.)
2. Connect the **SSTs** (Monitor, Engine Signal and Adapter Harness) to the ECM.
3. Warm up the engine to normal operating temperature.
4. Measure the voltage at ECM terminal 2K, and 3C.





Specification

Engine condition	ECM terminal voltage (V)	
	3C Heated oxygen sensor (front)	2K Heated oxygen sensor (rear)
IG-ON	Below 1.0	
Idle	0—1.0	
Deceleration	0—0.5	0—1.0
Acceleration	0.5—1.0	0—1.0

5. If not as specified, inspect following.

- Intake-air system
- Fuel system
- On-board diagnostic system

If these systems are OK, replace the heated oxygen sensor. (Refer to page F-22.)



Using the SSTs (NGS)

1. Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
2. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display.
3. Select "FHO2S", and "RHO2S", on the NGS display. NGS measures and shows the voltage.

Specification

Engine condition	Voltage (V)	
	FHO2S	RHO2S
IG-ON	Below 1.0	
Idle	0—1.0	
Deceleration	0—0.5	0—1.0
Acceleration	0.5—1.0	0—1.0

4. If not as specified, inspect following.

- Intake-air system
- Fuel system
- On-Board diagnostic system

If these systems are OK, replace the heated oxygen sensor. (Refer to page F-22.)

Inspection

Heater

1. Disconnect the heated oxygen sensor connector,
2. Measure the resistance between heated oxygen sensor terminals C and D by using an ohmmeter.

Specification: Approx. 13 Ω (20 °C { 68 °F })

3. If not as specified, replace the heated oxygen sensor. (Refer to page F-22.)

FUEL TANK PRESSURE SENSOR





Inspection

1. Connect the **SSTs** (Monitor, Engine Signal and Adapter Harness) to the ECM. (Refer to page F-31.)
2. Apply vacuum to the fuel tank pressure sensor by using a vacuum pump. Measure the pressure at ECM terminal 3A.

Specification

Vacuum	ECM terminal 3A voltage (V)
0 kPa { 0 mmHg , 0 inHg }	Approx. 2.5
6.7 kPa { 50 mmHg , 2.0 inHg }	Approx. 0.5

3. If not as specified, replace the fuel tank pressure sensor. (Refer to page F-27.)



Using the SSTs (NGS)

1. Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
2. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display.
3. Apply vacuum to the fuel tank pressure sensor by using a vacuum pump.
4. Select "FTP V" on the NGS display. The NGS measures and shows the voltage.

Specification

Vacuum	Fuel tank pressure signal voltage (V)
0 kPa { 0 mmHg , 0 inHg }	Approx. 2.5
6.7 kPa { 50 mmHg , 2.0 inHg }	Approx. 0.5

5. If not as specified, replace the fuel tank pressure sensor. (Refer to page F-27.)

POWER STEERING PRESSURE SWITCH

Inspection

1. Disconnect the power steering pressure switch connector.
2. Start the engine.
3. Check continuity of the switch by using an ohmmeter.

Specification

Steering wheel condition	Continuity
Turned	Yes
Straight ahead	No

4. If not as specified, replace the power steering pressure switch. (Refer to section N.)

MAIN RELAY

System Inspection

1. Listen for main relay operation sound while turning the ignition switch to ON and OFF.
2. If no sound was heard, inspect following.
 - Main relay
 - Harness and connector between ignition switch and main relay

Inspection

1. Remove the main relay.
2. Apply battery positive voltage and check continuity between terminals of the relay by using ohmmeter.

Specification








B+: Battery positive voltage


Terminal A—B	Terminal C—D
B+ applied	Yes
B+ not applied	No

3. If not as specified, replace the main relay.

ON-BOARD DIAGNOSTIC SYSTEM

PREPARATION SST


<p>49 T088 0A0 NGS set</p> 	<p>For diagnosis of ECM</p>	<p>49 T088 010B Program Card</p> 	<p>For diagnosis ECM</p>
<p>49 T088 008A Instruction Manual</p> 	<p>For diagnosis of ECM</p>	<p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p> 	<p>For diagnosis ECM</p>
<p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For diagnosis of ECM</p>	<p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis of ECM</p>
<p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis of ECM</p>	<p>—</p>	<p>—</p>



DIAGNOSTIC TROUBLE CODE NUMBER

Inspection

1. Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
2. Refer to the manufacturer-provided instruction manual for the NGS operation.
3. Select "DIAGNOSTIC TEST MODES" function and press trigger.
4. When "NO CODES RECEIVED/SYSTEM PASSED" is displayed, all systems monitored are judged OK.
5. When any of the diagnostic trouble codes is displayed, carry out troubleshooting according to the code.
6. When "LINK MONITOR ERROR" is displayed, check connection of the NGS.
7. After all problems have been repaired, carry out After-repair Procedure. (Refer to page F-47.)

**After-repair Procedure**




1. After repairs, connect the NGS to the data link connector 2 located under the driver side dashboard.
2. Select "CLEAR" function and erase diagnostic trouble codes from the NGS memory.
3. Perform diagnostic trouble code inspection again and verify that no diagnostic trouble codes are displayed.


Diagnostic Trouble Code Numbers

Code No.	Display on the NGS	Condition	Page
P0100	MAF/VAF-CIRCUIT MALFUNCTION	Mass or Volume air flow circuit malfunction	F-49
P0110	IAT-CIRCUIT MALFUNCTION	Intake air temperature circuit malfunction	F-50
P0115	ECT-CIRCUIT MALFUNCTION	Engine coolant temperature circuit malfunction	F-51
P0120	TP-CIRCUIT MALFUNCTION	Throttle position circuit malfunction	F-52
P0125	EXCESSIVE TIME TO ENTER CLOSED LOOP	Excessive time to enter closed loop fuel control	F-52
P0130	O2S 11-CIRCUIT MALFUNCTION	O ₂ sensor circuit malfunction	F-53
P0134	O2S 11-CIRCUIT NO ACTIVITY DETECTED	O ₂ sensor circuit no activity detected	F-53
P0135	O2S 11-HEATER CIRCUIT MALFUNCTION	O ₂ sensor heater circuit malfunction	F-54
P0140	O2S 12-CIRCUIT NO ACTIVITY DETECTED	O ₂ sensor circuit no activity detected	F-55
P0170	BANK 1-FUEL TRIM MALFUNCTION	Fuel trim malfunction	F-56
P0300	RANDOM MISFIRE DETECTED	Random misfire detected	F-57
P0301	CYLINDER 1 MISFIRE DETECTED	Cylinder 1 misfire detected	F-58
P0302	CYLINDER 2 MISFIRE DETECTED	Cylinder 2 misfire detected	F-59
P0303	CYLINDER 3 MISFIRE DETECTED	Cylinder 3 misfire detected	F-60
P0304	CYLINDER 4 MISFIRE DETECTED	Cylinder 4 misfire detected	F-61
P0305	CYLINDER 5 MISFIRE DETECTED	Cylinder 5 misfire detected	F-62





Code No.	Display on the NGS	Condition	Page
P0306	CYLINDER 6 MISFIRE DETECTED	Cylinder 6 misfire detected	F-63
P0335	CRANKSHAFT POS SENSOR-CKT MALFUNCTION	Crankshaft position sensor circuit malfunction	F-64
P0420	BANK1 CAT EFFICIENCY BELOW LIMIT	Catalyst system efficiency below threshold	F-64
P0440	EVAP SYSTEM-MALFUNCTION	Evaporative emission control system malfunction	F-65
P0443	EVAP SYSTEM-PURGE CTRL VALVE CKT MALF	Evaporative emission control system purge control valve circuit malfunction	F-66
P0450	EVAP PRESSURE SENSOR-MALFUNCTION	Evaporative emission control system pressure sensor malfunction	F-67
P0500	VEHICLE SPEED SENSOR-MALFUNCTION	Vehicle speed sensor malfunction	F-68
P0505	IDLE CONTROL SYSTEM-MALFUNCTION	Idle control system malfunction	F-68
P0510	CLOSED THROTTLE POS SWITCH-MALFUNCTION	Closed throttle position switch malfunction	F-69
P0703	TORQUE CONV/BRAKE SW-MALFUNCTION	Brake switch input malfunction	F-69
P1000	MORE DRIVING NEEDED TO COMPLETE TEST	Check of all OBD-II systems is not complete since last memory clear	F-70
P1110	IATS (D/C)-OPEN OR SHORT	Intake air temperature sensor (dynamic chamber) open or short	F-71
P1170	HO2S 11-INVERSION	O ₂ sensor stuck	F-72
P1195	EGRBS-OPEN OR SHORT	Barometric pressure sensor open or short	F-72
P1196	STA SW-OPEN OR SHORT	Ignition switch (Start) open or short	F-73
P1250	PRC-OPEN OR SHORT	PRC solenoid valve No.1 open or short	F-73
P1252	PRC2-OPEN OR SHORT	PRC solenoid valve No.2 open or short	F-74
P1345	SGC SIGNAL-NO SGC SIGNAL	No SGC signal	F-74

Code No.	Display on the NGS	Condition	Page
P1449	CANISTER DRAIN CUT VALVE— OPEN OR SHORT	Canister drain cut valve open or short	F-75
P1455	FUEL TANK LEVEL SENSOR— OPEN OR SHORT	Fuel gauge sender unit open or short	F-76
P1521	VRIS1—OPEN OR SHORT	VRIS solenoid valve No.1 open or short	F-77
P1601	COMM LINE (AT)—COMM ERROR	Communication error	F-77
P1608	PCME (CPU)—MALFUNCTION	ECM malfunction	F-78
P1794	BAT—BAT OR CIRCUIT FAIL	Battery or circuit fail	F-78
P1797	PNS—OPEN OR SHORT	No P or N range signal	F-78

Diagnostic trouble code No. P0100		MAF/VAF—CIRCUIT MALFUNCTION	
Symptom		Input voltage from Mass air flow sensor is below 0.2 V or above 4.9 V when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Mass air flow sensor malfunction • Open or short circuit wiring from main relay terminal D to mass air flow sensor terminal A • Open or short circuit in wiring from ECM terminal 3B to mass air flow sensor terminal B • Open or short circuit in wiring from ECM terminal 4A to mass air flow sensor terminal E 	
STEP	INSPECTION	ACTION	
1	Does mass air flow sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3B voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect mass air flow sensor connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Mass air flow sensor terminal A)
4	Is there continuity between connector terminal E and ECM terminal 4A?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between connector terminal B and ECM terminal 3B?	Yes	Go to next step
		No	Repair or replace wiring harness
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			



Diagnostic trouble code No. P0110		IAT-CIRCUIT MALFUNCTION	
Symptom		Input from intake air temperature sensor is below 0.1 V or above 4.8 V when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Intake air temperature sensor malfunction • Open or short circuit in wiring from mass air flow sensor terminal C to ECM terminal 3K • Open or short circuit in wiring from mass air flow sensor terminal D to ECM terminal 3O 	
STEP	INSPECTION	ACTION	
1	Does mass air flow sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3K voltage OK? <small>☞ page F-31</small>	Yes	Go to step 6
		No	Go to next step
3	Disconnect mass air flow sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal C?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (ECM terminal 3K — Mass air flow sensor terminal C)
4	Is there continuity between mass air flow sensor connector terminal D and ECM terminal 3O?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is intake air temperature sensor OK? <small>☞ page F-38</small>	Yes	Go to next step
		No	Replace mass air flow sensor <small>☞ page F-5</small>
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM <small>☞ page F-31</small>
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			

Diagnostic trouble code No. P0115	ECT-CIRCUIT MALFUNCTION
Symptom	Input voltage from engine coolant temperature sensor is below 0.1 V or above 4.8 V when ignition switch is turned on
Possible cause	<ul style="list-style-type: none"> • Engine coolant temperature sensor malfunction • Open or short circuit in wiring from engine coolant temperature sensor terminal A to ECM terminal 3E • Open or short circuit in wiring from engine coolant temperature sensor terminal B to ECM terminal 3O

STEP	INSPECTION		ACTION
1	Does engine coolant temperature sensor or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3E voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect engine coolant temperature sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (ECM terminal 3E — Engine coolant temperature sensor terminal A)
4	Is there continuity between connector terminal B and ECM terminal 3O?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is engine coolant temperature sensor OK?  page F-42	Yes	Go to next step
		No	Replace engine coolant temperature sensor  page F-30
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)




HARNESS SIDE CONNECTOR





Diagnostic trouble code No. P0120		TP-CIRCUIT MALFUNCTION	
Symptom		Input voltage from throttle position sensor is below 0.1 V or above 4.7 V when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Throttle position sensor malfunction • Open or short circuit in wiring from throttle position sensor terminal A to ECM terminal 3I • Open or short circuit in wiring from throttle position sensor terminal B to ECM terminal 3F • Open or short circuit in wiring from throttle position sensor terminal D to ECM terminal 3O 	
STEP	INSPECTION	ACTION	
1	Does throttle position sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3F voltage OK?  page F-31	Yes	Go to next step
		No	Go to step 4
3	Is voltage increase linear according to the throttle valve opening angle?	Yes	Go to step 7
		No	Replace throttle position sensor page F-42
4	Disconnect throttle position sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (ECM terminal 3I — Throttle position sensor terminal A)
5	Is there continuity between connector terminal B and ECM terminal 3F?	Yes	Go to next step
		No	Repair or replace wiring harness
6	Is there continuity between connector terminal D and ECM terminal 3O?	Yes	Replace throttle position sensor page F-42
		No	Repair or replace wiring harness
7	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			


Diagnostic trouble code No. P0125		EXCESSIVE TIME TO ENTER CLOSED LOOP	
Symptom		Engine coolant temperature sensor signal does not rise normally because of engine coolant system malfunction	
Possible cause		<ul style="list-style-type: none"> • Engine coolant temperature sensor malfunction • Thermostat malfunction • Engine cooling fan system malfunction • Water pump malfunction • Engine coolant passage clogged or leaking • Engine coolant level and protection incorrect 	
STEP	INSPECTION	ACTION	
1	Is engine coolant temperature sensor OK? page F-42	Yes	Go to next step
		No	Replace engine coolant temperature sensor
2	Is cooling system OK? section E	Yes	Go to next step
		No	Repair or replace
3	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM page F-31
		No	Temporary system malfunction

* During normal driving

Diagnostic trouble code No. P0130		O2S 11-CIRCUIT MALFUNCTION	
Symptom		<ul style="list-style-type: none"> • Heated oxygen sensor (Front) deterioration • Leakage in exhaust system 	
STEP	INSPECTION	ACTION	
1	Is heated oxygen sensor (Front) OK? ☞ page F-43	Yes	Replace ECM ☞ page F-31
		No	Repair or replace heated oxygen sensor (Front) ☞ page F-22

Diagnostic trouble code No. P0134		O2S 11-CIRCUIT NO ACTIVITY DETECTED	
Symptom		When heated oxygen sensor (Front) signal does not exceed 0.5 V after the engine is started, or stays below 0.5 V for 80 seconds after the engine has reached normal operating temperature and running at 1,500 rpm or over	
Possible cause		<ul style="list-style-type: none"> • Heated oxygen sensor (Front) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front) terminal A to ECM terminal 3C • Open circuit in wiring from heated oxygen sensor (Front) terminal B to ECM terminal 3O • Intake-air system, fuel system, ignition system malfunction 	
STEP	INSPECTION	ACTION	
1	Does heated oxygen sensor (Front) connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3C voltage OK? ☞ page F-31	Yes	Go to step 5
		No	Go to next step
3	Disconnect heated oxygen sensor (Front) connector. Is there continuity between connector terminal A and ECM terminal 3C?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Are following units OK? • Fuel injector ☞ page F-21 • Pressure regulator ☞ page F-19 • Mass air flow sensor ☞ page F-37 • Engine coolant temperature sensor ☞ page F-42 • Spark plug ☞ section G • Air suction ☞ page F-5 (Air/fuel ratio rich or lean)	Yes	Replace heated oxygen sensor (Front) ☞ page F-22
		No	Repair or replace
5	Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking?	Yes	Replace ECM ☞ page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			

Diagnostic trouble code No. P0135		O2S 11-HEATER CIRCUIT MALFUNCTION	
Symptom		Open or short circuit is observed in heated oxygen sensor heater (Front) system	
Possible cause		<ul style="list-style-type: none"> • Heated oxygen sensor heater (Front) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front) terminal C to main relay • Open or short circuit in wiring from heated oxygen sensor (Front) terminal D to ECM terminal 1T 	
STEP	INSPECTION		ACTION
1	Does heated oxygen sensor (Front) connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 1T voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect heated oxygen sensor (Front) connector and turn ignition switch to ON. Is there battery positive voltage at connector terminal C?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Heated oxygen sensor (Front) terminal C)
4	Is there continuity between connector terminal D and ECM terminal 1T?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between connector terminals C and D?	Yes	Go to next step
		No	Replace heated oxygen sensor (Front)  page F-22
6	Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
			
HARNESS SIDE CONNECTOR			

Diagnostic trouble code No. P0140		O2S 12-CIRCUIT NO ACTIVITY DETECTED	
Symptom		When heated oxygen sensor (Rear) signal does not exceed 0.5 V after the engine is started, or stays below 0.5 V for 80 seconds after the engine has reached normal operating temperature and running at 1,500 rpm or over	
Possible cause		<ul style="list-style-type: none"> • Heated oxygen sensor (Rear) malfunction • Open or short circuit in wiring from heated oxygen sensor (Rear) terminal A to ECM terminal 2K • Open circuit in wiring from heated oxygen sensor (Rear) terminal B to ECM terminal 3O • Intake-air system, fuel system, ignition system malfunction 	
STEP	INSPECTION	ACTION	
1	Does heated oxygen sensor (Rear) connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 2K voltage OK? 🔧 page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect heated oxygen sensor (Rear) connector. Is there continuity between connector terminal B and ECM terminal 3O?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Is there continuity between connector terminal A and ECM terminal 2K?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Are following units OK? • Fuel injector 🔧 page F-21 • Pressure regulator 🔧 page F-19 • Mass air flow sensor 🔧 page F-37 • Engine coolant temperature sensor 🔧 page F-42 • Spark plug 🔧 section G • Air suction 🔧 page F-5 (Air/fuel ratio rich)	Yes	Replace heated oxygen sensor (Rear) 🔧 page F-22
		No	Repair or replace
6	Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking?	Yes	Replace ECM 🔧 page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			

Diagnostic trouble code No. P0170	BANK 1–FUEL TRIM MALFUNCTION		
Symptom	Air/fuel ratio stays rich or lean longer than specified period because of system malfunction		
Possible cause	<ul style="list-style-type: none"> • Pressure regulator malfunction • Fuel injector malfunction • Fuel pump malfunction • Engine coolant temperature sensor malfunction • Mass air flow sensor malfunction • Heated oxygen sensor malfunction • Purge solenoid valve malfunction • Leakage in intake-air system • ECM malfunction • Open or short circuit in wiring between ECM terminals 4U, 4V, 4W, 4X, 4Y, 4Z to fuel injector • Intake air temperature sensor malfunction • PCV valve malfunction 		
STEP	INSPECTION		ACTION
1	Is there air leakage in intake-air system components? ☞ page F–5	Yes	Repair or replace intake air device system
		No	Go to next step
2	Is fuel line pressure OK? ☞ page F–12	Yes	Go to step 5
		No	Go to next step
3	Is fuel pump maximum pressure OK? ☞ page F–16	Yes	Go to next step
		No	Repair or replace fuel pump ☞ page F–17
4	Is pressure regulator OK? ☞ page F–19	Yes	Go to next step
		No	Repair or replace pressure regulator ☞ page F–20
5	Is fuel injector OK? ☞ page F–21	Yes	Go to next step
		No	Replace fuel injector ☞ page F–20
6	Is engine coolant temperature sensor OK? ☞ page F–42	Yes	Go to next step
		No	Replace engine coolant temperature sensor ☞ page F–30
7	Is mass air flow sensor OK? ☞ page F–37	Yes	Go to next step
		No	Replace mass air flow sensor ☞ page F–5
8	Is throttle position sensor OK? ☞ page F–40	Yes	Go to next step
		No	Adjust throttle position sensor ☞ page F–41
9	Is closed throttle position switch OK? ☞ page F–40	Yes	Go to next step
		No	Adjust throttle position sensor ☞ page F–41
10	Is intake air temperature sensor OK? ☞ page F–38	Yes	Go to next step
		No	Replace mass air flow sensor ☞ page F–5
11	Is purge solenoid valve OK? ☞ page F–25	Yes	Go to next step
		No	Replace purge solenoid valve
12	Is PCV valve OK? ☞ page F–28	Yes	Go to next step
		No	Replace PCV valve
13	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM ☞ page F–31
		No	Temporary system malfunction

* During idling

Diagnostic trouble code No. P0300	RANDOM MISFIRE DETECTED		
Symptom	ECM input signal from crankshaft position sensor signal is irregular		
Possible cause	<ul style="list-style-type: none"> • Ignition system malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression • Crankshaft position sensor air gap incorrect 		
STEP	INSPECTION		ACTION
1	Is ignition system OK? ☞ section G	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST] ☞ page F-3	Yes	Go to next step
		No	Adjust ignition timing ☞ page F-3
3	Is crankshaft position sensor air gap OK? ☞ page F-39	Yes	Go to next step
		No	Repair or replace crankshaft position sensor ☞ page F-39
4	Is fuel system OK? ☞ page F-11	Yes	Go to next step
		No	Repair or replace as necessary
5	Is compression at all cylinders normal? ☞ section B	Yes	Go to next step
		No	Repair or replace as necessary
6	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM ☞ page F-31
		No	Temporary system malfunction











* During normal driving

Diagnostic trouble code No. P0301		CYLINDER 1 MISFIRE DETECTED	
Symptom		ECM input signal from crankshaft position sensor signal for cylinder No.1 is irregular	
Possible cause		<ul style="list-style-type: none"> • Ignition system of cylinder No.1 malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression in cylinder No.1 • Crankshaft position sensor air gap incorrect 	
STEP	INSPECTION	ACTION	
1	Is ignition system of cylinder No.1 OK? section G	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST] page F-3	Yes	Go to next step
		No	Adjust ignition timing page F-3
3	Is crankshaft position sensor air gap OK? page F-39	Yes	Go to next step
		No	Repair or replace crankshaft position sensor page F-39
4	Is fuel injector at cylinder No.1 OK? page F-21	Yes	Go to next step
		No	Repair or replace fuel injector at cylinder No.1 page F-20
5	Is fuel system OK? page F-11	Yes	Go to next step
		No	Repair or replace as necessary
6	Is compression at cylinder No.1 normal? section B	Yes	Go to next step
		No	Repair or replace as necessary
7	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM page F-31
		No	Temporary system malfunction

* During normal driving

Diagnostic trouble code No. P0302		CYLINDER 2 MISFIRE DETECTED	
Symptom		ECM input signal from crankshaft position sensor signal for cylinder No.2 is irregular	
Possible cause		<ul style="list-style-type: none"> • Ignition system of cylinder No.2 malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression in cylinder No.2 • Crankshaft position sensor air gap incorrect 	
STEP	INSPECTION	ACTION	
1	Is ignition system of cylinder No.2 OK? <small>☞ section G</small>	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST] <small>☞ page F-3</small>	Yes	Go to next step
		No	Adjust ignition timing <small>☞ page F-3</small>
3	Is crankshaft position sensor air gap OK? <small>☞ page F-39</small>	Yes	Go to next step
		No	Repair or replace crankshaft position sensor <small>☞ page F-39</small>
4	Is fuel injector at cylinder No.2 OK? <small>☞ page F-21</small>	Yes	Go to next step
		No	Repair or replace fuel injector at cylinder No.2 <small>☞ page F-20</small>
5	Is fuel system OK? <small>☞ page F-11</small>	Yes	Go to next step
		No	Repair or replace as necessary
6	Is compression at cylinder No.2 normal? <small>☞ section B</small>	Yes	Go to next step
		No	Repair or replace as necessary
7	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM <small>☞ page F-31</small>
		No	Temporary system malfunction

* During normal driving

Diagnostic trouble code No. P0303		CYLINDER 3 MISFIRE DETECTED	
Symptom		ECM input signal from crankshaft position sensor signal for cylinder No.3 is irregular	
Possible cause		<ul style="list-style-type: none"> • Ignition system of cylinder No.3 malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression in cylinder No.3 • Crankshaft position sensor air gap incorrect 	
STEP	INSPECTION		ACTION
1	Is ignition system of cylinder No.3 OK?  section G	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST]  page F-3	Yes	Go to next step
		No	Adjust ignition timing  page F-3
3	Is crankshaft position sensor air gap OK?  page F-39	Yes	Go to next step
		No	Repair or replace crankshaft position sensor  page F-39
4	Is fuel injector at cylinder No.3 OK?  page F-21	Yes	Go to next step
		No	Repair or replace fuel injector at cylinder No.3  page F-20
5	Is fuel system OK?  page F-11	Yes	Go to next step
		No	Repair or replace as necessary
6	Is compression at cylinder No.3 normal?  section B	Yes	Go to next step
		No	Repair or replace as necessary
7	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM  page F-31
		No	Temporary system malfunction

* During normal driving

Diagnostic trouble code No. P0304	CYLINDER 4 MISFIRE DETECTED		
Symptom	ECM input signal from crankshaft position sensor signal for cylinder No.4 is irregular		
Possible cause	<ul style="list-style-type: none"> • Ignition system of cylinder No.4 malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression in cylinder No.4 • Crankshaft position sensor air gap incorrect 		
STEP	INSPECTION		ACTION
1	Is ignition system of cylinder No.4 OK? ☞ section G	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST] ☞ page F-3	Yes	Go to next step
		No	Adjust ignition timing ☞ page F-3
3	Is crankshaft position sensor air gap OK? ☞ page F-39	Yes	Go to next step
		No	Repair or replace crankshaft position sensor ☞ page F-39
4	Is fuel injector at cylinder No.4 OK? ☞ page F-21	Yes	Go to next step
		No	Repair or replace fuel injector at cylinder No.4 ☞ page F-20
5	Is fuel system OK? ☞ page F-11	Yes	Go to next step
		No	Repair or replace as necessary
6	Is compression at cylinder No.4 normal? ☞ section B	Yes	Go to next step
		No	Repair or replace as necessary
7	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM ☞ page F-31
		No	Temporary system malfunction


* During normal driving

Diagnostic trouble code No. P0305		CYLINDER 5 MISFIRE DETECTED	
Symptom		ECM input signal from crankshaft position sensor signal for cylinder No.5 is irregular	
Possible cause		<ul style="list-style-type: none"> • Ignition system of cylinder No.5 malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression in cylinder No.5 • Crankshaft position sensor air gap incorrect 	
STEP	INSPECTION	ACTION	
1	Is ignition system of cylinder No.5 OK? section G	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST] page F-3	Yes	Go to next step
		No	Adjust ignition timing page F-3
3	Is crankshaft position sensor air gap OK? page F-39	Yes	Go to next step
		No	Repair or replace crankshaft position sensor page F-39
4	Is fuel injector at cylinder No.5 OK? page F-21	Yes	Go to next step
		No	Repair or replace fuel injector at cylinder No.5 page F-20
5	Is fuel system OK? page F-11	Yes	Go to next step
		No	Repair or replace as necessary
6	Is compression at cylinder No.5 normal? section B	Yes	Go to next step
		No	Repair or replace as necessary
7	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM page F-31
		No	Temporary system malfunction

* During normal driving

Diagnostic trouble code No. P0306	CYLINDER 6 MISFIRE DETECTED		
Symptom	ECM input signal from crankshaft position sensor signal for cylinder No.6 is irregular		
Possible cause	<ul style="list-style-type: none"> • Ignition system of cylinder No.6 malfunction • Low fuel • Low battery voltage • Fuel system malfunction • Insufficient compression in cylinder No.6 • Crankshaft position sensor air gap incorrect 		
STEP	INSPECTION	ACTION	
1	Is ignition system of cylinder No.6 OK? ☞ section G	Yes	Go to next step
		No	Repair or replace as necessary
2	Is ignition timing within specification? Ignition timing: 10—12° [TEN terminal grounded with SST] ☞ page F-3	Yes	Go to next step
		No	Adjust ignition timing ☞ page F-3
3	Is crankshaft position sensor air gap OK? ☞ page F-39	Yes	Go to next step
		No	Repair or replace crankshaft position sensor ☞ page F-39
4	Is fuel injector at cylinder No.6 OK? ☞ page F-21	Yes	Go to next step
		No	Repair or replace fuel injector at cylinder No.6 ☞ page F-20
5	Is fuel system OK? ☞ page F-11	Yes	Go to next step
		No	Repair or replace as necessary
6	Is compression at cylinder No.6 normal? ☞ section B	Yes	Go to next step
		No	Repair or replace as necessary
7	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM ☞ page F-31
		No	Temporary system malfunction




* During normal driving




Diagnostic trouble code No. P0335		CRANKSHAFT POS SENSOR-CKT MALFUNCTION	
Symptom		No NE signal input from crankshaft position sensor for 1.1 seconds while engine running	
Possible cause		<ul style="list-style-type: none"> • Crankshaft position sensor malfunction • Open or short circuit in wiring from ECM terminal 4E to crankshaft position sensor terminal B • Open or short circuit in wiring from ECM terminal 4H to crankshaft position sensor terminal A 	
STEP	INSPECTION		ACTION
1	Does crankshaft position sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Disconnect crankshaft position sensor connector. Is there continuity between connector terminal B and ECM terminal 4E? Is there continuity between connector terminal A and ECM terminal 4H?	Yes	Go to next step
		No	Repair or replace wiring harness
3	Is crankshaft position sensor air gap OK? 🔧 page F-39	Yes	Go to next step
		No	Replace crankshaft position sensor or crankshaft pulley 🔧 page F-39
4	Is crankshaft position sensor OK? 🔧 page F-39	Yes	Go to next step
		No	Replace crankshaft position sensor 🔧 page F-39
5	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			

Diagnostic trouble code No. P0420		BANK 1 CAT EFFICIENCY BELOW LIMIT	
Symptom		<ul style="list-style-type: none"> • Three way catalytic converter (pre) deterioration • Leakage in exhaust system 	
STEP	INSPECTION		ACTION
1	Is heated oxygen sensor (Rear) OK? 🔧 page F-43	Yes	Replace three way catalytic converter (pre) 🔧 page F-22
		No	Replace heated oxygen sensor (Rear) 🔧 page F-22

Diagnostic trouble code No. P0440		EVAP SYSTEM–MALFUNCTION	
Symptom		Evaporative emission control system does not function normally because of mechanical trouble	
Possible cause		<ul style="list-style-type: none"> • Purge solenoid valve malfunction • Canister drain cut valve malfunction • Fuel tank pressure sensor malfunction • Fuel gauge sender unit malfunction • Charcoal canister malfunction • Cut valve malfunction • Catch tank malfunction • Separator malfunction • Tank pressure control valve malfunction • Clogs or leakage in piping connecting following units Intake manifold and purge solenoid valve Purge solenoid valve and catch tank Catch tank and charcoal canister Charcoal canister and tank pressure control valve Tank pressure control valve, cut valve, separator, fuel tank pressure sensor and fuel tank Charcoal canister and canister drain cut valve 	
STEP	INSPECTION	ACTION	
1	Is ECM terminal 4T voltage OK? 🔧 page F-31	Yes	Go to next step
		No	Inspect purge solenoid valve 🔧 page F-25
2	Is ECM terminal 2C voltage OK? 🔧 page F-31	Yes	Go to next step
		No	Inspect canister drain cut valve and tank pressure control valve 🔧 page F-26, 28
3	Is ECM terminal 3A voltage OK? 🔧 page F-31	Yes	Go to next step
		No	Inspect fuel tank pressure sensor 🔧 page F-44
4	Is ECM terminal 2L voltage OK? 🔧 page F-31	Yes	Go to next step
		No	Inspect fuel gauge sender unit 🔧 section T
5	Is charcoal canister OK? 🔧 page F-26	Yes	Go to next step
		No	Repair or replace as necessary
6	Is cut valve OK? 🔧 page F-26	Yes	Go to next step
		No	Repair or replace as necessary
7	Is catch tank OK?	Yes	Go to next step
		No	Repair or replace as necessary
8	Is separator OK? 🔧 page F-28	Yes	Go to next step
		No	Repair or replace as necessary
9	Erase diagnostic trouble code from memory. Is same code No. present after *rechecking?	Yes	Replace ECM 🔧 page F-31
		No	Temporary system malfunction

* During driving after engine warm-up


Diagnostic trouble code No. P0443		EVAP SYSTEM—PURGE CTRL VALVE CKT MALF	
Symptom		Open or short circuit is observed in purge solenoid valve system when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Purge solenoid valve malfunction • Open or short circuit in wiring from purge solenoid valve terminal A to main relay terminal D • Open or short circuit in wiring from purge solenoid valve terminal B to ECM terminal 4T 	
STEP	INSPECTION	ACTION	
1	Does purge solenoid valve connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 4T voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect purge solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Purge solenoid valve terminal A)
4	Is there continuity between connector terminal B and ECM terminal 4T?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between purge solenoid valve connector terminals A and B?	Yes	Go to next step
		No	Replace purge solenoid valve
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
			
HARNESS SIDE CONNECTOR			

Diagnostic trouble code No. P0450		EVAP PRESSURE SENSOR-MALFUNCTION	
Symptom		Input voltage from fuel tank pressure sensor is below 0.1 V or above 4.8 V when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Fuel tank pressure sensor malfunction • Open or short circuit in wiring from ECM terminal 3I to fuel tank pressure sensor terminal C • Open or short circuit in wiring from ECM terminal 3A to fuel tank pressure sensor terminal A • Open circuit in wiring from ECM terminal 3O to fuel tank pressure sensor terminal B 	
STEP	INSPECTION		ACTION
1	Does fuel tank pressure sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3A voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Are fuel tank pressure sensor and connecting hose free of freezing, breakage, and clogs?	Yes	Repair or replace
		No	Go to next step
4	Disconnect fuel tank pressure sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal C?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (ECM terminal 3I — Fuel tank pressure sensor terminal C)
5	Is there continuity between connector terminal B and ECM terminal 3O?	Yes	Replace fuel tank pressure sensor
		No	Repair or replace wiring harness
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			


Diagnostic trouble code No. P0500		VEHICLE SPEED SENSOR-MALFUNCTION	
Symptom		No vehicle speed sensor signal input from vehicle speed sensor while driving	
Possible cause		<ul style="list-style-type: none"> • Speedometer sensor malfunction • Open or short circuit in wiring from ignition switch to speedometer sensor • Open or short circuit in wiring from speedometer sensor to GND • Open or short circuit in wiring from speedometer sensor to vehicle speed sensor • Open or short circuit in wiring from vehicle speed sensor to ECM terminal 1M 	
STEP	INSPECTION		ACTION
1	Does vehicle speed sensor connector and ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 1M voltage OK? ☞ page F-31	Yes	Go to step 5
		No	Go to next step
3	Is there continuity between vehicle speed sensor terminal and ECM terminal 1M?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Is there continuity between vehicle speed sensor and speedometer sensor terminals? ☞ section T	Yes	Go to next step
		No	Repair or replace speedometer sensor and wiring harness ☞ section K1
5	Erase diagnostic trouble code from memory. Is same code No. present after* rechecking?	Yes	Replace ECM ☞ page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)

* During driving after engine warm-up

Diagnostic trouble code No. P0505		IDLE CONTROL SYSTEM-MALFUNCTION	
Symptom		<ul style="list-style-type: none"> • Mechanical trouble is observed in idle air control system • Open or short circuit is observed in idle air control system 	
Possible cause		<ul style="list-style-type: none"> • Idle air control valve malfunction • Leakage in intake-air system • Open or short circuit in wiring from idle air control valve terminal A to main relay terminal D • Open or short circuit in wiring from idle air control valve terminal B to ECM terminal 4Q 	
STEP	INSPECTION		ACTION
1	Does idle air control valve connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 4Q voltage OK? ☞ page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect idle air control valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Idle air control valve terminal A)
4	Is there continuity between connector terminal B and ECM terminal 4Q?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between idle air control valve connector terminals A and B?	Yes	Go to next step
		No	Replace BAC valve ☞ page F-5
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM ☞ page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)









HARNESS SIDE CONNECTOR

Diagnostic trouble code No. P0510		CLOSED THROTTLE POS SWITCH-MALFUNCTION	
Symptom		Input signal from closed throttle position switch (in throttle position sensor) and throttle position sensor do not match for more than 33 seconds	
Possible cause		<ul style="list-style-type: none"> • Closed throttle position switch (in throttle position sensor) malfunction • Throttle position sensor malfunction • Open or short circuit in wiring from throttle position sensor terminal C to ECM terminal 3L • Open or short circuit in wiring from throttle position sensor terminal D to ECM terminal 3O 	
STEP	INSPECTION		ACTION
1	Does throttle position sensor connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3L voltage OK? ☞ page F-31	Yes	Go to step 6
		No	Go to next step
3	Is there continuity between connector terminal C and ECM terminal 3L?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Is there continuity between connector terminal D and ECM terminal 3O?	Yes	Replace throttle position sensor
		No	Repair or replace wiring harness
5	Is closed throttle position switch (in throttle position sensor) OK? ☞ page F-40	Yes	Go to next step
		No	Repair or replace throttle position sensor ☞ page F-42
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM ☞ page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			




Diagnostic trouble code No. P0703		TORQUE CONV/BRAKE SW-MALFUNCTION	
Symptom		No signal input from brake switch to ECM when brake pedal is kept depressed for more than 33 seconds, or signal input when brake pedal is not depressed	
Possible cause		<ul style="list-style-type: none"> • Brake switch malfunction • Open or short circuit in wiring from ECM terminal 1Q to brake switch terminal • Open or short circuit in wiring from brake switch terminal to battery terminal 	
STEP	INSPECTION		ACTION
1	Does brake switch connector or ECM connector have poor connection?	Yes	Repair or replace
		No	Go to next step
2	Is ECM terminal 1Q voltage OK? ☞ page F-31	Yes	Go to step 4
		No	Go to next step
3	Is there continuity between brake switch and ECM terminal 1Q?	Yes	Check for open or short circuit in wiring harness (Battery — Brake switch) and check brake switch.
		No	Repair or replace wiring harness
4	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM ☞ page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)




Diagnostic trouble code No. P1000	MORE DRIVING NEEDED TO COMPLETE TEST																
Possible cause	Following diagnostic trouble code detection conditions not satisfied																
	<table border="1"> <thead> <tr> <th data-bbox="407 247 1073 289">Diagnosed circuit</th> <th data-bbox="1073 247 1448 289">Code No.</th> </tr> </thead> <tbody> <tr> <td data-bbox="407 289 1073 331">Excessive time to enter closed loop fuel control</td> <td data-bbox="1073 289 1448 331">P0125</td> </tr> <tr> <td data-bbox="407 331 1073 373">O₂ sensor circuit malfunction</td> <td data-bbox="1073 331 1448 373">P0130</td> </tr> <tr> <td data-bbox="407 373 1073 415">O₂ sensor heater circuit malfunction</td> <td data-bbox="1073 373 1448 415">P0135</td> </tr> <tr> <td data-bbox="407 415 1073 457">Fuel trim malfunction</td> <td data-bbox="1073 415 1448 457">P0170</td> </tr> <tr> <td data-bbox="407 457 1073 569">Misfire detected</td> <td data-bbox="1073 457 1448 569">P0300, P0301 P0302, P0303 P0304, P0305 P0306</td> </tr> <tr> <td data-bbox="407 569 1073 611">Catalyst system efficiency below threshold</td> <td data-bbox="1073 569 1448 611">P0420</td> </tr> <tr> <td data-bbox="407 611 1073 646">Evaporative emission control system malfunction</td> <td data-bbox="1073 611 1448 646">P0440</td> </tr> </tbody> </table>	Diagnosed circuit	Code No.	Excessive time to enter closed loop fuel control	P0125	O ₂ sensor circuit malfunction	P0130	O ₂ sensor heater circuit malfunction	P0135	Fuel trim malfunction	P0170	Misfire detected	P0300, P0301 P0302, P0303 P0304, P0305 P0306	Catalyst system efficiency below threshold	P0420	Evaporative emission control system malfunction	P0440
Diagnosed circuit	Code No.																
Excessive time to enter closed loop fuel control	P0125																
O ₂ sensor circuit malfunction	P0130																
O ₂ sensor heater circuit malfunction	P0135																
Fuel trim malfunction	P0170																
Misfire detected	P0300, P0301 P0302, P0303 P0304, P0305 P0306																
Catalyst system efficiency below threshold	P0420																
Evaporative emission control system malfunction	P0440																
ACTION	Carry out troubleshooting according to symptom																

Diagnostic trouble code No. P1110	IATS (D/C)–OPEN OR SHORT		
Symptom	Input from intake air temperature sensor (Dynamic chamber) is below 0.1 V or above 4.9 V when ignition switch is turned on		
Possible cause	<ul style="list-style-type: none"> • Intake air temperature sensor malfunction • Open or short circuit in wiring from intake air temperature sensor (Dynamic chamber) terminal A to ECM terminal 3M • Open or short circuit in wiring from intake air temperature sensor (Dynamic chamber) terminal B to ECM terminal 3O 		
STEP	INSPECTION		ACTION
1	Does intake air temperature sensor (Dynamic chamber) connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 3M voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect intake air temperature sensor (Dynamic chamber) connector. Turn ignition switch to ON. Is there 5 V at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness (ECM terminal 3M — Intake air temperature sensor (Dynamic chamber) terminal A)
4	Is there continuity between connector terminal B and ECM terminal 3O?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is intake air temperature sensor (Dynamic chamber) OK?  page F-43	Yes	Go to next step
		No	Repair intake air temperature sensor (Dynamic chamber)  page F-30
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			

Diagnostic trouble code No. P1170		HO2S 11-INVERSION	
Symptom		Heated oxygen sensor (Front) signal remains unchanged for more than 20 seconds after engine control has entered feedback zone	
Possible cause		<ul style="list-style-type: none"> • Heated oxygen sensor (Front) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front) terminal A to ECM terminal 3C • Intake-air system, fuel system, ignition system malfunction 	
STEP	INSPECTION	ACTION	
1	Does heated oxygen sensor (Front) connector or ECM connector have poor connection?	Yes	Repair or replace
		No	Go to next step
2	Is ECM terminal 3C voltage OK? 🔧 page F-31	Yes	Go to step 5
		No	Go to next step
3	Disconnect heated oxygen sensor (Front) connector. Is there continuity between connector terminal A and ECM terminal 3C?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Are following units OK? <ul style="list-style-type: none"> • Fuel injector 🔧 page F-21 • Pressure regulator 🔧 page F-19 • Mass air flow sensor 🔧 page F-37 • Engine coolant temperature sensor 🔧 page F-42 • Spark plug 🔧 section G • Air suction 🔧 page F-5 (Air/Fuel ratio rich or lean)	Yes	Replace heated oxygen sensor (Front) 🔧 page F-22
		No	Repair or replace
5	Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking?	Yes	Replace ECM 🔧 page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 HARNESS SIDE CONNECTOR			

Diagnostic trouble code No. P1195		EGRBS-OPEN OR SHORT	
Symptom		ECM's barometric pressure integrated circuit is damaged	
Possible cause		<ul style="list-style-type: none"> • ECM malfunction 	
STEP	INSPECTION	ACTION	
—	—	Replace ECM	🔧 page F-31

Diagnostic trouble code No. P1196		STA SW—OPEN OR SHORT	
Symptom		Input signal from starter to ECM continues for more than 20 seconds	
Possible cause		<ul style="list-style-type: none"> • Starter malfunction • Open or short circuit in wiring from starter terminal S and ECM terminal 1C 	
STEP	INSPECTION		ACTION
1	Does starter connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 1C voltage OK?  page F-31	Yes	Go to step 4
		No	Go to next step
3	Disconnect starter connector. Is there continuity between connector terminal S and ECM terminal 1C?	Yes	Replace starter  section G
		No	Repair or replace
4	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)




Diagnostic trouble code No. P1250		PRC—OPEN OR SHORT	
Symptom		Open or short circuit is observed in PRC solenoid valve No.1 system when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • PRC solenoid valve malfunction • Open or short circuit in wiring from PRC solenoid valve No.1 terminal A to main relay terminal D • Open or short circuit in wiring from PRC solenoid valve No.1 terminal B to ECM terminal 4J 	
STEP	INSPECTION		ACTION
1	Does PRC solenoid valve No.1 connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 4J voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect PRC solenoid valve No.1 connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — PRC solenoid valve No.1 terminal A)
4	Is there continuity between connector terminal B and ECM terminal 4J?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between PRC solenoid valve No.1 terminals A and B?	Yes	Go to next step
		No	Replace PRC solenoid valve No.1
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
			
HARNESS SIDE CONNECTOR			




Diagnostic trouble code No. P1252		PRC2-OPEN OR SHORT	
Symptom		Open or short circuit is observed in PRC solenoid valve No.2 system when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • PRC solenoid valve malfunction • Open or short circuit in wiring from PRC solenoid valve No.2 terminal A to main relay terminal D • Open or short circuit in wiring from PRC solenoid valve No.2 terminal B to ECM terminal 4L 	
STEP	INSPECTION	ACTION	
1	Does PRC solenoid valve No.2 connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 4L voltage OK? 🔊 page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect PRC solenoid valve No.2 connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — PRC solenoid valve No.2 terminal A)
4	Is there continuity between connector terminal B and ECM terminal 4L?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between PRC solenoid valve No.2 terminals A and B?	Yes	Go to next step
		No	Replace PRC solenoid valve No.2
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM 🔊 page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)





Diagnostic trouble code No. P1345		SGC SIGNAL-NO SGC SIGNAL	
Symptom		No SGC signal input from camshaft position sensor while engine rotates nine cycles	
Possible cause		<ul style="list-style-type: none"> • Camshaft position sensor malfunction • Open or short circuit in wiring from distributor 6-pin connector terminal B to main relay terminal D • Open or short circuit in wiring from ECM terminal 4G to distributor 6-pin connector terminal D 	
STEP	INSPECTION	ACTION	
1	Does distributor 6-pin connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Disconnect distributor 6-pin connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal B?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Distributor 6-pin connector terminal B)
3	Is there continuity between connector terminal D and ECM terminal 4G?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Is ECM terminal 4G voltage OK? 🔊 page F-31	Yes	Go to step 6
		No	Go to next step
5	Is camshaft position sensor OK? 🔊 page F-38	Yes	Go to next step
		No	Replace distributor 🔊 section G
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM 🔊 page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)





HARNESS SIDE CONNECTOR



Diagnostic trouble code No. P1449		CANISTER DRAIN CUT VALVE—OPEN OR SHORT	
Symptom		Open or short circuit is observed in canister drain cut valve or tank pressure control valve system when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Canister drain cut valve malfunction • Tank pressure control valve malfunction • Open or short circuit in wiring from canister drain cut valve terminal A to main relay terminal D • Open or short circuit in wiring from canister drain cut valve terminal B to ECM terminal 2C • Open or short circuit in wiring from tank pressure control valve terminal A to main relay terminal D • Open or short circuit in wiring from tank pressure control valve terminal B to ECM terminal 2C 	
STEP	INSPECTION	ACTION	
1	Does canister drain cut valve connector, tank pressure control valve connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 2C voltage OK?  page F-31	Yes	Go to step 9
		No	Go to next step
3	Disconnect canister drain cut valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Canister drain cut valve terminal A)
4	Disconnect tank pressure control valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — Tank pressure control valve terminal A)
5	Is there continuity between canister drain cut valve connector terminal B and ECM terminal 2C?	Yes	Go to next step
		No	Repair or replace wiring harness
6	Is there continuity between tank pressure control valve connector terminal B and ECM terminal 2C?	Yes	Go to next step
		No	Repair or replace wiring harness
7	Is there continuity between canister drain cut valve terminals A and B?	Yes	Go to next step
		No	Replace canister drain cut valve
8	Is there continuity between tank pressure control valve terminals A and B?	Yes	Go to next step
		No	Replace tank pressure control valve
9	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
			
HARNESS SIDE CONNECTOR			



Diagnostic trouble code No. P1455		FUEL TANK LEVEL SENSOR-OPEN OR SHORT	
Symptom		Input voltage from fuel gauge sender unit is above 3.2 V when ignition switch is turned on	
Possible cause		<ul style="list-style-type: none"> • Fuel gauge sender unit malfunction • Open or short circuit in wiring from ECM 2L to fuel pump terminal A • Open circuit in wiring from fuel pump terminal C to ground 	
STEP	INSPECTION		ACTION
1	Does fuel pump connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 2L voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Is there continuity between fuel pump connector terminal A and ECM terminal 2L?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Is there continuity between fuel pump connector terminal C and ground?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is fuel gauge sender unit OK?  section T	Yes	Go to next step
		No	Replace fuel gauge sender unit
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)

Diagnostic trouble code No. P1521		VRIS1—OPEN OR SHORT	
Symptom		Open or short circuit is observed in VRIS solenoid valve system	
Possible cause		<ul style="list-style-type: none"> • VRIS solenoid malfunction • Open or short circuit in wiring from VRIS solenoid valve terminal A to main relay terminal D • Open or short circuit in wiring from VRIS solenoid valve terminal B to ECM terminal 4K 	
STEP	INSPECTION	ACTION	
1	Does VRIS solenoid valve connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 4K voltage OK?  page F-31	Yes	Go to step 6
		No	Go to next step
3	Disconnect VRIS solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness. (Main relay terminal D — VRIS solenoid valve terminal A)
4	Is there continuity between connector terminal B and ECM terminal 4K?	Yes	Go to next step
		No	Repair or replace wiring harness
5	Is there continuity between VRIS solenoid valve terminals A and B?	Yes	Go to next step
		No	Replace VRIS solenoid valve  page F-5
6	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)
 <p>HARNESS SIDE CONNECTOR</p>			

Diagnostic trouble code No. P1601		COMM LINE (AT)—COMM ERROR	
Symptom		Open or short circuit in ECM—TCM communication line	
Possible cause		<ul style="list-style-type: none"> • Open or short circuit in wiring from ECM terminal 2H to TCM terminal 2N • Open or short circuit in wiring from ECM terminal 2G to TCM terminal 2K 	
STEP	INSPECTION	ACTION	
1	Does TCM connector or ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is there continuity between ECM terminal 2H and TCM terminal 2N?	Yes	Go to next step
		No	Repair or replace wiring harness
3	Is there continuity between ECM terminal 2G and TCM terminal 2K?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Replace TCM  section K1

Diagnostic trouble code No. P1608		PCME (CPU)-MALFUNCTION	
Symptom		ECM does not read diagnostic trouble codes from output devices	
Possible cause		<ul style="list-style-type: none"> • ECM malfunction • Short circuit in wiring output device 	
STEP	INSPECTION		ACTION
—	—		Replace ECM

Diagnostic trouble code No. P1794		BAT-BAT OR CIRCUIT FAIL	
Symptom		Battery positive voltage is not constantly applied to ECM terminal 4I	
Possible cause		<ul style="list-style-type: none"> • Battery malfunction • Open or short circuit in wiring from ECM terminal 4I to battery positive cable • Burnt fuse 	
STEP	INSPECTION		ACTION
1	Is battery fully charged?  section G	Yes	Go to next step
		No	Charge the battery  section G
2	Does battery positive voltage present at ECM terminal 4I?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness (ECM terminal 4I — Battery)
3	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)

Diagnostic trouble code No. P1797		PNS-OPEN OR SHORT	
Symptom		ECM judges N range for more than 33 seconds when shift lever is in D range	
Possible cause		<ul style="list-style-type: none"> • Transmission range switch malfunction • Open or short circuit in wiring from transmission range switch terminal B to ECM terminal 1L 	
STEP	INSPECTION		ACTION
1	Does transmission range switch connector and ECM connector have poor connection?	Yes	Repair or replace connector
		No	Go to next step
2	Is ECM terminal 1L voltage OK?  page F-31	Yes	Go to step 4
		No	Go to next step
3	Is there continuity between transmission range switch terminal B and ECM terminal 1L?	Yes	Go to next step
		No	Repair or replace wiring harness
4	Erase diagnostic trouble code from memory. Is same code No. present after rechecking?	Yes	Replace ECM  page F-31
		No	Intermittent poor connection of harness or connector (Repair connector and/or harness)

TROUBLESHOOTING GUIDE

RELATIONSHIP CHART

Output Device and Input Device

E/L SIGNAL		x	x	x	x	○	x	x	x	x	x
POWER STEERING PRESSURE SWITCH		x	x	x	x	○	x	x	x	x	x
TRANSMISSION RANGE SWITCH		○	x	○	x	○	x	○	○	x	○
DATA LINK CONNECTOR TERMINAL TEN		○	x	x	x	○	x	○	x	x	○
BAROMETRIC PRESSURE SENSOR (IN-ECM)		○	x	x	x	○	x	○	○	x	x
HEATED OXYGEN SENSOR		○	x	x	x	x	x	x	○	x	x
INTAKE AIR TEMPERATURE SENSOR	DYNAMIC CHAMBER	○	x	○	x	○	x	x	x	x	x
	MASS AIR FLOW SENSOR	○	x	x	x	○	x	x	○	x	x
IGNITION SWITCH (START)		○	○	○	x	○	x	○	x	○	○
ENGINE COOLANT TEMPERATURE SENSOR		○	x	○	x	○	x	○	○	○	x
THROTTLE POSITION SENSOR	THROTTLE POSITION SENSOR	○	x	○	x	○	x	x	○	x	○
	CLOSED THROTTLE POSITION SWITCH	○	x	x	x	○	x	x	○	x	x
MASS AIR FLOW SENSOR		○	x	x	x	x	x	○	○	○	x
SGC SIGNAL		x	○	x	x	x	x	○	x	x	x
NE SIGNAL		○	○	○	x	○	○	○	○	○	x
INPUT DEVICES	OUTPUT DEVICES	FUEL INJECTION AMOUNT	FUEL INJECTION TIMING	PRESSURE REGULATOR CONTROL SOLENOID VALVES	AIR VALVE	IDLE AIR CONTROL VALVE	VRIS SOLENOID VALVE	IGNITION CONTROL MODULE	PURGE SOLENOID VALVE	HEATED OXYGEN SENSOR	A/C RELAY (A/C CUT-OFF)
		FUEL INJECTOR			BAC VALVE						

○: Related
x: Not related

ENGINE CONTROL OPERATION CHART Input Devices and Engine Conditions

B+: Battery positive voltage

ENGINE CONDITION	APPROXIMATE TIME (BASED ON 10–16 °C { 50–60 °F } AMBIENT)	INPUT DEVICE							
		CRANK-SHAFT POSITION SENSOR	THROTTLE POSITION SENSOR		ENGINE COOLANT TEMPERATURE SENSOR	HEATED OXYGEN SENSOR	MASS AIR FLOW SENSOR		BAROMETRIC PRESSURE SENSOR
			CLOSED THROTTLE POSITION SWITCH	THROTTLE POSITION SENSOR			MASS AIR FLOW SENSOR	INTAKE AIR TEMPERATURE SENSOR	
CRANKING —COLD ENGINE • COLD AIR • COLD COOLANT	ZERO		SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM		SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM	
COLD START FAST IDLE • COLD AIR • COLD COOLANT	ONE MINUTE		LOW VOLTAGE SIGNAL TO ECM (BELOW 1.5 V)	CLOSED THROTTLE: LOW VOLTAGE (0.1–1.1 V)	COOL TO WARM: MEDIUM VOLTAGE (3V AND DROPPING)	SENSOR COLD: LOW TO HIGH VOLTAGE (0–0.8 V)	LOW MASS AIR FLOW: LOW-TO MEDIUM VOLTAGE (1.0–2.0 V)		
COLD DRIVE AWAY PART THROTTLE • COLD AIR • COLD COOLANT	TWO MINUTES								
WARM DRIVE AWAY-PART THROTTLE (25%) • WARM INTAKE AIR • WARM COOLANT	THREE MINUTES	SENDS NO.1 CYLINDER TDC SIGNAL TO ECM		PART THROTTLE: MEDIUM VOLTAGE (1–2.5 V)	WARM: MEDIUM VOLTAGE (APPROX. 0.7 V AND DROPPING)	SENSOR WARM: HIGH VOLTAGE (ABOVE 0.6 V)			SENDS VOLTAGE SIGNAL TO ECM THAT VARIES WITH ALTITUDE: VOLTAGE (APPROX. 4 V)
HOT CRUISE • WARM INTAKE AIR • HOT COOLANT			HIGH VOLTAGE SIGNAL TO ECM (B+)				SENSOR HOT SWITCHING FROM HIGH VOLTAGE (ABOVE 0.6 V RICH) TO LOW VOLTAGE (BELOW 0.4 V LEAN)	MODERATE-TO HIGH MASS AIR FLOW: (3.0–4.0 V)	
HOT ACCELERATION • 60% THROTTLE									
HOT ACCELERATION • WIDE OPEN THROTTLE	MORE THAN FOUR MINUTES			WIDE OPEN THROTTLE: MEDIUM VOLTAGE (2.8–4.5 V)	HOT: LOW VOLTAGE (APPROX. 0.5 V)	HIGH VOLTAGE (ABOVE 0.6 V RICH)	HIGH MASS AIR FLOW: (4.0–5.0 V)		
DECELERATION • CLOSED THROTTLE POSITION			LOW VOLTAGE SIGNAL TO ECM (BELOW 1.5 V)	CLOSED THROTTLE: LOW VOLTAGE (0.1–1.1 V)		LOW VOLTAGE (BELOW 0.4 V LEAN)	LOW MASS AIR FLOW: (1.0–2.0 V)		
HOT CURB IDLE (EXTENDED)						SWITCHING FROM HIGH TO LOW VOLTAGE (0.4–0.6 V)			
HOT ENGINE SHUT-DOWN		OFF	OFF	OFF	OFF	SENSOR HOT: LOW VOLTAGE (0.1 V LEAN) UNTIL SENSOR COOLS DOWN	OFF	OFF	OFF

B+: Battery positive voltage

INPUT DEVICES							
DIS-TRIBU-TOR (SGC SIGNAL)	TRANS-MISSION RANGE SWITCH	A/C SWITCH	POWER STEERING PRES-SURE SWITCH	CPU (E/L SIGNAL)	IGNITION SWITCH		TEN TERMINAL
					START POSITION	ON POSITION	
SENDS NO.1CYL-INDER TDC SIGNAL TO ECM	SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM	SENDS SIGNAL TO ECM (B+)	SIGNAL HAS NO EFFECT ON ECM	SIGNAL HAS NO EFFECT ON ECM
	PARK/ NEUTRAL POSI-TION: SENDS SIGNAL TO ECM (B+)	A/C SWITCH ON: SENDS SIGNAL TO ECM (B+) A/C SWITCH OFF: NO SIGNAL TO ECM (BELOW 1.5 V)	STEERING WHEEL TURNED: LOW VOLT-AGE SIG-NAL TO ECM (BE-LOW 1.5 V) STEERING WHEEL STRAIGHT AHEAD: HIGH VOLT-AGE SIG-NAL TO ECM (B+)	HEAD-LIGHT OR FAN OR REAR WIN-DOW DE-FROSTER SWITCH ON: LOW VOLTAGE SIGNAL TO ECM (BE-LOW 1.5 V) HEAD-LIGHT AND BLOWER AND REAR WINDOW DEFROST-ER SWITCHES OFF: HIGH VOLTAGE SIGNAL TO ECM (B+)	NO SIG-NAL TO ECM (BE-LOW 1.5 V)	SENDS SIGNAL TO ECM (B+)	CONNEC-TOR NOT GROUND ED: HIGH VOLTAGE SIGNAL TO ECM (B+)
	IN OTHER PARK/ NEUTRAL POSITION: NO VOLT-AGE SIG-NAL TO ECM (BE-LOW 1.5 V)						
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

Output Devices and Engine Conditions

ENGINE CONDITION	OUTPUT DEVICES	APPROXIMATE TIME (BASED ON 10-16 °C { 50-60 °F } AMBIENT TEMPERATURE	OUTPUT DEVICES								
			FUEL INJECTOR		BAC VALVE		A/C CUT RELAY	PURGE SOLENOID VALVE	PRC SOLENOID VALVES	MAIN RELAY	
			INJECTION	INJECTION TIMING	AIR VALVE	IDLE AIR CONTROL VALVE					
CRANKING COLD ENGINE • COLD AIR • COLD COOLANT		ZERO	RICH	SEQUENTIAL INJECTION	OPEN (COOLANT TEMP: BELOW 60 °C { 140 °F }	LARGE AMOUNT OF BY-PASS AIR	OFF (A/C ON)	OFF (PURGE CUT)	OFF (VACUUM TO PRESSURE REGULATOR)	ON	
COLD START FAST IDLE • COLD AIR • COLD COOLANT	ONE MINUTE										
COLD DRIVE AWAY PART THROTTLE • COLD AIR • COLD COOLANT	TWO MINUTES										
WARM DRIVE AWAY-PART THROTTLE (25%) • WARM INLET AIR • WARM COOLANT		THREE MINUTES	RICH and LEAN				ON(A/C ON)	OPERATES (DUTY VALUES) (PURGE GAS AMOUNT CHANGES)			
HOT CRUISE • WARM INLET AIR • HOT COOLANT		MORE THAN FOUR MINUTES	RICH	SEQUENTIAL INJECTION	CLOSE	SMALL AMOUNT OF BY-PASS AIR					
HOT ACCELERATION • 60% THROTTLE											
HOT ACCELERATION • WIDE OPEN THROTTLE									OFF (A/C OFF)	OFF (PURGE CUT)	
DECELERATION • CLOSED THROTTLE-POSITION			FUEL CUT			LARGE AND SMALL AMOUNT OF BY-PASS AIR		ON (SMALL)			
HOT CURB IDLE (EXTENDED)			RICH and LEAN	SEQUENTIAL INJECTION		SMALL AMOUNT OF BY-PASS AIR	ON (A/C ON)	OFF (PURGE CUT)	AFTER STARTING ON (DURING HOT START ONLY) PRC SOL. V. NO.1-VACUUM CUT PRC SOL. V. NO.2-VACUUM		
HOT ENGINE SHUT-DOWN			NOT INJECTION			OFF	ON	OFF	OFF	OFF	


OUTPUT DEVICES		
IGNITION CONTROL MODULE	VRIS SOLENOID VALVE	HEATED OXYGEN SENSOR (HEATER)
IGNITION TIMING BTDC 7°	OFF (VRIS-OFF)	OFF
IGNITION SPARK ADVANCE SIGNAL	ON (VRIS ON, 3,600—5,100 rpm ONLY)	ON (BELOW 2,250 rpm)
	ON (VRIS OFF)	OFF
	ON (VRIS ON, 3,600—5,100 rpm ONLY)	
	OFF (VRIS-OFF)	
	OFF	
OFF	OFF	OFF

HOW TO USE THIS SECTION

Introduction

Most of the fuel and emission system is electrically controlled. Thus, it is sometimes difficult to diagnose a problem in the system, especially intermittent problems. Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Work flow



How to read the troubleshooting chart

F TROUBLESHOOTING GUIDE

SYMPTOM TROUBLESHOOTING

STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Check for spark by disconnecting high tension leads while cranking engine.	Yes: Go to next step. No: Check ignition system (Refer to ignition system trouble - section G)	
2	Check for fuel pump operating sound from fuel line port. (Ignition switch ON, Fuel line connects RFP and GND terminals correctly)	Yes: Fuel pump relay and wiring (Starting circuit) Go to next step. No: Check fuel pump relay wiring operation (Refer to page F-150)	F-150 F-147 F-149 F-150
3	Check fuel line pressure. (Ignition switch ON, Fuel line connects RFP and GND terminals correctly) Fuel line pressure: 28-33 kPa (2.7-3.2 kgf/cm ² , 28-45 psi)	Yes: Go to next step. No: Check fuel pump maximum pressure. Fuel pump max. pressure: 440-457 kPa (4.3-4.5 kgf/cm ² , 64-67 psi) Refer to page F-147	F-152 F-148 F-148
4	Check for fuel injector operating sound while cranking	Yes: Go to next step. No: Check voltage at ECM 4U, 4V, 4W, 4X, 4Y and 4Z terminals with SST. Multiple ON (Ignition switch ON) Refer to page F-174	F-176 ECM malfunction (Fuels) F-171 F-174 F-174
5	Substitute a known-good ECM. Check if the condition becomes better.	Yes: Check ground on fuel line (ECM 2) terminal with SST. Relay: 4 R (Ignition switch ON) F-173 No: Poor ground circuit	F-173 F-174
6			Low compression section D

F-88

F TROUBLESHOOTING GUIDE

STEP 1 (1)

STEP 2 (1)

STEP 3 (1)

STEP 4 (1)

STEP 5 (1)

Warning: BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE. (REFER TO PAGE F-142)

STEP 3 (2)

F-89

Left page shows the troubleshooting procedure

- QUICK INSPECTION
- ACTION
- POSSIBLE CAUSE AND DETAILED INSPECTION

Right page illustrates how to perform QUICK INSPECTION

Crank normally but won't start (No combustion)						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check for spark by disconnecting high-tension leads while cranking	Yes	Go to next step			
		No	Check ignition system (Refer to ignition system troubleshooting)		section G	
2	Check for fuel pump operating sound from fuel filler port [Ignition switch ON, Data link connector F/P and GND terminals connected]	Yes	Check if the engine starts with this condition	Yes	Fuel pump relay and wiring (Starting circuit) Go to next step	F-150
		No	Check fuel pump relay switching operation Refer to page F-150	Yes	Wiring open (Check relay circuit)	F-150
					Fuel pump malfunction	F-147
					Wiring open (Check fuel pump circuit)	F-150
No	Fuel pump relay malfunction (Replace)	F-150				
3	Check fuel line pressure [Ignition switch ON, Data link connector F/P and GND terminals connected]	Yes	Go to next step			
		No	Check fuel pump maximum pressure Fuel pump max. pressure: 442—637 kPa (4.42—6.37 kgf/cm ²)	Yes	Pressure regulator malfunction (Replace)	F-152
			No	Fuel pump malfunction (Replace)	F-147	

STEP:

This shows the order of the troubleshooting. Proceed with the troubleshooting by the steps.

QUICK INSPECTION:

This describes an easy inspection necessary to presume the malfunction parts quickly.

ACTION:

This recommends the appropriate action to take as a result (Yes or No) of the QUICK INSPECTION. How to perform the action is shown on the reference page.

POSSIBLE CAUSE AND DETAILED INSPECTION:


This shows the possible point of malfunction. The detailed inspection is shown on the reference page.

DIAGNOSTIC INDEX

No.	TROUBLESHOOTING ITEMS	REMARKS	PAGE
1	No cranks	Refer to section G	section G
2	Cranks normally but won't start	No combustion	F- 88
3	Cranks normally but hard to start (Always)		F- 90
4	Cranks normally but hard to start (Only when engine is cold)		F- 92
5	Cranks normally but hard to start (Only when engine is warm)		F- 94
6	Cranks normally but hard to start (Only after heat soak)		F- 96
7	Cranks normally but won't start (Intermittent)	No combustion	F- 97
8	Rough idle (Always)		F- 98
9	Rough idle (Only when engine is cold)		F-100
10	Rough idle (Only when engine is warm)		F-102
11	Rough idle (Only after heat soak)		F-103
12	Rough idle just after starting		F-104
13	Low idle speed (When A/C, P/S, E/L is ON)	Idle speed down and keeps low speed	F-104
14	High idle speed after warm up		F-106
15	Idle hunting or surging		F-108
16	Engine stall at idle (Always)		F-110
17	Engine stall at idle (Only when engine is cold)		F-112
18	Engine stall at idle (Only when engine is warm)		F-112
19	Engine stall at idle (Only after heat soak)		F-113
20	Engine stall at idle (When A/C, P/S, E/L is ON)		F-114
21	Engine stall at idle (in "D" range)		F-114
22	Engine stall during start up		F-115
23	Engine stall on deceleration (Only when engine is cold)		F-116
24	Engine stall on deceleration (Only after warm up)		F-117
25	Engine stall at idle (Intermittent)		F-117
26	Hesitates/Stumbles on acceleration	Includes start up	F-118
27	Hesitates at steady speed		F-120
28	Knocking		F-122
29	Poor acceleration		F-124
30	Bucking at high speed		F-126
31	Bucking on deceleration		F-128
32	Poor fuel economy		F-130
33	High oil consumption/White exhaust smoke		F-132
34	Afterburn on deceleration		F-132
35	Rotten egg smell		F-134
36	Black exhaust smoke		F-134
37	Gasoline fumes		F-135
38	Fails emission test	Engine condition is OK	F-136
39	MIL always ON	Engine condition is OK	F-138
40	MIL never ON	Engine condition is not OK	F-138
41	A/C does not work		F-138

Description of Drivability

- (1) SURGE: Continuous soft jerking during cruise.
- (2) STUMBLE: Mild jerking during acceleration.
- (3) JERK: Shock occurring when the accelerator pedal is depressed just after deceleration.
- (4) HESITATION: Flat spot occurring just after the accelerator pedal is depressed.




SYMPTOM TROUBLESHOOTING


B+: Battery positive voltage

Crank normally but won't start (No combustion)						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check for spark by disconnecting high-tension leads while cranking	Yes	Go to next step			
		No	Check ignition system (Refer to ignition system troubleshooting)	section G		
2	Check for fuel pump operating sound from fuel filler port [Ignition switch ON, Data link connector F/P and GND terminals connected]	Yes	Check if the engine starts with this condition	Yes	Fuel pump relay and wiring	F-18
		No	Check fuel pump relay switching operation Refer to page F-18	Go to next step		
				Yes	Wiring open (Check relay circuit)	
				Fuel pump malfunction		F-17
No	Fuel pump relay malfunction (Replace)	F-18				
3	Check fuel line pressure [Ignition switch ON, Data link connector F/P and GND terminals connected] Fuel line pressure: 265—313 kPa { 2.7—3.2 kgf/cm ² , 39—45 psi }	Yes	Go to next step			
		No	Check fuel pump maximum pressure	Yes	Pressure regulator malfunction (Replace)	F-20
			Fuel pump max. pressure: 442—637 kPa { 4.5—6.5 kgf/cm ² , 64—92 psi }	No	Fuel pump malfunction (Replace)	F-17
Refer to page F-16						
4	Check for fuel injector operating sound while cranking	Yes	Go to next step			
		No	Check voltage at ECM 4U, 4V, 4W, 4X, 4Y and 4Z terminals with SST Voltage: B+ (Ignition switch ON) Refer to page F-31	Yes	Throttle position sensor malfunction	F-42
				ECM malfunction (Replace)		F-31
				No	Wiring open or short	
Poor ground circuit from ECM 4C terminal						
5	Substitute a known-good ECM Check if the condition becomes better	Yes	ECM malfunction			
		No	Check ground circuit from ECM 4A terminal with SST Voltage: 0 V (Ignition switch ON)	F-31	Yes	Go to next step
				Poor ground circuit		
6				Low compression	section B	


STEP 1




STEP 3
(3)




STEP 2
(1)




STEP 4



STEP 2
(2)



STEP 5




STEP 3
(1)

Warning


- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 3
(2)




Crank normally but hard to start (Always)							
STEP	QUICK INSPECTION		ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check ignition timing at idle after warm up Ignition timing: 10—12° BTDC [TEN terminal grounded with SST]	Yes	Go to next step				
		No	Adjust ignition timing			F-3	
2	Disconnect high-tension lead of each cylinder at idle Check if the engine condition changes	Yes	Go to next step				
		No	Check ignition system [Refer to ignition system troubleshooting (Misfire)]	section G	Yes	Fuel injector clogging (Replace)	F-20
					No	Spark plug	section G
						High-tension lead	section G
Distributor cap	section G						
3	Check fuel injector operating sound at idle	Yes	Go to next step				
		No	Check fuel injector resistance	F-21	Yes	Wiring short or open	
4	Check fuel line pressure [Ignition switch ON, Data link connector F/P and GND terminals connected] Fuel line pressure: 265—313 kPa { 2.7—3.2 kgf/cm ² , 39—45 psi }	Yes	Go to next step				
		No	Check fuel pump max. pressure Fuel pump max. pressure: 442—637 kPa { 4.5—6.5 kgf/cm ² , 64—92 psi }	F-16	Yes	Pressure regulator malfunction (Replace)	F-20
No	Fuel pump malfunction (Replace)				F-17		
5	Operate the fuel pump [Ignition switch ON, Data link connector F/P and GND terminals connected] Turn the ignition switch OFF and observe fuel pressure for 5 minutes Fuel pressure: More than 147 kPa { 1.5 kgf/cm ² , 21 psi }	Yes	Go to next step				
		No	Check fuel pump pressure drop	F-15	No	Fuel pump malfunction (Replace)	F-17
			Check pressure regulator pressure drop	F-19	Yes	Fuel injector fuel leaks	F-20
6	Check voltage at ECM terminal 1C with SST	Yes	Go to next step				
		No	Check STA fuse	section T	Yes	Wiring short or open	
7						Low compression	section B
						Replace	section T
8	Substitute a known-good ECM						


STEP 1
(1)




STEP 4
(2)




STEP 1
(2)



STEP 4
(3)



STEP 2



STEP 5
(1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 3



STEP 5
(2)




STEP 4
(1)

Warning


- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 5
(3)




Crank normally but hard to start (only when engine is cold)							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check gravity of battery by using a hydrometer Specific gravity: Above 1.200	Yes	Go to next step				
		No	Recharge the battery			section G	
2	Check diagnostic trouble code No.P0115 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
3	Disconnect high-tension lead of each cylinder at idle Check if the engine condition changes	Yes	Go to next step				
		No	Check ignition system [Refer to ignition system troubleshooting (Misfire)]	section G	Yes	Fuel injector clogging (Replace)	F-20
					No	Spark plug	section G
						High-tension lead	section G
Distributor cap	section G						
4	Check fuel line pressure [Ignition switch ON, Data link connector F/P and GND terminals connected] Fuel line pressure: 265—313 kPa { 2.7—3.2 kgf/cm ² , 39—45 psi }	Yes	Go to next step				
		No	Check fuel pump max. pressure	F-16	Yes	Pressure regulator malfunction (Replace)	F-20
	Fuel pump max. pressure: 442—637 kPa { 4.5—6.5 kgf/cm ² , 64—92 psi }	No	Fuel pump malfunction (Replace)		F-17		
5	Disconnect the idle air control valve connector Check idle speed during warm up	Yes	Go to next step				
		No				BAC valve stuck close	F-5
6	Substitute a known-good ECM						


STEP 1




STEP 4
(3)




STEP 2




STEP 5



STEP 3



STEP 6




STEP 4
(1)

Warning


- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 4
(2)




Crank normally but hard to start (only when engine is warm)							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check diagnostic trouble code No.P0443 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Disconnect engine coolant temperature sensor connector Check if the condition becomes better	Yes	Check engine coolant temperature sensor connector for connecting condition as follows 1. Shake connector and check if the condition changes 2. Check condition of terminal (burning or damaged) 3. Connect a male terminal to the connector and check for connection condition	Yes	Engine coolant temperature sensor malfunction	F-30	
				No	Poor contact at engine coolant temperature sensor connector		
		No	Go to next step				
3	Operate the fuel pump [Ignition switch ON, Data link connector F/P and GND terminals connected] Turn the ignition switch OFF and observe fuel pressure for 5 minutes Fuel pressure: More than 147 kPa { 1.5 kgf/cm², 21 psi }	Yes	Go to next step				
		No	Check fuel pump pressure drop	F-15	No	Fuel pump malfunction (Replace)	F-17
			Check pressure regulator pressure drop	F-19	Yes	Fuel injector fuel leaks	F-20
				No	Pressure regulator malfunction (Replace)	F-20	
4	Substitute a known-good ECM						


STEP 1



STEP 4



STEP 2




STEP 3
(1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 3
(2)




STEP 3
(3)




Crank normally but hard to start (only after heat soak)							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check diagnostic trouble code No.P0110, P0115, P1250, P1252 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Circulate the fuel by operating fuel pump for 20 sec. [Ignition switch ON, Data link connector F/P and GND terminals connected] Check if the condition becomes better	Yes	Go to step 4				
		No	Go to next step				
3	Check the PRC system Is system normal? Refer to page F-141	Yes	Go to next step				
		No	Repair or replace				
4	Operate the fuel pump [Ignition switch ON, Data link connector F/P and GND terminals connected] Turn the ignition switch OFF and observe fuel pressure for 5 min. Fuel pressure: More than 147 kPa { 1.5 kgf/cm², 21 psi }	Yes	Go to next step				
		No	Check fuel pump pressure drop	F-15	No	Fuel pump malfunction (Replace)	F-17
			Check pressure regulator pressure drop	F-19	Yes	Fuel injector fuel leaks	F-20
				F-19	No	Pressure regulator malfunction (Replace)	F-20
5	Change fuel with specified one Check if the condition becomes better	Yes				Poor fuel quality	
		No	Go to next step				
6	Substitute a known-good ECM						

STEP 1



STEP 2




STEP 4
(1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 4
(3)




STEP 4
(2)




Crankes normally but won't start (Intermittent)			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Shake connector of distributor, main relay and ECM while cranking Check if the engine starts	Yes	There may be a poor contact at the connector Repair or replace the wiring
		No	Go to troubleshooting "Crankes normally but hard to start (always)" F-90


STEP 1
(1)



STEP 1
(3)




STEP 1
(2)



Rough idle (Always)								
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION			
1	Check diagnostic trouble code No.P0110, P0115, P0443, P0505 with SST	Yes	Check for the cause by referring to the check sequence			F-46		
		No	Go to next step					
2	Check ignition timing at idle after warm up Ignition timing: 10—12° BTDC [TEN terminal grounded with SST]	Yes	Go to next step					
		No	Adjust ignition timing (If possible)			F-3		
3	Disconnect high-tension lead of each cylinder at idle Check if the condition changes	Yes	Go to next step					
		No	Check ignition system [Refer to ignition system troubleshooting (Misfire)]	section G	Yes	Fuel injector clogging (Replace)	F-20	
					No	Spark plug	section G	
						High-tension lead	section G	
Distributor cap	section G							
4	Check idle speed after warm up Idle speed: 760—800 rpm (P range) [TEN terminal grounded with SST]	Yes	Go to next step					
		No	Adjust idle speed (If possible) If not possible check if idle air control system is OK			F-3 F-139		
5	Check fuel injector operating sound at idle	Yes	Go to next step					
		No	Check fuel injector resistance	F-21	Yes	Wiring short or open	F-20	
No			No	Fuel injector malfunction (Replace)	F-20			
6	Check fuel line pressure [Ignition switch ON, Data link connector F/P and GND terminals connected] Fuel line pressure: 265—313 kPa { 2.7—3.2 kgf/cm ² , 39—45 psi }	Yes	Go to next step					
		No				Fuel leaks		
						Fuel filter clogging		F-15
			Check fuel pump max. pressure	F-16	Yes	Pressure regulator malfunction (Replace)	F-20	
No	Fuel pump max. pressure: 442—637 kPa { 4.5—6.5 kgf/cm ² , 64—92 psi }		No	Fuel pump malfunction (Replace)		F-17		
7	Check intake manifold vacuum at idle Vacuum: 61.4—66.6 kPa { 460—500 mmHg, 18.2—19.6 inHg }	Yes	Go to next step					
		No	Check for air leaks	F-5	Yes	Throttle valve	F-5	
					No	Vacuum hoses	F-5	
						Gaskets		
Bolts or nuts								
Component broken								
8	Substitute a known-good ECM Check if the condition becomes better	Yes				ECM malfunction		
		No	Check voltage at ECM 4A terminal with SST	F-31	Yes	Go to next step		
					No	Poor ground circuit		
9					Check compression	section B		


STEP 1



STEP 5



STEP 2 (1)




STEP 6 (1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)


STEP 2 (2)




STEP 6 (2)




STEP 3




STEP 6 (3)



STEP 4




STEP 7




Rough idle (only when engine is cold)							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check diagnostic trouble code NoP0100, P0115 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Disconnect high-tension lead of each cylinder at idle Check if the engine condition changes	Yes	Go to next step				
		No	Check ignition system [Refer to ignition system troubleshooting (Misfire)]	section G	Yes	Fuel injector clogging	F-20
					No	Spark plug	section G
						High-tension lead	section G
Distributor cap	section G						
3	Check fuel injector operating sound at idle	Yes	Go to next step				
		No	Check fuel injector resistance	F-21	Yes	Wiring short or open	
No	Fuel injector malfunction (Replace)				F-20		
4	Disconnect idle air control valve connector and check idle speed during warm up	Yes	Go to next step				
		No			BAC valve stuck close	F-5	
5	Disconnect engine coolant temperature sensor connector Check if the condition becomes better	Yes	Check engine coolant temperature sensor connector for connecting condition as follows 1. Shake connector and check if the condition changes 2. Check condition of terminal (burning or damaged) 3. Connect a male terminal to the connector and check for connection condition	Yes	Engine coolant temperature sensor malfunction	F-30	
							No
		No	Go to next step				
6	Check if idle air control system is OK Refer to page F-139	Yes	Go to next step				
		No	Repair or replace				
7	Check if the specified engine oil is used	Yes	Go to next step				
		No	Change engine oil with specified one				
8	Substitute a known-good ECM Check if the condition becomes better	Yes				ECM malfunction	
		No				Mass air flow sensor malfunction	F-5


STEP 1




STEP 7



STEP 2




STEP 8




STEP 3



STEP 4




STEP 5




Rough idle (only when engine is warm)						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Run the engine at 2,000 rpm for more than 20 sec. Check diagnostic trouble code No.P0100, P0110, P0115, P0134 with SST	Yes	Check for the cause by referring to the check sequence		F-46	
		No	Go to next step			
2	Check idle speed after warm up Idle speed: 760—800 rpm (P range) [TEN terminal grounded with SST]	Yes	Go to next step			
		No	Adjust idle speed (if possible)	F-3		
3	Disconnect idle air control valve connector Check if the engine speed drops	Yes	Go to next step			
		No		Idle air control valve malfunction	F-5	
4	Disconnect engine coolant temperature sensor connector Check if the condition becomes better	Yes	Check engine coolant temperature sensor connector for connecting condition as follows 1. Shake connector and check if the condition changes 2. Check condition of terminal (burning or damaged) 3. Connect a male terminal to the connector and check for connection condition	Yes	Engine coolant temperature sensor malfunction	F-30
				No	Poor contact at engine coolant temperature sensor connector	
		No	Go to next step			
5	Substitute a known-good ECM			ECM malfunction		


STEP 1




STEP 3



STEP 2




STEP 4



Rough idle (only after heat soak)				
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Run the engine at 2,000 rpm for more than 20 sec. Check diagnostic trouble code No.P0115, P0134, P0154, P1250, P1252 with SST	Yes	Check for the cause by referring to the check sequence	F-46
		No	Go to next step	
2	Check pressure regulator control system Is system normal? Refer to page F-141	Yes	Go to next step	
		No	Repair or replace	
3	Change fuel to specified one			Poor fuel quality

STEP 1




Rough idle just after starting							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check Diagnostic trouble code No.P0110, P0115 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Check closed throttle position switch with SST	Yes	Go to next step				
		No	Closed throttle position switch malfunction			F-42	
3	Check ignition timing at idle after warm up Ignition timing: 10—12° BTDC [TEN terminal grounded with SST]	Yes	Go to next step				
		No	Adjust ignition timing			F-3	
4	Check idle speed after warm up Idle speed: 760—800 rpm (P range) [TEN terminal grounded with SST]	Yes	Go to next step				
		No	Try to adjust idle speed	F-3	Yes	Idle speed misadjustment	
					No	Accelerator cable free play	F-8
						Idle air control valve stuck close	F-5
Throttle valve	F-5						
5	Substitute a known-good ECM Check if the condition becomes better	Yes	ECM malfunction				
		No	Check voltage at ECM 1C terminal with SST Voltage: Approx. 10 V (While cranking)	F-31	Yes	Go to next step	
					No	Transmission range switch	
				Related wiring open			
6			Poor quality engine oil				

Low idle speed (when A/C, P/S, E/L is ON)						
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check diagnostic trouble code No.P0505 with SST	Yes	Check for the cause by referring to the check sequence			F-46
		No	Go to next step			
2	Disconnect idle air control valve connected at idle Check if the condition does not change	Yes	Go to next step			
		No			Low coolant level	section E
					Engine oil poor quality	section D
3	Check if idle air control system is OK Refer to page F-139	Yes	Go to next step			
		No	Repair or replace			
4	Check the continuity between TEN terminal and ground		Wiring short to ground			


Note

- In case of low idle speed with A/C ON, if the problem can not be solved by the above steps, it may be an A/C compressor malfunction. (Refer to section U.)


STEP 1




STEP 3 (2)




STEP 2




STEP 4




STEP 3 (1)




STEP 5



STEP 1




STEP 2




High idle speed after warm up								
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION			
1	Disconnect idle air control valve connector and check idle speed decrease during warm up	Yes	Go to next step					
		No		Air valve stuck open	F-5			
2	Check if idle air control system is ok Refer to page F-139 [TEN terminal grounded with SST]	Yes	Go to next step					
		No	Repair or replace					
3	Check diagnostic trouble code No.P0115, P0505 with SST	Yes	Check for the cause by referring to the check sequence		F-46			
		No	Go to next step					
4	Check ignition timing at idle after warm up Ignition timing: 10—12° BTDC [TEN terminal grounded with SST]	Yes	Go to next step					
		No	Adjust ignition timing		F-3			
5	Check intake manifold vacuum at idle Vacuum: 61.4—66.6 kPa { 460—500 mmHg , 18.2-19.6 inHg }	Yes	Go to next step					
		No	Check for air leak	F-5	Yes	Vacuum hose misrouting	F-5	
						Throttle valve open		
					No	Vacuum hoses	F-5	Gaskets
								Bolts or nuts loose
Intake air system components								
6	Disconnect engine coolant temperature sensor connector and check if the condition becomes better	Yes	Check for engine coolant temperature sensor connector condition as follows 1. Shake the connector and check if the engine condition become better 2. Check pin condition (burning or broken) 3. Connect the male pin to the connector and check for connector condition	Yes	Engine coolant temperature sensor malfunction	F-30		
				No	Poor contact at engine coolant temperature sensor connector			
		No	Go to next step					
7	Substitute a known-good ECM							


STEP 1




STEP 6




STEP 3




STEP 4
(1)



STEP 4
(2)




STEP 5




Idle hunting or surging				
STEP	QUICK INSPECTION		ACTION	POSSIBLE CAUSE
1	(If trouble occurs at warm condition) Check diagnostic trouble code No.P0134, P0443, P0505 with SST	Yes	Check for the cause by referring to the check sequence	F-46
		No	Go to next step	
2	Check for intake manifold vacuum at idle Vacuum: 61.4—66.6 kPa { 460—500 mmHg , 18.2—19.6 inHg }	Yes	Go to next step	
		No		Air leakage F-5
3	Pinch PCV hose Check if the engine condition changes	Yes		PCV valve malfunction
		No	Go to next step	
4	Disconnect the engine coolant tem- perature sensor connector Check if the engine condition changes	Yes		Engine coolant tem- perature sensor mal- function F-30
		No	Go to next step	
5	Check fuel line pressure at idle Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }	Yes	Go to next step	
		No	Check if pressure regulator control system	F-141
6	Substitute a known-good ECM			ECM malfunction


STEP 1




STEP 6



STEP 2



STEP 4




STEP 5
(1)

Warning


- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 5
(2)



Engine stall at idle (Always)						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE		
1	Check diagnostic trouble code with SST	Yes	Check the cause by referring to the check sequence		F-46	
		No	Go to next step			
2	Shake connectors of distributor, main relay and ECM while idle Check if the engine stalls	Yes	There may be a poor contact at the connector Repair or replace the harness and connector			
		No	Go to next step			
3	Check the vacuum hoses and the air funnel for sucking air	Yes	Shut the air leak part			
		No	Go to next step			
4	Check fuel line pressure [Ignition switch ON, Data link connector F/P and GND terminals connected] Fuel line pressure: 265—313 kPa { 2.7—3.2 kgf/cm ² , 39—45 psi }	Yes	Go to next step			
		No			Fuel leaks	
					Fuel filter clogging	F-15
			Check fuel pump maximum pressure	Yes	Pressure regulator malfunction (Replace)	F-20
			No	Fuel pump malfunction (Replace)	F-17	
5				ECM malfunction		

STEP 1




STEP 4
(1)


Warning

- **BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)**

STEP 4
(2)




STEP 4
(3)




Engine stall at idle (Only when engine is cold)

STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE		
1	Check voltage at ECM terminal 3E Refer to page F-31	Yes	Go to next step			
		No	Replace engine coolant temperature sensor	Engine coolant temperature sensor malfunction	F-30	
2	Blow the air valve (cold condition) Check the air flow	Yes	Go to next step			
		No	Replace the BAC valve	BAC valve malfunction (Replace)	F-5	
3	Substitute a known-good ECM			ECM malfunction (Replace)		

STEP 1




STEP 3




Engine stall at idle (only when engine is warm)

STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE		
1	Check voltage at ECM terminal 3E Refer to page F-31	Yes	Go to next step			
		No	Replace engine coolant temperature sensor	Engine coolant temperature sensor malfunction	F-30	
2	Substitute a known-good ECM			ECM malfunction		

STEP 1




STEP 2



Engine stall at idle (Only after heat soak)			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE
1	Run the engine at 2,000 rpm for more than 20 sec. Check diagnostic trouble code No.P0115, P0134, P1250, P1252 with SST	Yes	Check for the cause by referring to the check sequence
		No	Go to next step
2	Check if pressure regulator control system Is system normal? Refer to page F-141	Yes	Go to next step
		No	Repair or replace
3	Change fuel to specified one		

STEP 1




Engine stall at idle (When A/C, P/S, E/L is ON)					
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE	
1	Check diagnostic trouble code No.P0505 with SST	Yes	Check for the cause by referring to the check sequence	F-46	
		No	Go to next step		
2	Disconnect idle air control valve connector at idle Check if the condition does not change	Yes	Go to next step		
		No		Low coolant level	section E
				Engine oil poor quality	section B
3	Check if idle air control system is OK Refer to page F-139	Yes	Go to next step		
		No	Repair or replace		
4	Check the continuity between TEN terminal and ground		Wiring short to ground		


Note

- In case of engine stall at idle with A/C ON, if the trouble can not be fixed after checking above steps, it may be A/C compressor malfunction. (Refer to section U.)

STEP 1




STEP 2




Engine stall at idle (in "D" range)					
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE	
1	Check diagnostic trouble code with SST	Yes	Check the cause by referring to the check sequence		
		No	Go to next step		
2	Check voltage at ECM terminal 1L Refer to page F-31	Yes	Go to next step		
		No	Adjustment or replacement	Transmission range switch malfunction	
3	Substitute a known-good ECM		ECM malfunction (Replace)	F-31	

STEP 1




STEP 2




Engine stall during start up							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE		
1	Check diagnostic trouble code No.P0100, P0115 with SST	Yes	Check the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Check intake manifold vacuum at idle Vacuum: 61.4—66.6 kPa { 460—500 mmHg , 18.2—19.6 inHg }	Yes	Go to next step				
		No	Check for air leaks	F-132	Yes	Throttle valve	F-5
					No	Vacuum hoses	F-5
						Gaskets	
Bolts or nuts							
	Component broken						
3	Check if idle air control system is OK Refer to page F-139	Yes	Go to next step				
		No	Repair or replace				
4	Check for correct ignition timing advance	Yes	Go to next step				
		No	Adjust or replace		Distributor malfunction	section G	
5	Substitute a known-good ECM				ECM malfunction	F-30	


STEP 1



STEP 5




STEP 2




Engine stall on deceleration (only when engine is cold)				
STEP	QUICK INSPECTION		ACTION	POSSIBLE CAUSE
1	Check diagnostic trouble code with SST	Yes	Check the cause by referring to the check sequence	
		No	Go to next step	
2	Check volatge at ECM terminal 3E Refer to page F-31	Yes	Go to next step	
		No	Replace the engine coolant temperature sensor	Engine coolant temperature sensor malfunction F-30
3	Substitute a known-good ECM		ECM malfunction	F-31

STEP 1




STEP 3




Engine stall on deceleration (Only after warm up)			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE
1	Check diagnostic trouble code with SST	Yes	Check the cause by referring to the check sequence
		No	Go to next step
2	Substitute a known-good ECM		ECM malfunction

STEP 1




STEP 2




Engine stall at idle (Intermittent)			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Shake connectors of distributor, main relay, and ECM while cranking Check if the engine starts	Yes	There may be a poor contact at the connector. Repair or replace the wiring
		No	Go to troubleshooting "Engine stall at idle (always)"


STEP 1
(1)



STEP 1
(3)




STEP 1
(2)




Hesitates/Stumbles on acceleration						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Run the engine at 2,000 rpm for 20 sec. and stop it Check diagnostic trouble code No. P0100, P0115, P0120, P0134 with SST	Yes	Check for the cause by referring to the check sequence		F-46	
		No	Go to next step			
2	Check voltage at ECM terminal 3F Refer to page F-31	Yes	Go to next step			
		No	Adjust or replace throttle position sensor			
3	Disconnect heated oxygen sensor connector Check if the condition becomes better	Yes		Heated oxygen sensor	F-43	
		No	Go to next step			
4	Check fuel line pressure while acceleration Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }	Yes	Go to next step			
		No	Check if pressure regulator control system		F-141	
5	Check for air leaks with throttle valve open by listening for sucking noise	Yes	Go to next step			
		No		Vacuum hoses	F-5	
				Gaskets		
				Nuts or bolts loose		
	Damaged components					
6	Disconnect engine coolant temperature sensor connector Check if the condition improves	Yes	Check engine coolant temperature sensor connector for connecting condition as follows 1. Shake connector and check if the condition changes 2. Check condition of terminal (burning or damaged) 3. Connect a male terminal to the connector and check for connection condition	Yes	Engine coolant temperature sensor malfunction	F-30
				No	Poor contact at engine coolant temperature sensor connector	
		No	Go to next step			
7	Check if VRIS control system is ok Refer to page F-140	Yes	Go to next step			
		No	Repair or replace			
8	Substitute a known-good ECM Check if the condition becomes better	Yes	ECM malfunction			
		No		Mass air flow sensor	F-37	
				Throttle valve	F-5	
		Spark plug	section G			
9	Check other systems			Automatic transmission	section K1	


STEP 1



STEP 8



STEP 2




STEP 4
(1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 4
(2)




STEP 6



Hesitates at steady speed					
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Run the engine at 2,000 rpm for 20 sec. and stop it Check diagnostic trouble code No.P0100, P0115, P0120, P0134 with SST	Yes	Check for the cause by referring to the check sequence		F-46
		No	Go to next step		
2	Disconnect heated oxygen sensor connector Check if the condition becomes better	Yes		Heated oxygen sensor deterioration	F-43
		No	Go to next step		
3	Check for air leaks with throttle valve open by listening for sucking noise	Yes	Go to next step		
		No		Vacuum hoses	F-5
				Gaskets	
				Nuts or bolts loosen	
	Damaged components				
4	Check fuel line pressure while acceleration Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }	Yes	Go to next step		
		No	Check if pressure regulator control system		F-141
5	Gradually open the throttle valve Check if engine speed increases smoothly	Yes	Go to next step		
		No		Mass air flow sensor	F-37
				Throttle valve	F-5
			Throttle position sensor	F-40	
6	Are all spark plugs ok?	Yes	Go to next step		
		No	Clean or replace spark plug(s)		
7	Change fuel with specified one Check if the condition becomes better	Yes		Poor fuel quality	
		No	Go to next step		
8	Substitute a known-good ECM				

STEP 1




STEP 4
(1)


Warning

- **BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)**


STEP 4
(2)



STEP 5




STEP 6




Knocking				
STEP	QUICK INSPECTION		ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Check diagnostic trouble code No.P0100, P0115 with SST	Yes	Check for cause by referring to check sequence	F-46
		No	Go to step 2 (at sea level) Go to step 3 [at high-altitude (1,000 m { 3,280 ft })]	
2	Check ignition timing after warm up Ignition timing 10—12 ° BTDC [TEN terminal grounded with SST]	Yes	Go to next step	
		No	Adjust ignition timing	
3	Check fuel line pressure at idle Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm ² , 30—36 psi }	Yes	Go to next step	
		No	Check if pressure regulator control system	F-141
4	Check the mass air flow sensor Refer to page F-37	Yes	Go to next step	
		No	Replace the mass air flow sensor	Mass air flow sensor malfunction F-5
5	Change fuel with specified one Check if the condition becomes better Fuel spec: (R+M)/2 method 87 or higher	Yes		Poor fuel quality
		No	Go to next step	
6	Substitute a known-good ECM			ECM malfunction F-31


STEP 1



STEP 2
(1)



STEP 2
(2)




STEP 3
(1)

Warning


- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 3
(2)




Poor acceleration						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check diagnostic trouble code with SST	Yes	Check the cause by referring to the check sequence		F-46	
		No	Go to next step			
2	Check voltage at ECM terminal 3F Refer to page F-31	Yes	Go to next step			
		No	Adjust or replace throttle position sensor			
3	Disconnect high-tension lead of each cylinder at idle Check if the engine condition changed	Yes	Go to next step			
		No	Check ignition system Refer to section G	Yes	Fuel injector malfunction	F-20
				No	Ignition system malfunction	section G
4	Check air cleaner element for clogging	Yes	Go to next step			
		No	Replace air cleaner element			
5	Check ignition timing at idle after warm up Ignition timing: 10—12 ° BTDC [Data link connector TEN terminal grounded]	Yes	Go to next step			
		No	Adjust ignition timing	F-3		
6	Check the vacuum hoses and the air funnel for sucking air	Yes	Shut the air leak part			
		No	Go to next step			
7	Check fuel line pressure at idle Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }	Yes	Go to next step			
		No	Check if pressure regulator control system	F-141		
8	Check if VRIS control system is OK Refer to page F-140	Yes	Go to next step			
		No	Repair or replace			
9	When the accelerator pedal is depressed, engine speed increases smoothly	Yes	Go to next step			
		No	Mass air flow sensor malfunction	F-5		
10	Change the fuel with specified one Check if the condition becomes better Fuel spec: (R+M)/2 method 87 or higher	Yes		Poor fuel quality		
		No	Go to next step			
11	Check other systems			Automatic transmission	section K1	
12	Substitute a known-good ECM			ECM malfunction	F-31	


STEP 1



STEP 5
(2)



STEP 2




STEP 7
(1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)


STEP 3




STEP 7
(2)



STEP 4




STEP 5
(1)




Bucking at high speed				
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check diagnostic trouble code with SST	Yes	Check for the cause by referring to the check sequence	F-46
		No	Go to next step	
2	Disconnect the heated oxygen sensor connector Check if the engine condition becomes better	Yes	Replace the heated oxygen sensor	
		No	Go to next step	
3	Check fuel line pressure at idle Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm ² , 30—36 psi }	Yes	Go to next step	
		No	Check if pressure regulator control system	F-141
4	Check the vacuum hoses and the air funnel for sucking air	Yes	Shut the air leak part	
		No	Go to next step	
5	Check ignition timing at idle after warm up Ignition timing: 10—12 ° BTDC	Yes	Go to next step	
		No	Adjust ignition timing	F-3
6	When the accelerator pedal is depressed, engine speed increases smoothly	Yes	Go to next step	
		No	Mass air flow sensor malfunction	F-5
7	Substitute a known-good ECM		ECM malfunction	F-31

STEP 1



STEP 7




STEP 3
(1)


Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)


STEP 3
(2)



STEP 5
(1)




STEP 5
(2)




Bucking on deceleration					
STEP	QUICK INSPECTION		ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check diagnostic trouble code No.P0100, P0115, P0505, P0510 with SST	Yes	Check for the cause by referring to the check sequence	F-46	
		No	Go to next step		
2	Check voltage at ECM terminal 3L	Yes	Go to next step		
		No	Adjust or replace throttle position sensor	F-41	
3	Substitute a known-good ECM Check if the condition becomes better	Yes	ECM malfunction		
		No	Go to next step		
4	Check other system			Spark plug gap	section G
				Compression differs between cylinders	section B


STEP 1



STEP 2




STEP 3




Poor fuel economy						
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Run the engine at 2,000—3,000 rpm for more than 20 sec. after warm up and stop it Check diagnostic trouble code No.P0134 with SST	Yes	Check for the cause by referring to the check sequence			F-46
		No	Go to next step			
2	Check voltage at ECM terminal 3L Refer to page F-31	Yes	Go to next step			
		No	Adjust or replace throttle position sensor			F-41
3	Check fuel line pressure at idle Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }	Yes	Go to next step			
		No	Check vacuum line to pressure regulator for clogging or air leak	Yes	Vacuum line (Replace)	
		No		Check PRC system		F-141
4	Check for fuel cut operation while deceleration Fuel cut: Until approx. 1,000 rpm After warm up	Yes	Go to next step			
		No	Check engine coolant temperature sensor	F-42	Yes	ECM malfunction
		No		Engine coolant temperature sensor malfunction/Replace		F-30
5	Check ignition timing advance	Yes	Go to next step			
		No	Check ignition system			section G
6	Check other systems				TCM malfunction	section K1
					Brake wear	section P
					Tire air pressure	section Q

STEP 1



STEP 2




STEP 3
(1)

Warning

- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 3
(2)




STEP 4




High oil consumption/White exhaust smoke						
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check for oil leak from engine	Yes	Repair or replace			
		No	Go to next step			
2	Disconnect PCV valve from engine Check if there is vacuum at idle	Yes	Go to next step			
		No	Check PCV valve	F-28	Yes	PCV hose clogging
					No	PCV valve malfunction
3	Check that the ventilation hose is installed correctly	Yes	Go to next step			
		No	Install ventilation hose correctly			
4	It may be a malfunction of the engine Check for the cause by referring to the check sequence of section B					

Afterburn on deceleration							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Check diagnostic trouble code No.P0505, P0510 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Check voltage at ECM terminal 3L Refer to page F-31	Yes	Go to next step				
		No	Adjust or replace throttle position sensor			F-41	
3	Check ignition timing at idle after warm up Ignition timing: 10—12 ° BTDC [TEN terminal grounded with SST]	Yes	Go to next step				
		No	Check for the distributor			section G	
4	Check air cleaner element for clogging	Yes	Go to next step				
		No	Replace air cleaner element				
5	Check fuel cut operation while deceleration Fuel cut: Above approx. 1,000 rpm after warm up	Yes	Go to next step				
		No	Check engine coolant temperature sensor	F-180	Yes	ECM terminal 3E malfunction	F-31
					No	Engine coolant temperature sensor (Replace)	F-30
6	Run the engine at idle and stop the engine (Ignition switch OFF) Check if fuel pressure drops	Yes	Go to next step				
		No	Check fuel pump for pressure drop	Yes	Check pressure regulator for pressure drop		
				No	Fuel pump malfunction (Replace)	F-17	
			Check pressure regulator for pressure drop	Yes	Fuel injector leak		F-20
No	Pressure regulator malfunction (Replace)			F-20			
7					Low compression	section B	
					Valve timing	section B	


STEP 1



STEP 5



STEP 2




STEP 6
(1)


Warning

- **BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)**

STEP 4




STEP 6
(2)




Rotten egg smell			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Change fuel with specified one		Poor fuel quality

Black exhaust smoke						
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Run the engine at 2,000 rpm for more than 20 sec. check for diagnostic trouble code No.P1170 with SST	Yes	Check for the cause by referring to the check sequence		F-46	
		No	Go to next step			
2	Check if pressure regulator control system Is system OK? Refer to page F-141	Yes	Go to next step			
		No	Repair or replace			
3	Disconnect engine coolant temperature sensor connector Check if the condition improves	Yes	Check engine coolant temperature sensor connector for connecting condition as follows 1. Shake connector and check if the condition changes 2. Check condition of terminal (burning or damaged) 3. Connect a male terminal to the connector and check for connection condition	Yes	Engine coolant temperature sensor malfunction	F-30
				No	Poor contact at engine coolant temperature sensor connector	
		No	Go to step 4 [at high-altitude (1,000 m { 3,280 ft })] Go to step 5 (at sea level)			
4				Barometric pressure sensor malfunction (Replace the ECM)	F-31	
5				Mass air flow sensor malfunction (Replace)		
6	Substitute a known-good ECM			ECM malfunction	F-31	

STEP 1




STEP 3




Gasoline fumes			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Check for fuel leaks	Yes	Go to next step
		No	Repair or replace
2	Check if the evaporative fume is emitted from the cut valve	Yes	Check cut valve Is it OK?
			Yes
		No	Cut valve malfunction (Replace)
3	Check diagnostic trouble code No.P0440, P0443, P0450 with SST	Yes	Check for the cause by referring to the check sequence F-46
		No	Go to next step
4	Check if purge control system is OK Refer to page F-143	Yes	Check charcoal canister
		No	Repair or replace

STEP 2




STEP 3




Fails emission test (Engine condition is OK)							
STEP	QUICK INSPECTION	ACTION			POSSIBLE CAUSE AND DETAILED INSPECTION		
1	Run the engine at 2,000 rpm for 20 sec. and stop it Check diagnostic trouble code No. P0100, P0115, P0134, P0443 with SST	Yes	Check for the cause by referring to the check sequence			F-46	
		No	Go to next step				
2	Check voltage at ECM terminal 3C Refer to page F-31	Yes	Go to next step				
		No	Adjust or replace throttle position sensor			F-41	
3	Check for air leaks by hearing sucking noise • At idle • Throttle valve open	Yes	Go to next step				
		No	Repair or replace				
4	Check fuel line pressure at idle Fuel line pressure: 206—254 kPa { 2.1—2.6 kgf/cm² , 30—36 psi }	Yes	Go to next step				
		No	Check if pressure regulator control system			F-141	
5	Check fuel cut operation while decelerating Fuel cut: Above approx. 1,000 rpm after warm up	Yes	Go to next step				
		No	Check engine coolant temperature sensor	F-42	Yes	ECM malfunction (Replace)	F-31
					No	Engine coolant temperature sensor malfunction/Replace	F-30
6	Check for fuel fumes	Yes	Check for the cause by referring to troubleshooting "Gasoline fumes"			F-135	
		No	Go to next step				
7	Check PCV valve and hose	Yes	Go to next step				
		No	PCV valve or hose malfunction (Replace)				
8	Check spark plug • Gap • Damage	Yes	Poor fuel quality				
		No	Spark plug malfunction (Repair or Replace)				

STEP 1



STEP 2




STEP 4
(1)

Warning


- BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F-10)

STEP 4
(2)




MIL always ON (Engine condition is OK)			
STEP	QUICK INSPECTION	ACTION	POSSIBLE CAUSE AND DETAILED INSPECTION
1	Check diagnostic trouble code with SST		"LINK COMMUNICATION ERROR" ① Open or short circuit in wiring between DLC2 KLN terminal and ECM terminal 1D ② ECM <ul style="list-style-type: none"> • Vref terminal voltage malfunction • Open or short circuit in wiring between main relay and PCM terminal 4B • Open circuit in ground terminals of ECM
			"NO DTCS RECEIVED" Wiring between ECM 1E terminal and MIL short to ground

STEP 1 (1)



MIL never ON (Engine condition is not OK)					
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check if other indicator lights illuminate	Yes	Go to next step		
		No	Check power supply circuit to combination meter	section T	
2	Check MIL	Yes	Ground the ECM terminal 1E	Yes	ECM malfunction
			Check if the MIL illuminates	No	Wiring between ECM and MIL open
		No	Replace bulb		









STEP 2





A/C does not work					
STEP	QUICK INSPECTION	ACTION		POSSIBLE CAUSE AND DETAILED INSPECTION	
1	Check if A/C cut system is OK Refer to page F-144	Yes	Check A/C system		
		No	Repair or replace		

SYSTEM INSPECTION

PREPARATION
SST

<p>49 B019 9A0 System Selector</p> 	<p>For each system inspection</p>	<p>49 T088 0A0 NGS set</p> 	<p>For each system inspection</p>
<p>49 T088 010B Program Card</p> 	<p>For each system inspection</p>	<p>49 T088 008A Instruction Manual</p> 	<p>For each system inspection</p>
<p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For each system inspection</p>	<p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p> 	<p>For each system inspection</p>
<p>49 T088 004 NGS OBD II Adapter (Part of 49 T088 0A0)</p> 	<p>For each system inspection</p>	<p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For each system inspection</p>



IDLE AIR CONTROL INSPECTION

1. Start the engine and run it at idle.
2. Disconnect the IAC valve connector and verify that the engine rotation changes.
3. If the engine condition will not change, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
 - (2) Verify that diagnostic trouble code No. P0505 is not displayed. If code No. P0505 is shown, carry out troubleshooting of the code No. P0505.
 - (3) Select the "SIMULATION TEST" function on the NGS display.
 - (4) Change the duty value of the IAC valve to 100% by using the "IACV" and verify that the idle speed increases.
 - a. If the idle speed increases, replace the ECM, (Refer to page F-31.)
 - b. If the idle speed does not change, replace the BAC valve. (Refer to page F-5.)
4. Warm up the engine to normal operating temperature and run it at idle.

- Turn the electrical loads ON and verify that the engine speed is within the specification.



Engine speed (rpm)

No load	760—800
E/L operated	730—830
A/C operated	750—850
P/S operated	730—830

Note

- Excludes temporary idle speed drop just after the electrical loads are turned on.

- If not as specified, check the related switches and wiring harnesses.




VRIS INSPECTION


- Start the engine.
- Verify that the rod of the shutter valve actuator is pulled.
- If the rod is not pulled, do as follows.
 - Stop the engine.
 - Install the **SST** to the data link connector 2 located under the driver side dashboard.
 - Verify that diagnostic trouble code No. P1521 is not displayed. If code No. P1521 is shown, carry out troubleshooting of the code No. (Refer to page F-46.)
 - If diagnostic trouble code P1521 is not shown, do as follows.
 - Start the engine and run it at idle.
 - Turn the VRIS solenoid valve from ON to OFF by using the simulation function and check if operation sound of the valve is heard.
 - If the operation sound is not heard, check the following.
 - Shutter valve actuator (Refer to page F-7.)
 - If the operation sound is heard, check the following.
 - VRIS solenoid valve (Refer to page F-7.)
- Check the rod operation under the following conditions.

Rod operation

Engine speed (rpm)	0	3600	5100	7500
Shutter valve actuator	Operate	Not operate	Operate	Operate



5. If the rod operation is not as specified, do as follows.
 - (1) Stop the engine.
 - (2) Connect the **SST** to the data link connector 2 located under the driver side dashboard.
 - (3) Verify that diagnostic trouble code No. P1521 is not displayed. If code No. P1521 is shown, carry out troubleshooting of the code No.1521. (Refer to page F-46.)
 - (4) If diagnostic trouble code is not shown, do as follows.
 - I. Start the engine and run it at idle.
 - II. Turn the VRIS solenoid valve from ON to OFF by using the simulation function and check if operation sound of the valve is heard.
 - III. If the operation sound is not heard, check the following.
 - Shutter valve actuator (Refer to page F-7.)
 - IV. If the operation sound is heard, check the following.
 - VRIS solenoid valve (Refer to page F-7.)



PRESSURE REGULATOR CONTROL INSPECTION

Warning



- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-10.**

1. Install the fuel pressure gauge.
2. Measure the fuel pressure under the following conditions.

Specifications



	Fuel pressure [kPa { kgf cm ² , psi }]		
Idling	206—254 { 2.1—2.6, 30—36 }	206—254 { 2.1—2.6, 30—36 }	304—382
During 60 (180) sec. of hot (super hot) start	304—382 { 3.1—3.9, 44—55 }		{ 3.1—3.9, 44—55 }
After 60 (180) sec. of hot (super hot) start	206—254 { 2.1—2.6, 30—36 }	206—254 { 2.1—2.6, 30—36 }	304—382 { 3.1—3.9, 44—55 }
Judgement	Normal	Not normal (Perform Inspection 1)	Not normal (Perform Inspection 2)

3. If the fuel pressure is not within the specification, carry out either Inspection 1 or Inspection 2 as required.



Inspection 1



1. Stop the engine.
2. Connect the **SSTs** to the data link connector 2 located under the driver side dashboard.
3. Verify that diagnostic trouble code No. P1250, P1252 is not displayed. If code No. P1250, P1252 is shown, carry out troubleshooting of the code No. P1250, P1252. (Refer to page F-46.)
4. Start the engine and run it at idle.
5. Select the "SIMULATION TEST" function on the NGS display.
6. Turn the PRC solenoid valve No.1 from OFF to ON by using the "PRC V" and check if the fuel pressure changes (from normal to high).
 - (1) If the pressure changes, check the following.
 - ECM terminal voltage (Refer to page F-31.)
 - Engine coolant temperature signal
 - Intake air temperature signal
 - Throttle valve TVO signal
 - (2) If the pressure does not change, do as follows.
 - a. Stop the engine.
 - b. Turn the ignition switch to ON.
 - c. Select the "SIMULATION TEST" function on the NGS display.
 - d. Turn the PRC solenoid valve No.1 from OFF to ON by using the "PRC V" and check if the operation sound of the valve is heard.
 - i. If the operation sound is heard, check the following.
 - Pressure regulator (Refer to page F-19.)
 - Loose or damaged vacuum hose
 - ii. If the operation sound is not heard, check the following.
 - PRC solenoid valve No.1 (Refer to page F-20.)



Inspection 2



1. Stop the engine.
2. Connect the **SSTs** to the data link connector 2 located under the driver side dashboard.
3. Verify that diagnostic trouble code No. P1250, P1252 is not displayed. If code No. P1250, P1252 is shown, carry out troubleshooting of the code No. P1250, P1252. (Refer to page F-46.)
4. Start the engine and let it idle.
5. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display after 3 minutes from the engine start.
6. By using the "PRC V2", verify that the PRC solenoid valve No.2 is OFF.
7. If the PRC solenoid valve No.2 is ON, check the following.
 - ECM terminal voltage (Refer to page F-31.)
 - Engine coolant temperature signal
 - Intake air temperature signal
8. Select the "SIMULATION TEST" function on the NGS display.

9. Turn the PRC solenoid valve No.2 from OFF to ON by using the "PRC V2" and check if the operation sound of the valve is heard.
 - If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - Pressure regulator (Refer to page F-19.)
 - If the operation sound is not heard, check the following.
 - PRC solenoid valve No.2 (Refer to page F-20.)



PURGE CONTROL INSPECTION

1. Start and warm up the engine to the normal operating temperature.
2. Let the engine idle.
3. Disconnect the vacuum hose between the purge solenoid valve and the charcoal canister.
4. Put a finger to the purge solenoid valve and verify that there is no vacuum applied.
5. If there is vacuum, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443 (Refer to page F-46.)
 - (3) If diagnostic trouble code is not shown, check the following.
 - Purge solenoid valve (Refer to page F-25.)
6. Reconnect the vacuum hose.
7. Connect the **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
8. Select the "SIMULATION TEST" function on the NGS display.
9. Increase the duty value of the purge solenoid valve from 0% to 100% by using the "PRG V". Operate the purge solenoid valve and check if the idle condition changes.
10. If the condition does not change, do as follows.
 - (1) Turn the ignition switch to ON.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F-46.)
 - (3) Increase duty value of the purge solenoid valve from 0% to 100% by using the "PRG V". Operate the purge solenoid valve and check if the operation sound of the valve is heard.
 - a. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - b. If the operation sound is not heard, check the following.
 - Purge solenoid valve (Refer to page F-25.)



A/C CUT CONTROL INSPECTION


1. Turn the ignition switch to ON.
2. Shift the selector lever into other than P and N.
3. Turn the A/C switch and the blower switch on.
4. Fully open the throttle valve. Then 3—6 seconds after, check if the operation sound of the A/C compressor electromagnetic clutch is heard.
5. If the operation sound is not heard, do as follows.
 - (1) Connect **SSTs** (NGS) to the data link connector 2 located under the driver side dashboard.
 - (2) Select the "SIMULATION TEST" function on the NGS display.
 - (3) Turn the A/C relay from OFF to ON by using the "A/C RLY" and check for the operation sound of the relay.
 - I. If the operation sound is heard, check the following.
 - ECM terminal voltage (Refer to page F-31.)
 - Load/no load distinction signal
 - Throttle position sensor TVO signal
 - II. If the operation sound is not heard, check the following.
 - A/C relay (Refer to section U)
 - Open circuit in wiring harnesses and connectors (Ignition switch–A/C relay–ECM)

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

ENGINE ELECTRICAL SYSTEM

INDEX	G- 2
OUTLINE	G- 3
SPECIFICATIONS	G- 3
TROUBLESHOOTING GUIDE	G- 4
CHARGING SYSTEM	G- 6
PREPARATION	G- 6
BATTERY	G- 6
GENERATOR	G- 8
IGNITION SYSTEM	G-15
CIRCUIT DIAGRAM	G-15
SPARK PLUG	G-17
HIGH-TENSION LEAD	G-18
IGNITION COIL	G-18
DISTRIBUTOR	G-19
STARTING SYSTEM	G-21
PREPARATION	G-21
CIRCUIT DIAGRAM	G-21
STARTER	G-21

INDEX



- | | | | |
|------------------------------|-----------|------------------------------|-----------|
| 1. Battery | | 5. Ignition coil | |
| Inspection | page G- 6 | Inspection | page G-18 |
| Recharging | page G- 6 | 6. Distributor | |
| Diagnosis | page G- 7 | Spark test | page G-19 |
| 2. Generator | | Removal / Installation | page G-19 |
| Troubleshooting | page G- 9 | Disassembly / Assembly | page G-20 |
| Removal | page G-11 | 7. Starter | |
| Disassembly / Assembly | page G-12 | On-vehicle inspection | page G-21 |
| Inspection | page G-13 | Removal / Installation | page G-22 |
| Installation | page G-14 | Disassembly / Assembly | page G-23 |
| 3. Spark plug | | Inspection | page G-24 |
| Spark test | page G-17 | Checking operation | page G-26 |
| Removal / Installation | page G-17 | 8. Ignition control module | |
| Inspection | page G-17 | | |
| 4. High-tension lead | | | |
| Removal / Installation | page G-18 | | |
| Inspection | page G-18 | | |

OUTLINE

SPECIFICATIONS

Item		Engine	JE	
Battery	Voltage	V	12, Negative ground	
	Type and capacity (5-hour rate Ah)		55D23L (48), 75D26L (52) ^{*2} Maintenance-free	
Dark current ^{*1}		mA	Max. 20.0	
Generator	Type		A.C.	
	Output	V-A	12-70	
	Regulator type		Transistorized (built-in voltage regulator)	
	Regulated voltage	V	14.1—14.7 [20 °C { 68 °F }]	
	Brush length mm { in }	Standard		21.5 { 0.846 }
Minimum			8.0 { 0.315 }	
Starter	Type		Reduction	
	Output	V-kW	12-1.0, 12-1.7 ^{*2}	
	Brush length mm { in }	Standard		12.3 { 0.48 }, 16.5 { 0.65 } ^{*2}
		Minimum		7.0 { 0.28 }, 7.0 { 0.28 } ^{*2}
Distributor	Type		Electronic spark advance	
Ignition timing		BTDC	11 ° (TEN terminal grounded)	
Spark plug	Type	NGK	BKR5E-11 ^{*3} BKR6E-11	
		NIPPON-DENSO	K16PR-U11 ^{*3} K20PR-U11	
	Plug gap	mm { in }	1.0—1.1 { 0.040—0.043 }	
	Firing order		1—2—3—4—5—6	

*1 Dark current is the constant flow of current while the ignition switch is (i.e. audio unit, clock, etc.)

*2 Cold area

*3 Standard plug

G

TROUBLESHOOTING GUIDE

Problem	Page
Will not crank	G-4
Discharged battery	G-4
Cranks slowly	G-5
Misfire	G-5

Will Not Crank

On-vehicle check

“Clicks” when ignition switch turned ON.

(Ignition switch OK.)

Check battery and starter.

Possible cause	Remedy	Page
Battery and related parts		
Poor contact of battery terminal(s)	Clean and tighten	G-6
Poor ground of negative cable	Clean and repair	G-6
Insufficient voltage caused by battery malfunction	Replace	G-6, 7
Voltage drop caused by discharged battery	Repair or recharge	G-4
Ignition switch and related parts		
Poor contact at ignition switch	Repair or replace	section T
Loose connector(s)	Repair	section T
Broken wire between ignition switch and magnetic switch	Repair or replace	section T
Starter		
Loose wiring and/or connectors	Repair or replace	G-23
Burnt or improper contact of magnetic switch contact plate	Replace	G-23
Worn parts	Replace	G-23
Others	Repair or replace	G-23

Discharged Battery

* Numbers show checking order.

Condition	Related parts	Battery	Generator	Drive belt
		Vehicle not operated for extended period	1	
Electrical load	Heavy use	1	2	
	Load left on	1		
Normal use		3	2	1

Part	Remedy	Page
Battery	Recharge or replace	G-6, 7
Generator	Repair or replace	G-11, 12
Drive belt	Adjust or replace	section B

Cranks Slowly


Possible cause	Remedy	Page
Battery and related parts		
Poor contact of battery terminal(s)	Clean and tighten	G-6
Poor ground of negative cable	Clean and repair	G-6
Insufficient voltage caused by battery malfunction	Replace	G-6, 7
Voltage drop caused by discharged battery	Repair or recharge	G-4
Starter		
Loose wiring and/or connectors	Repair or replace	G-23
Burnt or improper contact of magnetic switch contact plate	Replace	G-23
Worn parts	Replace	G-23
Others	Repair or replace	G-23

G

	Refer to	Page
Misfire		
No spark, weak spark	Ignition system troubleshooting	G-16

CHARGING SYSTEM

PREPARATION
SST

<p>49 G032 354 Adjust wrench</p> 	<p>For removal and installation of P/S pulley</p>
--	---

BATTERY
Inspection

Warning

- Hydrogen gas is produced during normal battery operation. A battery-related explosion can cause serious injury. Keep all flames (including cigarettes), heat, and sparks away from the top and surrounding area of open battery cells.

Caution


- To prevent damage to electrical components or the battery, turn all accessories off and stop the engine before performing maintenance or recharging the battery.

Temperature (°C { °F })		Specific gravity of electrolyte
-40	-40	1.322
-30	-22	1.315
-20	-4	1.308
-10	14	1.301
0	32	1.294
10	50	1.287
20	68	1.280
30	86	1.273
40	104	1.266
50	122	1.259
60	140	1.252

Charged rate : 100%

Electrolyte level and specific gravity

- Verify that the electrolyte level is between the "Upper" and "Lower" level marks.
- Add distilled water if necessary, but do not overfill.
- Check the specific gravity with a hydrometer. If 1.200 or less, recharge the battery.




Terminal and cable

- Remove any corrosion on the clamps or battery posts, and coat them with grease.
- Verify that the battery top is clean. If necessary, clean with baking soda and water.
- Verify that cables are not frayed or corroded. Repair or replace if necessary.
- Verify that cable clamps are tight.
- Verify that the rubber protector completely covers the positive terminal and clamp.

Recharging

Caution

- When disconnecting the battery, remove the negative cable first and install it last to prevent damage to electrical components or the battery.
- Do not quick charge for over 30 minutes. It will damage the battery.




Battery	Slow charge (A)	Quick charge (A)
55D23L	4.5—5.5	Max. 30
75D26L	5.0—6.0	Max. 35

Diagnosis
Voltage check

1. Disconnect the battery terminals from the battery.
2. Connect a voltmeter to the battery.

G

Battery discharge test





Test load chart

Battery	Load (A)
55D23L	180
75D26L	195

Battery voltage with load

Approximate battery temp.	Minimum voltage (V)
21 °C { 70 °F }	9.6
15 °C { 60 °F }	9.5
10 °C { 50 °F }	9.4
4 °C { 40 °F }	9.3
-1 °C { 30 °F }	9.1
-7 °C { 20 °F }	8.9
-12 °C { 10 °F }	8.7
-18 °C { 0 °F }	8.5

GENERATOR
Charging System




On-board Diagnosis System

The generator has an on-board diagnostic function to warn the driver of the following problems in the charging system. If a problem arises, the generator warning light illuminates.

1. S circuit open
2. No voltage output
3. Field circuit open
4. B circuit open
5. Voltage output too high


Troubleshooting
Preliminary check

1. Turn the ignition switch to ON, and check that the generator warning light illuminates.
2. Start the engine, and check that the generator warning light goes out.




G

1. Generator warning light will not illuminate



2. Generator warning light illuminates when engine running



3. Battery discharged

Does generator warning light illuminate when engine running?

YES

Perform Troubleshooting No.2 (Refer to page G-9)

NO



- Check generator warning light circuit
- Check other electrical components


MAXIMUM OUTPUT TEST

1. Connect an ammeter (**75 A min.**) between terminal B wire and terminal B.
2. Turn all headlights and accessories on and depress the brake pedal.
3. Start the engine and verify that the output current is **70 A or more** at **2,500—3,000 rpm**.

Caution

- **Grounding terminal B can damage the generator and other electrical components.**






Removal

Caution

- Reversing the battery connections or using high-voltage testers will damage the rectifier.
- Do not start the engine while the connector is disconnected from terminals L and S. It can damage the generator.
- When the battery cables are connected, touching the vehicle body with generator terminal B will generate sparks. This can cause personal injury, fire, and damage to the electrical components. Always disconnect the battery before performing the following operation.

Note


- Battery positive voltage is always present at generator terminal B when the battery is connected.



1. Disconnect the negative battery cable.
2. Disconnect the wire and connector from the generator.
3. Remove the power steering pulley by using the SST. (Refer to page G-22.)
4. Remove the generator bolts.
5. Remove the drive belt.
6. Remove the generator.


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



- | | |
|------------------|-----------|
| 1. Pulley | |
| 2. Front cover | |
| 3. Rotor | |
| Inspection | page G-13 |
| 4. Rear bracket | |
| 5. Stator | |
| Inspection | page G-13 |

- | | |
|--------------------------|-----------|
| 6. Rectifier | |
| Inspection | page G-14 |
| 7. Brush holder assembly | |
| Inspection | page G-13 |
| 8. Bearing | |
| Inspection | page G-14 |




Inspection

Rotor

1. Wiring damage
 - (1) Measure the resistance between the slip rings by using an ohmmeter.


Specification: 2.4—2.9 Ω [20 °C { 68 °F }]

- (2) If it is not within the specification, replace the rotor.




2. Ground of field coil
 - (1) Check continuity between the slip ring and the core by using an ohmmeter.
 - (2) Replace the rotor if there is continuity.
3. Slip ring surface

If the slip ring surface is rough, use a lathe or fine sandpaper to repair it.




Stator

1. Wiring damage
 - (1) Check for continuity between the stator coil leads by using an ohmmeter.
 - (2) Replace the stator if there is no continuity.



2. Ground of stator coil
 - (1) Check continuity between the stator coil leads and the core by using a circuit tester.
 - (2) Replace the stator if there is continuity.




Brush

If any brush is worn almost to or beyond the limit, replace all of the brushes.

Standard: 21.5 mm { 0.846 in }

Minimum: 8.0 mm { 0.315 in }


**Brush spring**

1. Measure the force of the brush spring by using a spring pressure gauge. Read the spring pressure gauge at the brush tip projection of **2 mm { 0.079 in }**.
2. Replace the spring if necessary.

Standard force:

3.2—4.3 N { 0.32—0.44 kgf , 0.71—0.96 lbf }



Minimum: 1.8 N { 0.18 kgf , 0.4 lbf }

**Rectifier**

1. Check continuity of the diodes by using an ohmmeter.

Negative (Black)	Positive (Red)	Continuity
E	P1, P2, P3	Yes
B		No
T		No
P1, P2, P3	E	No
	B	Yes
	T	Yes

2. Replace the rectifier if not as specified.

**Bearing**

1. Check for abnormal noise, looseness, and sticking.
2. Replace if necessary.

Installation

1. Install the generator, and tighten the bolts to the specified torque.
2. Install in the reverse order of removal.

Tightening torque**Bolt ①:**

32—46 N·m { 3.2—4.7 kgf·m , 23—33 ft·lbf }

Bolt ②:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }


Nut ③:

40—58 N·m { 4.0—6.0 kgf·m , 29—43 ft·lbf }

Nut ④:


9.9—14.7 N·m

{ 100—150 kgf·cm , 86—130 in·lbf }



IGNITION SYSTEM

CIRCUIT DIAGRAM




Troubleshooting


1. Disconnect the fuel pump relay. (Refer to section F.)
2. Verify that each high-tension lead and connector is connected properly.
3. Inspect the ignition system in the following procedure.

Warning

- **High voltage in the ignition system can cause strong electrical shock. Avoid direct contact to the vehicle body during the following spark test.**

Remove high-tension lead from spark plug. Hold high-tension lead with insulated pliers 5—10 mm {0.20—0.39 in} from ground. Turn ignition switch to START and verify that there is a strong blue spark. (Check each cylinder)






SPARK PLUG

Spark Test

1. Disconnect the high-tension lead from the spark plug.
2. Connect a new spark plug to the high-tension lead.
3. Hold it with insulated pliers **approx. 5—10 mm { 0.20—0.39 in }** from a ground.
4. Crank the engine and verify that a strong blue spark is visible.



Removal / Installation

Caution

- Pulling on the wire part of the spark plug lead may break it. To remove the lead, pull only on the boot.
- To avoid breaking the spark plug, be sure to fit the socket squarely over it.

Tighten to the specified torque.

Spark plug tightening torque:


15—22 N·m { 1.5—2.3 kgf·m , 11—16 ft·lbf }


Inspection

Check the following points. If a problem is found, replace the spark plug.

1. Damaged insulation
2. Worn electrodes
3. Carbon deposits
4. Damaged gasket

Plug gap: 1.0—1.1 mm { 0.040—0.043 in }





HIGH-TENSION LEAD Removal / Installation

Caution


- Incorrect installation can damage the leads and cause power loss, and negatively effect electronic components.

Reinstall the high-tension leads to their original positions.

Inspection

Use an ohmmeter to measure the resistance.

Resistance: 16 k Ω /1.00 m { 3.28 ft }



IGNITION COIL


Inspection

Primary coil winding

1. Disconnect the distributor 3-pin connector.
2. Measure the resistance between terminals A and B by using an ohmmeter.

Specification: 0.49—0.74 Ω [20 °C { 68 °F }]

3. If not as specified, replace the distributor.




Secondary coil winding

1. Disconnect the distributor 3-pin connector.
2. Remove the distributor cap.
3. Measure the resistance as shown in the figure by using an ohmmeter.

Specification: 20—31 k Ω [20 °C { 68 °F }]

4. If not as specified, replace the distributor.



DISTRIBUTOR
Spark Test


Warning

- High voltage in the ignition device system can cause strong electrical shock. Avoid direct contact to the vehicle body during the following spark test.

1. Remove the spark plug.
2. Connect the spark plug to a high-tension lead.
3. Hold the high-tension lead with insulated pliers 5—10 mm { 0.20—0.39 in } from a ground.
4. Crank the engine and verify that there is a strong blue spark. If not, replace the spark plug or high-tension lead as necessary.


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation note**.



1. High-tension leads
2. Connect


3. Distributor
Installation note below

**Installation Note**

Verify that the No.1 cylinder is at top dead center and align the distributor matching marks.
After installing the distributor, adjust the ignition timing.
(Refer to section F.)

Disassembly / Assembly

1. Disassembly in the order shown in the figure.
2. Assembly in the reverse order of disassembly.




1. Cap
2. Rotor



3. Distributor set

STARTING SYSTEM

PREPARATION
SST

<p>49 G032 354</p> <p>Adjust wrench</p> 	<p>For removal and installation of P/S pulley</p>
---	---

CIRCUIT DIAGRAM


**STARTER****On-Vehicle Inspection**

Charge the battery fully before starting the following inspection.

1. Turn the ignition switch to START.
2. Verify that the starter motor operates.
3. If the starter does not operate, measure the voltage between terminal S and a ground.
4. If the voltage is 8 V or more, the starter is malfunctioning.
5. If less than 8 V, the wire harness is defective.

Note

- If the magnetic switch is hot, it may not function even though the voltage is standard voltage or more.



Removal / Installation

2WD

1. Disconnect the negative battery cable.
2. Disconnect the wiring from the starter.
3. Raise the front of the vehicle and support it with safety stands.
4. Remove the starter bolts; remove the lower bolt last.
5. Draw out the starter from under side of the vehicle.
6. Install in the reverse order of removal.

Tightening torque

Nut (A):


9.9—11.7 N·m { 1.0—1.2 kgf·m , 7.3—8.6 ft·lbf }

Bolt (B):


32—46 N·m { 3.2—4.7 kgf·m , 24—33 ft·lbf }

4WD

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal.



- | | |
|----------------------------------|-------------------------------|
| 1. Drive belt | 7. AT oil pipe bracket |
| 2. P/S pulley | 8. Front propeller shaft |
| 3. Wire and connector | 9. Wiring harness bracket |
| 4. Generator | 10. AT oil pipe bracket |
| 5. Undercover | 11. Wire and connector |
| 6. P/S oil pump | 12. Fuel and brake pipe cover |
| Removal Note page G-23 | 13. Starter |




Removal note
P/S oil pump

Remove the P/S oil pump with the hoses still connected to it to remove the AT oil pipe brackets.


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.




- | | | |
|--------------------------|------------------|-----------|
| 1. Magnetic switch | Inspection | page G-25 |
| 2. Rear housing | | |
| 3. Brush holder assembly | Inspection | page G-26 |
| 4. Armature | Inspection | page G-24 |

- | | | |
|-------------------|------------------|-----------|
| 5. Yoke | Inspection | page G-25 |
| 6. Planetary gear | | |
| 7. Front cover | | |
| 8. Drive pinion | | |
| 9. Internal gear | | |
| 10. Gear shaft | | |

**Inspection****Armature**


1. Ground of armature coil
Check continuity between the commutator and the core by using a circuit tester. Replace the armature if there is continuity.



2. Runout of commutator
 - (1) Place the armature on V-blocks, and measure the runout by using a dial indicator.
 - (2) If the runout is at the limit or more, repair by using a lathe or replace the armature.


Standard runout: 0.05 mm { 0.002 in }

Limit: 0.1 mm { 0.004 in }



3. Outer diameter of commutator
Replace the armature if the outer diameter of the commutator is at the wear limit or less.
4. Roughness of commutator surface
If the commutator surface is dirty, wipe it with a cloth; if it is rough, repair by using a lathe or fine sandpaper.


Wear limit: 28.8 mm { 1.14 in }



5. Segment groove depth
If the depth of the mold between segments is at the minimum depth or less, undercut the grooves to the standard depth.

Standard depth: 0.5 mm { 0.020 in }


Minimum depth: 0.2 mm { 0.008 in }



Yoke


Field coil

1. Wiring damage
 - (1) Check for continuity between the connector and the brushes by using a circuit tester.
 - (2) Replace the yoke assembly if there is no continuity.



2. Ground of field coil
 - (1) Check continuity between the connector and the yoke by using a circuit tester.
 - (2) Repair or replace the yoke assembly if there is continuity.
3. Installation of field coil


Replace the yoke assembly if the field coil is loose.



Magnetic switch


1. Wiring damage (terminal S — terminal M)

Check for continuity between terminals S and M by using a circuit tester. Replace the magnetic switch if there is no continuity.




2. Wiring damage (terminal S — body)

Check for continuity between terminal S and the body by using a circuit tester. Replace the magnetic switch if there is no continuity.




3. Ground of magnetic switch

Check continuity between terminals M and B by using a circuit tester. Replace the magnetic switch if there is continuity.



Brush holder assembly


Check continuity between the insulated brush and the plate by using a circuit tester. Replace the brush holder if there is continuity.



Brush

If any brush is worn almost to or beyond the wear limit, replace all of the brushes.

Type	kw	1.0	1.7
Standard	mm { in }	2.3 { 0.48 }	16.5 { 0.65 }
Minimum	mm { in }	7.0 { 0.28 }	7.0 { 0.28 }




Checking Operation

Magnetic switch

Make the following tests:

Pull-out test


Apply battery positive voltage to terminal S and ground the body, and verify that the pinion is pulled out.



Measure the pinion gap while the pinion is pulled out.


Specification: 0.5—2.0 mm { 0.02—0.08 in }

If not within the specification, adjust with an adjustment washer (drive housing front cover—magnetic switch).



Return test

1. Disconnect the motor wire from terminal M, and then connect the battery power to terminal M and ground the body.
2. Pull out the drive pinion by using a screwdriver. Verify that the drive pinion returns to its original position when released.



No-load test

1. After adjusting the pinion gap, form a test circuit with a voltmeter and an ammeter.
2. Close switch K to run the starter.
3. Check for the following:

Type	kW	1.0	1.7
Voltage	V	11.0	11.0
Current	A	90 max.	90 max.
Gear shaft speed	rpm	2,800 min.	3,600 min.

4. If not as specified, check for the cause according to "Inspection". (Refer to page G-24.)


Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

AUTOMATIC TRANSMISSION (Electronically-Controlled)

K1

INDEX	K1- 2	HIGH CLUTCH AND FRONT SUN	
OUTLINE	K1- 3	GEAR	K1- 59
SPECIFICATIONS	K1- 3	BAND SERVO	K1- 64
CROSS-SECTIONAL VIEW	K1- 4	FRONT INTERNAL GEAR, REAR INTERNAL	
POWER FLOW DIAGRAM	K1- 5	GEAR, FORWARD CLUTCH HUB,	
OPERATION OF COMPONENTS	K1- 5	OVERRUNNING CLUTCH HUB	K1- 68
FLUID PASSAGE LOCATION	K1- 6	FORWARD CLUTCH DRUM	
MECHANICAL SYSTEM TEST	K1- 8	(FORWARD CLUTCH, OVERRUNNING	
PREPARATION	K1- 8	CLUTCH, LOW ONE-WAY CLUTCH) .	K1- 71
MECHANICAL SYSTEM TEST		LOW AND REVERSE BRAKE	K1- 79
PREPARATION	K1- 8	EXTENSION HOUSING AND PARKING	
LINE PRESSURE TEST	K1- 8	MECHANISM	K1- 85
STALL TEST	K1-10	OIL SEAL	K1- 90
TIME LAG TEST	K1-11	CONTROL VALVE BODY	K1- 91
ROAD TEST	K1-13	UPPER VALVE BODY	K1- 96
ROAD TEST PREPARATION	K1-13	LOWER VALVE BODY	K1-104
SHIFT DIAGRAM	K1-13	CONTROL VALVE BODY	K1-109
D RANGE TEST	K1-14	ON-VEHICLE REMOVAL	K1-112
2 RANGE TEST	K1-16	ON-VEHICLE INSTALLATION	K1-114
1 RANGE TEST	K1-16	TRANSMISSION UNIT (ASSEMBLY) ..	K1-116
P POSITION TEST	K1-16	TRANSMISSION UNIT	
ELECTRICAL SIGNAL INSPECTION	K1-17	(INSTALLATION)	K1-129
PREPARATION	K1-17	OIL COOLER	K1-133
ELECTRICAL SIGNAL INSPECTION ...	K1-18	DRIVE PLATE	K1-135
ELECTRONIC SYSTEM COMPONENTS .	K1-23	SHIFT MECHANISM	K1-137
O/D OFF SWITCH	K1-23	SHIFT-LOCK AND KEY INTERLOCK	
TRANSMISSION RANGE SWITCH	K1-23	SYSTEM	K1-137
TRANSMISSION FLUID TEMPERATURE		SELECTOR LEVER	K1-138
SENSOR	K1-24	ON-BOARD DIAGNOSTIC SYSTEM	K1-141
OUTPUT SPEED SENSOR	K1-25	PREPARATION	K1-141
SOLENOID VALVES	K1-26	DIAGNOSTIC TROUBLE CODE	K1-141
DROPPING RESISTOR	K1-26	TROUBLESHOOTING	K1-161
TRANSMISSION FLUID TEMPERATURE		GENERAL NOTES	K1-161
SWITCH (4WD)	K1-26	QUICK DIAGNOSIS CHART	K1-162
TRANSMISSION CONTROL		HYDRAULIC CIRCUIT	K1-166
MODULE	K1-27	P POSITION	K1-166
AUTOMATIC TRANSMISSION FLUID		R POSITION	K1-167
(ATF)	K1-30	N POSITION	K1-168
INSPECTION	K1-30	D RANGE; FIRST GEAR	K1-169
REPLACEMENT	K1-30	D RANGE; SECOND GEAR	K1-170
TRANSMISSION	K1-32	D RANGE; THIRD GEAR	K1-171
TRANSMISSION UNIT (REMOVAL)	K1-32	D RANGE; FOURTH GEAR, TORQUE	
TRANSMISSION UNIT		CONVERTER CLUTCH OFF	K1-172
(DISASSEMBLY)	K1-35	D RANGE; FOURTH GEAR, TORQUE	
TORQUE CONVERTER	K1-46	CONVERTER CLUTCH ON	K1-173
ACCUMULATORS	K1-47	2 RANGE; SECOND GEAR	K1-174
OIL PUMP	K1-49	1 RANGE; FIRST GEAR	K1-175
REVERSE CLUTCH	K1-53		

INDEX



- 1. O/D OFF switch
Inspection page K1-23
- 2. Transmission range switch
Inspection page K1-23
Adjustment page K1-24
- 3. Transmission fluid temperature sensor
Inspection page K1-24
- 4. Output speed sensor
Inspection page K1-25
- 5. Solenoid valves
Inspection page K1-26
- 6. Dropping resistor
Inspection page K1-26
- 7. Transmission fluid temperature switch (4WD)
Inspection page K1-26
- 8. Transmission control module
Inspection page K1- 27
- 9. Transmission
Removal page K1- 32
Disassembly page K1- 35
Assembly page K1-116
Installation page K1-129
- 10. Oil cooler(s)
Removal / Installation page K1-133
- 11. Selector lever
Inspection page K1-138
Adjustment page K1-138
Removal / Inspection /
Installation page K1-139


K1

OUTLINE


SPECIFICATIONS

Item	Model	RA4A-EL	RA4AX-EL	
		2WD	4WD	
Torque converter stall torque ratio		2.000		
Gear ratio	First gear	3.027	2.786	
	Second gear	1.619	1.546	
	Third gear	1.000		
	Fourth gear	0.694		
	Reverse	2.272		
Number of drive/ driven plates	Reverse clutch	2/2		
	High clutch	4/7		
	Forward clutch	6/6		
	Overrunning clutch	3/5		
	Low and reverse brake	6/6		
Automatic transmission fluid (ATF)	Type	Dexron®II or M-III		
	Capacity L { US qt , Imp qt }	Total	8.6 { 9.1 , 7.6 }	
		Oil pan	4.0 { 4.2 , 3.5 }	

CROSS-SECTIONAL VIEW



POWER FLOW DIAGRAM




K1

OPERATION OF COMPONENTS


Position/Range	Mode	Gear	Reverse clutch	High clutch	Forward clutch	Over-running clutch	Brake band			Forward one-way clutch	Low one-way clutch	Low and reverse brake	
							2GR applied	3GR released	4GR applied				
P	—	—											
R	—	Reverse	○									○	
N		—											
D	Except O/D OFF	1			○	■				●	●		
		2			○	□	○			●			
		3		○	○	○	□	⊗ ^{*1}	⊗		●		
	O/D OFF	4		○	⊗			⊗ ^{*2}	⊗	○			
		1				○	■				●	●	
		2				○	⊙	○			●		
		3		○	○	⊙	⊗ ^{*1}	⊗		●			
2	—	2			○	⊙	○			●			
1	—	1			○	○				●		○	

- *1 : Hydraulic pressure is applied to both second gear applied side and third gear released side of band servo piston. However, because the area of the third gear released side is larger than the second gear applied side, the brake band does not operate.
- *2 : Hydraulic pressure is applied to fourth gear applied side, plus condition *1 above. Brake band is applied.
- : Operates.
- ⊙ : Operates when throttle opening is less than 1/8. Engine braking effect available.
- : Operates when the engine control module receives 4GR inhibit signal from the cruise control module and throttle opening is less than 1/8. Engine braking effect available.
- : Operates when the engine control module receives 4GR inhibit signal from the cruise control module and throttle opening is less than 1/8. Engine braking effect not available.
- ⊗ : Operates but does not transmit power.
- : Operates during acceleration and cruising.

FLUID PASSAGE LOCATION
Transmission Case




Oil Pump





K1

Input Shaft





Output Shaft



MECHANICAL SYSTEM TEST

PREPARATION

SST


<p>49 0378 400A</p> <p>Gauge set, oil pressure</p> 	<p>For oil pressure test</p>	<p>49 H019 002</p> <p>Adapter</p> 	<p>For oil pressure test</p>
--	------------------------------	---	------------------------------

MECHANICAL SYSTEM TEST PREPARATION

1. Engage the parking brake and use wheel chocks at the front and rear of the wheels.
2. Check the engine coolant. (Refer to section E.)
3. Check the engine oil. (Refer to section B.)
4. Check the ATF level. (Refer to page K1-30.)
5. Check the idle speed and ignition timing in P position. (Refer to section F.)

LINE PRESSURE TEST

Procedure



1. Connect the **SST** to the line pressure inspection hole.
2. Shift the selector lever to D range and read the line pressure at idle.

Caution

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transmission could be damaged. Therefore, do steps 3 and 4 within 5 seconds of each other.

3. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot.
4. Read the line pressure as soon as the engine speed becomes constant, then release the accelerator pedal.
5. Shift the selector lever to N position and let the engine idle for one minute or more to cool the ATF.
6. Read the line pressure at idle and at the engine stall speed for each range in the same manner.



**Specified line pressure:
(2WD)**

Position /Range	Line pressure kPa { kgf/cm ² , psi }	
	Idle	Stall
D, 2, 1	500—530 { 5.0—5.4 , 71—77 }	1,200-1,270 { 12.2—13.0 , 174—185 }
R	620—650 { 6.3—6.7 , 89—95 }	1,510—1,570 { 15.3—16.1 , 217—229 }

(4WD)

Position /Range	Line pressure kPa { kgf/cm ² , psi }	
	Idle	Stall
D, 2, 1	440—470 { 4.4—4.8 , 63—68 }	1,040—1,110 { 10.6—11.4 , 150—162 }
R	600—630 { 6.1—6.5 , 87—92 }	1,460—1,530 { 14.8—15.6 , 210—222 }


1. Install new plugs in the inspection ports.

Tightening torque: 4.9—9.8 N·m { 50—100 kgf·cm , 43—87 in·lbf }

Evaluation of Line Pressure Test

Condition		Possible cause
When idling	Low pressure in every range	Worn oil pump Damaged control piston (in oil pump) Pressure regulator valve or plug sticking Damaged pressure regulator valve spring Fluid leaking between oil strainer and pressure regulator valve
	Low pressure in forward ranges	Fluid leaking from hydraulic circuit of forward clutch
	Low pressure in 2 ranges	Fluid leaking from hydraulic circuit of band servo second gear apply side
	Low pressure in R position only	Fluid leaking from hydraulic circuit of reverse clutch
	Low pressure in R position and 1 ranges only	Fluid leaking from hydraulic circuit of low and reverse brake
	Higher than specification	Throttle position sensor out of adjustment Damaged transmission fluid temperature sensor Pressure control solenoid sticking Short circuit of pressure control solenoid circuit Pressure modifier valve sticking Pressure regulator valve or plug sticking
At stall speed	Low pressure	Throttle position sensor out of adjustment Damaged control piston (in oil pump) Pressure control solenoid sticking Short circuit of pressure control solenoid circuit Pressure regulator valve or plug sticking Pressure modifier valve sticking Pilot valve sticking

STALL TEST Procedure



1. Shift the selector lever to R position.

Caution

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transmission could be damaged. Therefore, do steps 4 and 5 within 5 seconds of each other.
2. Firmly depress the foot brake with the left foot, and gently depress the accelerator pedal with the right.
 3. When the engine speed no longer increases, quickly read the engine speed and release the accelerator.
 4. Shift the selector lever to N position and let the engine idle for one minute or more to cool the ATF.


5. Perform the stall test for the following ranges in the same manner.
 (1) D range
 (2) 2 range
 (3) 1 range

Engine stall speed: 2,300—2,600 rpm

Evaluation of Stall Test

Condition		Possible cause	
Above specification	In all ranges and R position	Insufficient line pressure	Worn oil pump
			Oil leakage from oil pump, control valve, and/or transmission case
		Stuck pressure regulator valve	
	In D and 2 ranges	Forward clutch slipping Forward one-way clutch slipping Low one-way clutch slipping	
	In R position	Low and reverse brake slipping Reverse clutch slipping Perform road test to determine whether problem is in low and reverse brake or in reverse clutch a) Engine brake applied in 1 range first gear ...Reverse clutch b) Engine brake not applied in 1 range first gear ...Low and reverse brake	
Within specification		All shift control elements within transmission are functioning normally	
Below specification		Engine out of tune	
		One-way clutch slipping within torque converter	

TIME LAG TEST
 Procedure



1. Shift the selector lever from N position to D range.
2. Use a stopwatch to measure the time it takes from shifting until shock is felt.
3. Shift the selector lever to N position and let the engine idle for one minute or more to cool the ATF.
4. Do the time lag test for the following shifts in the same manner. Make three measurements for each test and average the results.
 - (1) N position→D range
 - (2) N position→D range (O/D OFF mode)
 - (3) N position→R position

Specified time lag

N position→D range **0.5—1.5 second**
N position→R position **0.7—1.7 second**

Evaluation of Time Lag Test



Condition		Possible cause
Above specification	N→D and N→D (O/D OFF mode) shift	Insufficient line pressure Forward clutch slipping Forward one-way clutch slipping
	N→D shift	Insufficient line pressure Low one-way clutch slipping N-D accumulator not operating properly
	N→D (O/D OFF mode) shift	Insufficient line pressure Brake band slipping 1-2 accumulator not operating properly
	N→R shift	Insufficient line pressure Reverse clutch slipping Low and reverse brake slipping 3-4/N-R accumulator not operating properly

ROAD TEST

ROAD TEST PREPARATION

1. Check the engine coolant. (Refer to section E.)
2. Check the engine oil. (Refer to section B.)
3. Check the ATF level. (Refer to page K1-30.)
4. Check the idle speed and ignition timing in P position. (Refer to section F.)

SHIFT DIAGRAM



D RANGE TEST**D range (Except O/D OFF mode)****Note**

- The POWER mode and the NORMAL mode are automatically selected by the transmission control module.

1. Shift the selector lever to D range.
2. Accelerate the vehicle to half throttle and wide open throttle.
3. Verify that 1–2, 2–3, and 3–4 upshifts and downshifts are obtained. The shift points must be as shown in the table in the next page.
4. Drive the vehicle in fourth, third, and second gears and verify that kickdown occurs for 4→3, 4→2, 3→2, 3→1, 2→1, and that the shift points are as shown in the table in the following page.
5. Decelerate the vehicle and verify that engine braking effect is felt in fourth and third gears.

Note

- There is torque converter clutch non-operation in the following conditions.
 1. The ATF temperature is below 10 °C { 50 °F }.
 2. The accelerator pedal is at the closed throttle position (closed throttle position switch ON) while the vehicle is being driven below 120 km/h { 74 mph }.

6. Drive the vehicle and verify that torque converter clutch operation is obtained.

D range (O/D OFF mode)

1. Turn the O/D OFF switch from OFF to ON.
2. Accelerate the vehicle to half throttle and wide open throttle, and verify that 1–2 and 2–3 upshift and downshift are obtained. The shift points must be as shown in the table below.
3. Drive the vehicle in third and second gears and verify that kickdown occurs for 3→2, 3→1, 2→1, and that the shift points are as shown in the table in the following page.
4. Decelerate the vehicle and verify that engine braking effect is felt in third gear.

Noise and vibration

Drive the vehicle in fourth gear (torque converter clutch operation), fourth gear (torque converter clutch non-operation), and second gear (O/D OFF mode), and listen closely for any out of the ordinary noise or vibration. The torque converter, propeller shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

Shift Point

Range	Mode		Throttle condition (Throttle position sensor voltage)	Shift	Vehicle speed km/h { mph }		
					2WD	4WD	
D	Except O/D OFF	POWER	Wide open throttle	D ₁ →D ₂	51—57 { 32—35 }	54—60 { 34—37 }	
				D ₂ →D ₃	101—109 { 63—67 }	102—110 { 64—68 }	
				TCC ON (D ₃)	98—106 { 61—65 }	98—106 { 61—65 }	
				D ₃ →D ₄	159—169 { 99—104 }	155—165 { 97—102 }	
			Half throttle	D ₁ →D ₂	39—49 { 25—30 }	39—49 { 25—30 }	
				D ₂ →D ₃	62—79 { 39—48 }	63—81 { 40—50 }	
				TCC ON (D ₃)	94—106 { 59—65 }	94—106 { 59—65 }	
				D ₃ →D ₄	102—131 { 64—81 }	102—131 { 64—81 }	
			TCC ON (D ₄)	D ₄ →D ₃	126—154 { 79—95 }	126—154 { 79—95 }	
				D ₄ →D ₃	44—50 { 28—31 }	44—50 { 28—31 }	
				D ₃ →D ₂	22—28 { 14—17 }	22—28 { 14—17 }	
			Closed throttle position	D ₂ →D ₁	6—12 { 4—7 }	6—12 { 4—7 }	
		D ₄ →D ₃		149—159 { 93—98 }	145—155 { 90—96 }		
		D ₃ →D ₂		87—95 { 54—58 }	92—100 { 58—62 }		
		Kickdown	D ₂ →D ₁	42—48 { 27—29 }	42—48 { 27—29 }		
			D ₁ →D ₂	51—57 { 32—35 }	54—60 { 34—37 }		
			D ₂ →D ₃	101—109 { 63—67 }	102—110 { 64—68 }		
		O/D OFF	POWER	Wide open throttle	TCC ON (D ₃)	98—106 { 61—65 }	98—106 { 61—65 }
					D ₃ →D ₄	159—169 { 99—104 }	155—165 { 97—102 }
					D ₁ →D ₂	28—36 { 18—22 }	29—38 { 18—23 }
					D ₂ →D ₃	54—70 { 34—43 }	52—69 { 33—42 }
				Half throttle	TCC ON (D ₃)	94—106 { 59—65 }	94—106 { 59—65 }
					D ₃ →D ₄	70—98 { 44—60 }	69—96 { 43—59 }
					TCC ON (D ₄)	70—97 { 44—60 }	70—96 { 44—59 }
	D ₄ →D ₃				22—28 { 14—17 }	22—28 { 14—17 }	
	Closed throttle position			D ₃ →D ₂	11—19 { 7—11 }	12—18 { 8—11 }	
				D ₂ →D ₁	6—12 { 4—7 }	6—12 { 4—7 }	
				D ₄ →D ₃	126—136 { 79—84 }	145—155 { 90—96 }	
	Kickdown			D ₃ →D ₂	81—89 { 51—55 }	92—100 { 58—62 }	
			D ₂ →D ₁	42—48 { 27—29 }	42—48 { 27—29 }		
			D ₁ →D ₂	51—57 { 32—35 }	54—60 { 34—37 }		
	NORMAL		Wide open throttle	D ₂ →D ₃	101—109 { 63—67 }	102—110 { 64—68 }	
				TCC ON (D ₃)	98—106 { 61—65 }	98—106 { 61—65 }	
				D ₁ →D ₂	39—49 { 25—30 }	39—49 { 25—30 }	
				D ₂ →D ₃	62—79 { 39—48 }	63—81 { 40—50 }	
			Half throttle	TCC ON (D ₃)	94—106 { 59—65 }	94—106 { 59—65 }	
				D ₃ →D ₂	22—28 { 14—17 }	22—28 { 14—17 }	
				D ₂ →D ₁	6—12 { 4—7 }	6—12 { 4—7 }	
			Closed throttle position	D ₃ →D ₂	87—95 { 54—58 }	92—100 { 58—62 }	
				D ₂ →D ₁	42—48 { 27—29 }	42—48 { 27—29 }	
				D ₁ →D ₂	51—57 { 32—35 }	54—60 { 34—37 }	
		Kickdown	D ₂ →D ₃	101—109 { 63—67 }	102—110 { 64—68 }		
			TCC ON (D ₃)	98—106 { 61—65 }	98—106 { 61—65 }		
	D ₁ →D ₂		28—36 { 18—22 }	29—38 { 18—23 }			
	Half throttle	D ₂ →D ₃	54—70 { 34—43 }	52—69 { 33—42 }			
		TCC ON (D ₃)	94—106 { 59—65 }	94—106 { 59—65 }			
		D ₃ →D ₂	11—19 { 7—11 }	12—18 { 8—11 }			
		D ₂ →D ₁	6—12 { 4—7 }	6—12 { 4—7 }			
Closed throttle position	D ₃ →D ₂	81—89 { 51—55 }	92—100 { 58—62 }				
	D ₂ →D ₁	42—48 { 27—29 }	42—48 { 27—29 }				
	D ₁ →D ₂	51—57 { 32—35 }	54—60 { 34—37 }				
Kickdown	D ₂ →D ₁	42—48 { 27—29 }	42—48 { 27—29 }				

2 RANGE TEST

1. Shift the selector lever to 2 range.
2. Accelerate the vehicle with half throttle and wide open throttle, and verify that second gear is held.
3. Decelerate the vehicle and verify that engine braking effect is felt.

Noise and vibration

Drive the vehicle in second gear and listen closely for any out of the ordinary noise or vibration. The torque converter, propeller shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

Shift point

Range	Throttle condition (Throttle position sensor voltage)	Shift	Vehicle speed km/h { mph }	
			2WD	4WD
2	—	TCC ON (2 ₃)	95—105 { 59—65 }	95—105 { 59—65 }
		2 ₃ →2 ₂	100—106 { 63—65 }	101—107 { 63—66 }

1 RANGE TEST

1. Shift the selector lever to 1 range.
2. Accelerate the vehicle with half throttle and wide open throttle, and verify that first gear is held.
3. Decelerate the vehicle and verify that engine braking effect is felt.

Noise and vibration

Drive the vehicle in second gear and listen closely for any out of the ordinary noise or vibration. The torque converter, propeller shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

Shift point

Range	Throttle condition (Throttle position sensor voltage)	Shift	Vehicle speed km/h { mph }	
			2WD	4WD
1	—	1 ₂ →1 ₁	43—49 { 27—30 }	45—51 { 28—31 }

P POSITION TEST

Shift the selector lever into P position on a gentle slope, release the brake, and verify that the vehicle does not roll.













Evaluation

Condition		Possible Cause
Shifting	Starts in second gear or shifts directly from first gear to fourth gear	Stuck shift solenoid A Stuck shift valve A
	Starts in fourth gear	Stuck shift solenoid B Stuck shift valve B
	No shift	Stuck shift solenoid A and/or B Stuck shift valve A and/or B
	Incorrect shift points	Throttle position sensor out of adjustment Output speed sensor not operating properly
Shift shock felt or slipping	Stuck pressure control solenoid Accumulators not operating properly Throttle position sensor out of adjustment Output speed sensor not operating properly Transmission fluid temperature sensor not operating properly Worn clutches, one-way clutches, and/or brakes	
No engine braking	Stuck overrunning clutch solenoid Worn clutches and/or brakes	
Torque converter clutch non-operation	Stuck torque converter clutch solenoid Stuck torque converter clutch control valve	



ELECTRICAL SIGNAL INSPECTION

PREPARATION

SST

<p>49 G019 901 EC-AT Tester</p> 	<p>For inspection of electrical signal</p>	<p>49 H019 902 Adapter</p> 	<p>For inspection of electrical signal</p>
<p>49 L019 901 Adapter</p> 	<p>For inspection of electrical signal</p>	<p>49 L019 903 Panel</p> 	<p>For inspection of electrical signal</p>
<p>49 L019 901A Adapter</p> 	<p>For inspection of electrical signal</p>	<p>49 G019 901B EC-AT Tester</p> 	<p>For inspection of electrical signal</p>
<p>49 L019 902 Panel</p> 	<p>For inspection of electrical signal</p>	<p>49 G019 901C EC-AT Tester</p> 	<p>For inspection of electrical signal</p>
<p>49 L019 906 Adapter Harness</p> 	<p>For inspection of electrical signal</p>	<p>49 H019 913 Panel</p> 	<p>For inspection of electrical signal</p>
<p>49 G019 929 Power Harness</p> 	<p>For inspection of electrical signal</p>	<p>49 D088 008 Harness Adapter, Power</p> 	<p>For inspection of electrical signal</p>

EC-AT tester (49 G019 901C)



Inspection Procedure

Caution


- Do not connect the NGS to the data link connector 2 when EC-AT tester is connected to the transmission control module. Doing so can cause incorrect test results.

When using the EC-AT tester (49 G019 901) and adapter (49 L019 901)

1. Assemble the **SST**. (Refer to page K1-18.)
2. Set the **SST** (49 H019 902) vehicle switch to 929 position.
3. Turn the ignition switch and EC-AT tester main switch to ON.
4. Check indication of the respective light or digital display in each condition referring to the indication table on page K1-21.

When using the EC-AT tester (49 G019 901) and adapter (49 L019 901A)

1. Assemble the **SST**. (Refer to page K1-18.)
2. Set the **SST** (49 H019 902) vehicle switch to 929 position and **SST** (49 L019 901A) vehicle switch to MPV position.
3. Turn the ignition switch and EC-AT tester main switch to ON.
4. Check indication of the respective light or digital display in each condition referring to the indication table on page K1-21.




When using the EC-AT tester (49 G019 901B) and adapter unit (49 L019 901)

1. Assemble the **SST**. (Refer to page K1-18.)
2. Set the **SST** (49 G019 901B) vehicle switch to 929 position.
3. Turn the ignition switch and the EC-AT tester main switch to ON.
4. Check indication of the respective light or digital display in each condition, referring to the indication table on page K1-21.

When using the EC-AT tester (49 G019 901B) and adapter unit (49 L019 901A)

1. Assemble the **SST**. (Refer to page K1-18.)
2. Set the **SST** (49 G019 901B) vehicle switch to 929 position and **SST** (49 L019 901A) vehicle switch to MPV position.
3. Turn the ignition switch and the EC-AT tester main switch to ON.
4. Check indication of the respective light or digital display in each condition, referring to the indication table on page K1-21.



When using the EC-AT tester (49 G019 901C)





1. Assemble the **SST**. (Refer to page K1-19.)
2. Turn the **SST** select switch to the ▲ mark on the panel.
3. Turn the ignition switch and the **SST** main switch to ON.
4. Check indication of the respective light or digital display in each condition, referring to the indication table on page K1-22.

Indication Table
Indication table of light and digital display
EC-AT tester (49 G019 901 or 49 G019 901B)

Item		Indication	Condition	Possible cause	
Input (Light)					
Transmission range switch (INHIBITOR SW)	P, N	ON	P or N position	Transmission range switch or wiring	
		OFF	R position, all ranges		
	D	ON	D position		
		OFF	Other ranges, all positions		
	2 (S)	ON	2 range		
		OFF	Other ranges, all positions		
	1 (L)	ON	1 range		
		OFF	Other ranges, all positions		
R	ON	R position			
	OFF	Other positions, all ranges			
MODE SW		Not used			
HOLD SW		Not used			
Transmission fluid temperature sensor (ATF THERMOSENSOR)		ON	ATF temperature above 40 °C { 140 °F }	Transmission fluid temperature sensor	
		OFF	ATF temperature below 40 °C { 140 °F }		
Closed throttle position switch (IDLE SW)		ON	Closed throttle position	Closed throttle position switch or wiring	
		OFF	Other position		
Barometric pressure sensor (ATMOSPHERIC PRESSURE SENSOR)		OFF	Normal condition	Barometric pressure sensor wiring	
		ON	Atmospheric pressure below 89.5 kPa { 672 mmHg , 26.4 inHg } at 1,500 m { 4,921 ft }		
4GR inhibit signal (CRUISE CONTROL SW)		ON	Normal condition	Cruise control module or wiring	
		OFF	Set or resume switch ON or vehicle speed 8 km/h { 5 mph } lower than preset speed		
Input (Digital Display)					
Throttle position sensor voltage (THROTTLE SENSOR V.)		TCM terminal voltage	Constant	Throttle position sensor or wiring	
VEHICLE SPEED km/h		Vehicle speed	Vehicle moving	Vehicle speedometer sensor, vehicle speed sensor, or wiring	
ENGINE RPM		Engine rpm	Constant	Engine control module or wiring	
Output (Light)					
SOLENOID	Shift solenoid A (SHIFT A)	ON	1GR and 4GR position	Transmission control module, shift solenoid A, or wiring	
		OFF	2GR and 3GR position		
	Shift solenoid B (SHIFT B)	ON	1GR and 2GR position		
		OFF	3GR and 4GR position		
	Overrunning clutch	ON	Other than below		Transmission control module, overrunning clutch solenoid valve, or wiring
		OFF	Engine braking and 3-2 timing control applied		
	TCC (LOCKUP)	Bright	TCC operation		Transmission control module, torque converter clutch solenoid valve, or wiring
		Dim	TCC non-operation		
Pressure control (LINE PRESSURE)	ON (Bright↔Dim)	While driving (Accelerator released↔depressed)	Transmission control module, pressure control solenoid, or wiring		
HOLD INDICATOR		Not used			
MODE INDICATOR		Not used			
GEAR	1	ON	First gear	—	
	2	ON	Second gear		
	3	ON	Third gear		
	4	ON	Fourth gear		

EC-AT tester (49 G019 901 C)

Item		Indication	Condition	Possible cause
Input (Light)				
TRANSMISSION RANGE SWITCHW	P/N	ON	P or N position	Transmission range switch or wiring
		OFF	R position, all ranges	
	R	ON	R position	
		OFF	Other positions, all ranges	
	D	ON	D range	
		OFF	Other ranges, all positions	
	2 (S)	ON	2 range	
		OFF	Other ranges, all positions	
	1 (L)	ON	1 position	
		OFF	Other ranges, all positions	
HOLD/O/D OFF SWITCH		ON	O/D OFF switch ON	O/D OFF switch or wiring
		OFF	O/D OFF switch OFF	
CLOSED THROTTLE POSITION SWITCH		ON	Closed throttle position	Closed throttle position switch or wiring
		OFF	Other position	
Input (Digital Display)				
THROTTLE POSITION SENSOR (V)		TCM terminal voltage	Constant	Throttle position sensor or wiring
VEHICLE SPEED (km/h)		Vehicle speed	Vehicle moving	Vehicle speedometer sensor, vehicle speed sensor, or wiring
TURBINE SPEED (rpm)		Not used		
TFT SENSOR (V)		TCM terminal voltage	Constant	Transmission fluid temperature sensor or wiring
Output (Light)				
SOLENOID	SHIFT A	ON	1GR and 4GR position	Transmission control module, shift solenoid A, or wiring
		OFF	2GR and 3GR position	
	SHIFT B	ON	1GR and 2GR position	Transmission control module, shift solenoid B, or wiring
		OFF	3GR and 4GR position	
	TCC CONTROL	Bright	TCC operation	Transmission control module, torque converter clutch solenoid valve, or wiring
		Dim	TCC non-operation	
	PRESSURE CONTROL	ON (Bright↔Dim)	While driving (Accelerator released↔depressed)	Transmission control module, pressure control solenoid, or wiring
	OVERRUNNING	ON	Other than below	Transmission control module, overrunning clutch solenoid valve, or wiring
		OFF	Engine braking and 3-2 timing control applied	
	HOLD/O/D OFF INDICATOR LIGHT		Not used	
Output (Digital Display)				
GEAR POSITION		1	First gear	—
		2	Second gear	
		3	Third gear	
		4	Fourth gear	



ELECTRONIC SYSTEM COMPONENTS

O/D OFF SWITCH

Inspection

Terminal voltage

1. Remove the column covers.
2. Turn the ignition switch to ON.
3. Check the voltage between terminal C and a ground.

B+: Battery positive voltage

Terminal voltage	Switch
B+	Released
0 V	Depressed

4. If not correct, go to the next step.

Continuity

1. Disconnect the connector.
2. Check continuity between terminals A and C.

Continuity	Switch
Yes	Released
No	Depressed






3. If not correct, replace the change knob as an assembly.

TRANSMISSION RANGE SWITCH

Inspection

Operation

1. Verify that the starter operates with the ignition switch at the START position and the selector lever in P or N position only, and that it does not operate in any other position.
2. Verify that the back-up lights illuminate when the selector lever is shifted to R position with the ignition switch in the ON position.
3. Check the transmission range switch if not as specified.



Continuity

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the selector cable.
3. Remove the manual shaft nut and lever.
4. Disconnect the transmission range switch connector.
5. Check continuity of the terminals.

Position	Connector terminal								
	A	B	C	D	E	F	G	H	I
P	○	○			○				
R	○		○						
N	○	○				○			○
D	○						○		
2	○			○					
1	○								○

○—○: Indicates continuity

6. If not correct, adjust the transmission range switch.
7. If correct, check or adjust the selector lever and selector cable. (Refer to page K1-138.)

Adjustment

1. Move the manual shaft to N position.
2. Loosen the transmission range switch mounting bolts.
3. Align the holes of the transmission range switch and the manual shaft lever and insert an **approx. 4.0 mm { 0.157 in }** outer diameter pin through the holes.
4. Tighten the mounting bolts, and remove the pin.

Tightening torque:

2.5—3.9 N·m { 25—40 kgf·cm , 22—34 in·lbf }

5. Recheck the continuity of the transmission range switch.
6. If not correct, replace the transmission range switch.
7. Install the lever and manual shaft nut.

Tightening torque:


30—39 N·m { 3.0—4.0 kgf·m , 22—28 ft·lbf }

8. Install the selector cable.


TRANSMISSION FLUID TEMPERATURE SENSOR

Inspection

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Loosen the oil pan mounting bolts, and drain the ATF into a container.




3. Remove the oil pan. (Refer to page K1-30.)
4. Remove the control valve body and solenoid connector. (Refer to page K1-112.)




5. Place the transmission fluid temperature sensor in water with a thermometer as shown and heat the water gradually.
6. Measure the resistance between the terminals. If necessary, replace the transmission fluid temperature sensor.

Water temperature	Resistance
20 °C { 68 °F }	Approx. 2.5 kΩ
80 °C { 176 °F }	Approx. 0.3 kΩ



7. Install the solenoid connector and control valve body. (Refer to page K1-114.)
8. Install the oil pan. (Refer to page K1-30.)
9. Pour in ATF, and with the engine idling, check the ATF level and check for leaks. (Refer to page K1-30.)
10. Carry out the time lag test and the line pressure test. (Refer to page K1-8.)
11. Carry out the road test. (Refer to page K1-13.)



OUTPUT SPEED SENSOR

Inspection


1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Disconnect the connector.
3. Measure the resistance between the terminals.





Terminal	Resistance
A and B	504—616 Ω
B and C	∞
A and C	∞

4. If not correct, replace the output speed sensor.

Tightening torque:

5.0—6.8 N·m { 50—70 kgf·cm , 44—60 in·lbf }





SOLENOID VALVES

Inspection

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Disconnect the connector.
3. Measure the resistance between the terminals.

Note

- Terminal A is for the transmission fluid temperature switch (4WD).

Terminal	Connected to	Resistance
B	Shift solenoid A	20—40 Ω
C	Shift solenoid B	20—40 Ω
D	Overrunning clutch solenoid	20—40 Ω
E	Pressure control solenoid	2.5—5 Ω
F	TCC solenoid	10—20 Ω

4. If the resistance is not within the specification, replace the solenoid. If the shift A, shift B, overrunning clutch, or pressure control solenoid resistance is not correct, then replace those 4 solenoids as an assembly.

DROPPING RESISTOR

Inspection

1. Disconnect the dropping resistor connector.
2. Measure the resistance of the terminals.

Resistance: 10—14 Ω

3. If not correct, replace the dropping resistor.


TRANSMISSION FLUID TEMPERATURE SWITCH (4WD)

Inspection

1. Drain the ATF. (Refer to transmission fluid temperature sensor inspection; page K1-24, steps 1—3.)
2. Remove the control valve body and disconnect the solenoid connector. (Refer to page K1-112.)
3. Place the transmission fluid temperature switch in ATF with a thermometer as shown, and heat the fluid gradually.
4. Measure the continuity between terminal and bracket.

Fluid temperature	Continuity
Above 150 °C { 302 °F }	Yes
Below 145 °C { 293 °F }	No

5. If not correct, replace the transmission fluid temperature switch.
6. Install the solenoid connector and control valve body. (Refer to page K1-114.)
7. Add ATF to the correct level. (Refer to transmission fluid temperature sensor inspection; page K1-24, steps 8, 9.)
8. Carry out the time lag test and line pressure test. (Refer to page K1-8.)
9. Carry out the road test. (Refer to page K1-13.)

**TRANSMISSION CONTROL MODULE****Inspection**

1. Turn the ignition switch to ON, and check the transmission control module terminal voltage, referring to the Terminal Voltage Chart.
2. If not correct, check or replace the component(s), wiring, and/or transmission control module.

Terminal Voltage Chart (Reference Data)

Note

- Use the ground of terminal 1J of the transmission control module when measuring terminal voltage, as an error may occur when the negative (-) lead of the circuit tester is connected to ground.

2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

B+: Battery positive voltage






Terminal	Connected to	Voltmeter		Voltage	Condition
		+ terminal	- terminal		
1A	Battery	1A	Ground	B+	Constant
1B	Shift solenoid B	1B		B+	Solenoid ON in following condition: • 1GR and 2GR positions
				0 V	Solenoid OFF in following condition: • 3GR and 4GR positions
1C	—	—	—	—	—
1D	Shift solenoid A	1D	Ground	B+	Solenoid ON in following condition: • 1GR and 4GR positions
				0 V	Solenoid OFF in following condition: • 2GR and 3GR positions
1E	Transmission range switch (R position)	1E		B+	R position
				0 V	Other positions and all ranges
1F	Pressure control solenoid	1F		Below 1.5 V	Accelerator pedal depressed (After ATF warm, engine stopped)
				1.7—4.5 V	Accelerator pedal fully released (After ATF warm, engine stopped)
1G	Engine speed input signal*	1G		Above 1 V (AC)	Engine running
				Below 0.5 V (AC)	Engine stopped
1H	Dropping resistor	1H		B+	Accelerator pedal fully released (After ATF warm, engine stopped)
				Below 1.5 V	Accelerator pedal depressed (After ATF warm, engine stopped)
1I	Vehicle speed sensor	1I		2—3 V	While driving
				0 V or 4.5—5.5 V	Vehicle stopped
1J	—	1J		0 V	Constant
1K	O/D OFF indicator light	1K		B+	Except O/D OFF mode
				0 V	O/D OFF mode
1L	—	1L	0 V	Constant	
1M	TCC solenoid	1M	B+	Solenoid ON, TCC operation	
			Below 1.5 V	Solenoid OFF, TCC non-operation	
1N	—	—	—	—	
1O	Overrunning clutch solenoid	1O	Ground	B+	Solenoid ON in following condition: • D range (Engine stopped)
				0 V	Solenoid OFF in following condition: • Except D range (Engine stopped)
1P	Battery	1P		B+	Ignition switch ON
			0 V	Ignition switch OFF	

* Checked with AC range

B+: Battery positive voltage

Terminal	Connected to	Voltmeter		Voltage	Condition
		+ terminal	- terminal		
2A	Throttle position sensor	2A	2L	4.5—5.5 V	Ignition switch ON
				0 V	Ignition switch OFF
2B	Transmission range switch (D range)	2B	Ground	B+	D range
				0 V	Other ranges and all positions
2C	—	—	—	—	—
2D	Transmission range switch (N and P positions)	2D	Ground	B+	R position and all ranges
				0 V	P or N position
				Below 7 V	P or N position and engine crank
2E	Cruise control module	2E	Ground	Above 6 V	Normal conditions
				Below 1.5 V	Set or resume switch ON or vehicle speed 8 km/h (5 mph) lower than preset speed (Driving vehicle cruise control operation)
2F	—	—	—	—	—
2G	Engine control module	2G	Ground	Above 6 V	Normal condition
				Below 1.5 V	Atmospheric pressure below 89.5 kPa { 672 mmHg , 26.4 inHg } at 1,500 m { 4,921 ft }
2H	—	—	—	—	—
2I	O/D OFF switch	2I	Ground	Above 6 V	Switch released
				0 V	Switch depressed
2J	Output speed sensor	2J	Ground	Above 1 V (AC)	Vehicle speed above 25 km/h { 16 mph }
				Approx. 0 V (AC)	Vehicle stopped
2K	TEST signal	2K	Ground	B+	Ignition switch ON
				Below 1.0 V or repeat B+ and 0 V	TEST mode
2L	Ground (For sensors)	2L	Ground	0 V	Constant
2M	Closed throttle position switch	2M	Ground	B+	Closed throttle position switch OFF (Throttle valve open)
				0 V	Closed throttle position switch ON (Throttle valve wide open throttle)
2N	FAIL signal	2N	Ground	Below 1.0 V or repeat B+ and 0 V	Other modes
				B+	TEST mode
2O	—	—	—	—	—
2P	—	—	—	—	—
2Q	Transmission range switch (L range)	2Q	Ground	B+	L range
				0 V	Other ranges and all positions
2R	Transmission fluid temperature sensor	2R	2L	Approx. 2.4—0.4 V	While warming up ATF Note Approx. 1.8 V: ATF temp. 10 °C { 50 °F } Approx. 1.1 V: ATF temp. 40 °C { 104 °F }
2S	Transmission range switch (S range)	2S	Ground	B+	S range
				0 V	Other ranges and all positions
2T	Throttle position sensor	2T	2L	Approx. 0.4—4.4 V	Throttle valve moved from closed throttle position to wide open throttle

* Checked with AC range



AUTOMATIC TRANSMISSION FLUID (ATF)

INSPECTION

Level

1. Park the vehicle on level ground.
2. Apply the parking brake and position wheel chocks securely to prevent the vehicle from rolling.
3. Warm up the engine until the ATF reaches **60—70 °C { 140—158 °F }**.
4. While the engine is idling, shift the selector lever from P position to 1 range and back again.
5. Let the engine idle.
6. Shift the selector lever to P position.
7. Ensure that the ATF level is between the notches on the transmission level gauge. Add ATF to specification if necessary.

ATF type: Dexron®II or M-III


Condition

One way of determining whether the transmission should be disassembled is by noting;


1. If the ATF is muddy or varnished.
2. If the ATF smells strange or unusual.

REPLACEMENT

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Loosen the oil pan mounting bolts, and drain the ATF into a container.



3. Remove the oil pan and gasket.
4. Clean the oil pan and the magnet.



5. Remove any old locking compound from the bolt holes.
6. Install the oil pan along with a new gasket.
7. Tighten new oil pan mounting bolts evenly and quickly.

Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }

8. Lower the vehicle and add **approx. 4.0 L { 4.2 US qt , 3.5 Imp qt }** ATF.

ATF type: Dexron®II or M-III







9. Check the ATF level. (Refer to page K1–30.)

TRANSMISSION

TRANSMISSION UNIT (REMOVAL)

Preparation

SST


<p>49 S120 440</p> <p>Holder, mainshaft</p> 	<p>For prevention of ATF leakage</p>	<p>49 0107 680A</p> <p>Engine stand</p> 	<p>For disassembly of transmission</p>
<p>49 U019 0A0A</p> <p>Transmission hanger</p> 	<p>For disassembly of transmission</p>	<p>49 H075 495B</p> <p>Body (Part of 49 U019 0A0A)</p> 	<p>For disassembly of transmission</p>
<p>49 U019 003</p> <p>Holder (Part of 49 U019 0A0A)</p> 	<p>For disassembly of transmission</p>	<p>49 0378 390</p> <p>Puller, oil pump</p> 	<p>For disassembly of transmission</p>

Removal


The oil pan could contain small chips, shavings, and other particles helpful in checking the condition of the transmission and diagnosing certain problems. To ensure that all foreign particles stay in the oil pan, make sure that the transmission is never tipped completely over while the oil pan is still installed.

1. Disconnect the negative battery cable.
2. On level ground, jack up the vehicle and support it evenly on safety stands.
3. Drain the ATF into a container.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. After removal, remove the oil pan to check condition of the transmission.


(2WD)



- | | |
|-----------------------------------|--------------------------------------|
| 1. Speedometer cable | 10. Starter |
| 2. Connector | 11. Exhaust pipe bracket |
| 3. Exhaust pipe | 12. Transmission mount mounting bolt |
| 4. Heat insulator | 13. Oil pipe |
| 5. Propeller shaft | 14. Gusset plate |
| Removal section L | 15. Transmission |
| 6. Selector cable | Disassembly page K1- 35 |
| 7. Filler tube | Assembly page K1-116 |
| 8. Undercover | 16. Transmission lower mount |
| 9. Torque converter mounting bolt | 17. Transmission upper mount |



- | | |
|--------------------------|--------------------------------------|
| 1. Speedometer cable | 10. Torque converter mounting bolt |
| 2. Connector | 11. Starter |
| 3. Exhaust pipe | 12. Exhaust pipe bracket |
| 4. Heat insulator | 13. Transmission mount mounting bolt |
| 5. Rear propeller shaft | 14. Oil pipe |
| Removal section L | 15. Gusset plate |
| 6. Front propeller shaft | 16. Transmission |
| Removal section L | Disassembly page K1- 35 |
| 7. Selector cable | Assembly page K1-116 |
| 8. Filler tube | 17. Transmission lower mount |
| 9. Undercover | 18. Transmission upper mount |



Removal note Transmission

Set the transmission onto the transmission jack, paying special attention not to damage the oil pipes. Make sure that the torque converter side of the transmission is tilted slightly upward during removal. Carefully lower the transmission from the vehicle.

TRANSMISSION UNIT (DISASSEMBLY)

Precaution

General notes:

The oil pan could contain small chips, shavings, and other particles helpful in checking the condition of the transmission and diagnosing certain problems. To ensure that all foreign particles stay in the oil pan, make sure that the transmission is never tipped completely over while the oil pan is still installed.

1. Disassemble the transmission in a clean area (dustproof work space) to prevent entry of dust into the mechanisms.
2. Inspect the individual transmission components in accordance with the QUICK DIAGNOSIS CHART during disassembly.
3. Use only plastic hammers when applying force to separate the light alloy case joints.
4. Never use rags during disassembly; they may leave particles that can clog fluid passages.
5. Several parts resemble one another; arrange them so that they do not get mixed up.
6. Disassemble the control valve assembly and thoroughly clean it when the clutch or brake band has burned or when the ATF has degenerated.

Cleaning notes:


1. Clean the transmission exterior thoroughly with steam or cleaning solvents, or both, before disassembly.

Warning

- **Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.**


2. Clean the removed parts with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and verify that there are no obstructions.

Component




- | | |
|----------------------------------|---|
| 1. Transfer case (4WD) | 7. Oil pan |
| 2. Adapter case (4WD) | 8. Converter housing |
| Disassembly / Inspection / | 9. Oil strainer |
| Assembly page K1-85 | 10. Control valve body |
| 3. Transmission range switch | Disassembly / Inspection page K1- 91 |
| Inspection page K1-23 | Assembly page K1-109 |
| Adjustment page K1-24 | 11. Solenoid valve connectors |
| 4. Speedometer driven gear (2WD) | 12. Anchor end bolt and nut |
| 5. Output speed sensor | 13. Extension housing |
| Inspection page K1-25 | Disassembly / Inspection / |
| 6. Torque converter | Assembly page K1- 85 |
| Inspection page K1-46 | |

Components (cont'd)



- | | |
|---|--|
| <p>14. Input shaft</p> <p>15. Oil pump
Disassembly / Inspection /
Assembly page K1-49</p> <p>16. Brake band and strut</p> <p>17. Reverse clutch
Disassembly / Inspection /
Assembly page K1-53</p> <p>18. High clutch and front sun gear
Disassembly / Inspection /
Assembly page K1-59</p> <p>19. Front planetary carrier</p> <p>20. Rear sun gear</p> | <p>21. Snap ring</p> <p>22. Parking gear and bearing</p> <p>23. Snap ring</p> <p>24. Output shaft</p> <p>25. Front internal gear, rear internal gear, forward
clutch hub, overrunning clutch hub
Disassembly / Inspection /
Assembly page K1-68</p> <p>26. Forward clutch drum (forward clutch, overrun-
ning clutch, low one-way clutch)
Disassembly / Inspection /
Assembly page K1-71</p> |
|---|--|


Components (cont'd)



27. Accumulator spring and piston
Disassembly / Inspection /
Assembly page K1-47

28. Band servo
Disassembly / Inspection /
Assembly page K1-64

29. Low and reverse brake piston and spring
Disassembly / Inspection /
Assembly page K1-79

**Procedure**

1. Support the transmission by placing wooden blocks under the converter housing and the extension housing.

2. Remove the oil pan and gasket.

Examine any material found in the pan or on the magnet to determine the condition of the transmission.


Clutch facing material Drive plate and brake band wear

Steel (magnet) Bearing, gear, and driven-plate wear

Aluminum (nonmagnetic) . . Bushings or cast aluminum parts wear


If large amounts of material are found, replace the torque converter and carefully check the transmission for the cause.

3. Install the oil pan with a few bolts to protect the valve body.




4. Remove the connector bracket from the transmission case.

5. Remove the transmission range switch.



6. Remove the connector bracket from the extension housing.

7. Disconnect the harness from the harness bracket.





8. Remove the speedometer driven gear from the extension housing. (2WD)

9. Remove the O-ring from the speedometer driven gear. (2WD)


10. Remove the output speed sensor.

11. Remove the O-ring from the output speed sensor.







12. Remove the torque converter and immediately turn it so that the hole faces upward. This will help to keep any remaining fluid from spilling.



13. Assemble the **SSTs** as shown.




14. Mount the transmission to the **SST**.
15. Remove the oil pan.




16. Remove the extension housing and gasket. For 4WD models, do not reuse bolts **C**.

Bolt length (Measured from below the head)


- A:** 30 mm { 1.181 in }
- B:** 45 mm { 1.772 in }
- C:** 45 mm { 1.772 in }



17. Remove the clip by carefully prying with a small flathead screwdriver.
18. Disconnect the torque converter clutch solenoid valve connector.




19. Remove the transmission fluid temperature sensor.



20. Remove the oil strainer.

21. Remove the O-ring from the oil strainer.


Bolt length (Measured from below the head):
50 mm { 1.969 in }



22. Separate the solenoid harness from the harness clip.

23. Remove the clip by carefully prying with a small flatted screwdriver.

24. Remove the transmission fluid temperature switch. (4WD)




25. Remove bolts A and B, and the brackets shown in the figure.


Bolt length (Measured from below the head)

(A): 33 mm { 1.299 in }


(B): 45 mm { 1.772 in }




26. Remove the clip by carefully prying with a small flathead screwdriver.
27. Disconnect the solenoid connectors.




28. Remove the control valve body and the oil pipes.



29. Remove the solenoid connector from the transmission case.
30. Remove the O-ring from the solenoid connector.



31. Remove the converter housing from the transmission case.




32. Remove the O-rings from the converter housing.


Caution

- The converter housing is made of aluminum, and is therefore easily dented and scratched by metal tools. When removing old sealant, do not gouge or strike the sealing surface of the converter housing.


33. Remove the sealing compound from the converter housing.




34. Remove the O-ring from the input shaft.




35. Install the **SST** to the oil pump assembly.
 36. Slowly remove the oil pump from the transmission case by evenly sliding the weights of the **SST**.
 37. Remove the **SST** from the oil pump.




38. Clean the sealant from the oil pump housing, being careful not to scratch or dent the machined surface.




39. Remove the oil pump gasket.
 40. Pull out the input shaft while holding the reverse clutch drum.




41. While holding the anchor end bolt, loosen the locknut.
 42. Remove the locknut from the anchor end bolt.
 43. Remove the anchor end bolt.
 44. Clean the sealing compound from the transmission case threads.



45. Remove the brake band, and hold it together with a piece of wire as shown in the figure.
46. Remove the band strut.




47. Remove the reverse clutch, high clutch, and the front sun gear from the transmission case as an assembly.




48. Remove the front planetary carrier, bearings, and the rear sun gear.
Inspect the following parts, and repair or replace as necessary.


- 1) Front planetary carrier
Inspect individual gear teeth for damage, wear, and cracks, and check the rotation of the pinion gears
- 2) Rear sun gear
Inspect individual gear teeth for damage, wear, and cracks
- 3) Bearing
Inspect for damage and rough rotation




49. Remove the rear snap ring and the speedometer drive gear. (2WD)
50. Remove the key and the front snap ring. (2WD)




51. Remove the snap ring (rear) from the output shaft.
52. Remove the parking gear.




53. Remove the bearing from behind the transmission case.




54. While pushing the output shaft slightly forward, remove the snap ring (front) from the output shaft.




55. Pull out the output shaft.




56. Remove the front internal gear (with rear planetary carrier).



57. Remove the rear internal gear, forward clutch hub, and overrunning clutch hub as an assembly.




58. Remove the forward clutch drum (forward clutch, over-running clutch, low one-way clutch) from the transmission case.



TORQUE CONVERTER

Inspection

1. Check the outside of the converter for damage and cracks, and replace the torque converter if there is any problem.
2. Check for rust on the pilot hub on the boss, and remove it completely if there is any.




Washing Inside the Converter

1. Drain any ATF remaining in the converter.
2. Pour in solvent (0.5 L { 0.5 US qt , 0.4 Imp qt }).
3. Shake the converter to clean the inside. Pour out the solvent.
4. Pour in ATF.
5. Shake the converter to clean the inside. Pour out the ATF.

ACCUMULATORS

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. 3-4/N-R accumulator spring
Inspection page K1-48 2. 1-2 accumulator spring
Inspection page K1-48 3. 2-3 accumulator spring
Inspection page K1-48 4. N-D accumulator piston
Disassembly note page K1-47 5. O-rings 6. N-D accumulator spring
Inspection page K1-48 | <ol style="list-style-type: none"> 7. 2-3 accumulator piston
Disassembly note page K1-47 8. O-rings 9. 1-2 accumulator piston
Disassembly note page K1-47 10. O-rings 11. 3-4/N-R accumulator piston
Disassembly note page K1-47 12. O-rings 13. Transmission case |
|---|---|






**Disassembly note
Accumulator piston**

Remove the accumulator pistons and springs from the transmission case by applying compressed air through the oil passage as shown in the figure.



Accumulator	Item	Location	Oil passage
N-D accumulator		A	a
2-3 accumulator		B	b
1-2 accumulator		C	c
3-4/N-R accumulators		D	d

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.



Inspection Accumulator, spring

1. Measure the spring free length.

Spring	Item	Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
N-D accumulator position		18.0 { 0.709 }	43.0 { 1.693 }	12.3	2.3 { 0.091 }
2-3 accumulator position		20.0 { 0.787 }	66.0 { 2.598 }	11.4	3.5 { 0.138 }
1-2 accumulator position		29.3 { 1.154 }	45.0 { 1.772 }	3.6	4.0 { 0.157 }
3-4/N-R accumulator position		17.3 { 0.681 }	58.4 { 2.299 }	12.3	2.3 { 0.091 }

2. If not within the specification, replace the spring.

Assembly procedure Outer diameter of spring




Spring	Outer dia. mm { in }
a N-D accumulator	18.0 { 0.709 }
b 2-3 accumulator	20.0 { 0.787 }
c 1-2 accumulator	29.3 { 1.154 }
d 3-4/N-R accumulator	17.3 { 0.681 }

1. Apply ATF to the new O-rings and install them onto the accumulator pistons.
2. Apply even pressure to the perimeter of the accumulator pistons and install them into the transmission case.
3. Install each spring into its own accumulator piston.

Piston	O-ring	Large mm { in }	Small mm { in }	Installation order
A N-D accumulator		45.0 { 1.772 }	29.0 { 1.142 }	spring, piston
B 2-3 accumulator		50.0 { 1.969 }	32.0 { 1.260 }	piston, spring
C 1-2 accumulator		50.0 { 1.969 }	45.0 { 1.772 }	piston, spring
D 3-4/N-R accumulator		45.0 { 1.772 }	29.0 { 1.142 }	piston, spring


4. Install the accumulator pistons and springs.

**OIL PUMP
Preparation
SST**


<p>49 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 796</p> <p>Body (Parts of 49 G030 795)</p> 	<p>For installation of oil seal</p>
<p>49 G030 797</p> <p>Handle (Parts of 49 G030 795)</p> 	<p>For installation of oil seal</p>	<p>—</p>	<p>—</p>

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Bearing 2. Oil pump cover
Disassembly Note page K1-50
Inspection page K1-50 3. Seal ring (small diameter) 4. Seal ring (large diameter) 5. Seal ring 6. Vane ring 7. Rotor
Disassembly Note page K1-50
Inspection page K1-51 8. Vane
Inspection page K1-51 9. Vane ring 10. Pivot pin
Disassembly Note page K1-50 | <ol style="list-style-type: none"> 11. Cam ring
Disassembly Note page K1-50
Inspection page K1-51 12. Cam ring spring
Inspection page K1-51 13. Spring seat 14. Friction ring 15. O-Ring 16. Pivot pin 17. Control piston
Inspection page K1-51 18. Side seal 19. Oil pump housing
Inspection page K1-51 20. Oil seal |
|---|---|

**Disassembly note****Oil pump cover**


Loosen the mounting bolts evenly in the pattern shown and remove the oil pump cover from the oil pump housing.

**Rotor**


1. Mark the rotor and cam ring without scratching or denting them.
2. Remove the rotor and vanes from the cam ring.

**Pivot pin**

Hold the cam ring back with a tape-wrapped screwdriver, and remove the pivot pin.

**Cam ring**


1. Hold the cam ring spring back and remove the cam ring.
2. Remove the cam ring spring.

**Inspection****Oil pump cover**

1. Apply petroleum jelly to new seal ring.
2. Measure the clearance between the seal ring and the ring groove.

Clearance: 0.10—0.25 mm { 0.0039—0.0098 in }

3. If not within the specification, replace the oil pump as an assembly.



Oil pump housing, cam ring, rotor, vane, and control piston


1. Install the cam ring, vanes, rotor, and control piston. Do not install the friction ring, O-ring, control piston side seals, and cam ring spring yet.
2. Measure the clearance between the end of the oil pump housing and cam ring, rotor, vanes and control piston in at least four places along their circumferences.

Clearance

mm { in }

Port	Clearance	Standard	Maximum
Cam ring		0.010—0.024 { 0.0004—0.0009 }	0.030 { 0.0012 }
Rotor, vane, control piston		0.030—0.044 { 0.0012—0.0017 }	0.050 { 0.0020 }

3. If not within the specification, replace the oil pump as an assembly.




Cam ring spring

1. Measure the spring specification.

Specification


Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
13.7 { 0.539 }	39.8 { 1.567 }	7.8	2.3 { 0.091 }

2. If not correct, replace the cam ring spring.




Assembly procedure


1. Apply ATF to the new oil seal. Install the oil seal by using the SSTs.




2. Apply ATF to the side seals, and install them on the control piston with the black surface facing toward the control piston.
3. Install the control piston and pivot pin.




4. Apply petroleum jelly to the cam ring groove and install a new O-ring and friction ring into the cam ring.
5. Install the cam ring and spring while compressing the spring against the oil pump housing.



6. Hold the cam ring with a tape-wrapped screwdriver, and install the pivot pin.
7. While pushing on the cam ring, install the pivot pin.




8. Confirm the marks and install the rotor, vanes, and vane rings.




9. Carefully install the oil pump cover onto the oil pump housing.
10. Tighten the bolts evenly and gradually in the order shown.

Tightening torque:

16—20 N·m { 1.6—2.1 kgf·m , 12—15 ft·lbf }



11. Apply petroleum jelly to the seal rings. Fit the large seal ring (yellow mark) into the bottom ring groove and the small seal ring (no mark) into the top ring groove.
12. Apply ATF to a new O-ring , and install it on the oil pump.








13. Apply petroleum jelly to the bearing, and set it on the oil pump.


Bearing outer diameter: 47.0 mm { 1.850 in }

REVERSE CLUTCH

Preparation

SST

<p>49 G019 0A7A Compressor set, return spring</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>—</p>	<p>—</p>



Preinspection

Reverse clutch operation

1. Install the reverse clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage as shown.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

2. Verify that the retaining plate moves to the snap ring. If not, the D-ring or the oil seal may be damaged or fluid may be leaking at the piston check ball. Inspect them and replace when assembling.


Clearance between retaining plate and snap ring

Measure the clearance between the retaining plate and the snap ring.

Standard clearance:


0.50—1.20 mm { 0.020—0.047 in }

Select the correct retaining plate when assembling.




Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.



- | | |
|-----------------------------------|-----------------------------------|
| 1. Snap ring | 7. Return spring |
| 2. Retaining plate | Inspection page K1-55 |
| 3. Drive plates and driven plates | 8. Clutch piston |
| Inspection page K1-55 | Disassembly Note page K1-55 |
| 4. Dished plate | Inspection page K1-55 |
| 5. Snap ring | 9. Seal ring |
| Disassembly Note page K1-55 | 10. D-ring |
| 6. Spring retainer | 11. Reverse clutch drum |




Disassembly note
Snap ring

Caution

- Depress the spring retainer only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.


1. Compress the spring by using the SSTs, then remove the snap ring with snap ring pliers.
2. Remove the spring retainer and spring.



Piston

1. Install the reverse clutch onto the oil pump along with the seal rings.
2. Remove the piston by applying compressed air to the oil passage.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




Inspection
Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard thickness: 2.0 mm { 0.079 in }
Minimum thickness: 1.8 mm { 0.071 in }

2. If it is less than the minimum, replace the drive plates.




Return spring

1. Measure the spring specifications.

Specification

Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
11.6 { 0.457 }	19.69 { 0.775 }	4.0	1.3 { 0.051 }


2. If not correct, replace the return spring.



Clutch piston


1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is airflow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




Assembly procedure


1. Apply ATF to the new D-ring and install it into the clutch piston.




2. Apply ATF to the new seal ring and install it into the clutch piston.



3. Apply ATF to the inner surface of the reverse clutch drum.
4. Apply even pressure to the perimeter of the clutch piston, and install it into the reverse clutch drum by turning it evenly and gradually.
5. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.




6. Install the return springs and spring retainer.




Caution


- Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.




7. Install the snap ring while compressing the springs by using the **SSTs**.



8. Install the dished plate as shown in the figure.



- 9. Soak new drive plates in ATF for at least two hours.
- 10. Apply ATF to the driven plates immediately before assembly.
- 11. Install the drive and driven plates into the reverse clutch drum in the following order.
Driven-Drive-Driven-Drive






- 12. Install the retaining plate.
- 13. Install the snap ring.
- 14. Measure the clearance between the retaining plate and snap ring with a feeler gauge. If not within the specification, adjust the clearance by installing the correct retaining plate.

Standard clearance:
0.50—1.20 mm { 0.020—0.047 in }

Retaining plate sizes

mm { in }			
4.6 { 0.181 }	4.8 { 0.189 }	5.0 { 0.197 }	5.2 { 0.205 }
5.4 { 0.213 }	5.6 { 0.220 }	5.8 { 0.228 }	





15. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.

Standard Clearance:

0.50—0.80 mm { 0.020—0.031 in }

Retaining plate sizes

mm { in }

4.6 { 0.181 }	4.8 { 0.189 }	5.0 { 0.197 }	5.2 { 0.205 }
5.4 { 0.213 }	5.6 { 0.220 }	5.8 { 0.228 }	

Caution






- **Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.**



16. Install the reverse clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage and check the clutch operation.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

HIGH CLUTCH AND FRONT SUN GEAR

**Preparation
SST**

<p>49 G019 0A7A Compressor set, return spring</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>—</p>	<p>—</p>



Preinspection

High clutch operation

1. Install the high clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage as shown.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

2. Verify that the retaining plate moves toward the snap ring.
If not, the D-ring may be damaged or fluid may be leaking at the piston check ball.
Inspect them and replace when assembling.

Clearance between retaining plate and snap ring

Measure the clearance between the retaining plate and the snap ring.


Standard clearance:

1.8—3.0 mm { 0.071—0.118 in }


Select and install the correct retaining plate when assembling.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.



- | | |
|-----------------------------------|-----------------------------------|
| 1. Front sun gear | 11. Spring retainer |
| 2. Bearing race | 12. Return spring |
| 3. Bearing | Inspection page K1-61 |
| 4. High clutch hub | 13. Clutch piston |
| 5. Bearing | Disassembly Note page K1-61 |
| 6. Bearing race | Inspection page K1-61 |
| 7. Snap ring | 14. D-ring |
| 8. Retaining plate | 15. D-ring |
| 9. Drive plates and driven plates | 16. Bearing race |
| Inspection page K1-61 | 17. High clutch drum |
| 10. Snap ring | |
| Disassembly Note page K1-61 | |




Disassembly note
Snap ring

Caution

- **Depress the spring retainer only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.**


1. While holding the spring retainer down by using the **SSTs**, remove the snap ring by using snap ring pliers.
2. Remove the spring retainer and spring.



Piston

1. Install the high clutch onto the oil pump along with the seal rings.
2. Remove the piston by applying compressed air through the oil passage.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




Inspection
Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard thickness: 1.6 mm { 0.063 in }
Minimum thickness: 1.4 mm { 0.055 in }

2. If not within specification, replace the drive plates.




Return spring

1. Check the spring specifications.

Specifications

Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
11.6 { 0.457 }	22.1 { 0.870 }	6.0	1.3 { 0.051 }






2. If not within specification, replace the return spring.



Clutch piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.



Assembly procedure


High clutch

1. Apply ATF to the new D-rings and install them into the clutch piston.
2. Apply ATF to the inner surface of the high clutch drum.
3. Apply even pressure to the perimeter of the clutch piston, and install it into the reverse clutch drum by turning it evenly and gradually.
4. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.
5. Install the return springs and spring retainer.


Caution

- **Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.**


6. While holding the spring retainer down by using the **SSTs**, install the snap ring into the spring retainer stopper.



7. Soak new drive plates in ATF for at least two hours.
8. Apply ATF to the driven plates immediately before assembly.
9. Install the drive and driven plates into the high clutch drum in the following order:
Driven-Drive-Driven-Driven-Drive-Driven-Driven-Drive Driven-Driven-Drive



10. Install the retaining plate.
11. Install the snap ring.




12. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within the specification, adjust the clearance by installing the correct retaining plate.

Standard clearance:

1.8—3.0 mm { 0.071—0.118 in }

Retaining plate sizes

mm { in }			
3.0 { 0.118 }	3.2 { 0.126 }	3.4 { 0.134 }	3.6 { 0.142 }
3.8 { 0.150 }	4.0 { 0.157 }	4.2 { 0.165 }	4.4 { 0.173 }



13. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.

Standard clearance:


1.8—2.2 mm { 0.071—0.087 in }

Retaining plate sizes

mm { in }			
3.0 { 0.118 }	3.2 { 0.126 }	3.4 { 0.134 }	3.6 { 0.142 }
3.8 { 0.150 }	4.0 { 0.157 }	4.2 { 0.165 }	4.4 { 0.173 }


Caution

- **Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.**



14. Install the high clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage and check the clutch operation.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




- Apply petroleum jelly to the bearing races and install them in the high clutch as shown.

Bearing race outer diameter

Front side: 43.5 mm { 1.713 in }


Rear side : 51.5 mm { 2.028 in }



- Apply petroleum jelly to the bearing and install it in the high clutch hub.

Bearing outer diameter: 53.0 mm { 2.087 in }

- Apply ATF to the high clutch hub, and install it in the high clutch by turning it evenly and gradually.




Front sun gear

Apply petroleum jelly to the bearing and bearing race, and install them to the front sun gear.

Bearing outer diameter: 53.0 mm { 2.087 in }

Bearing race outer diameter: 75.0 mm { 2.953 in }



BAND SERVO


Preinspection

Band servo

- Apply compressed air to the oil passage as shown.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

- Verify that the piston stem moves to the brake band. If not, the D-ring or the oil seal may be damaged or fluid may be leaking at the piston assembly. Inspect them, and replace when assembling.




Disassembly note

Piston assembly and servo piston retainer

Apply compressed air to the oil hole in the transmission case to remove the piston assembly and servo piston retainer from the transmission case.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




4GR band servo piston

1. Block one oil hole in the 4GR servo piston retainer, and block the center hole in the 4GR band servo piston.
2. Apply compressed air to the other oil hole in the 4GR servo piston retainer to remove 4GR band servo piston from the 4GR servo piston retainer.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

3. Remove the D-ring from the 4GR band servo piston.



Inspection

Return spring

1. Measure the spring specifications.



Specifications

	Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
Return A	40.3 { 1.587 }	53.8 { 2.118 }	3.0	2.3 { 0.091 }
Return B	34.3 { 1.350 }	45.6 { 1.795 }	3.0	2.3 { 0.091 }
Return C	27.6 { 1.087 }	29.7 { 1.169 }	3.2	2.6 { 0.102 }


2. If not correct, replace the return spring.

Assembly procedure


1. Apply ATF to the new O-rings and install them onto the servo piston retainer.
2. Apply ATF to the new D-rings and install them onto the band servo piston.




3. Apply ATF to the servo cushion spring retainer and retaining ring, and assemble them in the band servo piston.




4. Apply ATF to the band servo piston assembly.
5. Apply even pressure to the perimeter of the piston and install it onto the servo piston retainer.




6. Apply ATF to the piston stem return spring and spring retainer, and assemble them in the band servo piston.
7. Install the retaining ring.




8. Apply ATF to the new D-ring, and install it onto the 4GR band servo piston.




9. Apply ATF to the 4GR band servo piston.
10. Apply even pressure to the perimeter of the piston, and install it into the band servo retainer.



11. Install return springs A and B.
12. Apply ATF to the piston assembly.
13. Apply even pressure to the perimeter of the piston assembly, and install it into the transmission case.




14. Apply ATF to the band servo retainer and a new gasket, and install them onto the transmission case.



15. Tighten the bolts evenly and gradually in the order shown.



Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }



16. Check the servo piston operation by applying compressed air through the oil holes.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.



FRONT INTERNAL GEAR, REAR INTERNAL GEAR, FORWARD CLUTCH HUB, OVERRUNNING CLUTCH HUB

Preinspection


Forward one-way clutch operation

While holding the forward clutch hub, verify that the rear internal gear rotates smoothly when turned clockwise, and locks when turned counterclockwise.


If not, replace the one-way clutch.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.




- | | |
|--|-----------------------------|
| 1. Front internal gear (with rear planetary carrier) | 8. Thrust washer |
| 2. Bearing race | 9. Snap ring |
| 3. Bearing | 10. Forward one-way clutch |
| 4. Rear internal gear | Inspection page K1-69 |
| 5. Thrust washer | 11. Snap ring |
| 6. Bearing | 12. Forward clutch hub |
| 7. Overrunning clutch hub | |




Assembly procedure


1. Install the snap ring into the forward clutch hub.
2. Apply ATF to the forward one-way clutch. Install it into the forward clutch hub, with the flange facing upward.



3. Apply petroleum jelly to the thrust washer, and set it so that the tabs fit in the holes of the rear internal gear.




4. Apply ATF to the rear internal gear, and install it in the forward clutch hub by turning it evenly and gradually.
5. Hold the forward clutch hub and verify that the rear internal gear turns counterclockwise. If it does not, then the one way clutch is installed upside down.




6. Apply petroleum jelly to the bearing, and install it on the rear internal gear.


Bearing outer diameter: 78.0 mm { 3.071 in }



7. Apply petroleum jelly to the thrust washer, and set it so that the tabs fit in the holes of the overrunning clutch hub.



8. Set the overrunning clutch hub on the rear internal gear.










9. Apply petroleum jelly to the bearing race, and set it on the front internal gear.

Bearing race outer diameter: 75.0 mm { 2.953 in }

**FORWARD CLUTCH DRUM
(FORWARD CLUTCH, OVERRUNNING CLUTCH, LOW ONE-WAY CLUTCH)**

**Preparation
SST**

<p>49 G019 0A7A Compressor set, return spring</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 L019 001 Bolts</p> 	<p>For disassembly / assembly of snap ring</p>




Preinspection

Low one-way clutch operation

Install the forward clutch drum into the transmission case, and verify that the forward clutch drum rotates smoothly when turned clockwise and locks when turned counterclockwise.

If not, replace the one-way clutch.




Forward clutch and overrunning clutch operation

1. Install the forward clutch drum and low one-way clutch inner race into the transmission case. Apply compressed air through the oil passage as shown.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

2. Verify that the retaining plates move toward the snap ring. If not, the D-ring or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect the parts, and replace if necessary when assembling.



Clearance between retaining plate and snap ring

Measure the clearance between the retaining plate and the snap ring of the forward clutch and the overrunning clutch.

Standard clearance

Forward clutch:

0.45—2.05 mm { 0.018—0.081 in }


Overrunning clutch:

1.0—2.0 mm { 0.039—0.079 in }


Select the correct retaining plate when assembling if not within the specification.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Snap ring 2. Snap ring 3. Retaining plate 4. Drive plates and driven plates
Inspection page K1-74 5. Dished plate 6. Snap ring 7. Retaining plate 8. Drive plates and driven plates
Inspection page K1-74 9. Dished plate 10. Snap ring
Disassembly Note page K1-73 11. Spring retainer 12. Return spring
Inspection page K1-74 | <ol style="list-style-type: none"> 13. Forward clutch piston
Disassembly Note page K1-73 14. Seal ring 15. D-ring 16. Overrunning clutch piston
Disassembly Note page K1-73
Inspection page K1-74 17. D-ring 18. D-ring 19. Snap ring 20. Side plate 21. Low one-way clutch 22. Snap ring 23. Bearing (radial bearing) 24. Forward clutch drum
Inspection page K1-74 |
|---|--|



Disassembly note

Snap ring


1. Assemble the SSTs.



Caution

- Depress the spring retainer only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.

2. While holding the spring retainer down by using the SSTs, remove the snap ring by using snap ring pliers.
3. Remove the spring retainer and springs.




Piston

1. Set the forward clutch drum in the transmission case.
2. Remove the piston by applying compressed air through the oil passage.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.

3. Remove the overrunning clutch piston from the forward clutch piston.




Inspection Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard thickness: 2.0 mm { 0.079 in }
Minimum thickness: 1.8 mm { 0.071 in }

2. If it is less than the minimum, replace the drive plates.




Return spring

1. Measure the spring specifications.

Specifications

Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
9.7 { 0.382 }	35.8 { 1.409 }	10.3	1.3 { 0.051 }


2. If not correct, replace the spring.



Clutch piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is airflow when applying compressed air through the oil hole on return spring side.


Air pressure: 392 kPa { 4.0 kgf/cm², 57 psi } max.



Forward clutch drum


1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the low and reverse brake.
2. Verify that there is air flow when applying compressed air through the oil hole on the low and reverse brake side.

Air pressure: 392 kPa { 4.0 kgf/cm², 57 psi } max.




Assembly procedure


1. Apply ATF to the bearing, and install it into the forward clutch drum.
2. Install the snap ring.




3. Apply ATF to the low one-way clutch. Install it carefully into the forward clutch drum with the flange facing upward.




4. Apply ATF to the side plate and snap ring, and install them into the forward clutch drum.




5. Apply ATF to the new D-ring and seal ring, and install them into the forward clutch as shown.




6. Apply ATF to the new D-ring and seal ring, and install them into the overrunning clutch piston as shown.




7. Apply ATF to the inner surface of the forward clutch drum and overrunning clutch piston.
8. Apply even pressure to the perimeter of the forward clutch piston, and install it into the forward clutch drum by turning it evenly and gradually. Align the notches in the forward clutch piston with the grooves in the forward clutch drum.
9. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.



10. Apply ATF to the inner surface of the forward clutch piston and overrunning clutch piston.
11. Apply even pressure to the perimeter of the overrunning clutch piston, and install it into the forward clutch piston by turning it evenly and gradually.





12. Install the springs and spring retainer.




Caution

- Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.


13. While holding the spring retainer down by using the SSTs, install the snap ring into the spring retainer stopper.



14. Install the dished plate as shown.
15. Soak new drive plates in ATF for at least two hours.
16. Apply ATF to the driven plates immediately before assembly.
17. Install the drive and driven plates into the forward clutch piston in the following order.
Driven-Drive-Driven-Driven-Drive-Driven-Driven-Drive



18. Install the retaining plate.
19. Install the snap ring.



20. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within specification, adjust the clearance by installing the correct retaining plate.


Standard clearance:

1.0—2.0 mm { 0.039—0.079 in }

Retaining plate sizes

mm { in }

4.0 { 0.157 }	4.2 { 0.165 }	4.4 { 0.173 }	4.6 { 0.181 }
4.8 { 0.189 }	5.0 { 0.197 }	5.2 { 0.205 }	



21. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.


Standard clearance:

1.0—1.4 mm { 0.039—0.055 in }

Retaining plate sizes


mm { in }

4.0 { 0.157 }	4.2 { 0.165 }	4.4 { 0.173 }	4.6 { 0.181 }
4.8 { 0.189 }	5.0 { 0.197 }	5.2 { 0.205 }	




22. Install the dished plate as shown.
23. Soak new drive plates in ATF for at least two hours.
24. Apply ATF to the driven plates immediately before assembly.
25. Install the drive and driven plates into the forward clutch piston in the following order.

Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven Drive-Driven-Drive



26. Install the retaining plate.
27. Install the snap ring.




28. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within the specification, adjust the clearance by installing the correct retaining plate.

Standard clearance:
0.45—2.05 mm { 0.018—0.081 in }

Retaining plate sizes

mm { in }			
4.0 { 0.157 }	4.2 { 0.165 }	4.4 { 0.173 }	4.6 { 0.181 }
4.8 { 0.189 }	5.0 { 0.197 }	5.2 { 0.205 }	—




29. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining ring.

Standard clearance:
0.45—0.85 mm { 0.018—0.033 in }


Retaining plate sizes


mm { in }			
4.0 { 0.157 }	4.2 { 0.165 }	4.4 { 0.173 }	4.6 { 0.181 }
4.8 { 0.189 }	5.0 { 0.197 }	5.2 { 0.205 }	—



30. Install the snap ring.

Installation of proper assembly




**Caution**


- Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.

1. Set the forward clutch drum in the transmission. Apply compressed air through the oil passage, and check the forward clutch and overrunning clutch operation.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




2. Verify that the forward clutch drum turns clockwise only. If it turns counterclockwise, the one-way clutch is installed upside down.

**LOW AND REVERSE BRAKE****Preinspection****Low and reverse brake operation**

1. Apply compressed air through the oil passage as shown.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.


2. Verify that the retaining plates move toward the snap ring. If not, the D-ring or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect them, and replace when assembling.

**Clearance between retaining plate and snap ring**

Measure the clearance between the retaining plate and the snap ring to the forward clutch and the overrunning clutch.


Standard clearance: 0.7—2.3 mm { 0.028—0.091 in }

Select the correct retaining plate when assembling if not within the specification.




Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.




- | | |
|-----------------------------------|-----------------------------------|
| 1. Snap ring | 7. Spring retainer |
| 2. Retaining plate | 8. Return spring |
| 3. Drive plates and driven plates | Inspection page K1-99 |
| Inspection page K1-81 | 9. Bearing |
| 4. Dished plate | 10. Seal rings |
| 5. Allen head bolts | 11. Low and reverse brake piston |
| 6. Low one-way clutch inner race | Disassembly Note page K1-81 |
| Disassembly Note page K1-81 | 12. D-ring |
| Inspection page K1-81 | 13. Seal ring |



Disassembly note

Low one-way clutch inner race


1. Loosen the bolts gradually in a crisscross pattern. Hold the inner race with your free hand so that it doesn't spring out.
2. Remove the low one-way clutch inner race, spring retainer, and return springs.



Low and reverse brake piston

Remove the low and reverse brake piston by applying compressed air through the oil passage as shown in the figure.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.



Inspection


Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard thickness: 2.0 mm { 0.079 in }

Minimum thickness: 1.8 mm { 0.071 in }

2. If it is less than the minimum, replace the drive plates.




Return spring

1. Measure the spring specifications.

Specifications

Outer dia. mm { in }	Free length mm { in }	No. of coil	Wire dia. mm { in }
11.6 { 0.457 }	23.7 { 0.933 }	5.0	1.1 { 0.043 }

2. If not correct, replace the spring.




Low one-way clutch inner race

1. Apply petroleum jelly to a new seal ring and install the seal ring.
2. Measure the clearance between the seal ring and the ring groove.


Clearance: 0.10—0.25 mm { 0.0039—0.0098 in }

3. If not within the specification, replace the low one-way clutch inner race.




Assembly procedure

1. Apply ATF to the new D-ring and seal ring and install them to the low and reverse brake piston.




2. Apply ATF to the inner surface of the transmission case.
3. Apply even pressure to the perimeter of the low and reverse brake piston, and install it into the transmission case by turning it evenly and gradually.
4. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.




5. Apply petroleum jelly to the bearing, and install it on the low one-way clutch inner race.


Bearing outer diameter: 78.0 mm { 3.071 in }



6. Assemble the return spring, spring retainer and low one way clutch inner race to the low and reverse brake piston.




7. Check that the return spring, spring retainer, and low one way clutch inner race are properly positioned before securing them with the Allen head bolts.



8. Tighten the Allen head bolts evenly and gradually in the order shown.


Tightening torque:

21—26 N·m { 2.1—2.7 kgf·m , 15—20 ft·lbf }




9. Soak new drive plates in ATF for at least two hours.
10. Apply ATF to the driven plates immediately before assembly.
11. Install the drive and driven plates into the transmission case in the following order.

Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven Drive-Driven-Drive



12. Install the retaining plate.
13. Install the snap ring.



14. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within specification, adjust the clearance by installing the correct retaining plate.

Standard clearance: 0.7—2.3 mm { 0.028—0.091 in }

Retaining plate sizes

mm { in }

9.0 { 0.354 }	9.2 { 0.362 }	9.4 { 0.370 }	9.6 { 0.378 }
9.8 { 0.386 }	10.0 { 0.394 }	—	—


15. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.


Standard clearance: 0.7—1.1 mm { 0.028—0.043 in }

Retaining plate sizes

mm { in }

9.0 { 0.354 }	9.2 { 0.362 }	9.4 { 0.370 }	9.6 { 0.378 }
9.8 { 0.386 }	10.0 { 0.394 }	—	—




**Caution**

- Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.

16. Check operation of the piston by applying compressed air through the oil passage of the low and reverse brake.

Air pressure: 392 kPa { 4.0 kgf/cm² , 57 psi } max.




17. Apply petroleum jelly to the seal rings and fit them into the ring grooves of the low one-way clutch inner race.

EXTENSION HOUSING AND PARKING MECHANISM

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.




1. Extension housing (2WD)
2. Adapter case (4WD)
3. Parking gear
4. Output shaft
5. Parking pawl spacer
6. Return spring
7. Parking pawl
8. Parking pawl shaft
9. Parking actuator
10. Locknut


11. Manual plate
12. Parking rod
13. Roll pin
14. Manual shaft
15. Spacer
16. Detent spring
17. Oil seal

Disassembly Note page K1-86

18. Transmission case



Disassembly note
Oil seal (Transmission side)
 Remove the oil seal.




Assembly procedure
Extension housing


1. Apply ATF to the parking actuator, and install it in the extension housing.

Tightening torque:

24—29 N·m { 2.4—3.0 kgf·m , 18—21 ft·lbf }




2. Apply ATF to the parking pawl shaft and install it in the extension housing.
3. Apply ATF to the parking pawl, return spring and spacer, and install them in the extension housing.




Manual shaft


1. Apply ATF to the lip surface of a new oil seal and install it onto the manual shaft.
2. Wrap the threads of the manual shaft with tape.



3. Apply ATF to the bearing in the transmission case.
4. Install the manual shaft into the transmission case.
5. Push the oil seal squarely into the transmission case.
6. Remove the tape.




7. Align the groove in manual shaft with the roll pin hole, then tap the roll pin into the case as shown in the figure.




8. Install the detent spring and spacer.

Tightening torque:

4.0—5.8 N·m { 40—60 kgf·cm , 35—52 in·lbf }




9. Install the manual plate and parking rod.




10. Tighten the locknuts.

Tightening torque:


30—39 N·m { 3.0—4.0 kgf·m , 22—28 ft·lbf }




11. Check the parking mechanism operation.

**On-vehicle Removal**


1. Disconnect the negative battery terminal.
2. On level ground, jack up the vehicle and support it evenly on safety stands.
3. Remove the propeller shaft. (Refer to section L.)
4. Disconnect the speedometer cable.
5. Disconnect the output speed sensor.
6. Support the transmission with a transmission jack.




7. Remove the lower transmission mount.



8. Remove the upper transmission mount.



9. Remove the extension housing and gasket, making sure to catch any draining ATF in a container.

**On-vehicle Installation**


1. Install a new gasket on the transmission case.
2. Install the extension housing.

Bolt length (Measured from below the head)

- Ⓐ : 30 mm { 1.181 in }
- Ⓑ : 45 mm { 1.772 in }

Tightening torque:


20—25 N·m { 2.0—2.5 kgf·m , 14—18 ft·lbf }



3. Install the transmission upper mount.

Tightening torque:


44—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }



4. Install the transmission lower mount.
 (1) Temporarily install bolts and nuts (A).
 (2) Tighten bolts (B).

Tightening torque:


43—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }



5. Remove the transmission jack, and tighten bolts and nuts (A).

Tightening torque:


43—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }



6. Connect the speedometer cable. (2WD)
 7. Connect the output speed sensor.

Tightening torque:




5.0—6.8 N·m { 50—70 kgf·cm , 44—60 in·lbf }




8. Install the propeller shaft. (Refer to section L.)
 9. Add ATF, and check the ATF level.
 (Refer to page K1-30.)

OIL SEAL Preparation SST

The following **SSTs** are used for the 4WD model.

<p>49 U027 003</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>
<p>49 G030 797</p> <p>Handle (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>	<p>—</p>	<p>—</p>




Inspection


Check for damage, wear, and oil leakage. Replace if necessary.

On-vehicle Replacement 2WD model


1. Remove the propeller shaft. (Refer to section L.)
2. Remove the oil seal from the extension housing.




3. Apply ATF to the oil seal lip.
4. Install the new oil seal with a plastic hammer.



5. Install the propeller shaft. (Refer to section L.)

**4WD model**

1. Remove the transfer case. (Refer to section K2.)
2. Remove the oil seal from the adapter case.



3. Apply ATF to the oil seal lip.
4. Install the new oil seal with the **SSTs**.
5. Install the transfer case. (Refer to section K2.)

CONTROL VALVE BODY

Disassembly / Inspection

Caution

- **Denting or scratching these precisely machined components will reduce the ability of the transmission to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.**


1. Disassemble in the order shown in the figure, referring to **Disassembly Procedure**.
2. Neatly arrange the removed parts to avoid confusing similar parts.
3. Inspect all parts and repair or replace as necessary.

Warning


- **Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.**

4. Clean the removed parts with cleaning solvent, and dry them with compressed air. Clean out all holes and passages with compressed air.

Components




- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Torque converter clutch solenoid
Inspection page K1- 26 2. Side plate 3. Pressure control solenoid
Inspection page K1- 26 4. Overrunning clutch solenoid, shift solenoid A,
and shift solenoid B
Inspection page K1- 26 5. Support plate 6. Retaining bolts and nuts
Installation position page K1-108 7. Bracket
Installation position page K1-109 8. Lower valve body
Disassembly / Inspection /
Installation page K1-104 | <ul style="list-style-type: none"> 9. Steel ball
Installation position page K1-107 10. Upper gasket 11. Separator plate 12. Lower gasket 13. Accumulator filter 14. Orifice check valve and spring 15. Pilot filter 16. Manual valve 17. Upper valve body
Disassembly / Inspection /
Assembly page K1- 96 |
|---|--|




Procedure


1. Remove the torque converter clutch solenoid and side plate.




2. Remove the O-ring from the torque converter clutch solenoid.




3. Remove the clip and pressure control solenoid.
4. Remove the O-ring from the pressure control solenoid.




5. Remove the solenoids.
6. Remove the O-rings from the solenoids.




7. Remove the support plate.




8. Hold the lower valve body, lower and upper gaskets, and separator plate with a large clip.
9. Separate the lower valve body from the upper valve body.




10. Remove the steel balls from the upper valve body.



11. Face the lower valve body downward, and remove the holding clip.
12. Remove the separator plate and gaskets.



13. Remove the orifice check valve, orifice check spring, pilot filter and accumulator filter.



14. Remove the manual valve from the upper valve body.

UPPER VALVE BODY

Disassembly / Inspection / Assembly

Caution

- Denting or scratching these precisely machined components will reduce the ability of the transmission to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.
- Using a magnet in this procedure could magnetize the valve body inner components, reducing the ability of the transmission to shift properly.

Note


- If a valve does not slide out under its own weight, place the valve body open-side down and tap on the valve body lightly with a plastic hammer.

1. Disassemble in the order shown in the figure, noting the proper reassembly direction of the valves and internal parts.
2. Inspect all parts and repair or replace as necessary.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.

3. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | | | |
|--|------------|--|------------|
| 1. Retainer
Disassembly Note | page K1-98 | 29. Shift valve A spring
Inspection | page K1-98 |
| 2. Torque converter relief spring
Inspection | page K1-98 | 30. Shift valve A | |
| 3. Torque converter relief valve | | 31. Stopper pin
Disassembly Note | page K1-98 |
| 4. Stopper pin
Disassembly Note | page K1-98 | 32. 4-2 relay plug | |
| 5. Pressure regulator sleeve | | 33. 4-2 relay valve | |
| 6. Pressure regulator spring
Inspection | page K1-98 | 34. 4-2 relay spring
Inspection | page K1-98 |
| 7. Pressure regulator plug | | 35. Stopper pin
Disassembly Note | page K1-98 |
| 8. Pressure regulator valve | | 36. Overrunning clutch control plug | |
| 9. Stopper pin
Disassembly Note | page K1-98 | 37. Overrunning clutch control spring
Inspection | page K1-98 |
| 10. Pressure modifier plug | | 38. Overrunning clutch control valve | |
| 11. Pressure modifier spring
Inspection | page K1-98 | 39. Stopper pin
Disassembly Note | page K1-98 |
| 12. Pressure modifier valve | | 40. Overrunning clutch reducing plug | |
| 13. Stopper pin
Disassembly Note | page K1-98 | 41. Overrunning clutch reducing valve | |
| 14. Accumulator control plug | | 42. Overrunning clutch reducing spring
Inspection | page K1-98 |
| 15. Accumulator control spring (2WD)
Inspection | page K1-98 | 43. Stopper pin
Disassembly Note | page K1-98 |
| 16. Accumulator control valve | | 44. Shuttle shift valve S plug | |
| 17. Accumulator control sleeve | | 45. Shuttle shift valve S spring
Inspection | page K1-98 |
| 18. Stopper pin
Disassembly Note | page K1-98 | 46. Plug (2WD) | |
| 19. Shuttle shift valve D plug | | 47. Shuttle shift valve S | |
| 20. Shuttle shift valve D | | 48. Retainer
Disassembly Note | page K1-98 |
| 21. Shuttle shift valve D spring
Inspection | page K1-98 | 49. Pilot spring
Inspection | page K1-98 |
| 22. Retainer
Disassembly Note | page K1-98 | 50. Pilot valve | |
| 23. Shift valve B spring
Inspection | page K1-98 | 51. Stopper pin
Disassembly Note | page K1-98 |
| 24. Shift valve B | | 52. Torque converter clutch control sleeve | |
| 25. Stopper pin
Disassembly Note | page K1-98 | 53. Torque converter clutch control plug | |
| 26. 4-2 sequence plug | | 54. Torque converter clutch control valve | |
| 27. 4-2 sequence valve | | 55. Torque converter clutch control spring
Inspection | page K1-98 |
| 28. 4-2 sequence spring
Inspection | page K1-98 | 56. Upper valve body | |



Disassembly note


Stopper pin

1. Push the stopper pin way out with a wire.
2. Depress and hold the plug or sleeve with a finger to prevent the valve from jumping out.
3. Remove the stopper pin, and remove the valve and internal parts.




Retainer

1. Push the retainer way out with a wire.
2. Hold the inside parts with a finger to prevent the valve from popping out.
3. Remove the retainer, the valve, and the internal parts.



4-2 sequence valve and 4-2 relay valve

1. Push the stopper pin way out with a wire.
2. Depress the plug with a vinyl tape wrapped 1.5 mm { 0.059 in } around the diameter rod to prevent the valve from popping out.
3. Remove the stopper pin, the valve, and the internal parts.



Inspection

1. Measure the spring specifications.
2. If not as specified, replace the spring(s).

(2WD)

Spring	Item	Outer dia. mm { in }	Free length mm { in }	No. of coils	Wire dia. mm { in }
Torque converter relief valve		9.0 { 0.354 }	38.0 { 1.496 }	12.7	1.4 { 0.055 }
Pressure regulator valve		31.5 { 1.240 }	14.0 { 0.551 }	5.64	1.6 { 0.063 }
Pressure modifier valve*	A	6.8 { 0.268 }	31.95 { 1.258 }	15.5	0.8 { 0.031 }
	B	6.9 { 0.272 }	32.60 { 1.283 }	13.2	0.8 { 0.031 }
	C	6.9 { 0.272 }	32.80 { 1.291 }	15.6	0.9 { 0.035 }
Accumulator control plug		10.5 { 0.413 }	17.0 { 0.669 }	4.3	0.5 { 0.020 }
Shuttle shift valve D		6.0 { 0.236 }	26.5 { 1.043 }	12.0	0.7 { 0.028 }


*: Either A, B or C type spring is installed before shipment. Only A type spring is available for replacement.

Spring	Item	Outer dia. mm { in }	Free length mm { in }	No. of coils	Wire dia. mm { in }
4-2 sequence valve		6.95 { 0.274 }	29.1 { 1.146 }	11.0	0.55 { 0.022 }
Shift valve B		7.0 { 0.276 }	25.0 { 0.984 }	9.5	0.65 { 0.026 }
4-2 relay valve		6.95 { 0.274 }	29.1 { 1.146 }	11.0	0.55 { 0.022 }
Shift valve A		7.0 { 0.276 }	25.0 { 0.984 }	9.5	0.65 { 0.026 }
Overrunning clutch control valve		7.0 { 0.276 }	23.6 { 0.929 }	7.9	0.6 { 0.024 }
Overrunning clutch reducing valve		7.1 { 0.279 }	32.7 { 1.287 }	14.1	1.1 { 0.043 }
Shuttle shift valve S		6.0 { 0.236 }	27.1 { 1.067 }	15.0	0.9 { 0.035 }
Pilot valve		9.1 { 0.358 }	25.7 { 1.012 }	8.3	1.1 { 0.043 }
Torque converter clutch control valve		13.0 { 0.512 }	18.5 { 0.728 }	3.5	0.75 { 0.030 }

(4WD)


Spring	Item	Outer dia. mm { in }	Free length mm { in }	No. of coils	Wire dia. mm { in }
Torque converter relief valve		9.0 { 0.354 }	38.0 { 1.496 }	12.7	1.4 { 0.055 }
Pressure regulator valve		14.0 { 0.551 }	44.0 { 1.732 }	7.9	1.4 { 0.055 }
Pressure modifier valve*	A	6.8 { 0.268 }	31.95 { 1.258 }	15.5	0.8 { 0.031 }
	B	6.9 { 0.272 }	32.60 { 1.283 }	13.2	0.8 { 0.031 }
	C	6.9 { 0.272 }	32.80 { 1.291 }	15.6	0.9 { 0.035 }
Shuttle shift valve D		6.0 { 0.236 }	26.5 { 1.043 }	12.0	0.7 { 0.028 }
4-2 sequence valve		6.95 { 0.274 }	29.1 { 1.146 }	11.0	0.55 { 0.022 }
Shift valve B		7.0 { 0.276 }	25.0 { 0.984 }	9.5	0.65 { 0.026 }
4-2 relay valve		6.95 { 0.274 }	29.1 { 1.146 }	11.0	0.55 { 0.022 }
Shift valve A		7.0 { 0.276 }	25.0 { 0.984 }	9.5	0.65 { 0.026 }
Overrunning clutch control valve		7.0 { 0.276 }	23.6 { 0.929 }	7.9	0.6 { 0.024 }
Overrunning clutch reducing valve		7.1 { 0.279 }	34.7 { 1.366 }	15.2	1.1 { 0.043 }
Shuttle shift valve S		5.5 { 0.217 }	43.0 { 1.693 }	22.2	0.85 { 0.033 }
Pilot valve		9.1 { 0.358 }	25.7 { 1.012 }	8.3	1.1 { 0.043 }
Torque converter clutch control valve		13.0 { 0.512 }	18.5 { 0.728 }	3.5	0.75 { 0.030 }

*: Either A, B or C type spring is installed before shipment. Only A type spring is available for replacement.




Assembly procedure


1. Insert the torque converter relief valve and spring.




2. Install the retainer while compressing the spring.




- Center the plug so that it fits onto the sleeve. While turning the sleeve slightly, insert the pressure regulator valve, plug, spring, and sleeve.




- Insert the stopper pin while pushing the sleeve.




- Insert the pressure modifier valve, spring, and plug.
- Insert the stopper pin while pushing the sleeve.




- Align the tab of the sleeve with the plug notch.




- Insert the accumulator control valve, sleeve, spring (2WD), and plug.
- Insert the stopper pin while pushing the plug.




10. Insert the shuttle valve D, spring, and plug.
11. Insert the stopper pin while pushing the plug.




12. Insert the 4-2 sequence valve, spring, and plug.




13. Push in the plug with a vinyl tape-wrapped 1.5 mm { 0.059 in } diameter rod.
14. Insert the stopper pin.




15. Insert the 4-2 relay valve and spring.
16. Push in the plug with a vinyl tape-wrapped 1.5 mm { 0.059 in } diameter rod.
17. Insert the stopper pin.




18. Insert the shift valve B and spring.
19. Insert the shift valve A and spring.
20. Insert the retainer while compressing the springs.




21. Insert the overrunning clutch control valve, spring, and plug.
22. Insert the stopper pin while pushing the plug.




23. Insert the overrunning clutch reducing valve, spring, and plug.
24. Insert the stopper pin while pushing the plug.



25. Insert the shuttle shift valve S, plug (2WD), spring, and plug.
26. Insert the stopper pin while pushing the plug.



27. Insert the torque converter clutch control valve, spring, plug, and sleeve.
28. Insert the stopper pin while pushing the sleeve.



29. Insert the pilot valve and spring.
30. Insert the retainer while pushing the spring.

MEMO

LOWER VALVE BODY**Disassembly / Inspection / Assembly****Caution**

- Denting or scratching these precisely machined components will reduce the ability of the transmission to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.
- Using a magnet in this procedure could magnetize the valve body inner components, reducing the ability of the transmission to shift properly.

1. Disassemble in the order shown in the figure.
2. Inspect all parts, repair or replace as necessary.


Note

- If a valve does not slide out under its own weight, place the valve body open-side down and tap on the valve body lightly with a plastic hammer.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.

3. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|--|--|
| 1. Stopper key
Disassembly Note page K1- 98 | 8. 3-2 timing spring
Inspection page K1-105 |
| 2. Modifier accumulator spring
Inspection page K1-105 | 9. 3-2 timing valve |
| 3. Modifier accumulator valve | 10. Stopper pin
Disassembly Note page K1- 98 |
| 4. Retainer | 11. Servo charger plug |
| 5. First reducing spring
Inspection page K1-105 | 12. Servo charger valve |
| 6. First reducing valve | 13. Servo charger spring
Inspection page K1-105 |
| 7. Retainer
Disassembly Note page K1- 98 | 14. Lower valve body |



Inspection


1. Measure the spring specifications.
2. If not as specified, replace the spring(s).

Spring	Item	Outer dia. mm { in }	Free length mm { in }	No. of coils	Wire dia. mm { in }
Modifier accumulator piston		9.8 { 0.386 }	30.5 { 1.201 }	8.8	1.3 { 0.051 }
First reducing valve		6.75 { 0.266 }	25.4 { 1.0 }	12.5	0.75 { 0.030 }
3-2 timing		6.75 { 0.266 }	20.55 { 0.809 }	7.5	0.75 { 0.030 }
Servo charger valve		6.5 { 0.256 }	33.2 { 1.307 }	12.0	0.5 { 0.020 }




Assembly procedure


1. Insert the servo charger valve, spring, and plug.
2. Insert the stopper pin while pushing the plug.



3. Insert the 3-2 timing valve and spring.
4. Insert the retainer while compressing the spring.




5. Insert the first reducing valve and spring.
6. Insert the retainer while compressing the spring.




7. Insert the modifier accumulator valve, spring.
8. Insert the stopper pin.


Steel ball installation positions









Bracket installation positions







Bolts and nuts installation positions




Identification letter	Bolts and nuts	Length mm { in }	Torque specification N-m { kgf-cm , in-lbf }
A		70 { 2.756 }	6.9—8.8 { 70—90 , 61—78 }
B		50 { 1.969 }	
C		33 { 1.299 }	
D		27 { 1.063 }	
E		55 { 2.165 }	
F		45 { 1.772 }	

CONTROL VALVE BODY**Assembly**


1. Verify that all parts are clean and free of dust and other small particles.
2. Apply ATF to all O-ring and gaskets.

**Assembly procedure**


1. Install the steel balls and reamer bolts into their proper positions of the upper valve body.
(Refer to page K1-108 for installation positions.)
2. Install the pilot filter, orifice check spring, orifice check valve and accumulator filter into their proper positions in the lower valve body.
3. Set the new upper and lower gaskets and the separator plate onto the lower valve body. Refer to the figure to distinguish the two gaskets.



4. Set the lower valve body onto the upper valve body.
5. Remove the holding clip.




6. The support plate locations are as shown.




7. Install the bolts, nuts, support plates, and brackets in their proper positions. (Refer to page K1-107 for installation positions.) Tighten the fasteners evenly and gradually.

Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




8. Install a new O-ring onto the torque converter clutch solenoid.




9. Install the torque converter clutch solenoid and side plate to the control valve body assembly.

Tightening torque:

9.8—12.7 N·m { 100—130 kgf·cm , 87—112 in·lbf }




10. Install the side plate as shown.



11. Install the new O-rings onto the solenoids.
12. Install the solenoids into the control valve body assembly.

Tightening torque:


6.9—9.8 N·m { 70—100 kgf·cm , 61—87 in·lbf }




13. Install a new O-ring onto the pressure control solenoid.
14. Install the pressure control solenoid and clip into the control valve body assembly.

Tightening torque:


6.9—9.8 N·m { 70—100 kgf·cm , 61—87 in·lbf }




15. Insert the manual valve.

**ON-VEHICLE REMOVAL**


1. Disconnect the negative battery cable.
2. On level ground, jack up the vehicle and support it evenly on safety stands.
3. Loosen the oil pan installation bolts, and drain the ATF into a container.




4. Install the new oil pan installation bolts.
5. Remove the oil pan and gasket.
6. Remove the magnet from the oil pan.




7. Remove the clip by using a small flathead screwdriver.
8. Disconnect the torque converter clutch solenoid connector.




9. Remove the transmission fluid temperature sensor.




10. Remove the oil strainer.
11. Remove the O-ring from the oil strainer.




12. Separate the solenoid harness from the harness clip.
13. Remove the transmission fluid temperature switch. (4WD)




14. Remove bolts (A) and (B) and the bracket shown in the figure.




15. Remove the clip.
16. Separate the solenoid connectors.



17. Carefully remove the control valve body assembly and accumulator springs.




18. If necessary, remove the solenoid connector from the transmission case.



ON-VEHICLE INSTALLATION

1. Install the solenoid connector into the transmission case if removed.
2. Connect the solenoid connector to the solenoids.
3. Install the clip.




4. Set the accumulator springs into the control valve body as shown.


Spring specifications

mm { in }

Spring	Item	Outer dia.	Free length	No. of coil	Wire dia.
3-4/N-R accumulator piston		17.3 { 0.681 }	58.4 { 2.299 }	12.3	2.3 { 0.091 }
1-2 accumulator piston		29.3 { 1.154 }	45.0 { 1.772 }	3.6	4.0 { 0.157 }
2-3 accumulator piston		20.0 { 0.787 }	66.0 { 2.598 }	11.4	3.5 { 0.138 }



5. Verify that the manual valve and manual shaft are assembled correctly.
6. Set the control valve body into the transmission case and secure it.



7. Install bolts (A) and (B) and the brackets as shown.

Bolt length (Measured from below the head)


(A): 33 mm { 1.299 in }

(B): 45 mm { 1.772 in }

8. Tighten the bolts in sequence.

Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




9. Apply ATF to the new O-ring and install it onto the oil strainer.
10. Install the oil strainer.

Bolt length (Measured from below the head):


50 mm { 1.969 in }

Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




11. Mount the solenoid harness with the harness clip.
12. Install the transmission fluid temperature switch. (4WD)




13. Install the transmission fluid temperature sensor.

Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




14. Connect the torque converter clutch solenoid connector.
15. Install the clip.



16. Remove any old locking compound from the bolt holes.
17. Set the magnet into the oil pan.
18. Install the oil pan along with a new gasket.
19. Tighten the new bolts evenly and quickly.

Tightening torque:

6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }







20. Add approximately **4.0 L { 4.2 US qt , 3.5 Imp qt }** ATF, and check the ATF level. (Refer to page K1-30.)

TRANSMISSION UNIT (ASSEMBLY)

Preparation


SST

<p>49 0107 680A Engine stand</p> 	<p>For assembly of transmission</p>	<p>49 U019 0A0A Transmission hanger</p> 	<p>For assembly of transmission</p>
<p>49 H075 495B Body (Part of 49 U019 0A0A)</p> 	<p>For assembly of transmission</p>	<p>49 U019 003 Holder (Part of 49 U019 0A0A)</p> 	<p>For assembly of transmission</p>

Precaution

1. If the drive plates or brake band are replaced with new ones, soak in ATF for at least 2 hours before installation.
2. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, D-rings and sliding parts.
3. All O-rings, D-rings, seals, and gaskets must be replaced with new ones included in the overhaul kit.
4. Use petroleum jelly, not grease, during reassembly.
5. When it is necessary to replace a bushing, replace the subassembly that includes that bushing.
6. Assemble the housing within 10 minutes after applying sealant, and allow it to cure at least 30 minutes after assembly before filling the transmission with ATF.

Thrust washer, bearing, and race locations





Outer diameter of bearing and race

		1	2	3	4	5	6
Bearing	mm { in }	47.0 { 1.850 }	53.0 { 2.087 }	53.0 { 2.087 }	78.0 { 3.071 }	53.0 { 2.087 }	78.0 { 3.071 }
Race	mm { in }	43.5 { 1.713 }	51.5 { 2.028 }	—	75.0 { 2.953 }	—	75.0 { 2.953 }


		7	8
Bearing	mm { in }	59.0 { 2.323 }	64.0 { 2.520 }
Race	mm { in }	—	—

Torque specifications




**Procedure**

1. Install the forward clutch drum while slowly turning it clockwise until its hub passes fully over the clutch inner race.




2. Verify that the forward clutch assembly will turn only clockwise.




3. Install the rear internal gear, forward clutch hub, and overrunning clutch hub in the forward clutch assembly.
4. Measure the height difference between forward clutch retaining plate and top of the forward clutch drum.


Height: Approx. 2.0—3.0 mm { 0.079—0.118 in }




5. Install the front internal gear and rear planetary carrier into the forward clutch assembly.




6. Insert the output shaft.




7. Push the output shaft forward slightly, and install a new snap ring on it. Verify that the output shaft cannot be removed from the rear.




8. Apply petroleum jelly to the bearing and install it to the transmission case with the black surface facing toward the rear.




9. Install the parking gear.



10. Pull the output shaft back slightly, and install a new snap ring on it. Verify that the output shaft does not move forward.



11. Install the front snap ring, key, and speedometer drive gear onto the output shaft. (2WD)
12. Secure the speedometer drive gear with the rear snap ring. (2WD)



13. Install the gasket and extension housing.

Bolt length (Measured from below the head)

- Ⓐ: 30 mm { 1.181 in }
- Ⓑ: 45 mm { 1.772 in }

Tightening torque:



20—24 N·m { 2.0—2.5 kgf·m , 15—18 ft·lbf }

14. Install the O-ring onto the speedometer driven gear. (2WD)
15. Install the speedometer driven gear into the extension housing. (2WD)


Tightening torque:

5.0—6.8 N·m { 50—70 kgf·cm , 44—60 in·lbf }

16. Install the rear sun gear into the front internal gear, with the oil groove facing as shown.




17. Verify that the bearing and bearing race are installed correctly.
18. While rotating the forward clutch drum clockwise, install the front planetary carrier into the forward clutch assembly.




19. Install the reverse clutch, high clutch, and front sun gear into the transmission case as an assembly.

When any part in the following table is replaced, the total end play and/or reverse end play must be adjusted.


Part name	Item	Total end play	Reverse end play
Transmission case		○	○
Low one-way clutch inner race		○	○
Overrunning clutch hub		○	○
Rear internal gear		○	○
Rear planetary carrier		○	○
Rear sun gear		○	○
Front planetary carrier		○	○
Front sun gear		○	○
High clutch hub		○	○
High clutch drum		○	○
Oil pump cover		○	○
Reverse clutch drum		—	○




20. Adjust total end play.
 (1) Install the oil pump gasket.



- (2) Measure height A with vernier calipers and a straight edge.




- (3) Measure height B with vernier calipers.



- (4) Install the needle bearing on the oil pump.
- (5) Measure height C with vernier calipers and a straight edge.
- (6) Calculate the total end play by using the formula below.

Formula: $T1 = A - B - C - 0.1 \text{ mm } \{ 0.0039 \text{ in } \}$




- T1: Total end play**
A : Distance between bearing race of front side of transmission case and reverse clutch
B : Distance between front side of transmission case and oil pump gasket
C : Distance between upper surface of needle bearing of oil pump and oil pump gasket contact surface
0.1: Amount of compression of new oil pump gasket

Total end play specification:
0.25—0.55 mm { 0.010—0.022 in }


- (7) If the total end play is not within the specification, adjust it by selecting and installing the proper bearing race.

Bearing race size


				mm { in }
0.8 { 0.031 }	1.0 { 0.039 }	1.2 { 0.047 }	1.4 { 0.055 }	
1.6 { 0.063 }	1.8 { 0.071 }	2.0 { 0.079 }	—	



21. Adjust reverse clutch end play.
 - (1) Install the thrust washer on the reverse clutch.
 - (2) Measure height E with vernier calipers and a straight edge.




- (3) Measure height B with vernier calipers and a straight edge.



- (4) Measure height F with vernier calipers and a straight edge.
- (5) Calculate the reverse clutch end play by using the formula below.

Formula: $T_2 = E - B - F - 0.1 \text{ mm } \{ 0.0039 \text{ in } \}$




- T2: Reverse clutch end play
- B : Distance between front side of transmission case and oil pump gasket
- E : Distance between thrust washers of front side of transmission case and reverse clutch
- F : Distance between reverse clutch thrust washer contact surface of oil pump and oil pump gasket contact surface
- 0.1: Amount of compression of new oil pump gasket

**Reverse clutch end play specification:
0.55—0.90 mm { 0.022—0.035 in }**


- (6) If the reverse clutch end play is not within specification, adjust it by selecting and installing the proper reverse clutch thrust washer.

Thrust washer size


				mm { in }
0.7 { 0.028 }	0.9 { 0.035 }	1.1 { 0.043 }	1.3 { 0.051 }	
1.5 { 0.059 }	1.7 { 0.067 }	1.9 { 0.075 }	—	




22. Apply ATF to the brake band and band strut, and install them into the transmission.




23. Install a new anchor end bolt.



24. Apply ATF to the input shaft, and install it into the transmission case.




25. Apply petroleum jelly to the oil pump assembly as shown.




26. Turn the transmission as shown. Install the oil pump assembly into the transmission case by hand only, using two converter housing bolts as guides. Measure the height difference between the top of the transmission case and oil pump.


Height: Approx. 1.0 mm { 0.039 in }




27. Apply ATF to a new O-ring, and install it onto the input shaft.



28. Apply ATF to the new O-rings, and install them into the converter housing, as shown.




29. Apply sealant lightly as shown.



30. Remove the converter housing bolts used as guides.
 31. Install the converter housing onto the transmission case, and tighten the bolts evenly in a crisscross pattern.

Tightening torque:

74—76 N·m { 7.5—7.8 kgf·m , 55—56 ft·lbf }




32. Adjust the brake band.

- (1) Tighten the anchor end bolt with a hex wrench.

Tightening torque:

4.0—5.8 N·m { 40—60 kgf·cm , 35—52 in·lbf }




- (2) Loosen the anchor end bolt 2.5 turns.

(3) Install the locknut.

- (4) Hold the anchor end bolt with a hex wrench and tighten the locknut.

Tightening torque:

41—50 N·m { 4.1—5.2 kgf·m , 30—37 ft·lbf }




33. Apply ATF to a new O-ring, and install it onto the output speed sensor.


34. Mount the output speed sensor into the extension housing.

Tightening torque:


5.0—6.8 N·m { 50—70 kgf·cm , 44—60 in·lbf }




35. Apply ATF to a new O-ring, and install it onto the solenoid connector.
36. Install the solenoid connector into the transmission case.



37. Connect the solenoid connector to the solenoids.
38. Install the clip.



39. Verify that the manual valve and manual shaft are assembled correctly.
40. Set the control valve body into the transmission case and secure it.



41. Install the bolts (A) and (B) and the brackets as shown.


Bolt length (Measured from below the head)

(A): 33 mm { 1.299 in }

(B): 45 mm { 1.772 in }

Tightening torque:


6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




42. Apply ATF to a new O-ring, and install it onto the oil strainer.
43. Install the oil strainer.

Bolt length (Measured from below the head):
50 mm { 1.969 in }

Tightening torque:
6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




44. Mount the solenoid harness with the harness clips.
45. Install the transmission fluid temperature switch. (4WD)




46. Install the transmission fluid temperature sensor as shown in the figure.

Tightening torque:
6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }




47. Connect the torque converter clutch solenoid connector.
48. Install the clip.



49. Remove any old locking compound from the bolt holes.
50. Set the magnet into the oil pan.
51. Install the oil pan along with the new gasket.
52. Tighten the new bolts evenly and quickly.

Tightening torque:
6.9—8.8 N·m { 70—90 kgf·cm , 61—78 in·lbf }



53. Install the transmission range switch.


(1) Install the bracket.

Tightening torque:

7.8—12 N·m { 80—120 kgf·cm , 69—104 in·lbf }

(2) Verify that the manual shaft is positioned at the L position (fully forward).

(3) Install the transmission range switch over the manual shaft.



(4) Turn the manual shaft fully rearward, then return it two (2) notches (N position).


(5) Insert a **4.0 mm { 0.157 in }** pin through the holes of the transmission range switch and the manual shaft lever.

(6) Tighten the transmission range switch retaining bolts.

Tightening torque:


2.5—3.9 N·m { 25—40 kgf·cm , 22—34 in·lbf }

(7) Remove the pin.



54. If the torque converter is completely empty, hold it upright and fill it with **2.0 L { 2.1 US qt , 1.81 Imp qt }** of ATF. If the torque converter has not been completely drained, add the same amount of ATF that was drained out.

55. Install the torque converter into the transmission.



56. Measure the installation depth of the torque converter with vernier calipers and a straight edge.

Specification: 29.5 mm { 1.161 in }


TRANSMISSION UNIT (INSTALLATION)**Installation**

1. Install in the order shown in the figure, referring to **Installation Note**.
2. Fill the transmission with the specified ATF after installation. (Refer to page K1-30.)
3. Check for leakage of ATF from all connecting points.
4. Connect the negative battery cable.
5. Check operation of the transmission range switch. (Refer to page K1-23.)
6. Check operation of the selector lever. (Refer to page K1-138.)
7. Carry out the mechanical system test. (Refer to page K1-8.)

Service item	Test item	Line pressure test	Stall test	Time lag test
Automatic transmission replacement		○		
Automatic transmission overhaul		○	○	○
Torque converter replacement		○	○	
Oil pump replacement		○		
Clutch system replacement		○		


○: Test to be performed after work

8. Carry out the road test. (Refer to page K1-13.)




1. Transmission upper mount
Installation Note page K1-132
2. Transmission lower mount
Installation Note page K1-132
3. Transmission
Installation Note page K1-132
4. Gusset plate
5. Exhaust pipe bracket
6. Oil pipe
7. Transmission mount mounting bolt
8. Torque converter mounting bolt
Installation Note page K1-132

9. Undercover
10. Starter
11. Filler tube
12. Connector
13. Speedometer cable
14. Heat insulator
15. Exhaust pipe
16. Propeller shaft
Installation section L
17. Selector cable



- | | |
|--|---|
| 1. Transmission upper mount
Installation Note page K1-132 | 9. Undercover |
| 2. Transmission lower mount
Installation Note page K1-132 | 10. Starter |
| 3. Transmission
Installation Note page K1-132 | 11. Filler tube |
| 4. Gusset plate | 12. Connector |
| 5. Exhaust pipe bracket | 13. Speedometer cable |
| 6. Oil pipe | 14. Heat insulator |
| 7. Transmission mount mounting bolt | 15. Exhaust pipe |
| 8. Torque converter mounting bolt
Installation Note page K1-132 | 16. Front propeller shaft
Installation section L |
| | 17. Rear propeller shaft
Installation section L |
| | 18. Selector cable |


**Installation note****Transmission upper mount, Transmission lower mount**

1. Install the transmission upper mount on the transmission.


Tightening torque

Ⓑ: 44—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }

2. Hand tighten bolts and nuts Ⓐ.

**Transmission**


1. Set the transmission onto the transmission jack, paying special attention not to damage the oil pipes. Make sure that the torque converter side of the transmission is tilted slightly upward.



2. Install the exhaust pipe bracket.
3. Raise the transmission into place and tighten the installation bolts.

Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }



4. Tighten bolts Ⓑ.


Tightening torque

Ⓑ: 44—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }

5. Tighten bolts and nuts Ⓐ (transmission lower mount and transmission upper mount).

Tightening torque

Ⓐ: 44—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }

**Torque converter mounting bolts**

Loosely and equally tighten the torque converter bolts, then further tighten them to the specified tightening torque.

Tightening torque:


37—53 N·m { 3.7—5.5 kgf·m , 27—39 ft·lbf }

OIL COOLER

Removal / Installation


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.

Components (With towing package)




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Connector bolts 2. Packing 3. Transmission 4. Oil pipe 5. Oil hose Installation Note page K1-134 | <ol style="list-style-type: none"> 6. Oil pipe 7. Oil hose Installation Note page K1-134 8. Oil cooler 9. Radiator Refer to section E |
|--|---|

Components (Without towing package)



- 1. Connector bolts
- 2. Packing
- 3. Transmission
- 4. Oil pipe

- 5. Oil hose
Installation Note page K1-134
- 6. Radiator
Refer to section E







Installation note

Oil hose

1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated against the ridge.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other part.


DRIVE PLATE

Preparation
SST

<p>49 E011 1A0 Brake, Ring gear</p> 	<p>For prevention of engine rotation</p>	<p>49 E011 103 Shaft (Part of 49 E011 1A0)</p> 	<p>For prevention of engine rotation</p>
<p>49 E011 104 Collar (Part of 49 E011 1A0)</p> 	<p>For prevention of engine rotation</p>	<p>49 E011 105 Stopper (Part of 49 E011 1A0)</p> 	<p>For prevention of engine rotation</p>


Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



- 1. Transmission
Removal page K1- 32
Installation page K1-129
- 2. Bolts
- 3. Backing plate


- 4. Drive plate
Removal note page K1-136
Installation note page K1-136
- 5. Adapter



Removal note

Drive plate

Remove the drive plate by using the SST.








Installation note

Drive plate

1. Assemble the adapter, drive plate and backing plate.
2. Install the SST and tighten the bolts.

Tightening torque:

103—109 N·m { 10.5—11.2 kgf·m , 76—81 ft·lbf }



SHIFT MECHANISM

SHIFT-LOCK AND KEY INTERLOCK SYSTEM

Inspection

Shift-lock system operation

Shift-lock system

1. Verify that the selector lever is in P position.
2. Turn the ignition switch to ON (engine off).
3. Without the brake pedal depressed, verify that the selector lever cannot be shifted from P position.
4. Depress the brake pedal. Verify that the selector lever can be shifted from P position.
5. If not as specified, check or adjust the shift-lock system.

Key-interlock system

1. Shift the selector lever to R position.
2. Verify that the ignition key cannot be turned to the LOCK position.
3. Shift the selector lever to P position.
4. Verify that the ignition key can be turned to the LOCK position.
5. If not as specified, check or replace the key cylinder.

Emergency override link

1. Verify that the selector lever is locked in P position.
2. Depress and hold the emergency override link. Verify that the selector lever can be shifted from P position.
3. If not as specified, check or replace the shift-lock actuator.

Terminal voltage

1. Remove the column covers.
2. Turn the ignition switch to ON.
3. Measure the voltage between terminal-wire (O) and a ground.

B+: Battery positive voltage

Terminal voltage	Selector lever	Brake pedal
B+	P position (P position switch ON)	Depressed (Brake switch ON)
Below 1.5 V	Other conditions	



4. If not as specified, check the transmission range switch, brake switch, and CPU.

Adjustment

1. Remove the column covers.
2. Verify that the lock pin of the actuator is in the center of the lock lever.
3. If not, loosen the shift-lock actuator mounting bolts and adjust the lock pin position.

Tightening torque:

16—22 N·m { 1.6—2.3 kgf·m , 12—16 ft·lbf }



SELECTOR LEVER

Inspection

1. Verify that the selector lever can be shifted only as shown in the figure.
2. Make sure there is a click at each range when shifted from P position ↔ 1 range.
3. Verify that the positions of the selector lever and the indicator align.
4. Verify that the selector lever moves smoothly.
5. If not correct, adjust or repair the selector lever.

Adjustment

Selector cable

1. Shift the selector lever to P position.
2. Loosen nut (A) as shown in the figure.
3. Position the selector cable so that there is no load in the direction of the arrows, and tighten the nut.


Tightening torque:

16—22 N·m { 1.6—2.3 kgf·m , 12—16 ft·lbf }


4. Shift the selector lever from P position to 1 range, and make sure that there is no interference from other components in that area.

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts, and replace or repair as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|-------------------------------------|---|
| 1. Column cover | 8. Gear shift mounting |
| 2. Side cover | 9. Retaining ring, wave washer, adjustment washer |
| 3. Lower panel | Installation Note page K1-140 |
| 4. Connector | 10. Selector lever |
| 5. Nut | Installation Note page K1-140 |
| Installation Note page K1-140 | 11. Clip |
| 6. Clip | 12. Clip |
| 7. Shift-lock actuator | 13. Selector cable |
| Installation Note page K1-140 | |

**Installation note****Retaining ring, wave washer, adjustment washer**


1. Measure the clearance between the bracket of the steering shaft and the adjustment washer.

Clearance: 0.3 mm { 0.012 in } max.


2. If not within the specification, adjust the clearance by installing the correct adjustment washer(s).

Adjustment washer size:

**1.0 mm { 0.039 in }, 1.2 mm { 0.047 in },
1.4 mm { 0.055 in }**

**Selector lever**


1. Shift the selector lever to P position.
2. Pull the selector lever rearward (toward driver) and insert a **5.0 mm { 0.197 in }** outer diameter pin into the selector lever assembly as shown.

**Shift-lock actuator**

1. Install the lock pin of the actuator in the center of the lock lever.

Tightening torque:

16—22 N·m { 1.6—2.3 kgf·m , 12—16 ft·lbf }

**Nut**

1. Position the selector cable so that there is no load in the direction of the arrows, and tighten the nut.









Tightening torque:


16—22 N·m { 1.6—2.3 kgf·m , 12—16 ft·lbf }

2. Remove the pin from the selector lever assembly.

ON-BOARD DIAGNOSTIC SYSTEM




PREPARATION
SST

<p>49 T088 0A0 NGS set</p> 	<p>For diagnosis of EC-AT</p>	<p>49 T088 010B Program Card</p> 	<p>For diagnosis of EC-AT</p>
<p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For diagnosis of EC-AT</p>	<p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p> 	<p>For diagnosis of EC-AT</p>
<p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis of EC-AT</p>	<p>49 T088 009 Case (Part of 49 T088 0A0)</p> 	<p>For diagnosis of EC-AT</p>
<p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis of EC-AT</p>	<p>49 T088 008 Instruction Manual</p> 	<p>For diagnosis of EC-AT</p>



**DIAGNOSTIC TROUBLE CODE
Inspection Procedure**

1. Connect the **SST** (NGS) to the data link connector 2 and battery.
2. Turn the ignition switch to ON.
3. Check the diagnostic trouble code(s), referring to the **SST** (NGS). (Refer to section F.)
4. If a diagnostic trouble code(s) is displayed, check for the cause by using the number on the diagnostic trouble code table. (Repair as necessary.)
5. Following repairs, do the After-repair Procedure to verify that there are no remaining codes.

**After-repair Procedure**

1. Cancel the diagnostic trouble code memory by using the **SST (NGS)**. (Refer to section F.)
2. Remove the **SST (NGS)** from the data link connector 2.

3. Drive the vehicle at 50 km/h { 31 mph }, and depress the accelerator pedal fully to activate kickdown. Stop the vehicle gradually.

4. Connect the **SST (NGS)** to the data link connector 2 and battery.
5. Turn the ignition switch to ON.
6. Verify that no diagnostic trouble codes are displayed. (Refer to section F.)
7. Remove the **SST** from the data link connector 2.

Troubleshooting

If a diagnostic trouble code is shown on the **SST**, check for the cause by using the chart related to the code shown.

Diagnostic trouble code

Code No.	Display on the NGS	Condition	Page
P0705	TRANS RANGE SENSOR — CKT MALFUNCTION	Transmission range switch	K1-144
P0710	TRANS FLUID TEMP SENS — CKT MALFUNCTION	Transmission fluid temperature sensor	K1-145
P0720	OUTPUT SPEED SENSOR — CKT MALFUNCTION	Output speed sensor	K1-146
P0725	ENGINE SPEED INPUT — CKT MALFUNCTION	Engine speed input signal	K1-147
P0731	GEAR 1 INCORRECT RATIO	Gear 1 incorrect ratio	K1-148
P0732	GEAR 2 INCORRECT RATIO	Gear 2 incorrect ratio	K1-149
P0733	GEAR 3 INCORRECT RATIO	Gear 3 incorrect ratio	K1-150
P0734	GEAR 4 INCORRECT RATIO	Gear 4 incorrect ratio	K1-151
P0740	TORQUE CONV CLUTCH SYS — MALFUNCTION	Torque converter clutch system	K1-152
P0745	PRESSURE CTRL SOLENOID — MALFUNCTION	Pressure control solenoid	K1-153
P0750	SHIFT SOLENOID A — MALFUNCTION	Shift solenoid A	K1-154
P0755	SHIFT SOLENOID B — MALFUNCTION	Shift solenoid B	K1-155
P1720	VSS2 — No VSS2 SIGNAL	Vehicle speedometer sensor	K1-156
P1743	SOLENOID TCC — OPEN OR SHORT	Torque converter clutch solenoid valve	K1-157
P1770	OVRCSOL. — OPEN OR SHORT	Overrunning clutch solenoid valve	K1-158
P1790	TPS — OPEN OR SHORT	Throttle position sensor	K1-159
P1792	BARO — CIRCUIT MALFUNCTION	Barometric pressure sensor	K1-160

DIAGNOSTIC TROUBLE CODE P0705		TRANS RANGE SENSOR—CKT MALFUNCTION (Transmission range switch)																													
DETAILS	No input signal or input of two or more signals from transmission range switch																														
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Transmission range switch malfunction • Damaged wiring or connectors between transmission range switch and transmission control module • Transmission control module malfunction 																														
STEP	INSPECTION		ACTION																												
1	Are transmission control module and transmission range switch connections at the connector and connector pins OK?	Yes	Go to next step																												
		No	Repair or replace connector(s) Go to step 6 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart 																												
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect the EC-AT tester to transmission control module • Are transmission range switch range and EC-AT tester display correct? <p style="text-align: center;">🔍 page K1-17</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Item</th> <th>Indication</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">P/N</td> <td>ON</td> <td>P or N position</td> </tr> <tr> <td>OFF</td> <td>R position, all ranges</td> </tr> <tr> <td rowspan="2">R</td> <td>ON</td> <td>R position</td> </tr> <tr> <td>OFF</td> <td>Other positions, all ranges</td> </tr> <tr> <td rowspan="2">D</td> <td>ON</td> <td>D range</td> </tr> <tr> <td>OFF</td> <td>Other ranges, all positions</td> </tr> <tr> <td rowspan="2">2</td> <td>ON</td> <td>2 range</td> </tr> <tr> <td>OFF</td> <td>Other ranges, all positions</td> </tr> <tr> <td rowspan="2">1</td> <td>ON</td> <td>1 range</td> </tr> <tr> <td>OFF</td> <td>Other ranges, all positions</td> </tr> </tbody> </table>	Item	Indication	Condition	P/N	ON	P or N position	OFF	R position, all ranges	R	ON	R position	OFF	Other positions, all ranges	D	ON	D range	OFF	Other ranges, all positions	2	ON	2 range	OFF	Other ranges, all positions	1	ON	1 range	OFF	Other ranges, all positions	Yes	Go to step 6
		Item	Indication	Condition																											
		P/N	ON	P or N position																											
			OFF	R position, all ranges																											
		R	ON	R position																											
			OFF	Other positions, all ranges																											
		D	ON	D range																											
			OFF	Other ranges, all positions																											
		2	ON	2 range																											
			OFF	Other ranges, all positions																											
1	ON	1 range																													
	OFF	Other ranges, all positions																													
No	Go to next step																														
3	Check for continuity between terminals of transmission range switch and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission range switch and transmission control module connectors • Is there continuity between terminals? 	Yes	Go to next step																												
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 6 • When No, go to next step 																												
4	Check for continuity between terminal of the transmission range switch as follows <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission range switch connector • Is there continuity between terminals? 	Yes	Go to next step																												
		No	Repair or adjust transmission range switch 🔍 page K1-23 Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 6 • When No, go to next step 																												
5	Check for continuity between terminal of transmission range switch and main relay <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission range switch and main relay • Is there continuity between terminals? 	Yes	Go to next step																												
		No	Repair or replace connectors and wiring																												
6	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown 🔍 page K1-141	Yes	Replace the transmission control module																												
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further																												

DIAGNOSTIC TROUBLE CODE P0710		TRANS FLUID TEMP SENS—CKT MALFUNCTION (Transmission fluid temperature sensor)	
DETAILS		Transmission control module input voltage is less than 0.09V or over 5.0V	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • Transmission fluid temperature sensor malfunction • Damaged wiring or connectors between transmission fluid temperature sensor and transmission control module • Transmission control module malfunction 	
STEP	INSPECTION		ACTION
1	Are transmission control module and transmission fluid temperature sensor connections at the connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector Go to step 6 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is transmission fluid temperature sensor voltage correct? Voltage ATF temp. 10 °C { 50 °F } : Approx. 1.8 V 40 °C { 104 °F } : Approx. 1.1 V ↳ page K1-17	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of transmission fluid temperature sensor and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission fluid temperature sensor and transmission control module connectors • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step
4	Measure resistance between transmission fluid temperature sensor terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission fluid temperature sensor connector • Is resistance between terminals correct? Resistance ATF temp. 20 °C { 68 °F } : Approx. 2.5 kΩ 80 °C { 176 °F } : Approx. 0.3 kΩ ↳ page K1-24	Yes	Go to next step
		No	Replace transmission fluid temperature sensor ↳ page K1-24
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ↳ page K1-141	Yes	Replace the transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P0720		OUTPUT SPEED SENSOR—CKT MALFUNCTION (Output speed sensor)	
DETAILS	Signal from output speed sensor is not input to transmission control module when vehicle is moving		
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Output speed sensor malfunction • Damaged harness or connectors between output speed sensor and transmission control module • Transmission control module malfunction 		
STEP	INSPECTION		ACTION
1	Are transmission control module and output speed sensor connection at the connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector Go to step 5 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Measure terminal voltage at terminals 2J and 2L of transmission control module as follows <ul style="list-style-type: none"> • Start engine • Connect a circuit tester • Is terminal voltage as specified? Standard voltage Vehicle speed above 25 km/h { 16 mph }: Above 1 V Vehicle stopped: 0 V ⓘ page K1-27	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of output speed sensor and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect output speed sensor and transmission control module connectors • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step
4	Measure resistance between output speed sensor terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect output speed sensor connector • Is resistance between terminals correct? Resistance: 504—616 Ω ⓘ page K1-25	Yes	Go to next step
		No	Replace output speed sensor ⓘ page K1-25
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ⓘ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P0725		ENGINE SPEED INPUT—CKT MALFUNCTION (Engine speed input circuit)	
DETAILS		Engine speed input signal is not input to the transmission control module	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • Crank angle sensor—2 malfunction • Damaged wiring or connector between engine control module and transmission control module • Engine control module • Transmission control module 	
STEP	INSPECTION		ACTION
1	Is diagnostic trouble code P0335 indicated? <small>☞</small> section F	Yes	Refer to flowchart for diagnostic trouble code P0335, and perform troubleshooting <small>☞</small> section F
		No	Go to next step
2	Are transmission control module and engine speed input signal connection at the connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector Go to step 7 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
3	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is speed indicated on EC-AT tester after engine is started and vehicle is idling? <small>☞</small> page K1-17	Yes	Go to step 7
		No	Go to next step
4	Check for continuity between terminals of transmission control module and engine control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission control module and engine control module connectors • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 3 <ul style="list-style-type: none"> • When Yes, go to step 7 • When No, go to next step
5	Measure voltage at terminal 4R of engine control module <ul style="list-style-type: none"> • Connect a circuit tester to terminal 4R of engine control module • Is voltage at terminal correct? Voltage Idling: Approx. 8 V Ignition switch ON: Approx. 10 V <small>☞</small> section F	Yes	Go to next step
		No	Check for engine control module or crankshaft position sensor <small>☞</small> section F Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 7 • When No, go to next step
6	Measure resistance between terminals 1N and 2P of transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission control module connector • Is resistance correct? Resistance: 7.2—8.0 Ω	Yes	Go to next step
		No	Replace transmission control module
7	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown <small>☞</small> page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P0731		GEAR 1 INCORRECT RATIO (Gear 1 incorrect ratio)	
DETAILS		Transmission control module outputs solenoid pattern of first gear when gear ratio is other than first gear	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • ATF level low • Solenoid valve malfunction • Line pressure low 	<ul style="list-style-type: none"> • Control valve stuck • Transmission control module malfunction
STEP	INSPECTION	ACTION	
1	Is diagnostic trouble code P0750 or P0755 indicated? ☞ page K1-141	Yes	Refer to flowchart for diagnostic trouble code P0750 or P0755 and perform troubleshooting ☞ page K1-154, 155
		No	Go to next step
2	Are amount and condition (color) of ATF OK? Check for ATF leakage at transmission connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-30	Yes	Go to next step
		No	Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle When pressure is less than specification, go to step 3 • If ATF color is ③ or ④, replace ATF
3	Check line pressure in D range (O/D OFF SW OFF) • Is line pressure OK? Line pressure when in D range (O/D OFF SW OFF) (2WD) Idling: 491—530 kPa { 5.0—5.4 kgf/cm ² , 71—77 psi } Stalled: 1,197—1,275 kPa { 12.2—13.0 kgf/cm ² , 174—185 psi } (4WD) Idling: 432—471 kPa { 4.4—4.8 kgf/cm ² , 63—68 psi } Stalled: 1,040—1,118 kPa { 10.6—11.4 kgf/cm ² , 150—162 psi } ☞ page K1-8	Yes	Go to next step
		No	Repair or replace any defective parts • Line pressure is low only when in D or 2 range: ATF leakage in forward clutch circuit
4	Check stall speed in D range (O/D OFF SW OFF) • Is stall speed OK? Stall speed when in D range (O/D OFF SW OFF): 2,300—2,600 rpm ☞ page K1-10	Yes	Go to next step
		No	Repair or replace any defective parts • High in D range: shifting of forward clutch, forward one-way clutch, or low one-way clutch
5	Inspect operation of shift solenoid A and B • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-26	Yes	Go to next step
		No	Replace shift solenoid A and/or B ☞ page K1-26 Go to step 7 • When Yes, go to next step • When No, end of flowchart
6	Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK?	Yes	Go to next step
		No	Repair or replace control valve and replace return spring
7	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary slip of clutch, and should be investigated further





DIAGNOSTIC TROUBLE CODE P0732		GEAR 2 INCORRECT RATIO (Gear 2 incorrect ratio)	
DETAILS		Transmission control module output solenoid pattern of second gear when gear ratio is other than second gear	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • ATF level low • Forward clutch slippage • Brake band slippage • Solenoid valve malfunction 	<ul style="list-style-type: none"> • Line pressure low • Forward one-way clutch slippage • Control valve stuck • Transmission control module malfunction
STEP	INSPECTION	ACTION	
1	Is diagnostic trouble code P0750 or P0755 indicated? ☞ page K1-141	Yes	Refer to flowchart for diagnostic trouble code P0750 or P0755 and perform troubleshooting ☞ page K1-154, 155
		No	Go to next step
2	Are amount and condition (color) of ATF OK? Check for ATF leakage at transmission connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-30	Yes	Go to next step
		No	Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle When pressure is less than specification, go to step 3 • If ATF color is ③ or ④, replace ATF
3	Check line pressure in D, 2 range • Is line pressure OK? Line pressure when in D, 2 range (2WD) Idling: 491—530 kPa { 5.0—5.4 kgf/cm ² , 71—77 psi } Stalled: 1,197—1,275 kPa { 12.2—13.0 kgf/cm ² , 174—185 psi } (4WD) Idling: 432—471 kPa { 4.4—4.8 kgf/cm ² , 63—68 psi } Stalled: 1,040—1,118 kPa { 10.6—11.4 kgf/cm ² , 150—162 psi } ☞ page K1-8	Yes	Go to next step
		No	Repair or replace any defective parts • ATF leakage in brake band circuit • ATF leakage in forward clutch circuit
4	Check stall speed in D, 2 range • Is stall speed OK? Stall speed when in D, 2 range: 2,300—2,600 rpm ☞ page K1-10	Yes	Go to next step
		No	Repair or replace any defective parts • Brake band slipping • Forward clutch slipping • Forward one-way clutch slipping • Low one-way clutch slipping
5	Inspect operation of shift solenoid A and B • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-26	Yes	Go to next step
		No	Replace shift solenoid A and/or B ☞ page K1-26 Go to step 7 • When Yes, go to next step • When No, end of flowchart
6	Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK?	Yes	Go to next step
		No	Repair or replace control valve and replace return spring
7	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-141	Yes	Replace the transmission control module
		No	Problem is a temporary slip of clutch, and should be investigated further

DIAGNOSTIC TROUBLE CODE P0733		GEAR 3 INCORRECT RATIO (Gear 3 incorrect ratio)	
DETAILS		Transmission control module output solenoid pattern of third gear when gear ratio is other than third gear	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • ATF level low • Forward clutch slippage • High clutch slippage • Solenoid valve malfunction 	<ul style="list-style-type: none"> • Line pressure low • Forward one-way clutch slippage • Control valve stuck • Transmission control module malfunction
STEP	INSPECTION	ACTION	
1	Is diagnostic trouble code P0750 or P0755 indicated? ☞ page K1-141	Yes	Refer to flowchart for diagnostic trouble code P0750 or P0755 and perform troubleshooting ☞ page K1-154, 155
		No	Go to next step
2	Are amount and condition (color) of ATF OK? Check for ATF leakage at transmission connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-30	Yes	Go to next step
		No	Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle When pressure is less than specification, go to step 3 • If ATF color is ③ or ④, replace ATF
3	Inspect operation of shift solenoid A and B • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-26	Yes	Go to next step
		No	Replace shift solenoid A and/or B ☞ page K1-26 Go to step 5 • When Yes , go to next step • When No , end of flowchart
4	Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK?	Yes	Go to next step
		No	Repair or replace control valve and replace return spring
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary slip of clutch, and should be investigated further



DIAGNOSTIC TROUBLE CODE P0734		GEAR 4 INCORRECT RATIO (Gear 4 incorrect ratio)	
DETAILS		Transmission control module output solenoid pattern of fourth gear when gear ratio is other than fourth gear	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • ATF level low • Brake band slippage • Control valve stuck • Transmission control module malfunction 	<ul style="list-style-type: none"> • Line pressure low • High clutch slippage • Solenoid valve malfunction
STEP	INSPECTION	ACTION	
1	Is diagnostic trouble code P0750 or P0755 indicated? ☞ page K1-141	Yes	Refer to flowchart for diagnostic trouble code P0750 or P0755 and perform troubleshooting ☞ page K1-154, 155
		No	Go to next step
2	Are amount and condition (color) of ATF OK? Check for ATF leakage at transmission connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-30	Yes	Go to next step
		No	Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle When pressure is less than specification, repair or replace any defective parts • If ATF color is ③ or ④, replace ATF
3	Is diagnostic trouble code P0732 (Gear 2 incorrect ratio) indicated? ☞ page K1-141	Yes	Refer to flowchart for diagnostic trouble code P0732 (Gear 2 incorrect ratio), and perform troubleshooting ☞ page K1-149
		No	Go to next step
4	Is diagnostic trouble code P0733 (Gear 3 incorrect ratio) indicated? ☞ page K1-141	Yes	Refer to flowchart for diagnostic trouble code P0733 (Gear 3 incorrect ratio), and perform troubleshooting ☞ page K1-150
		No	Go to next step
5	Inspect operation of shift solenoid A and B • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-26	Yes	Go to next step
		No	Replace shift solenoid A and/or B ☞ page K1-26 Go to step 7 • When Yes, go to next step • When No, end of flowchart
6	Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK?	Yes	Go to next step
		No	Repair or replace control valve and replace return spring
7	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary slip of clutch, and should be investigated further





DIAGNOSTIC TROUBLE CODE P0740		TORQUE CONV CLUTCH SYS—MALFUNCTION (Torque converter clutch system)	
DETAILS		Transmission control module outputs torque converter clutch signal, but no torque converter clutch obtained	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • ATF level low • Torque converter clutch slippage • Torque converter clutch solenoid valve malfunction 	<ul style="list-style-type: none"> • Transmission control module malfunction • Line pressure low • Control valve stuck
STEP	INSPECTION		ACTION
1	Are amount and condition (color) of ATF OK? Check for ATF leakage at transmission connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ⓘ page K1-30	Yes	Go to next step
		No	Adjust ATF amount or replace ATF if necessary <ul style="list-style-type: none"> • If ATF color is ②, disassemble transmission and repair or replace any defective parts as necessary • If ATF color is ③ or ④, replace ATF
2	Check line pressure in D range (O/D OFF SW OFF) <ul style="list-style-type: none"> • Is line pressure OK? Line pressure when in D range (O/D OFF SW OFF) (2WD) Idling: 491—530 kPa { 5.0—5.4 kgf/cm ² , 71—77 psi } Stalled: 1,197—1,275 kPa { 12.2—13.0 kgf/cm ² , 174—185 psi } (4WD) Idling: 432—471 kPa { 4.4—4.8 kgf/cm ² , 63—68 psi } Stalled: 1,040—1,118 kPa { 10.6—11.4 kgf/cm ² , 150—162 psi } ⓘ page K1-8	Yes	Go to next step
		No	Repair or replace any defective parts <ul style="list-style-type: none"> • ATF leakage in transmission case, oil pump, control valve
3	Inspect operation of solenoid valve <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ⓘ page K1-26	Yes	Go to next step
		No	Replace torque converter clutch solenoid valve ⓘ page K1-26
4	Check operation of each valve and inspect return spring <ul style="list-style-type: none"> • Is each valve operating OK and is return spring OK? 	Yes	Go to next step
		No	Repair or replace control valve and replace return spring
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ⓘ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary slip of clutch, and should be investigated further

DIAGNOSTIC TROUBLE CODE P0745		PRESSURE CTRL SOLENOID—MALFUNCTION (Pressure control solenoid)	
DETAILS		<ul style="list-style-type: none"> • Damaged wiring or connectors between pressure control solenoid and transmission control module • Short or open circuit in pressure control solenoid • Short or open circuit in transmission control module internal transistors 	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • Damaged wiring or connectors between pressure control solenoid and transmission control module • Short or open circuit in pressure control solenoid • Short or open circuit in transmission control module internal transistors 	
STEP	INSPECTION	ACTION	
1	Are transmission control module and pressure control solenoid connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 8 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Does indication on EC-AT tester display change according to throttle opening angle? Indication Pressure control solenoid: Light (Wide open throttle)—Dark (Closed throttle position) ☞ page K1-17	Yes	Go to step 8
		No	Go to next step
3	Check for continuity between terminals of pressure control solenoid and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and transmission control module connectors • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 8 • When No, go to next step
4	Measure resistance between pressure control solenoid terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance between terminals correct? Resistance: 2.5—5 Ω ☞ page K1-26	Yes	Go to next step
		No	Replace pressure control solenoid ☞ page K1-26
5	Check for continuity between terminals of dropping resistor and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect dropping resistor and transmission control module connector • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 8 • When No, go to next step
6	Measure resistance between dropping resistor terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect dropping resistor connector • Is resistance between terminals correct? Resistance: 10—14 Ω ☞ page K1-26	Yes	Go to next step
		No	Replace dropping resistor Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 8 • When No, go to next step
7	Check for continuity between terminals of dropping resistor and pressure control solenoid <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect dropping resistor and pressure control solenoid connector • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring
8	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-141	Yes	Replace the transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further






DIAGNOSTIC TROUBLE CODE P0750		SHIFT SOLENOID A—MALFUNCTION (Shift solenoid A)	
DETAILS	<ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid A and transmission control module • Short or open circuit in shift solenoid A • Short or open circuit in transmission control module internal transistor 		
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid A and transmission control module • Short or open circuit in shift solenoid A • Short or open circuit in transmission control module internal transistor 		
STEP	INSPECTION		ACTION
1	Are transmission control module and shift solenoid A connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 6 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is light for shift solenoid A normally off and illuminated when valve is on?  page K1-17	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of shift solenoid A and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and transmission control module connector • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 6 • When No, go to next step
4	Measure resistance at shift solenoid A terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 20—40 Ω  page K1-26	Yes	Go to next step
		No	Replace shift solenoid A  page K1-26
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P0755		SHIFT SOLENOID B—MALFUNCTION (Shift solenoid B)	
DETAILS	<ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid B and transmission control module • Short or open circuit in shift solenoid B • Short or open circuit in transmission control module internal transistors 		
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid B and transmission control module • Short or open circuit in shift solenoid B • Short or open circuit in transmission control module internal transistors 		
STEP	INSPECTION		ACTION
1	Are transmission control module and shift solenoid B connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 6 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is light for shift solenoid B normally off and illuminated when valve is on? ↗ page K1-17	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of shift solenoid B and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and transmission control module connector • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step
4	Measure resistance at shift solenoid B terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 20—40 Ω ↗ page K1-26	Yes	Go to next step
		No	Replace shift solenoid B ↗ page K1-26
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ↗ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P1720		VSS2—NO VSS2 SIGNAL (Vehicle speed sensor)	
DETAILS		Signal from vehicle speed sensor is not input to transmission control module when vehicle is moving	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • Vehicle speed sensor malfunction • Damaged wiring or connectors between vehicle speed sensor and transmission control module • Transmission control module malfunction 	
STEP	INSPECTION		ACTION
1	Are transmission control module and vehicle speed sensor connectors at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 5 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is vehicle speed indicated on EC-AT tester when vehicle is being driving?  page K1-17	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of vehicle speed sensor and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Remove instrument cluster • Is there continuity between terminal 1G of instrument cluster and terminal 1I of transmission control module? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step
4	Check for continuity between terminals of vehicle speed sensor <ul style="list-style-type: none"> • Disconnect negative battery cable • Remove instrument cluster • Is there continuity between terminals 1H and 1G of instrument cluster? 	Yes	Go to next step
		No	Replace vehicle speed sensor
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P1743		SOLENOID TCC—OPEN OR SHORT (Torque converter clutch solenoid valve)	
DETAILS	<ul style="list-style-type: none"> • Damaged wiring or connectors between torque converter clutch solenoid valve and transmission control module • Short or open circuit in torque converter clutch solenoid valve • Short or open circuit in transmission control module internal transistors 		
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Damaged wiring or connectors between torque converter clutch solenoid valve and transmission control module • Short or open circuit in torque converter clutch solenoid valve • Short or open circuit in transmission control module internal transistors 		
STEP	INSPECTION	ACTION	
1	Are transmission control module and torque converter clutch solenoid valve connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 5 • When Yes , go to next step • When No , end of flowchart
2	Check EC-AT tester display • Connect EC-AT tester to transmission control module • Is light for torque converter clutch solenoid valve normally off and illuminated when valve is on?  page K1-17	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of torque converter clutch solenoid valve and transmission control module • Disconnect negative battery cable • Disconnect solenoid connector and transmission control module connector • Is there continuity between terminals?	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 • When Yes , go to step 5 • When No , go to next step
4	Measure resistance at torque converter clutch solenoid valve terminal • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 10—20 Ω  page K1-26	Yes	Go to next step
		No	Replace torque converter clutch solenoid valve  page K1-26
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P1770		OVRCSOL.—OPEN OR SHORT (Overrunning clutch solenoid valve)	
DETAILS		<ul style="list-style-type: none"> • Damaged wiring or connectors between overrunning clutch solenoid valve and transmission control module • Short or open circuit in overrunning clutch solenoid valve • Short or open circuit in transmission control module internal transistors 	
POSSIBLE CAUSE		<ul style="list-style-type: none"> • Damaged wiring or connectors between overrunning clutch solenoid valve and transmission control module • Short or open circuit in overrunning clutch solenoid valve • Short or open circuit in transmission control module internal transistors 	
STEP	INSPECTION		ACTION
1	Are transmission control module and overrunning clutch solenoid valve connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 5 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is light for overrunning clutch solenoid valve normally off and illuminated when valve is on? ⓘ page K1-17	Yes	Go to step 5
		No	Go to next step
3	Check for continuity between terminals of overrunning clutch solenoid valve and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and transmission control module connector • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step
4	Measure resistance at overrunning clutch solenoid valve terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 20—40 Ω ⓘ page K1-26	Yes	Go to next step
		No	Replace overrunning clutch solenoid valve ⓘ page K1-26
5	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ⓘ page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

DIAGNOSTIC TROUBLE CODE P1790		TPS—OPEN OR SHORT (Throttle position sensor)	
DETAILS	Throttle position sensor voltage is less than 0.09 V or greater than 4.95 V		
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Throttle position sensor malfunction • Damaged wiring or connectors between throttle position sensor and engine control module • Damaged wiring or connectors between throttle position sensor and transmission control module 		
STEP	INSPECTION	ACTION	
1	Is diagnostic trouble code P0120 indicated?  section F	Yes	Refer to flowchart for diagnostic trouble code P0120 and perform troubleshooting  section F
		No	Go to next step
2	Are transmission control module and throttle position sensor connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 7 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
3	Measure throttle position sensor output voltage <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Is throttle position sensor voltage OK? Voltage Wide open throttle: 0.1—1.1 V Closed throttle position: 3.1—4.4 V  page K1-17	Yes	Go to step 7
		No	Go to next step
4	Measure voltage at terminal 2A of transmission control module <ul style="list-style-type: none"> • Is voltage at terminal OK? Voltage Ignition switch at ON: 4.4—5.5 V Ignition switch at OFF: 0 V  page K1-27	Yes	Go to next step
		No	Repair or replace connectors or wiring Go to step 3 <ul style="list-style-type: none"> • When Yes, go to step 7 • When No, go to next step
5	Check for continuity between terminals of transmission control module and throttle position sensor <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transmission control module and throttle position sensor connectors • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors or wiring Go to step 3 <ul style="list-style-type: none"> • When Yes, go to step 7 • When No, go to next step
6	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further


DIAGNOSTIC TROUBLE CODE P1792		BARO—CIRCUIT MALFUNCTION (Barometric pressure sensor)	
DETAILS	<ul style="list-style-type: none"> • Damaged wiring or connectors between engine control module and transmission control module • Short or open circuit transmission control module internal transistor 		
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Damaged wiring or connectors between engine control module and transmission control module • Short or open circuit in transmission control module internal transistor 		
STEP	INSPECTION	ACTION	
1	Are transmission control module and engine control module connections at connector and connector pins OK?	Yes	Go to next step
		No	Repair or replace connector(s) Go to step 4 <ul style="list-style-type: none"> • When Yes, go to next step • When No, end of flowchart
2	Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to transmission control module • Are barometric pressure sensor and EC-AT tester display correct? Barometric pressure Below 90 kPa { 672 mmHg , 26.47 inHg } : ON Above 90 kPa { 672 mmHg , 26.47 inHg } : OFF 🔍 page K1-17	Yes	Go to step 4
		No	Go to next step
3	Check for continuity between terminals of engine control module and transmission control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect engine control module and transmission control module connector • Is there continuity between terminals? 	Yes	Go to next step
		No	Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 4 • When No, go to next step
4	After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown 🔍 page K1-141	Yes	Replace transmission control module
		No	Problem is a temporary poor connection of wiring or connectors, and should be investigated further

TROUBLESHOOTING


GENERAL NOTES

A problem with the EC-AT may be caused by the engine, the EC-AT powertrain, the hydraulic control system, or the electronic control system.


When troubleshooting, begin from these points, which can be inspected quickly and easily. The recommended troubleshooting sequence is described below.

**Step 1: On-Board Diagnosis System Inspection**

Check for diagnostic trouble code(s) memorized in the Transmission control module with the NGS. (Refer to page K1-141.)

**Step 2: Mechanical System Test**

Check the engine stall speed, time lag, and line pressure. (Refer to page K1-8.)

**Step 3: Road Test**

Check the shift point, shift schedule, and shift shock. (Refer to page K-13.)

Use the EC-AT tester when checking vehicle speed, engine speed, throttle opening (throttle position sensor voltage), and gear position.

If the 4 steps on page K1-162 are followed, the cause of the problem should be located. Another guide to faster location of the causes of problems, the QUICK DIAGNOSIS CHART, is on pages K1-163 to 166.

In this chart, numbers are used to indicate the components that may be the cause of 51 possible problems. It is necessary to check only those components indicated by numbers during each step of the troubleshooting process to locate the cause of the problem quickly.

QUICK DIAGNOSIS CHART


The QUICK DIAGNOSIS CHART shows different problems and the relationship of components that might be the cause.

- Components indicated in the "Adjustment" row indicate the possibility that the problem may result from an incorrect adjustment.
Check the adjustment of each component, and readjust if necessary.
- Components indicated in the "On-board Diagnosis" row are diagnosed by the Transmission control module On-board diagnostic system.
The NGS can be used for easy retrieval of the these signals.
- Components indicated in the "Mechanical System Test" row can be checked for malfunction by the results of the oil pressure test.
- Components indicated in the "Road Test" row can be checked for malfunction by the results of the road test.
- The numbers in the chart indicate the order of inspection for detecting malfunctions.
- Circled numbers indicate that the transmission must be removed from the vehicle.
- The checking, adjusting, repair, and replacement procedures for components are described in the page(s) shown in the "Reference page" column.


Item	Inspection point and reference page	ON VEHICLE															OFF VEHICLE																									
		Preliminary		Electronic system										Hydraulic control system					Powertrain																							
		K1-30	K1-138	section F	section G	K1-23	K1-23	section T	section F	section F	section F	section F	K1-25	K1-24	section F	K1-26	K1-26	K1-26	K1-26	K1-26	K1-26	K1-8	K1-91	K1-47	K1-47	K1-47	K1-47	K1-49	K1-46	K1-53	K1-59	K1-71	K1-35	K1-71	K1-71	K1-79	K1-64	K1-85				
	ATF level and condition																																									
Adjustment	Selector lever and selector cable	X																																								
On-board diagnosis	Idle speed and engine condition		X																																							
Mechanical System Test	Ignition switch and starter				X																																					
Road Test	Transmission range switch					X																																				
	O/D OFF switch																																									
	Cruise control switch																																									
	Barometric pressure sensor																																									
	Closed throttle position switch										X																															
	Throttle position sensor										X																															
	Output speed sensor											X																														
	Transmission fluid temperature sensor											X																														
	Engine rpm														X																											
	Shift solenoid A															X																										
	Shift solenoid B																X																									
	Pressure control solenoid																	X																								
	Dropping resistor																		X																							
	Torque converter clutch solenoid																			X																						
	Overrunning clutch solenoid																				X																					
	Line pressure																					X																				
	Control valve body																						X																			
	N-D accumulator																							X																		
	1-2 accumulator																								X																	
	2-3 accumulator																									X																
	3-4/N-R accumulator																										X															
	Oil pump																											X														
	Torque converter																												X													
	Reverse clutch																																									
	High clutch																																									
	Forward clutch																																									
	Forward one-way clutch																																									
	Overrunning clutch																																									
	Low one-way clutch																																									
	Low and reverse brake																																									
	Brake band and band servo																																									
	Parking mechanism																																									

Inspection point and reference page		ON VEHICLE															OFF VEHICLE																						
		Preliminary			Electronic system										Hydraulic control system					Powertrain																			
		K1-30	K1-138	section F	section G	K1-23	K1-23	section T	section F	section F	section F	K1-25	K1-24	section F	K1-26	K1-26	K1-26	K1-26	K1-26	K1-26	K1-8	K1-91	K1-47	K1-47	K1-47	K1-47	K1-49	K1-46	K1-53	K1-59	K1-71	K1-35	K1-71	K1-71	K1-71	K1-79	K1-64	K1-85	
ATF level and condition	Selector lever and control linkage	Idle speed and engine condition	Ignition switch and starter	Transmission range switch	O/D OFF switch	Cruise control switch	Barometric pressure sensor	Closed throttle position switch	Throttle position sensor	Output speed sensor	Transmission fluid temperature sensor	Engine rpm	Shift solenoid A	Shift solenoid B	Pressure control solenoid	Dropping resistor	Torque converter clutch solenoid	Overrunning clutch solenoid	Line pressure	Control valve body	N-D accumulator	1-2 accumulator	2-3 accumulator	3-4/N-R accumulator	Oil pump	Torque converter	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrunning clutch	Low one-way clutch	Low and reverse brake	Brake band and band servo	Parking mechanism				
Engine starting	Engine does not start in N and/or P position	2		1	3																																		
	Engine starts in all ranges and R position	1			2																																		
Accelerating	Vehicle does not move in D range (moves in 1, 2 ranges and R position)	1																																					
	Vehicle does not move in forward ranges (moves in R position) Extremely poor acceleration	1											3						2	4	5						6	7	8	9			10						
	Vehicle does not move in R position (moves in forward position) Extremely poor acceleration	1											3						2	4							5	6	7			8			9				
	Vehicle does not move in any range and position	1	2										4						3							5	9		6					8	7	10			
	Slippage felt when accelerating	1	2						3					5					4	6	7				8	12	13	10		9				11					
	Vehicle moves in N position	1																							4		3		2		5								
	Excessive creep			1																																			
	No creep	1																		2	3					5	6			4									
	Low maximum speed and poor accelerating	1			2									3	4						5					10	11	6	7						9	8			
	No shift	Does not shift from 1GR to 2GR	3		2	1				6			4								5																	7	
Does not shift from 2GR to 3GR		3		2	1				6			4								5								7									8		
Does not shift from 3GR to 4GR		4		3	1	2			6	7		5																										8	
TCC operation does not occur					4				1	2	3	6	5				8		7	9						10													
Does not shift from 4GR to 3GR		1								2				4	5				3		6											8		7					
Does not shift from 3GR to 2GR, or from 4GR to 2GR		1								2				3	4					5								6									7		
Does not shift from 2GR to 1GR or from 3GR to 1GR	1				3				2				4	5					6									8				7					9		


N POSITION




D RANGE; FIRST GEAR




D RANGE; SECOND GEAR




D RANGE; THIRD GEAR



D RANGE; FOURTH GEAR, TORQUE CONVERTER CLUTCH ON



2 RANGE; SECOND GEAR




Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

AUTOMATIC TRANSMISSION

(Transfer Case)

<p>INDEX K2- 2</p> <p>OUTLINE K2- 3</p> <p style="padding-left: 20px;">SPECIFICATIONS K2- 3</p> <p style="padding-left: 20px;">CROSS-SECTIONAL VIEW K2- 4</p> <p style="padding-left: 20px;">POWERFLOW K2- 5</p> <p>TROUBLESHOOTING K2- 6</p> <p style="padding-left: 20px;">GENERAL NOTES K2- 6</p> <p style="padding-left: 20px;">QUICK DIAGNOSIS CHART K2- 7</p> <p>ON-BOARD DIAGNOSTIC SYSTEM</p> <p style="padding-left: 20px;">INSPECTION K2- 8</p> <p style="padding-left: 40px;">FAIL MODE FUNCTION K2- 8</p> <p style="padding-left: 40px;">CAUTION MODE FUNCTION K2- 8</p> <p>ELECTRICAL SIGNAL INSPECTION K2- 8</p> <p>SYSTEM OPERATION INSPECTION . K2- 9</p> <p style="padding-left: 20px;">2WD TO 4WD (FREE) MODE</p> <p style="padding-left: 40px;">SHIFT K2- 9</p> <p style="padding-left: 20px;">4WD (FREE) TO 2WD MODE</p> <p style="padding-left: 40px;">SHIFT K2-10</p> <p style="padding-left: 20px;">4WD (FREE) TO 4WD (LOCKED)</p> <p style="padding-left: 40px;">MODE SHIFT K2-11</p> <p style="padding-left: 20px;">4WD (LOCKED) TO 4WD (FREE)</p> <p style="padding-left: 40px;">MODE SHIFT K2-11</p> <p style="padding-left: 20px;">2WD TO 4WD (LOCKED) MODE</p> <p style="padding-left: 40px;">SHIFT K2-12</p> <p>SYMPTOM TROUBLESHOOTING ... K2-13</p> <p style="padding-left: 20px;">NO SHIFT FROM 2WD TO 4WD (FREE) MODE K2-13</p> <p style="padding-left: 20px;">NO SHIFT FROM 4WD (FREE) TO 2WD MODE K2-15</p> <p style="padding-left: 20px;">NO SHIFT FROM 4WD (FREE) TO 4WD (LOCKED) MODE K2-17</p> <p style="padding-left: 20px;">NO SHIFT FROM 4WD (LOCKED) TO 4WD (FREE) MODE K2-19</p> <p style="padding-left: 20px;">NO SHIFT FROM 2WD TO 4WD (LOCKED) MODE K2-20</p>	<p>ELECTRICAL SYSTEM</p> <p>COMPONENTS K2-22</p> <p style="padding-left: 20px;">PREPARATION K2-22</p> <p style="padding-left: 20px;">CHANGE MOTOR K2-22</p> <p style="padding-left: 20px;">4WD RELAY (CHANGE MOTOR RELAY No.1, No.2) K2-25</p> <p style="padding-left: 20px;">4WD/2WD SHIFT SWITCH K2-25</p> <p style="padding-left: 20px;">CENTER DIFFERENTIAL LOCK SWITCH K2-26</p> <p style="padding-left: 20px;">4WD CONTROL MODULE K2-26</p> <p>TRANSFER CASE OIL K2-29</p> <p>TRANSFER CASE K2-30</p> <p style="padding-left: 20px;">PREPARATION K2-30</p> <p style="padding-left: 20px;">PRECAUTION K2-30</p> <p style="padding-left: 20px;">TRANSFER CASE UNIT (REMOVAL / INSTALLATION) K2-31</p> <p style="padding-left: 20px;">TRANSFER CASE UNIT (DISASSEMBLY / INSPECTION / ASSEMBLY) K2-34</p> <p style="padding-left: 20px;">OIL SEAL (FRONT DRIVE SPROCKET) K2-50</p> <p style="padding-left: 20px;">OIL SEAL (REAR COVER) K2-51</p> <p style="padding-left: 20px;">SPEEDOMETER DRIVEN GEAR .. K2-53</p> <p style="padding-left: 20px;">CENTER DIFFERENTIAL AND OUTPUT SHAFT ASSEMBLY K2-54</p> <p style="padding-left: 20px;">DRIVE GEAR AND CHAIN ASSEMBLY K2-56</p> <p style="padding-left: 20px;">PUMP HOUSING K2-60</p>
---	---

INDEX



- | | |
|--|------------|
| 1. Change motor | |
| Removal | page K2-22 |
| Inspection | page K2-22 |
| Installation | page K2-24 |
| 2. 4WD relay (Change motor relay No.1) | |
| Inspection | page K2-25 |
| 3. 4WD relay (Change motor relay No.2) | |
| Inspection | page K2-25 |
| 4. 4WD/2WD shift switch | |
| Inspection | page K2-25 |
| 5. Center differential lock switch | |
| Inspection | page K2-26 |
| 6. 4WD control module | |
| Inspection | page K2-26 |
| 7. Transfer case unit | |
| Removal / Installation | page K2-31 |
| Disassembly / Inspection / | |
| Assembly | page K2-34 |


OUTLINE

SPECIFICATIONS


Item		Transmission	RA4AX-EL
Mesh system			Double cone synchromesh
Gear ratio			1.000
Oil	Grade		API service GL-4 or GL-5
	Viscosity	All-season	SAE 75W-90
		Above 10 °C { 50 °F }	SAE 80W-90
	Capacity	L { US qt , Imp qt }	1.5 { 1.6 , 1.3 }

K2


CROSS-SECTIONAL VIEW



POWERFLOW
2WD




4WD (Free) [Center differential free]



K2

4WD (Locked) [Center differential lock]




TROUBLESHOOTING

GENERAL NOTES


A problem with the transfer case may be caused by the engine, the driving conditions, the transfer case itself, or the electrical control system.

When troubleshooting, therefore, begin with the points that can be inspected quickly and easily. The recommended troubleshooting sequence is described below.




Step 1: On-board Diagnostic System Inspection

Check the warning alarm for operation. When the ignition switch is turned to OFF, the warning alarm is canceled because there is no memory in the 4WD control module. When the ignition switch is turned to ON, the warning alarm will reappear only if the problem still exists. (Refer to page K2-8.)




Step 2: Electrical Signal Inspection

Check the signals to/from the 4WD control module. (Refer to pages K2-8, 26.)







Step 3: System Operation Inspection

Check the operation of the Multi-Mode 4WD system. (Refer to page K2-9.)



Step 4: Symptom Troubleshooting

Check the Multi-Mode 4WD system for malfunctions. (Refer to page K2-13.)



ON-BOARD DIAGNOSTIC SYSTEM INSPECTION

FAIL MODE FUNCTION






The warning alarm will sound if a malfunction is found in the change motor or electrical circuit. While in the fail mode, the warning alarm will sound whenever the 4WD/2WD shift switch or differential lock switch is activated. The fail mode function is canceled when the ignition switch is turned to OFF. If a malfunction occurs in either of the position switches while the change motor is running, the 4WD control module sets the mode to 2WD. If a malfunction occurs in either of the limit switches while shifting, the 4WD control module sets the motor step position.

CAUTION MODE FUNCTION

The caution alarm will sound as shown if the 4WD/2WD switch is activated while driving in 4WD (Locked) mode. The proper sequence is to first turn off the center differential lock switch to set 4WD (Free) mode; then activate the 4WD/2WD shift switch to set 2WD mode.

ELECTRICAL SIGNAL INSPECTION

Check the electrical signals to/from the 4WD control module. (Refer to page K2-26.)



SYSTEM OPERATION INSPECTION


For each of the inspections, do the following:


1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Shift the transmission to N position.
3. Start the engine and let it idle. Turn it off when indicated.

2WD TO 4WD (FREE) MODE SHIFT

Turn the center differential lock switch to the OFF position. Verify that the CENTER DIFF. LOCK indicator light is OFF, and that the 4WD indicator light is OFF.







K2






4WD (FREE) TO 2WD MODE SHIFT


Turn the center differential lock switch to the OFF position. Verify that the CENTER DIFF. LOCK indicator light is OFF, and that the 4WD indicator light is ON.





4WD (FREE) TO 4WD (LOCKED) MODE SHIFT

Turn the center differential lock switch to the OFF position. Verify that the CENTER DIFF. LOCK indicator light is OFF, and that the 4WD indicator light is ON.




Turn the center differential lock switch to ON

Does CENTER DIFF. LOCK indicator light come ON?

NO → Check center differential lock switch and indicator light (Refer to page K2-26, section T)

YES

OK




Turn engine OFF
Turn front tires clockwise
Do rear tires rotate clockwise?

YES → Vehicle in 4WD (Locked) mode
Selection completed


NO

Check actuator, change motor, 4WD relay (change motor relay No.2), and 4WD control module (Refer to section M, page K2-22, 25, 26)



4WD (LOCKED) TO 4WD (FREE) MODE SHIFT

Turn the center differential lock switch to the ON position. Verify that the CENTER DIFF. LOCK indicator light is ON, and that the 4WD indicator light is ON.



Turn the center differential lock switch to ON






Does CENTER DIFF. LOCK indicator light go OFF?

NO → Check center differential lock switch and indicator light (Refer to page K2-26, section T)


YES

OK

Cont'd









Cont'd



2WD TO 4WD (LOCKED) MODE SHIFT

Turn the center differential lock switch to the OFF position. Verify that the CENTER DIFF. LOCK INDICATOR LIGHT is OFF, and that 4WD indicator light is OFF.





SYMPTOM TROUBLESHOOTING

Drive the vehicle when troubleshooting for any of the following problems.

NO SHIFT FROM 2WD TO 4WD (FREE) MODE







1. Are there any exclusion items?
 - NO → Retest
2. Does shift alarm sound when activating 4WD/2WD shift switch?
 - NO → Check wiring and connector from S terminal of 4WD control module to 4WD/2WD shift switch. If OK, check 4WD/2WD shift switch and wiring (Refer to page K2-25)
 - YES → 3.
3. Does warning alarm sound when activating 4WD/2WD shift switch?
 - YES → Check wiring and connector from F terminal of 4WD control module to 4WD relay (change motor relay No.1)
 - NO → 4.
4. Does 4WD indicator light flash?
 - NO → Check 4WD indicator light and wiring (Refer to section T)
 - YES → 5.
5. Does 4WD indicator light come ON after driving vehicle approx. 0.5 km { 1/4 miles }?
 - YES → Vehicle in 4WD (Free) mode. Inspection completed
 - NO → 6.
6. Check each wiring and connector below
 - From M terminal of 4WD control module to position switch A
 - From O terminal of 4WD control module to position switch B
 - From Q terminal of 4WD control module to position switch C
7. Check change motor position by measuring 4WD control module terminal voltages







B+: Battery positive voltage

Terminal	Position	2H	α	4HL	β	4HF
M and ground	(V)	B+	B+	0 V	0 V	0 V
O and ground	(V)	0 V	B+	B+	B+	0 V
Q and ground	(V)	0 V	0 V	0 V	B+	B+


 - If position is 2H or α , go to step 8; if 4HL or β , go to step 10
 - If position is 4HF, replace change motor or 4WD control module






Cont'd





NO SHIFT FROM 4WD (FREE) TO 2WD MODE





Cont'd
NO

7. Check each wiring and connector below
 From terminal M of 4WD control module to position switch A
 From terminal O of 4WD control module to position switch B
 From terminal Q of 4WD control module to position switch C

OK

8. Check change motor position by measuring 4WD control module terminal voltages

B+: Battery positive voltage

Terminal \ Position		2H	α	4HL	β	4HF
M and ground (V)		B+	B+	0 V	0 V	0 V
O and ground (V)		0 V	B+	B+	B+	0 V
Q and ground (V)		0 V	0 V	0 V	B+	B+

If position is 4HF, go to step 9; if β , 4HL, or α , go to step 12; if 2H, go to step 15

9. Is there 0 V at terminal P of 4WD control module?

YES

Check wiring and connector from terminal P of 4WD control module to change motor

OK

Check change motor, 4WD relay (change motor relay No.2), and wiring (Refer to pages K2-22, 25)

NO

Check transfer case unit (Refer to page K2-32)

NO

10. Is there battery voltage at terminal C of 4WD control module?

NO

Replace 4WD control module

YES

11. Check wiring and connector from terminal C of 4WD control module to 4WD relay (change motor relay No.2)

OK

Check change motor, change motor relay No.2, and wiring (Refer to pages K2-22, 25)

OK

Check transfer case unit (Refer to page K2-30)

12. Is there 0 V at terminals R and P of 4WD control module?

YES

Check wiring and connector from terminals R and P of 4WD control module to change motor







OK

Check change motor, change motor relay No.2, and wiring (Refer to pages K2-22, 25)


OK

Check transfer case unit (Refer to page K2-30)






Cont'd



NO SHIFT FROM 4WD (FREE) TO 4WD (LOCKED) MODE



Cont'd



Cont'd
NO

7. Check each wiring and connector below
 From terminal M of 4WD control module to position switch A
 From terminal O of 4WD control module to position switch B
 From terminal Q of 4WD control module to position switch C

OK

8. Check change motor position by measuring 4WD control module terminal voltages

B+: Battery positive voltage

Terminal \ Position	2H	α	4HL	β	4HF
M and ground (V)	B+	B+	0 V	0 V	0 V
O and ground (V)	0 V	B+	B+	B+	0 V
Q and ground (V)	0 V	0 V	0 V	B+	B+

If position is 4HF, go to step 9; if β , go to step 12
 If position is 2H, α , or 4HL replace change motor or 4WD control module

9. Is there 0 V at terminal P of 4WD control module?

YES

Check wiring and connector from terminal P of 4WD control module to change motor

OK

Check change motor, 4WD relay (change motor relay No.2), and wiring (Refer to pages K2-22, 25)

NO

Check transfer case unit (Refer to page K2-30)

NO

10. Is there battery voltage at terminal F of 4WD control module?

NO

Replace 4WD control module

YES

11. Check wiring and connector from terminal F of 4WD control module to 4WD relay (change motor relay No.2)

OK

Check change motor, 4WD relay (change motor relay No.2), and wiring (Refer to pages K2-22, 25)

12. Is there 0 V at terminals R and P of 4WD control module?

YES

Check wiring and connector from terminals R and P of 4WD control module to change motor







OK

Check change motor, 4WD relay (change motor relay No.2), and wiring (Refer to pages K2-22, 25)


OK






Check transfer case unit (Refer to page K2-30)

Cont'd




NO SHIFT FROM 4WD (LOCKED) TO 4WD (FREE) MODE











Cont'd
NO



NO SHIFT FROM 2WD TO 4WD (LOCKED) MODE





Cont'd

6. Check each wiring and connector below
 From terminal M of 4WD control module to position switch A
 From terminal O of 4WD control module to position switch B
 From terminal Q of 4WD control module to position switch C

OK

7. Check change motor position by measuring 4WD control module terminal voltages
 B+: Battery positive voltage

Terminal \ Position	2H	α	4HL	β	4HF
M and ground (V)	B+	B+	0 V	0 V	0 V
O and ground (V)	0 V	B+	B+	B+	0 V
Q and ground (V)	0 V	0 V	0 V	B+	B+

If position is 2H or α , go to step 8 if 4HL, go to step 11
 If position is β or 4HF, replace change motor or 4WD control module

8. Is there 0 V at terminal P of 4WD control module?
 YES → Check wiring and connector from terminal P of 4WD control module to change motor

OK

Check change motor, 4WD relay (change motor relay No.1), and wiring (Refer to pages K2-22, 25)

NO

Check transfer case unit (Refer to page K2-30)

9. Is there battery voltage at terminal F of 4WD control module?
 NO → Replace 4WD control module

YES

10. Check wiring and connector from terminal F of 4WD control module to 4WD relay (change relay No.1)
 OK → Check change motor, 4WD relay (change motor relay No.1), and wiring (Refer to pages K2-22, 25)

NO

Check transfer case unit (Refer to page K2-30)

11. Is there 0 V at terminal N of 4WD control module?
 YES → Check wiring and connector from terminal N of 4WD control module to AFW switch

OK

Check AFW switch (Refer to section M)

OK

Check the AFW unit (Refer to section M)

12. Is there 0 V at terminal D of 4WD control module?
 NO → Replace 4WD control module

YES

13. Check wiring and connector from terminal of 4WD control module to lock solenoid
 OK → Check lock solenoid (Refer to section M)


OK





Check AFW unit (Refer to section M)

ELECTRICAL SYSTEM COMPONENTS

PREPARATION

SST

<p>49 L017 302</p> <p>Adapter, change motor</p>		<p>For inspection of change motor</p>
---	---	---



CHANGE MOTOR

On-vehicle Inspection

1. Turn the ignition to ON.
2. Using a voltmeter at the change motor connector, check for the following voltages during the indicated mode shift operation.
If not as specified, perform 4WD relay voltage inspection. (Refer to page K2-25.)

Terminal voltage

B+: Battery positive voltage

Mode shift	Terminal voltage	
	2A	2B
2WD→4WD FREE	Momentary B+	Ground 0 V
4WD FREE→2WD	Ground 0 V	Momentary B+
4WD FREE→4WD LOCKED	Ground 0 V	Momentary B+
4WD LOCKED→4WD FREE	Momentary B+	Ground 0 V
2WD→4WD LOCKED	Momentary B+	Ground 0 V

Removal

1. Disconnect the negative battery terminal.
2. On level ground, jack up the vehicle and support it evenly on safety stands.
3. Remove the protector plate.
4. Disconnect the change motor connector and remove the change motor.


Inspection

Motor


1. Connect battery voltage as shown and verify that the motor rotates clockwise.
2. Connect battery voltage as shown and verify that the motor rotates counterclockwise.
3. If not correct, replace the change motor.

Limit switch

1. Set the change motor in a vise.
2. Verify that there is no continuity between terminals F and H by using an ohmmeter.



- Turn the change motor shaft clockwise by using the **SST** until continuity is shown.




- Allow the shaft to turn counterclockwise and note the torque when continuity is lost.


Specified torque:

2.5—4.9 N·m { 25—50 kgf·cm , 22—43 in·lbf }


- Turn the shaft counterclockwise as in steps 3 and 4, and check for continuity and torque reading.



- Connect the ohmmeter between terminals E and H, and verify that there is no continuity.



- Turn the shaft clockwise by using the **SST** until continuity is shown.




- Allow the shaft to turn counterclockwise and note the torque when continuity is lost.

Specified torque:


6.9—12.7 N·m { 70—130 kgf·cm , 61—112 in·lbf }

- Turn the shaft counterclockwise as in steps 7 and 8 and check for continuity and torque reading.
- If not as specified, replace the change motor.




Position switch

1. Connect an ohmmeter to terminals A and D, B and D, and C and D of the change motor in order.
2. Connect battery voltage to terminals 2A and 2B as shown.
3. Verify that there is continuity at each set of terminals once per motor revolution.
4. If not as specified, replace the change motor.




Installation


1. Align the mark on the change drum groove with the 2H mark.



2. Check that the marks on the change motor salient and the body are aligned.




3. If not aligned, turn the shaft by applying battery voltage as shown.



4. Apply oil to the new O-ring and install the change motor.

Tightening torque:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }



5. Install the protector plate.

Tightening torque:

44—54 N·m { 4.4—5.6 kgf·m , 32—40 ft·lbf }


4WD RELAY (CHANGE MOTOR RELAY No.1, No.2)

Inspection

Terminal voltage

1. Turn the ignition to ON.
2. Using a voltmeter, measure the voltage at each wire at the indicated connector during each mode shift of the 4WD system.


If not as specified, perform 4WD Control Module Inspection.



4WD Relay No.1

B+: Battery positive voltage


Mode shift	Terminal voltage				
	E	C	A	F	B
2WD→4WD FREE	IGN. B+	MOM. B+	MOM. B+	0 V	0 V
4WD→2WD	IGN. B+	0 V	0 V	0 V	0 V
4WD→4WD LOCKED	IGN. B+	0 V	0 V	0 V	0 V
4WD LOCKED→4WD FREE	IGN. B+	MOM.	MOM.	0 V	0 V
2WD→4WD LOCKED	IGN. B+	MOM. B+	MOM. B+	0 V	0 V



4WD Relay No.2

B+: Battery positive voltage

Mode shift	Terminal voltage				
	E	C	A	F	B
2WD→4WD FREE	IGN. B+	0 V	0 V	0 V	0 V
4WD FREE→2WD	IGN. B+	MOM. B+	MOM. B+	0 V	0 V
4WD FREE→4WD LOCKED	IGN. B+	MOM. B+	MOM. B+	0 V	0 V
4WD LOCKED→4WD FREE	IGN. B+	0 V	0 V	0 V	0 V
2WD→4WD LOCKED	IGN. B+	0 V	0 V	0 V	0 V



Continuity

1. Remove the 4WD relay (change motor relay No.1, No.2).
2. Verify that there is continuity between terminals A and B, and C and F.
3. Connect battery voltage to terminals A and B as shown and verify that there is continuity between terminals C and E.
4. If not as specified, replace the 4WD relay (change motor relay No.1, No.2).

4WD/2WD SHIFT SWITCH


Inspection

Terminal voltage


1. Remove the column covers.
2. Turn the ignition switch ON.
3. Measure the voltage between terminal C and a ground.

B+: Battery positive voltage

Terminal voltage	Switch
B+	Released
0 V	Activated (Held to left)



4. If not correct, go to the next step.




Continuity

1. Disconnect the connector.
2. Check for continuity between terminals A and C (switch side).

Continuity	Switch
Yes	Activated (Held to left)
No	Released

3. If not as specified, replace the change knob assembly.



CENTER DIFFERENTIAL LOCK SWITCH


Inspection

Terminal voltage

1. Disconnect the center differential lock switch.
2. Turn the ignition switch to ON.
3. Measure the voltage between terminal A and a ground.
B+: Battery positive voltage

Terminal voltage	Switch
B+	OFF (Bottom of rocker in)
0 V	ON (Top of rocker in)

4. If not correct, go to the next step.




Continuity

1. Disconnect the connector.
2. Check for continuity between terminals A and B (switch side).

Continuity	Switch
Yes	ON (Top of rocker in)
No	OFF (Bottom of rocker in)

3. If not as specified, replace the switch assembly.




4WD CONTROL MODULE

Inspection

1. Turn the ignition switch to ON. Measure the 4WD control module terminal voltages, referring to the Terminal voltage chart (next page).
2. If not as specified, check, repair, or replace the component(s), wiring, and/or 4WD control module.

Terminal voltage chart




B+: Battery positive voltage

Terminal	Connected to	Voltage	Condition
A	Free solenoid	B+	Solenoid: OFF Vehicle in 4WD (Free) mode Vehicle in 4WD (Locked) mode
		Below 1.5 V	Solenoid: ON Vehicle in 2WD mode
B	Body	0 V	—
C	4WD relay (Change motor relay No.2)	B+	4WD relay (Change motor relay No.2): ON During 4WD (Free) mode to 2WD mode During 4WD (Free) mode to 4WD (Locked) mode shift
		Below 1.5 V	4WD relay (Change motor relay No.2): OFF Other than above conditions
D	Lock solenoid	B+	Solenoid: OFF Vehicle in 2WD mode
		Below 1.5 V	Solenoid: ON Vehicle in 4WD (Free) mode Vehicle in 4WD (Locked) mode
E	Battery	B+	Ignition switch ON
		0 V	Ignition switch OFF
F	4WD relay (Change motor relay No.1)	B+	4WD relay (Change motor relay No.1): ON During 2WD to 4WD (Free) mode shift During 2WD to 4WD (Locked) mode shift During 4WD (Locked) mode to 4WD (Free) mode shift
		Below 1.5 V	4WD relay (Change motor relay No.1): OFF Other than above conditions
G	Buzzer	B+	Buzzer: OFF Normal condition
		Below 1.5 V	Buzzer: ON 4WD/2WD shift switch activated Caution mode function Fail mode function (System failure)
H	4WD indicator light	B+	4WD indicator light: OFF Vehicle in 2WD mode
		Below 1.5 V	4WD indicator light: ON Vehicle in either 4WD mode
J	CENTER DIFF. LOCK indicator light	B+	CENTER DIFF. LOCK indicator light: OFF Vehicle in 2WD or 4WD (Free) mode
		Below 1.5 V	CENTER DIFF. LOCK indicator light: ON Vehicle in 4WD (Locked) mode
L	—	—	—

B+: Battery positive voltage

Terminal	Connected to	Voltage	Condition
M	Position switch A (In change motor)	B+	Position switch A: OFF Vehicle in 2WD mode Vehicle between 2WD mode and 4WD (Locked) mode
		0 V	Position switch A: ON Vehicle in 4WD (Free) mode Vehicle in 4WD (Locked) mode Vehicle between 4WD (Free) mode and 4WD (Locked) mode
N	AFW (Remote freewheel) switch	B+	RFW switch: OFF Vehicle in 2WD mode (AFW unit disengaged)
		0 V	RFW switch: ON Vehicle in either 4WD mode (AFW unit engaged)
O	Position switch B (In change motor)	B+	Position switch B: OFF Vehicle between 2WD mode and 4WD (Locked) mode Vehicle in 4WD (Locked) mode Vehicle between 4WD (Free) mode and 4WD (Locked) mode
		0 V	Position switch B: ON Vehicle in 2WD mode Vehicle in 4WD (Free) mode
P	Limit switch 1 (In change motor)	B+	Limit switch 1: OFF Normal condition
		0 V	Limit switch 1: ON High shift torque when shifting from 2WD to 4WD (Free) mode or vice-versa High shift torque when shifting from 2WD to 4WD (Locked) mode High shift torque when shifting from 4WD (Free) mode to 4WD (Locked) mode or vice-versa
Q	Position switch C (In change motor)	B+	Position switch C: OFF Vehicle between 4WD (Free) mode and 4WD (Locked) mode Vehicle in 4WD (Free) mode
		0 V	Position switch C: ON Vehicle in 2WD mode Vehicle between 2WD mode and 4WD (Locked) mode Vehicle in 4WD (Locked) mode
R	Limit switch 2 (In change motor)	B+	Limit switch 2: OFF Normal condition
		0 V	Limit switch 2: ON High shift torque when shifting from 2WD to 4WD (Free) mode or vice-versa High shift torque when shifting from 2WD to 4WD (Locked) mode High shift torque when shifting from 4WD (Free) mode to 4WD (Locked) mode or vice-versa
S	4WD/2WD shift switch	B+	4WD/2WD shift switch: OFF (released)
		0 V	4WD/2WD shift switch: ON (activated)
T	Center differential lock switch	B+	Center differential lock switch: OFF Bottom of rocker (Free position)
		0 V	Center differential lock switch: ON Top of rocker (Lock position)



TRANSFER CASE OIL

Inspection

1. Remove the level plug.
2. Verify that the oil is up to the brim of the level plug hole as shown.
If it is low, add the specified oil through the filler plug port.
3. Install the plugs and new washers.


Tightening torque

Filler plug:

40—58 N·m { 4.0—6.0 kgf·m , 29—43 ft·lbf }

Level plug:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }




Replacement

1. Remove the filler and level plugs.
2. Remove the drain plug, and drain the oil into a container.
3. Wipe all plugs clean.
4. Install the drain plug and a new washer.

Tightening torque:

40—58 N·m { 4.0—6.0 kgf·m , 29—43 ft·lbf }



5. Add the specified oil through the filler plug port until the oil rises to the brim edge of the level plug hole.

Specified oil

Grade: API service GL-4 or GL-5


Viscosity: All-season

SAE 75W-90

Viscosity: Above 10 °C { 50 °F }

SAE 80W-90

Capacity: 1.5 L { 1.6 US qt , 1.3 Imp qt }



6. Install the filler and level plugs and new washers.

Tightening torque

Filler plug:

40—58 N·m { 4.0—6.0 kgf·m , 29—43 ft·lbf }











Level plug:

19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }

TRANSFER CASE

PREPARATION

SST

<p>49 S120 710</p> <p>Holder, coupling flange</p> 	<p>For removal / installation of companion flange</p>	<p>49 U025 001</p> <p>Installer, protector</p> 	<p>For removal / installation of bearing</p>
<p>49 U027 003</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>
<p>49 G030 797</p> <p>Handle (Part of 49 G030 795)</p> 	<p>For installation of bearing</p>	<p>49 B043 002</p> <p>Installer, bearing</p> 	<p>For installation of oil seal</p>
<p>49 S231 395</p> <p>Expansion tool, chain</p> 	<p>For expansion of chain</p>	<p>49 F017 1A0</p> <p>Universal wrench</p> 	<p>For removal / installation of locknut</p>
<p>49 0839 425C</p> <p>Puller set, bearing</p> 	<p>For removal of bearing</p>	<p>49 0727 415</p> <p>Installer, bearing</p> 	<p>For installation of bearing</p>

PRECAUTION

1. Clean the exterior of the transmission and transfer case with steam and/or cleaning solvent before removal or disassembly.

Warning


- **Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.**

2. Clean all parts with cleaning solvent (except bearings). Dry with compressed air.
3. Clean out all holes and passages with compressed air. Check that there are no obstructions.
4. All O-rings must be replaced with new ones.
5. Assemble parts within 10 minutes after applying sealant. Allow all sealant to cure at least 30 minutes after assembly before filling the transfer case with oil.


TRANSFER CASE UNIT (REMOVAL / INSTALLATION)

Removal / Installation


1. Before removing the transfer case, drain the transfer case oil. (Refer to page K2-29.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installing the transfer case unit, add the transfer case oil. (Refer to page K2-29.)




- | | | | |
|-----------------------------|------------|-------------------------|------------|
| 1. Rear propeller shaft | | 5. Exhaust pipe | |
| Removal | section L | 6. Heat insulator | |
| 2. Front propeller shaft | | 7. Speedometer cable | |
| Removal | section L | 8. Connectors | |
| 3. Transmission lower mount | | 9. Transfer case | |
| Removal Note | page K2-32 | Removal Note | page K2-32 |
| Installation Note | page K2-33 | Installation Note | page K2-32 |
| 4. Transmission upper mount | | | |

**Removal note****Transmission lower mount**


1. Support the transmission on a transmission jack.
2. Remove the transmission lower mount.

**Transfer case**


1. Support the transfer case on a transmission jack.



2. Remove the transfer case by using a plastic hammer.

**Installation note****Transfer case**


1. Apply silicone sealant to the transfer case as shown.



2. Support the transfer case on a transmission jack.
3. Install the transfer case.

Tightening torque:

37—52 N·m { 3.7—5.5 kgf·m , 27—39 ft·lbf }

**Transmission lower mount**

1. Temporarily install washers and nuts (A).
2. Tighten bolts (B).


Tightening torque:

44—60 N·m { 4.4—6.2 kgf·m , 32—44 ft·lbf }


3. Tighten nuts (A).

Tightening torque:


32—46 N·m { 3.2—4.7 kgf·m , 24—33 ft·lbf }




- | | |
|--|--|
| <p>28. Pump cover
Inspection page K2-39</p> <p>29. Outer pump rotor
Disassembly Note page K2-38
Inspection page K2-39</p> <p>30. Inner pump rotor
Disassembly Note page K2-38
Inspection page K2-39</p> <p>31. Key</p> <p>32. Pump housing
Disassembly Note page K2-38
Disassembly / Inspection /
Assembly page K2-60</p> <p>33. Adjustment shim(s)</p> <p>34. Front oil pipe</p> <p>35. O-rings</p> <p>36. Rear oil pipe</p> <p>37. O-rings</p> <p>38. Retaining ring</p> <p>39. Input gear
Disassembly Note page K2-38
Inspect for damage, wear, or cracks</p> | <p>40. Baffle plate</p> <p>41. Rear oil pipe
Inspect for clogging or damage</p> <p>42. O-ring</p> <p>43. Transfer case housing</p> <p>44. Oil seal (front drive sprocket)
Inspect for damage
On-vehicle replacement page K2-50</p> <p>45. Bearing (input shaft)
Inspect for sticking or rough rotation
Disassembly Note page K2-38</p> <p>46. Oil seal (change drum)
Inspect for damage</p> <p>47. Bearing (output shaft)
Inspect for sticking or rough rotation
Disassembly Note page K2-39</p> <p>48. Oil seal (rear cover)
Inspect for damage
On-vehicle replacement page K2-51</p> |
|--|--|

**Disassembly note****Companion flange**


1. Hold the companion flange by using the **SST** and remove the companion flange nut.




2. Remove the companion flange by using the **SST**.




3. Clean the splines of the companion flange and output shaft.

**Rear cover**


1. Remove the rear cover by lightly tapping with a plastic hammer.




2. Remove the sealant from the rear cover and transfer case surfaces.

**Rear chain cover**


1. Separate the chain cover by lightly tapping with a plastic hammer.




2. Remove the rear chain cover while holding the shift rod.




3. Remove the sealant from the chain cover and transfer case mounting surfaces.

**Clutch gear**


Press out the clutch gear.

**2-4 shift rod**


Remove the 2-4 shift rod while holding the 2-4 shift fork.

**Drive gear and chain assembly**


Remove the drive gear and chain assembly by lightly tapping the front drive sprocket.

**Outer pump rotor and inner pump rotor**


1. Mark the inner and outer rotor positions without scratching or denting the rotors.
2. Remove the rotors from the housing.

**Pump housing**

1. Pry off the pump housing while the oil pipes are connected.
2. Separate the oil pipes from the pump housing.


**Input gear**

Press out the input gear.

**Bearing (input shaft)****Note**


- The bearing does not need to be removed unless it is being replaced.

Press out the bearing by using the **SST**.

**Bearing (output shaft)****Note**

- The bearing does not need to be removed unless it is being replaced.

Press out the bearing by using the **SST**.

**Inspection**

Inspect the following and replace parts as necessary.


Thrust washer

Measure the thickness of the thrust washer all around its edge.

Thickness**Standard:**

1.950—2.000 mm { 0.0768—0.0787 in }

Minimum: 1.900 mm { 0.0748 in }

**Oil pump**


Assemble the inner and outer pump rotors, and measure the following clearances. Measure each clearance three times and average the results.

1. Tooth clearance.

Clearance

Standard: 0.02—0.18 mm { 0.001—0.007 in }

Maximum: 0.2 mm { 0.008 in }




2. Side clearance.

Clearance

Standard: 0.17—0.26 mm { 0.007—0.010 in }

Maximum: 0.30 mm { 0.012 in }




3. Body clearance.


Clearance

Standard: 0.02—0.08 mm { 0.001—0.003 in }


Maximum: 0.10 mm { 0.004 in }

**Assembly procedure**


1. If the oil seal was removed, apply oil to the lip of a new oil seal and install it into the rear cover by using the **SST**.




2. If the bearing was removed, install a new bearing into the rear chain cover by using the **SST**.




3. If the oil seal was removed, apply oil to the lip of a new oil seal and install it into the rear chain cover by using the **SST**.




4. If the bearing was removed, install a new bearing into the transfer case housing by using the **SST**.



5. If the oil seal was removed, apply oil to the lip of a new oil seal and install it into the transfer case housing by using the **SST**.




6. Apply oil to a new O-ring and install it onto the rear oil pipe.
7. Install the rear oil pipe assembly to the transfer case housing.




8. Install the baffle plate.

Tightening torque:


7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }




9. Install the input gear.



10. Fit a new retaining ring onto the input gear.



11. Adjust the input gear end play. When measuring A and B, measure 6 times in a crisscross pattern and average the results.
 - (1) Measure depth \textcircled{A} of the input shaft bearing bore in the pump housing.




- (2) Measure the input shaft bearing snap ring height (B).
- (3) Select the proper adjustment shim(s) by using the formula below.


Formula: $(A) - (B) = 0 - 0.1 \text{ mm } \{ 0 - 0.004 \text{ in } \}$

Adjustment shim thickness:

mm { in }		
0.5 { 0.020 }	0.6 { 0.024 }	0.7 { 0.028 }
0.8 { 0.031 }	0.9 { 0.035 }	1.0 { 0.039 }




12. Apply oil to new O-rings and fit them onto the front and rear oil pipes.
13. Install the front and rear oil pipes into the pump housing.




14. Install the adjustment shim(s) selected in step 11. Align the oil pipes with the holes in the transfer case and install the pump housing.

Tightening torque:


19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }




15. Fit the key to the input gear.




16. Install the inner and outer pump rotors. If reusing the inner and outer pump rotors, install them with the marks facing upward.
17. Install the pump cover.




18. Verify that the input gear shaft rotates smoothly. If not, reinstall the pump cover.




19. Apply oil to the needle bearings, and fit them onto the center differential assembly.
20. Install the center differential assembly into the input shaft.




21. Adjust the center differential end play. When measuring A and B, measure 6 times in a crisscross pattern and average the results.
(1) Set the needle bearing onto the 2-4 clutch hub.
(2) Measure height A of the 2-4 clutch hub as shown.




- (3) Measure height B of the clutch gear as shown.



- (4) Install the needle bearings and the removed thrust washer.



- (5) Install the 2-4 clutch hub, needle bearing, and the clutch gear.



- (6) Measure clearance C between the 2-4 clutch hub and clutch gear as shown.
 (7) Select the proper thrust washer(s) by using the formula below.


Formula:

$$C - A - B = 0.1 - 0.3 \text{ mm } \{ 0.004 - 0.012 \text{ in } \}$$


Thrust washer thickness:

mm { in }


5.4 { 0.213 }	5.6 { 0.220 }	5.8 { 0.228 }
6.0 { 0.236 }	6.2 { 0.244 }	6.4 { 0.252 }
6.6 { 0.260 }	—	—




- (8) Remove the clutch gear and 2-4 clutch hub.
 (9) Install the proper thrust washer(s).
 22. Assemble the 2-4 clutch hub assembly, front drive sprocket, and chain.
 23. Using the **SST**, expand the chain without overtightening it.




24. Install the drive gear and chain assembly into the transfer case by lightly tapping it with a plastic hammer. Keep the chain horizontal.
 25. After installation, verify that the chain rotates smoothly.




26. Set the 2-4 shift fork onto the 2-4 hub sleeve and hold it.
 27. Install the 2-4 shift rod.




28. Apply oil to the thrust washers and fit them onto the change drum with the grooves inward.



29. Align the change drum groove and cam roller of the 2-4 shift fork, then install the change drum.




30. Install the clutch gear by using the **SST**.




31. Adjust the front drive sprocket end play. When measuring A and B, measure 6 times in a crisscross pattern and average the results.

(1) Measure depth **A** of the bearing bore in the rear chain cover.



(2) Install the front sprocket into the transfer case by lightly tapping it with a plastic hammer.




- (3) Measure height **B** between the transfer case and front sprocket rear bearing.
- (4) Select the proper adjustment shim(s) by using the formula below.


Formula: $A - B = 0 - 0.1 \text{ mm } \{ 0 - 0.004 \text{ in } \}$

Adjustment shim thickness:


			mm { in }
0.5 { 0.020 }	0.6 { 0.024 }	0.7 { 0.028 }	
0.8 { 0.031 }	0.9 { 0.035 }	1.0 { 0.039 }	
1.1 { 0.043 }	1.2 { 0.047 }	1.3 { 0.051 }	
1.4 { 0.055 }	1.5 { 0.059 }	1.6 { 0.063 }	




- (5) Remove the front sprocket from the transfer case housing by lightly tapping it with a plastic hammer.



32. Apply oil to a new O-ring and fit it onto the rear oil pipe.
33. Install the rear oil pipe.




34. Set the magnet into the transfer case housing.
35. Apply sealant to the transfer case housing as shown.




36. Set the adjustment shim(s) selected in step 31 into the rear chain cover.
37. Install the rear chain cover and brackets as shown.

Tightening torque:

$32 - 46 \text{ N}\cdot\text{m } \{ 3.2 - 4.7 \text{ kgf}\cdot\text{m}, 24 - 33 \text{ ft}\cdot\text{lbf} \}$




38. Verify that the change drum rotates smoothly. If not, re-install the rear chain cover.



39. Adjust the output shaft end play. When measuring A and B, measure 6 times in a crisscross pattern and average the results.

(1) Measure depth A of the bearing bore in the rear cover.




(2) Measure bearing snap ring height B.

(3) Select the proper adjustment shim(s) by using the formula below.


Formula: $A - B = 0 - 0.1 \text{ mm } \{ 0 - 0.004 \text{ in } \}$

Adjustment shim thickness:


mm { in }		
0.5 { 0.020 }	0.6 { 0.024 }	0.7 { 0.028 }
0.8 { 0.031 }	0.9 { 0.035 }	1.0 { 0.039 }



40. Install the key and speedometer drive gear onto the output shaft.




41. Set the adjustment shim(s) selected in step 39 into the rear cover.



42. Apply sealant to the rear cover as shown.
43. Install the rear cover.

Tightening torque:


37—53 N·m { 3.7—5.5 kgf·m , 27—39 ft·lbf }



44. Install the speedometer driven gear.

Tightening torque:


7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }




45. Apply sealant to the output shaft splines as shown.
46. Install the companion flange by using the SST.

Tightening torque:

128—176 N·m { 13—18 kgf·m , 94—130 ft·lbf }




47. Apply sealant to the control cover as shown.




48. Install the control cover and brackets.

Tightening torque:


19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }




49. Align the mark on the change drum groove with the 2H mark.



50. Check that the marks on the change motor salient and body are aligned.




51. If not aligned, turn the shaft by applying 12 V as shown.



52. Apply oil to a new O-ring and install the change motor.

Tightening torque:


19—25 N·m { 1.9—2.6 kgf·m , 14—18 ft·lbf }




53. Install the protector plate.

Tightening torque:


44—54 N·m { 4.4—5.6 kgf·m , 32—40 ft·lbf }

**OIL SEAL (FRONT DRIVE SPROCKET)****On-vehicle Replacement**


1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Mark the flanges for proper reassembly.
3. Remove the front propeller shaft.



4. Remove the oil seal.




5. Apply oil to the lip of the new oil seal, and install it by using the SST.




6. Align the marks and install the propeller shaft.

Tightening torque:


50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }

**OIL SEAL (REAR COVER)****On-vehicle Replacement**


1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Mark the flanges for proper reassembly.




3. Push a rag into the double-offset joint to hold the rear propeller shaft straight to prevent damaging the boot.
4. Remove the rear propeller shaft.




5. Hold the companion flange by using the **SST** and remove the companion flange nut.




6. Remove the companion flange by using the **SST**. Clean the splines.




7. Remove the oil seal.



8. Apply oil to the lip of the new oil seal and install it by using the **SST**.




9. Apply sealant to the output shaft and install the companion flange by using the **SST**.



10. Align the marks and install the propeller shaft.

Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }



11. Install the center bearing support assembly by using the removed bolts and spacers.

Tightening torque:


37—52 N·m { 3.7—5.4 kgf·m , 27—39 ft·lbf }

12. Remove the rag from the double-offset joint and check the boot for damage.


SPEEDOMETER DRIVEN GEAR

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. O-ring
Assembly Note below
2. Roll pin
Assembly Note below
3. Speedometer driven gear
Inspect for damage, wear, or cracks
4. Speedometer gear sleeve
5. Oil seal
Inspect for damage of oil seal lip
Disassembly Note below
Assembly Note below



Disassembly note

Oil seal


Remove the oil seal.



Assembly note

Oil seal

1. Apply oil to the lip of the new oil seal.
2. Install the oil seal by using a suitable pipe.




Roll pin

Install the new roll pin with the seam as shown.


CENTER DIFFERENTIAL AND OUTPUT SHAFT ASSEMBLY

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Planetary carrier assembly
Inspection page K2-55 2. Needle bearing
Inspect for damage and rough rotation 3. Retaining ring 4. Locknut
Disassembly Note below
Assembly Note page K2-55 5. Sun gear
Inspect for damage, wear, and cracks | <ol style="list-style-type: none"> 6. Thrust washer
Inspect bearing surface for
scoring and scratches 7. Ring gear
Inspect for damage, wear, and cracks
Inspection page K2-55 8. Needle bearing
Inspect for damage and rough rotation 9. Rear output shaft
Inspect for bearing surface
scoring and scratches
Inspection page K2-55 |
|---|--|



Disassembly note

Locknut

Remove the locknut by using the **SST**.



Inspection


Inspect the following and replace parts as necessary.

Planetary carrier assembly

Measure the clearance between the pinion washer and the planetary pinion carrier all around the edge.

Clearance

Standard: 0.2—0.7 mm { 0.008—0.028 in }
Maximum: 0.8 mm { 0.031 in }




Ring gear

Measure the inner diameter of the bushing. Measure three times and average the results.

Inner diameter

Standard:
 54.021—54.055 mm { 2.1268—2.1281 in }
Maximum: 54.100 mm { 2.1299 in }




Rear output shaft

1. Measure the outer diameter of the output shaft at the points shown. Measure each point three times and average the results.

Outer diameter


mm { in }

Position	Standard	Minimum
①	29.966—29.979 { 1.1798—1.1803 }	29.960 { 1.1795 }
②	41.975—41.991 { 1.6526—1.6532 }	41.970 { 1.6524 }
③	41.975—41.991 { 1.6526—1.6532 }	41.970 { 1.6524 }
④	35.975—36.000 { 1.4163—1.4173 }	35.970 { 1.4161 }



2. Measure the output shaft runout.

Maximum: 0.030 mm { 0.0012 in }



Assembly note

Locknut

Install a new locknut by using the SST. Stake the locknut.

Tightening torque (without SST):

206—284 N·m { 21—29 kgf·m , 152—209 ft·lbf }


Tightening torque (with SST):

187—254 N·m { 19—26 kgf·m , 138—188 ft·lbf }


DRIVE GEAR AND CHAIN ASSEMBLY

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|--|---|
| <p>1. Cam roller
Inspect for damage and rough rotation
Assembly Note pages K2-59</p> <p>2. 2-4 shift fork
Inspection pages K2-57</p> <p>3. Chain</p> <p>4. 2-4 hub sleeve
Inspection pages K2-57, 58</p> <p>5. Synchronizer keys
Inspect for damage, wear, and cracks</p> <p>6. Retaining ring</p> <p>7. 2-4 clutch hub
Inspect for damage, wear, and cracks
Inspection pages K2-58
Assembly Note pages K2-59</p> <p>8. Retaining ring</p> <p>9. Key springs
Inspect for fatigue and damage</p> <p>10. Outer cone
Inspection pages K2-58</p> <p>11. Double cone
Inspection pages K2-58</p> | <p>12. Inner cone
Inspect for damage, wear, and cracks
Inspection page K2-58</p> <p>13. Inner cone hub
Inspect for damage, wear, and cracks</p> <p>14. Spacer
Inspect splines for damage, wear, and cracks
Inspection page K2-58</p> <p>15. Needle bearings
Inspect for damage and rough rotation</p> <p>16. Spacer</p> <p>17. Drive sprocket
Inspection page K2-58</p> <p>18. Bearing (front)
Inspect for sticking and rough rotation
Disassembly Note page K2-57
Assembly Note page K2-59</p> <p>19. Bearing (rear)
Inspect for sticking and rough rotation
Disassembly Note page K2-57
Assembly Note page K2-59</p> <p>20. Front drive sprocket
Inspect for damage, wear, and cracks</p> |
|--|---|




Disassembly note Bearing (front)

Note

- The bearing does not need to be removed unless it is being replaced.

Remove the bearing by using the **SST**.




Bearing (rear)

Note

- The bearing does not need to be removed unless it is being replaced.

Remove the bearing by using the **SST**.




Inspection

Inspect the following and replace parts as necessary.

2-4 shift fork

- Assemble the 2-4 shift fork and rod. Verify that the shift fork moves smoothly on the rod.
- Measure the inner diameter of the bushing. Measure three times and average the results.




Inner diameter

Standard:

14.025—14.096 mm { 0.5522—0.5550 in }

Maximum: 14.100 mm { 0.5551 in }




2-4 shift fork and 2-4 hub sleeve

Measure the clearance between the 2-4 shift fork and hub sleeve. Measure the clearance three times and average the results.

Clearance


Standard: 0.10—0.57 mm { 0.004—0.022 in }

Maximum: 0.80 mm { 0.031 in }



2-4 hub sleeve and 2-4 clutch hub

Check for smooth operation of the 2-4 hub sleeve and clutch hub.




Outer cone, double cone, and inner cone

1. Set the outer cone, double cone, and inner cone squarely onto the drive sprocket.

Clearance


Standard: 0.72—1.59 mm { 0.028—0.063 in }
Minimum: 0.70 mm { 0.028 in }



2. Measure the clearance between the outer cone and the drive sprocket. Measure the clearance all around the edge.

Clearance

Standard: 0.72—1.39 mm { 0.028—0.055 in }
Minimum: 0.70 mm { 0.028 in }




Spacer

Measure the outer diameter of the spacer. Measure three times and average the results.

Outer diameter

Standard:
 69.971—69.990 mm { 2.7548—2.7555 in }
Minimum: 69.970 mm { 2.7547 in }




Drive sprocket


Measure the inner diameter of the drive sprocket. Measure three times and average the results.

Inner diameter


Standard:
 78.010—78.029 mm { 3.0713—3.0720 in }
Maximum: 78.030 mm { 3.0720 in }

**Assembly note****Bearing (rear)**


Install the new bearing by using the SST.

**Bearing (front)**


Install the new bearing by using the SST.

**2-4 clutch hub**

Align the outer cone grooves with the key grooves of the 2-4 clutch hub before assembly.

**Cam roller**

1. Mount the cam roller onto the 2-4 shift fork.



2. Tighten the locknut.

Tightening torque:

7.9—11.7 N·m { 80—120 kgf·cm , 70—104 in·lbf }


PUMP HOUSING

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.



APPLY SPECIFIED OIL TO INDIVIDUAL PARTS



- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Spring cap 2. Gasket 3. Pressure spring | <ol style="list-style-type: none"> 4. Steel ball 5. Pump housing |
|--|--|
- Inspection below



Inspection

Pressure spring

1. Measure the spring dimensions.

Specifications

Outer dia. mm { in }	Free length mm { in }	No. of coils	Wire dia. mm { in }
6.1 { 0.240 }	20.0 { 0.787 }	17.0	0.6 { 0.024 }

2. If not within the specification, replace the return spring.

PROPELLER SHAFT

OUTLINE	L- 2
SPECIFICATIONS	L- 2
(2WD)	L- 2
(4WD)	L- 2
TROUBLESHOOTING GUIDE	L- 3
PROPELLER SHAFT (2WD)	L- 4
PREPARATION	L- 4
REMOVAL / INSTALLATION	L- 5
OVERHAUL	L- 8
FRONT PROPELLER SHAFT (4WD)	L-14
REMOVAL / INSTALLATION	L-14
REAR PROPELLER SHAFT (4WD)	L-16
PREPARATION	L-16
REMOVAL / INSTALLATION	L-17
OVERHAUL	L-20

OUTLINE


SPECIFICATIONS
(2WD)

Item		Engine		JE	
Length	mm { in }	L		1474.3	{ 58.04 }
		L1		718.3	{ 28.28 }
		L2		756	{ 29.76 }
Outer diameter	mm { in }	D1		65	{ 2.56 }
		D2		65	{ 2.56 }


(4WD)


Item		Engine		JE	
Front propeller shaft					
Length	mm { in }	L		510	{ 20.08 }
Outer diameter	mm { in }	D		57	{ 2.24 }
Rear propeller shaft					
Length	mm { in }	L		1271.3	{ 50.05 }
		L1		515.3	{ 20.29 }
		L2		756	{ 29.76 }
Outer diameter	mm { in }	D1		65	{ 2.56 }
		D2		65	{ 2.56 }

PROPELLER SHAFT (2WD)



FRONT PROPELLER SHAFT (4WD)





TROUBLESHOOTING GUIDE

(2WD)











Problem	Possible Cause	Remedy	Page
Vibration	Worn universal joint	Replace	L-8
	Bent propeller shaft	Replace	L-8
	Worn slip yoke splines	Replace	L-8
	Runout of propeller shaft	Replace	L-8
	Imbalanced propeller shaft	Replace	L-8
	Incorrect propeller shaft alignment angle	Adjust	L-7
Abnormal noise	Worn or damaged universal joint	Replace	L-8
	Worn slip yoke splines	Replace	L-8
	Worn bearing	Replace	L-8
	Incorrect propeller shaft alignment angle	Adjust	L-7

(4WD)

Problem	Possible Cause	Remedy	Page
Vibration	Runout of propeller shaft	Replace	L-14, 17
	Imbalanced propeller shaft	Replace	L-14, 17
	Bent propeller shaft	Replace	L-14, 17
	Loose center support mounting bolts	Tighten	L-17
	Loose yoke mounting nut	Tighten	L-14, 17
	Worn slip yoke splines	Replace	L-14
	Incorrect rear propeller shaft alignment angle	Adjust	L-19
Abnormal noise	Worn or damaged universal joint bearing	Replace	L-14, 20
	Worn or damaged center support or bearing	Replace	L-20
	Worn slip yoke splines	Replace	L-14
	Incorrect rear propeller shaft alignment angle	Adjust	L-19


PROPELLER SHAFT (2WD)

**PREPARATION
SST**


<p>49 S120 440 Holder, main shaft</p> 	<p>For prevention of oil leakage</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal of center bearing support</p>
<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of center bearing support</p>	<p>49 B025 0A0 Installer, dust seal</p> 	<p>For removal / installation of bearing</p>
<p>49 B025 001 Body (Part of 49 B025 0A0)</p> 	<p>For removal / installation of bearing</p>	<p>49 H025 001 Installer, bearing</p> 	<p>For installation of oil seal</p>
<p>49 F026 102 Installer, bearing</p> 	<p>For removal of bearing</p>	<p>49 H025 002 Installer, dust seal</p> 	<p>For installation of oil seal</p>
<p>49 H025 004 Installer, bearing</p> 	<p>For installation of center bearing support</p>	<p>49 F401 331 Body</p> 	<p>For installation of center bearing support</p>

REMOVAL / INSTALLATION

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--------------------------|----------------------------------|
| 1. Nut | 8. Bushing |
| Removal Note below | 9. Washer |
| 2. Lock washer | 10. Spacer |
| 3. Bolt | 11. Washer |
| 4. Bolt | 12. Propeller shaft |
| 5. Washer | Removal Note page L-6 |
| 6. Bushing | Installation Note page L-6 |
| 7. Spacer | Check for oil leakage |




Removal Note

Nut


1. Mark the flanges for correct reassembly.
2. Remove the nuts.

**Propeller shaft**

1. Push a rag into the double-offset joint to hold the propeller shaft straight and to prevent damage to the boot.




2. When the propeller shaft is removed from the extension housing, immediately install the **SST** into the extension housing to prevent oil leakage.

**Installation Note****Propeller shaft**

1. Push a rag into the double-offset joint to prevent damage to the boot.

Note


- New propeller shafts are equipped with an insulator to prevent damage to the boot.



2. Align the marks and install the propeller shaft.

Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }




3. Install the center bearing support assembly by using the removed bolts and spacers.


Tightening torque:

37—52 N·m { 3.7—5.4 kgf·m , 27—39 ft·lbf }

4. Remove the rag or insulator from the double-offset joint, and check the boot for damage.



5. Verify that there is no abnormal noise or vibration when driving the vehicle.




6. If noise or vibration seems to be the result of incorrect propeller shaft alignment angle, replace the bolts and spacers at the center bearing support with new ones. Bolts and spacers used on one side must have the same dimensions as those used on the other side.


Bolt size	mm { in }	Spacer size	mm { in }
M10×40	{ 1.59 }	3.2	{ 0.13 }
M10×40	{ 1.59 }	4.5	{ 0.18 }
M10×45	{ 1.77 }	6.0	{ 0.24 }
M10×45	{ 1.77 }	8.0	{ 0.31 }
M10×50	{ 1.97 }	10.0	{ 0.39 }
M10×50	{ 1.97 }	13.0	{ 0.51 }
M10×50	{ 1.97 }	16.0	{ 0.63 }

OVERHAUL

1. Remove all mud, dirt, and other foreign particles from the propeller shaft.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and repair or replace as necessary.
4. Verify that all parts are completely free of dirt, dust, and other small particles.
5. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Nut	9. Front propeller shaft
2. Lock washer	Inspection page L-10
3. Bolt	10. Front dust seal
4. Rear propeller shaft	Assembly Note page L-11
Disassembly Note page L- 9	11. Rear dust seal
Inspection page L-10	Assembly Note page L-11
Assembly Note page L-12	12. Snap ring
5. O-ring	13. Center bearing support assembly
6. Flange nut	Disassembly Note page L-10
Disassembly Note page L- 9	Assembly Note page L-12
Assembly Note page L-12	14. Spacer
7. Lock washer	15. Bearing
8. Center companion flange	Disassembly Note page L-10
Disassembly Note page L- 9	Inspection page L-11
	Assembly Note page L-11




Disassembly Note
Rear propeller shaft


1. Push a rag into the double-offset joint to prevent damage to the boot.



2. Mark the center companion flange and the yoke for proper reassembly.
3. Place the front propeller shaft in a vise and separate the front and rear shaft.




4. After removing the rear propeller shaft, clean the yoke surface, then seal the vent hole with tape.




Flange nut

1. Mark the flange and shaft for proper reassembly.
2. Place the center companion flange in a vise.
3. Remove the flange nut and lock washer.




Center companion flange

1. Place the front propeller shaft in a vise.
2. Remove the center companion flange by using the SST.




Center bearing support assembly

Remove the center bearing support assembly by using the **SSTs**.



Bearing

Press the bearing from the support assembly toward the rear side by using the **SSTs**.




Inspection


Front and rear propeller shaft

1. Measure the front and rear propeller shaft runout by using a dial indicator.
Replace the front and rear propeller shaft assembly if runout is excessive.


Maximum runout: 0.4 mm { 0.016 in }



2. Move the universal joints in the direction shown and check for universal joint play.
If there is play, replace the front and rear propeller shaft assembly.
3. Check the operation of the universal joint.
If the universal joint has excessive resistance, replace the front and rear propeller shaft assembly.




4. Check the double-offset joint boot for damage.
If there is damage, replace the front and rear propeller shaft assembly.



Bearing


Turn the bearing while applying force in the axial direction.
If the bearing sticks or has excessive resistance, replace it.



Assembly Note


Bearing

Install the bearing into the bearing support assembly from the rear side by using the **SSTs**.




Rear dust seal

1. Before installing a new rear dust seal into the bearing support assembly, apply lithium-based grease to the shaded area.




2. Install the rear dust seal into the support assembly from the rear side by using the **SSTs** as shown in the figure.




Front dust seal

1. Before installing a new front dust seal into the bearing support assembly, apply lithium-based grease to the shaded area.




2. Install the front dust seal into the support assembly from the front side by using the **SSTs** as shown in the figure.




Center bearing support assembly

Install the center bearing support assembly onto the front propeller shaft by using the **SSTs**.



Flange nut


1. Align the marks on the flange and shaft.
2. Install the lock washer and temporarily tighten the flange nut.



3. Place the center companion flange in a vise.
4. Tighten the flange nut to the specified torque.


Tightening torque:

160—170 N·m { 16—18 kgf·m , 120—130 ft·lbf }




Rear propeller shaft

1. Push a rag into the double-offset joint to prevent damage to the boot.



2. Apply lithium-based grease to a new O-ring, and install the O-ring into the center companion flange.



3. Place the front propeller shaft in a vise.
4. Align the marks on the center companion flange and the yoke, and install the rear propeller shaft.


Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }

FRONT PROPELLER SHAFT (4WD)


REMOVAL / INSTALLATION

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.




1. Nut
Removal Note below
2. Lock washer
3. Bolt

4. Front propeller shaft
Installation Note below
Inspection page L-15



Removal Note

1. Mark the flanges for correct reassembly.
2. Remove the nuts.




Installation Note
Front propeller shaft

Align the marks and install the front propeller shaft.


Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }

**Inspection
Propeller shaft**

1. Measure the front propeller shaft runout by using a dial indicator.
Replace the front propeller shaft if runout is excessive.

Maximum runout: 0.4 mm { 0.016 in }












2. Measure the starting torque of the spider by using the pull gauge.

**Starting torque:
0.3—0.7 N·m { 3—8 kgf·cm , 3—6 in·lbf }**

3. Install different snap rings to adjust the starting torque if necessary.


REAR PROPELLER SHAFT (4WD)

**PREPARATION
SST**


<p>49 0839 425C Puller set, bearing</p> 	<p>For removal of center bearing support</p>	<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of center bearing support</p>
<p>49 B025 0A0 Installer, dust seal</p> 	<p>For removal / installation of bearing</p>	<p>49 B025 001 Body (Part of 49 B025 0A0)</p> 	<p>For removal / installation of bearing</p>
<p>49 H025 001 Installer, bearing</p> 	<p>For installation of oil seal</p>	<p>49 F026 102 Installer, bearing</p> 	<p>For removal of bearing</p>
<p>49 H025 002 Installer, dust seal</p> 	<p>For installation of oil seal</p>	<p>49 H025 004 Installer, bearing</p> 	<p>For installation of center bearing support</p>
<p>49 F401 331 Body</p> 	<p>For installation of center bearing support</p>	<p>—</p>	<p>—</p>

REMOVAL / INSTALLATION

1. Inspect the boots of the center bearing and the double-offset joint for damage, and repair or replace as necessary.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




- | | | | |
|----------------|--------------------|-------|-------------------------|
| 1. Nut | Removal Note | below | 10. Spacer |
| 2. Lock washer | | | 11. Bushing |
| 3. Bolt | | | 12. Washer |
| 4. Nut | | | 13. Spacer |
| 5. Lock washer | | | 14. Washer |
| 6. Bolt | | | 15. Propeller shaft |
| 7. Bolt | | | Removal Note |
| 8. Washer | | | Installation Note |
| 9. Bushing | | | Overhaul |
- page L-18
page L-18
page L-20




Removal Note

Nut

1. Mark the flanges for correct reassembly.
2. Remove the nuts.

**Propeller shaft**


1. Push a rag into the double-offset joint to hold the propeller shaft straight and to prevent damage to the boot.
2. Remove the rear propeller shaft.

**Installation Note****Propeller shaft**

1. Push a rag into the double-offset joint to prevent damage to the boot.

Note


- New propeller shafts are equipped with an insulator to prevent damage to the boot.



2. Align the marks and install the propeller shaft.

Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }




3. Install the center bearing support assembly by using the removed bolts and spacers.


Tightening torque:

37—52 N·m { 3.7—5.4 kgf·m , 27—39 ft·lbf }

4. Remove the rag or insulator from the double-offset joint, and check the boot for damage.



5. Verify that there is no abnormal noise or vibration when driving the vehicle.




6. If noise or vibration seems to be the result of incorrect propeller shaft alignment angle, replace the bolts and spacers at the center bearing support with new ones. Bolts and spacers used on one side must have the same dimensions as those used on the other side.


Bolt size	mm { in }	Spacer size	mm { in }
M10×40	{ 1.59 }	3.2	{ 0.13 }
M10×40	{ 1.59 }	4.5	{ 0.18 }
M10×45	{ 1.77 }	6.0	{ 0.24 }
M10×45	{ 1.77 }	8.0	{ 0.31 }
M10×50	{ 1.97 }	10.0	{ 0.39 }
M10×50	{ 1.97 }	13.0	{ 0.51 }
M10×50	{ 1.97 }	16.0	{ 0.63 }

OVERHAUL

1. Remove all mud, dirt, and other foreign particles from the propeller shaft.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and repair or replace as necessary.
4. Verify that all parts are completely free of dirt, dust, and other small particles.
5. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Nut 2. Lock washer 3. Bolt 4. No.2 propeller shaft assembly
 <ul style="list-style-type: none"> Disassembly Note page L-21 Inspection page L-22 Assembly Note page L-25 5. O-ring 6. Flange nut
 <ul style="list-style-type: none"> Disassembly Note page L-21 Assembly Note page L-24 7. Lock washer 8. Center companion flange
 <ul style="list-style-type: none"> Disassembly Note page L-21 9. Spacer | <ol style="list-style-type: none"> 10. No.1 propeller shaft
 <ul style="list-style-type: none"> Insection page L-22 11. Front dust seal
 <ul style="list-style-type: none"> Assembly Note page L-23 12. Rear dust seal
 <ul style="list-style-type: none"> Assembly Note page L-23 13. Snap ring 14. Center bearing support assembly
 <ul style="list-style-type: none"> Disassembly Note page L-22 Assembly Note page L-24 15. Bearing
 <ul style="list-style-type: none"> Disassembly Note page L-22 Inspection page L-23 Assembly Note page L-23 |
|---|--|




Disassembly Note

No.2 propeller shaft assembly


1. Push a rag into the double-offset joint to prevent damage to the boot.



2. Mark the center companion flange and the yoke for proper reassembly.
3. Place the No.1 propeller shaft assembly in a vise and separate the propeller shaft.




4. After removing the No.2 propeller shaft assembly, clean the yoke surface and seal the vent hole with tape.




Flange nut

1. Mark the flange and shaft for proper reassembly.
2. Place the center companion flange in a vise.
3. Remove the flange nut and lock washer.




Center companion flange


1. Place the No.1 propeller shaft in a vise.
2. Remove the center companion flange by using the SST.

**Center bearing support assembly**

Remove the center bearing support assembly by using the SSTs.


**Bearing**

Press the bearing out of the support assembly toward the rear by using the SSTs.


**Inspection****No.1 propeller shaft, No.2 propeller shaft assembly**

1. Measure the propeller shaft runout by using a dial indicator.
Replace the propeller shaft assembly if runout is excessive.

Maximum runout: 0.4 mm { 0.016 in }



2. Check the double-offset joint boot for damage.
If there is damage, replace the propeller shaft assembly.




3. Measure the starting torque of the spider.

Starting torque:


0.3—0.7 N·m { 3—8 kgf·cm , 3—6 in·lbf }

4. Install different snap rings to adjust the starting torque if necessary.



Bearing


Turn the bearing while applying force in the axial direction.
If the bearing sticks or has excessive resistance, replace it.



Assembly Note


Bearing

Install the bearing into the bearing support assembly from the rear side by using the **SSTs**.




Rear dust seal

1. Before installing a new rear dust seal into the bearing support assembly, apply lithium-based grease to the shaded area.




2. Install the rear dust seal into the support assembly from the rear side by using the **SSTs** as shown in the figure.




Front dust seal

1. Before installing a new front dust seal into the bearing support assembly, apply lithium-based grease to the shaded area.




2. Install the front dust seal into the support assembly from the front side by using the **SSTs** as shown in the figure.




Center bearing support assembly

Install the center bearing support assembly onto the front propeller shaft by using the **SSTs**.



Flange nut


1. Align the marks on the flange and shaft.
2. Install the lock washer and hand-tighten the flange nut.




3. Place the center companion flange in a vise.
4. Tighten the flange nut to the specified torque.

Tightening torque:

160—170 N·m { 16—18 kgf·m , 120—130 ft·lbf }




5. Apply lithium-based grease to a new O-ring. Install the O-ring into the center companion flange.



No.2 propeller shaft assembly

1. Push a rag into the double-offset joint to prevent damage to the boot.



2. Place the No.1 propeller shaft in a vise.
3. Align the marks on the center companion flange and the yoke. Mount the No.2 propeller shaft assembly.

Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }


Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

FRONT AND REAR AXLES

INDEX	M- 2
OUTLINE	M- 4
SPECIFICATIONS	M- 4
TROUBLESHOOTING GUIDE	M- 5
FRONT AXLE	M- 5
REAR AXLE	M- 5
AUTOMATIC FREEWHEEL (AFW) UNIT	M- 5
FRONT DIFFERENTIAL (4WD)	M- 6
REAR DIFFERENTIAL	M- 6
FRONT AXLE	M- 7
PREPARATION	M- 7
WHEEL HUB, STEERING KNUCKLE (2WD)	M- 8
WHEEL HUB, STEERING KNUCKLE (4WD)	M-12
REAR AXLE	M-18
PREPARATION	M-18
REAR AXLE SHAFT	M-19
DRIVE SHAFT (4WD)	M-24
PREPARATION	M-24
DRIVE SHAFT (DOUBLE OFFSET JOINT)	M-24
FRONT DIFFERENTIAL AND AUTOMATIC	
FREEWHEEL (AFW) MECHANISM (4WD)	M-31
PREPARATION	M-31
VACUUM HOSE ROUTING DIAGRAM	M-33
AFW SWITCH	M-33
ONE-WAY CHECK VALVE	M-34
SOLENOID VALVE	M-34
ACTUATOR	M-35
VACUUM RESERVOIR	M-35
DIFFERENTIAL OIL	M-35
OIL SEAL	M-36
FRONT DIFFERENTIAL AND AUTOMATIC	
FREEWHEEL UNIT	M-38
AUTOMATIC FREEWHEEL UNIT	M-41
CONTROL BOX ASSEMBLY	M-45
FRONT DIFFERENTIAL	M-47
REAR DIFFERENTIAL	M-56
PREPARATION	M-56
DIFFERENTIAL OIL	M-57
OIL SEAL	M-58
DIFFERENTIAL (STANDARD)	M-60

INDEX


(2WD)



- 1. Front axle
 - Inspection / Removal /
Installation page M- 8
 - Disassembly / Inspection /
Assembly page M- 9
- 2. Rear axle
 - Inspection / Removal /
Installation page M-19
 - Disassembly / Inspection /
Assembly page M-21

- 3. Rear differential
 - Differential oil and oil seal . page M-57, 58
 - Removal / Installation page M-60
 - Overhaul page M-62

(4WD)



<p>1. Front axle Inspection / Removal / Installation page M-12 Disassembly / Inspection / Assembly page M-14</p> <p>2. Drive shaft (4WD) Inspection / Removal / Installation page M-24 Overhaul page M-26</p> <p>3. Front differential and automatic freewheel unit Removal / Installation page M-38</p>	<p>4. Automatic freewheel unit Disassembly / Inspection / Assembly page M-41</p> <p>5. Control box assembly Overhaul page M-45</p> <p>6. Front differential Overhaul page M-47</p> <p>7. Rear differential Differential oil and oil seal . page M-57, 58 Removal / Installation page M-60 Overhaul page M-62</p>
---	---

OUTLINE

SPECIFICATIONS

Item		Model/Transmission		2WD	4WD		
Front axle	Type		Strut mounting				
	Bearing		Angular ball bearing				
	Maximum wheel bearing play		mm { in }	0.05 { 0.002 }			
Rear axle	Type		5-link mounting				
	Axle shaft	Support type		Semifloating			
		Bearing		Ball bearing			
		Casing		Banjo type housing			
	Maximum wheel bearing play		mm { in }	0.57 { 0.0224 }			
Front differential	Type		—	Standard			
	Reduction gear		—	Hypoid gear			
	Differential gear		—	Straight-bevel gear			
	Ring gear size		mm { in }	—	181.6 { 7.15 }		
	Reduction ratio		—	4.100			
	Number of teeth	Ring gear		—	41		
		Drive pinion gear		—	10		
	Oil	Grade		—	API Service GL-5		
		Viscosity	Above -18 °C { 0 °F }		—	SAE 90	
			Below -18 °C { 0 °F }		—	SAE 80W	
Capacity		L { US qt , Imp qt }	—	1.7 { 1.8 , 1.5 }			
Rear differential	Type		Standard				
	Reduction gear		Hypoid gear				
	Differential gear		Straight-bevel gear				
	Ring gear size		mm { in }	203.2 { 8.00 }			
	Reduction ratio		3.909	4.100			
	Number of teeth	Ring gear		43	41		
		Drive pinion gear		11	10		
	Oil	Grade		API service GL-5			
		Viscosity	Above -18 °C { 0 °F }		SAE 90		
			Below -18 °C { 0 °F }		SAE 80W		
Capacity		L { US qt , Imp qt }	1.5 { 1.6 , 1.3 }				

TROUBLESHOOTING GUIDE

FRONT AXLE

Problem	Possible Cause	Remedy	Page
Steering wheel vibration	Improperly adjusted wheel bearing play Worn or damaged wheel bearing	Tighten or replace Replace	M-12 M-8, 12
Steering wheel pulls or one-sided braking	Improperly adjusted wheel bearing play Worn or damaged wheel bearing	Adjust Replace	M-12 M-8, 12
Excessive steering wheel play	Improperly adjusted wheel bearing play	Tighten or replace	M-12
Abnormal noise	Bent axle casing Bent drive shaft Worn or damaged wheel bearing Worn drive shaft splines Insufficient grease in joint or on splines of drive shaft Worn double offset joint of drive shaft	Replace Replace Replace Replace Replenish or replace Replace	M-47 M-24 M-8, 12 M-24 M-24 M-24
Grease leakage from boot	Damaged or broken boot Faulty boot band Excessive grease	Replace Replace Repair	M-26 M-26 M-26

M

REAR AXLE

Problem	Possible Cause	Remedy	Page
Abnormal noise	Bent axle casing Bent axle shaft Worn or damaged wheel bearing Worn axle shaft spline	Replace Replace Replace Replace	— M-19 M-21 M-19
Oil leakage	Worn or damaged oil seal	Replace	M-19, 21

AUTOMATIC FREEWHEEL (AFW) UNIT

Problem	Possible Cause	Remedy	Page
No AFW operation	Free to Lock	Failed lock solenoid Failed actuator Air leak at vacuum reservoir or system Failed one-way check valve	M-34 M-35, 45 M-35 M-34
	Lock to Free	Failed AFW switch Failed lock solenoid Failed actuator Air leak at vacuum reservoir or system Failed one-way check valve	M-33, 45 M-34 M-35, 45 M-35 M-34
Abnormal noise	Insufficient front differential oil Incorrect front differential oil Worn or damaged bearing Worn spline of AFW hub Worn joint shaft Improperly adjusted shaft end play Improperly adjusted gear end play Worn spline of output shaft	Add oil Replace Replace Replace Replace Adjust Adjust Replace	M-35 M-35 M-41 M-41 M-41 M-43 M-44 M-41
Heat buildup	Insufficient front differential oil Improperly adjusted end play Excessive front differential oil	Add oil Adjust Drain oil	M-35 M-43, 44 M-35
Oil leakage	Excessive front differential oil Poorly tightened AFW unit Worn or damaged oil seal	Drain oil Tighten or repair Replace	M-35 M-38 M-35

FRONT DIFFERENTIAL (4WD)














Problem	Possible Cause	Remedy	Page
Abnormal noise	Insufficient front differential oil	Add oil	M-35
	Incorrect front differential oil	Replace	M-35
	Improperly adjusted backlash of final gear	Adjust	M-53
	Poor contact of teeth of final gear	Adjust	M-54
	Worn or damaged side bearing	Replace	M-47
	Worn or damaged final gear	Replace	M-47
	Worn or damaged drive pinion bearing	Replace	M-47
	Worn or damaged pinion and side gear	Replace	M-47
	Seized side gear	Replace	M-47
	Worn spline of side gear	Replace	M-47
	Worn pinion shaft	Replace	M-47
	Loose companion flange nut	Tighten	M-52
	Worn side gear thrust washer	Replace	M-53
	Improperly adjusted side bearing preload	Adjust	M-54
	Improperly adjusted drive pinion bearing preload	Adjust	M-52
Worn spline of output shaft	Replace	M-47	
Heat buildup	Insufficient front differential oil	Add oil	M-35
	Insufficient backlash of gears	Adjust	M-53
	Excessive bearing preload	Adjust	M-52
Oil leakage	Cracked axle casing	Replace	M-47
	Excessive front differential oil	Drain oil	M-35
	Clogged differential housing breather	Repair	—
	Poorly tightened differential carrier	Tighten or repair	M-47
	Worn or damaged oil seal	Replace	M-35

REAR DIFFERENTIAL

Problem	Possible Cause	Remedy	Page
Abnormal noise	Insufficient differential oil	Add oil	M-57
	Incorrect differential oil	Replace	M-57
	Improperly adjusted ring gear backlash	Adjust	M-68
	Poor contact of ring gear teeth	Adjust	M-69
	Worn or damaged side bearing	Replace	M-62
	Worn or damaged ring gear	Replace	M-62
	Worn or damaged drive pinion bearing	Replace	M-62
	Worn or damaged pinion and side gear	Replace	M-62
	Seized side gear and case	Replace	M-62
	Worn side gear spline	Replace	M-62
	Worn pinion shaft	Replace	M-62
	Loose companion flange nut	Tighten	M-62
	Worn thrust washer	Replace	M-62
	Improperly adjusted side bearing preload	Adjust	M-67
	Improperly adjusted drive pinion bearing preload	Adjust	M-66
Heat buildup	Insufficient differential oil	Add oil	M-57
	Insufficient gear backlash	Adjust	M-67
	Excessive bearing preload	Adjust	M-66
Oil leakage	Excessive differential oil	Remove oil	M-57
	Clogged air breather	Repair	M-59
	Loose differential carrier	Tighten or repair	M-59
	Worn or damaged oil seal	Replace	M-61
No differential operation	Misassembled	Repair	M-62

FRONT AXLE

PREPARATION
SST


<p>49 F026 103 Puller, wheel hub (4WD)</p> 	<p>For disassembly of wheel hub assembly, wheel bearing, and assembly of inner oil seal</p>	<p>49 G033 1A1 Puller set, wheel hub (4WD)</p> 	<p>For disassembly of wheel hub assembly and wheel bearing</p>
<p>49 G033 102 Handle (Part of 49 G033 1A1) (4WD)</p> 	<p>For disassembly of wheel hub assembly and wheel bearing</p>	<p>49 G033 105 Attachment (Part of 49 G033 1A1) (4WD)</p> 	<p>For disassembly / assembly of wheel hub assembly</p>
<p>49 G033 106 Attachment (Part of 49 G033 1A1) (4WD)</p> 	<p>For disassembly of wheel bearing</p>	<p>49 G033 107 Installer, dust cover (4WD)</p> 	<p>For assembly of dust cover</p>
<p>49 0636 145 Puller, fan pulley boss (4WD)</p> 	<p>For disassembly of wheel bearing</p>	<p>49 L033 101 Installer, oil seal (4WD)</p> 	<p>For assembly of dust cover, wheel bearing, outer oil seal, and inner oil seal</p>
<p>49 F026 102 Installer, bearing (4WD)</p> 	<p>For assembly of wheel bearing</p>	<p>49 G019 017 Installer, oil seal (4WD)</p> 	<p>For assembly of outer oil seal</p>
<p>49 F027 009 Attachment 68 & 77 (4WD)</p> 	<p>For assembly of wheel hub assembly</p>	<p>49 U025 001 Installer, protector</p> 	<p>For assembly of dust cover</p>
<p>49 L033 103 Installer, sensor rotor (2WD)</p> 	<p>For assembly of ABS sensor rotor</p>	<p>—</p>	<p>—</p>

M

WHEEL HUB, STEERING KNUCKLE (2WD)


Inspection / Removal / Installation

1. Inspect the wheel bearing play, referring to **Inspection**.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Hub cap
2. Locknut
Installation Note page M-9
3. Brake caliper assembly
Service section P
4. ABS wheel-speed sensor
5. Disc plate
Inspection section P
6. Wheel hub assembly
Inspect for cracks or damage
Disassembly / Inspection /
Assembly page M-9

7. Tie-rod end
Service section N
8. Lower arm
Service section R
9. Knuckle spindle and dust cover
Inspect the knuckle spindle for cracks or
damage
Inspect the dust cover for damage or distor-
tion
Disassembly / Inspection /
Assembly page M-9




Inspection

Wheel bearing play

Position a dial indicator against the disc plate. Push and pull the disc plate by hand in the axial direction and measure the wheel bearing play.

If the bearing play exceeds the specification, check and adjust the hub nut torque or replace the wheel bearing and hub assembly if necessary.

Maximum wheel bearing play: 0.05 mm { 0.002 in }



Installation note

Locknut

Install a new locknut and crimp it.


Tightening torque:

177—235 N·m { 18—24 kgf·m , 131—173 ft·lbf }




Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Wheel hub assembly 2. ABS sensor rotor (ABS)
Disassembly Note page M-10
Assembly Note page M-11 3. Hub bolt
Disassembly Note page M-10
Assembly Note page M-11 | <ol style="list-style-type: none"> 4. Dust cover
Disassembly Note page M-10
Assembly Note page M-10 5. Knuckle spindle |
|---|--|




Disassembly Note
ABS sensor rotor (ABS)

Note

- The sensor rotor does not need to be removed unless you are replacing it.

Remove the sensor rotor by using a chisel.




Hub bolts

Note

- The hub bolts do not need to be removed unless you are replacing them.

Remove the hub bolts by using a press if necessary.




Dust cover

Note

- The dust cover does not need to be removed unless you are replacing it.

1. Mark the dust cover and knuckle spindle for proper reassembly.


2. Remove the dust cover by using a chisel.




Assembly note


Dust cover

1. Mark the new dust cover as the removed one.






2. Align the marks of the new dust cover and the knuckle spindle.
3. Install the new dust cover by using the **SST**.



Hub bolts

Install the new hub bolts by using a press.



ABS sensor rotor (ABS)

1. Install a new ABS sensor rotor on to the wheel hub.


Note

- The ABS sensor rotor can be installed in either direction.
2. Using a steel plate and the **SST**, press the rotor on until it is flush with the wheel hub.

WHEEL HUB, STEERING KNUCKLE (4WD)


Inspection / Removal / Installation

1. Inspect the wheel bearing play, referring to **Inspection**.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. After installation, check the front wheel alignment and adjust it if necessary. (Refer to section R.)



- | | |
|---------------------------|-----------------|
| 1. Locknut | |
| Installation Note | page M-13 |
| 2. Screws | |
| 3. Brake caliper assembly | |
| Service | section P |
| 4. ABS wheel-speed sensor | |
| 5. Tie-rod end | |
| Service | section N |
| 6. Lower ball joint | |
| Service | section R |


- | | |
|--|-----------------|
| 7. Disc plate | |
| Inspection | section P |
| 8. Bolts, washers, and nuts | |
| 9. Knuckle, wheel hub, and dust cover | |
| Inspect wheel hub for cracks or damage | |
| Inspect knuckle spindle for cracks or damage | |
| Inspect dust cover for damage or distortion | |
| Disassembly / Inspection / | |
| Assembly | page M-14 |

**Inspection****Wheel bearing play**

Position a dial indicator against the disc plate. Push and pull the disc plate by hand in the axial direction and measure the wheel bearing play.

If the bearing play exceeds the specification, check and adjust the hub nut torque or replace the wheel bearing if necessary.

Maximum wheel bearing play: 0.05 mm { 0.002 in }

**Installation note****Locknut**


Install a new locknut and crimp it.

Tightening torque:


236—313 N·m { 24—32 kgf·m , 174—231 ft·lbf }

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|--|--|
| 1. Inner oil seal
Assembly Note page M-17 | 6. Dust cover
Disassembly Note page M-15
Assembly Note page M-16 |
| 2. Wheel hub assembly
Disassembly Note below
Assembly Note page M-17 | 7. Knuckle
Disassembly Note page M-16
Assembly Note page M-16 |
| 3. Outer oil seal
Assembly Note page M-17 | 8. Hub bolt
Disassembly Note page M-16
Assembly Note page M-16 |
| 4. Retaining ring | |
| 5. Wheel bearing
Disassembly Note page M-15
Assembly Note page M-16 | |




Disassembly note

Wheel hub assembly


Remove the wheel hub assembly by using the **SST**.

**Wheel bearing**


1. Remove the wheel bearing by using the **SST**.



2. Move the bearing inner race away from the wheel hub assembly by using a chisel.




3. Press the bearing inner race off the wheel hub by using the **SST**.


**Dust cover****Note**

- The dust cover does not need to be removed unless you are replacing it.

1. Mark the dust cover and knuckle spindle for proper reassembly.




2. Remove the dust cover by using a chisel.


**Hub bolt****Note**

- The hub bolts do not need to be removed unless you are replacing them.


Remove the hub bolts by using a press.

**Assembly note****Hub bolt**


Press in new hub bolts.

**Dust cover**


1. Mark the new dust cover as the one removed.




2. Align the marks of the new dust cover and the knuckle.
3. Install the new dust cover by using the **SST**.

**Wheel bearing**


Install the new wheel bearing by using the **SST**.

**Outer oil seal**

Install the new outer oil seal by using the **SST**.

**Wheel hub assembly**













Install the wheel hub assembly by using the **SST**.

**Inner oil seal**

Install the new inner oil seal by using the **SST**.

REAR AXLE


PREPARATION SST

<p>49 0223 630B</p> <p>Puller, rear axle shaft</p> 	<p>For removal / installation of dust cover and rear axle shaft assembly</p>	<p>49 8501 631A</p> <p>Attachment, rear axle shaft puller</p> 	<p>For removal / installation of dust cover and rear axle shaft assembly</p>
<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For removal / installation of brake pipe</p>	<p>49 S026 201</p> <p>Installer, bearing collar</p> 	<p>For assembly of bearing, ABS sensor rotor, and bearing collar</p>
<p>49 G030 797</p> <p>Handle (Part of 49 B025 0A0)</p> 	<p>For installation of oil seal</p>	<p>49 F027 0A1</p> <p>Installer set, bearing</p> 	<p>For installation of oil seal</p>
<p>49 F027 005</p> <p>Attachment, for bearing $\phi 62$ (Part of 49 F027 0A1)</p> 	<p>For installation of oil seal (ABS)</p>	<p>49 S026 001</p> <p>Installer</p> 	<p>For installation of oil seal (non ABS)</p>
<p>49 S121 520A</p> <p>Puller, rear axle shaft bearing</p> 	<p>For disassembly of bearing</p>	<p>49 S120 521</p> <p>Plate (Part of 49 S121 520A)</p> 	<p>For disassembly of bearing</p>
<p>49 S120 522</p> <p>Rod (Part of 49 S121 520A)</p> 	<p>For disassembly of bearing</p>	<p>49 S026 202</p> <p>Attachment (Part of 49 S121 520A)</p> 	<p>For disassembly of bearing</p>


REAR AXLE SHAFT

Inspection / Removal / Installation

1. Inspect the wheel bearing play, referring to **Inspection**.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Brake caliper assembly
Service section P 2. Disc plate
Inspection section P 3. Hold pin 4. Parking brake shoe assembly
Service section P 5. Parking brake cable
Service section P | <ol style="list-style-type: none"> 6. Brake pipe
Removal Note page M-20
Installation Note page M-21 7. Dust cover and rear axle shaft assembly
Removal Note page M-20
Installation Note page M-20 8. Oil seal
Installation Note page M-20 |
|--|--|



**Inspection
Wheel bearing play**

Position a dial indicator against the axle shaft. Push and pull the axle shaft by hand in the axial direction and measure the wheel bearing play. If the play exceeds the specification, replace the wheel bearing.


Maximum wheel bearing play: 0.57 mm { 0.0224 in }



Removal note


Brake pipe

Disconnect the brake pipe by using the **SST**, and then plug it.



Dust cover and rear axle shaft assembly


Remove the dust cover and rear axle shaft assembly by using the **SST**.



Installation note


Oil seal

Apply grease to a new oil seal lip, and install it by using the **SST**.



Dust cover and rear axle shaft assembly

Install the dust cover and rear axle shaft assembly by using the **SST**.




Brake pipe

1. Tighten the brake pipe by using the SST.
2. Bleed the brake system. (Refer to section P.)

Tightening torque: 12.8—21.5 N·m
 { 130—220 kgf·cm , 113—190 in·lbf }


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Retaining ring
2. Bearing collar
 Disassembly Note below
 Assembly Note page M-23
3. ABS sensor rotor (ABS)
 Assembly Note page M-23
4. Bearing
 Disassembly Note page M-22
 Inspect for damage and rough rotation
 Assembly Note page M-23


5. Backing plate
6. Rear axle shaft
 Inspect the splines for damage or wear
 Inspection page M-22
7. Hub bolt
 Disassembly Note page M-22
 Assembly Note page M-22




Disassembly note

Bearing collar

1. Grind a section of the bearing collar until about **0.5 mm** { **0.0197 in** } remains. Be careful not to grind the backing plate and the rear axle shaft.




2. Being careful not to dent or scratch the rear axle shaft, hit the grinded section of the bearing collar with a chisel.
3. Remove the bearing collar.



Bearing

Remove the bearing by using the SST.




Hub bolt

Note

- The hub bolts do not need to be removed unless you are replacing them.

Remove the hub bolts by using a press if necessary.




Inspection

Rear axle shaft

Measure the shaft runout by using a dial indicator. If runout exceeds the specification, replace the axle shaft.


Maximum runout: 1.5 mm { 0.059 in }



Assembly note


Hub bolt

Install the new hub bolts by using a press.




Bearing

Using the **SST** and a press, install a new bearing with the smooth side facing the wheel.



ABS sensor rotor (ABS)

Using a press, install a new ABS sensor rotor until it contacts the **SST**.





Bearing collar

1. Remove any grease or oil from the rear axle shaft and new bearing collar.
2. Install the bearing collar onto the rear axle shaft by using the **SST**. If **26,478 N { 2,700 kgf , 5,940 lbf }** or less is required to press the collar, replace the shaft.

DRIVE SHAFT (4WD)

PREPARATION


SST

<p>49 0180 321A</p> <p>Installer, main drive gear bearing</p> 	<p>For assembly of drive shaft</p>	<p>49 G025 001</p> <p>Installer, sensor rotor</p> 	<p>For installation of sensor rotor</p>
---	------------------------------------	--	---


DRIVE SHAFT (DOUBLE OFFSET JOINT)

Inspection / Removal / Installation

1. Drain the differential gear oil.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Locknut
Installation Note page M-25 3. Tie-rod end
Service section N 4. Ball joint bolt and nut 5. Front axle
Disassembly / Inspection /
Assembly page M- 8 | <ol style="list-style-type: none"> 6. Engine undercover 7. Left drive shaft
Inspect splines for damage or wear
Inspect drive shaft for cracks
Removal Note page M-25
Overhaul page M-26 8. Right drive shaft
Inspect splines for damage or wear
Inspect drive shaft for cracks
Removal Note page M-25
Overhaul page M-26 |
|--|---|



Inspection Drive shaft

Check the boots on the drive shaft for cracks, damage, grease leakage, or loose boot bands. Replace if necessary.




Removal note Left drive shaft, Right drive shaft

Separate the drive shaft from the differential by prying with a bar inserted between the outer ring and the differential.

Note

- If the drive shaft will not come out of the wheel hub easily, install a discarded nut onto the drive shaft so that the nut is flush with the end of the drive shaft, and tap the nut with a copper hammer.



Installation note

Locknut

Install a new locknut and stake it as shown.

Tightening torque:


236—313 N·m { 24—32 kgf·m , 174—231 ft·lbf }

Overhaul

Caution

- Secure the joint in a vise with protective material (such as copper plates) on the vise jaws.
- Be careful that dust or other foreign material does not enter the joint while the work is being performed.
- Do not disassemble the wheel side ball joint.
- Do not wash the joint unless it is being disassembled.


1. Disassemble in the order shown in the figure, referring to **Disassembly Procedure**.
2. Inspect all parts and repair or replace as necessary.
3. Verify that all parts are free of dust, dirt, and other foreign material immediately before reassembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



1. Boot band
2. Boot band
3. Clip
4. Outer ring
5. Ball
6. Snap ring
7. Cage
8. Inner ring


9. Boot
10. Boot band
11. Boot band
12. Boot
13. ABS sensor rotor
14. Shaft and ball joint assembly
15. Dust cover

Inspection page M-28




Disassembly procedure


1. Pry up the locking clip of the differential side boot by using a screwdriver.
2. Remove both bands by using pliers.
3. Slide the boot along the shaft to expose the joint.




4. Mark the outer ring and the cage for proper reassembly.
5. Remove the clip by using a screwdriver.




6. Remove the balls.
7. Mark the shaft, cage, and inner ring for proper reassembly.
8. Remove the snap ring by using snap-ring pliers.




9. Turn the cage about **30 degrees**. Separate it from the inner ring.



10. Remove the inner ring by using a press.




11. Wrap the splines of the shaft with tape to prevent damaging the boot. Remove the boot and small boot band.

**Note**

- The wheel-side boot does not need to be removed unless you are replacing it.


12. Pry up the locking clips of the wheel side boot by using a screwdriver.

13. Remove both bands by using pliers. Remove the boot.


**Note**

- The sensor rotor does not need to be removed unless you are replacing it.

14. Tap the ABS sensor rotor off of the drive shaft by using a chisel.




15. If necessary, remove the dust cover by using a plastic hammer.


**Inspection**

Check for the following and replace parts as necessary.


1. Bending, twisting, or other damage of the shaft.
2. Wear on the shaft splines.
3. Wear, excessive play, corrosion, or other damage to the joint on the differential side.
4. Excessive play, wear, corrosion, or other damage to the joint on the wheel side.

**Assembly procedure**


1. Install a new dust cover by using a plastic hammer, if it was removed.




- Set a new ABS sensor rotor on the drive shaft in the direction shown, and press it onto the shaft assembly by using the **SST**.




- Wrap the shaft splines with tape.




- Install the wheel-side and differential-side boots, noting the shape and size of each one as in the figure.



- Install the cage with the larger diameter facing the differential.
- Align the marks, and install the inner ring on the shaft by using the **SST**.




- Align the marks and install the balls to the inner ring.
- Install the cage, inner ring, and ball assembly to the drive shaft in the direction shown in the figure.
- Fit a new snap ring into the ring groove in the shaft.




10. Install the cage on the inner ring, and turn the cage about **30 degrees** with respect to the inner ring.
11. Fit the balls through the cage into the ball grooves of the inner ring.
12. Apply the specified grease to the cage, inner ring, and balls.

Specified grease: Type joint grease (yellow)



13. Align the marks, and install the outer ring on the shaft.
14. Install a new clip onto the outer ring.




15. Fill the differential-side boot with the greases supplied in the boot kit.
If the wheel-side boot was removed, apply specified grease to it also.

Grease amount

Differential-side: $105 \pm 10 \text{ g}$ { $3.71 \pm 0.35 \text{ oz}$ }

Wheel-side: $100 \pm 10 \text{ g}$ { $3.53 \pm 0.35 \text{ oz}$ }




16. Install the boot.
17. Carefully lift up the small end of the boot to release any trapped air.
18. Verify that the boot is not dented or twisted.

Standard length

Right side: 566.5 mm { 22.30 in }

















Left side: 498.5 mm { 19.63 in }



















19. Install the bands in the direction shown in the figure.
20. Fold the bands back, and lock them by bending the locking clips over the band tips.



FRONT DIFFERENTIAL AND AUTOMATIC FREEWHEEL (AFW) MECHANISM (4WD)

**PREPARATION
SST**


<p>49 S120 710</p> <p>Holder, coupling flange</p> 	<p>For disassembly / assembly of companion flange</p>	<p>49 0839 425C</p> <p>Puller set, bearing</p> 	<p>For disassembly of companion flange and side bearing</p>
<p>49 U027 003</p> <p>Installer, oil seal</p> 	<p>For assembly of oil seal</p>	<p>49 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>
<p>49 G030 796</p> <p>Body (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>	<p>49 0710 520</p> <p>Puller, bearing</p> 	<p>For disassembly of hub</p>
<p>49 U027 004</p> <p>Remover, oil seal</p> 	<p>For disassembly of oil seal</p>	<p>49 W027 0A0</p> <p>Installer set, oil seal</p> 	<p>For disassembly of bearing</p>
<p>49 W027 001</p> <p>Body (Part of 49 W027 0A0)</p> 	<p>For disassembly of bearing</p>	<p>49 U027 006</p> <p>Installer, bearing & oil seal</p> 	<p>For assembly of oil seal, ball bearing, joint shaft, and bearing</p>
<p>49 U027 005</p> <p>Installer, bearing</p> 	<p>For assembly of bearing, joint shaft, and hub</p>	<p>49 M005 795</p> <p>Installer set, oil seal</p> 	<p>For assembly of dust seal</p>
<p>49 M005 796</p> <p>Body (Part of 49 M005 795)</p> 	<p>For assembly of dust seal</p>	<p>49 U027 007</p> <p>Installer, oil seal</p> 	<p>For assembly of oil seal</p>
<p>49 0813 215A</p> <p>Puller, tubular dowel</p> 	<p>For disassembly of output shaft</p>	<p>49 M005 561</p> <p>Hanger, differential carrier</p> 	<p>For disassembly / assembly of differential assembly</p>

<p>49 0107 680A Engine stand</p>		<p>For disassembly / assembly of differential assembly</p>	<p>49 H027 002 Remover, bearing</p>		<p>for disassembly of rear bearing</p>
<p>49 F027 0A1 Installer set, bearing</p>		<p>For assembly of front bearing race, rear bearing race, and oil seal</p>	<p>49 F027 003 Handle (Part of 49 F027 0A1)</p>		<p>For assembly of front bearing race, rear bearing race, and oil seal</p>
<p>49 F027 005 Attachment φ62 (Part of 49 F027 0A1)</p>		<p>For assembly of front bearing race</p>	<p>49 F027 007 Attachment φ72 (Part of 49 F027 0A1)</p>		<p>For assembly of rear bearing race</p>
<p>49 0720 570 Gauge body, pinion height</p>		<p>For adjustment of drive pinion height</p>	<p>49 8531 565 Pinion model</p>		<p>For adjustment of drive pinion height</p>
<p>49 H027 001 Collar</p>		<p>For adjustment of drive pinion height</p>	<p>49 U027 001 Collar</p>		<p>For adjustment of drive pinion height</p>
<p>49 0305 555 Gauge block</p>		<p>For adjustment of drive pinion height</p>	<p>49 F401 330B Installer set, bearing</p>		<p>For assembly of rear bearing and side bearing</p>
<p>49 F401 331 Body (Part of 49 F401 330B)</p>		<p>For assembly of rear bearing and side bearing</p>	<p>49 F401 337A Attachment C (Part of 49 F401 330B)</p>		<p>For assembly of rear bearing</p>
<p>49 G030 338 Attachment E</p>		<p>For assembly of side bearing</p>	<p>49 0259 720 Adjustment wrench, side bearing</p>		<p>For adjustment of backlash</p>

VACUUM HOSE ROUTING DIAGRAM

**AFW SWITCH****Inspection**


1. Disconnect the negative battery cable.
2. Jack up the vehicle and support it on safety stands.
3. Disconnect the AFW switch connector and remove the switch.



4. Check for continuity at the switch by using an ohmmeter.

Switch	Continuity
Depressed	Yes
Released	No


5. If not as specified, replace the switch.



ONE-WAY CHECK VALVE

Inspection


1. Remove the one-way check valve.
2. Blow through (A) and verify that air flows from (B).
3. Blow through (B) and verify that air does not flow from (A).
4. If not as specified, replace the one-way check valve.




SOLENOID VALVE

Inspection


1. Disconnect the vacuum hoses and the connector from each solenoid valve.




2. Blow through each valve from port (B).
3. Verify that air flows from the air filter.




4. Connect 12 V and a ground to the terminals of each valve.
5. Blow through each valve from port (B).
6. Verify that air flows from port (A).
7. If not as specified, replace the solenoid valve(s).

**ACTUATOR****Inspection**

1. Jack up the vehicle and support it on safety stands.
2. Disconnect the vacuum hoses from the actuator.




3. Connect a vacuum pump tester to the actuator (free side) as shown.
4. Apply 26.66 kPa { 200 mmHg , 7.87 inHg } vacuum, and verify that the rod moves inward.
5. Disconnect the vacuum pump.




6. Connect the vacuum pump to the actuator (lock side) as shown.
7. Apply 26.66 kPa { 200 mmHg , 7.87 inHg } vacuum, and verify that the rod moves outward.
8. If not as specified, replace the actuator.

Tightening torque:

16—22 N·m { 1.6—2.3 kgf·m , 12—16 ft·lbf }

**VACUUM RESERVOIR****Inspection**


1. Disconnect the vacuum hoses.
2. Plug one hose fitting of the reservoir.
3. Connect a vacuum pump tester to the other fitting.
4. Apply 93.33 kPa { 700 mmHg , 27.56 inHg } vacuum, and verify that the vacuum is held.
5. If not as specified, replace the vacuum reservoir.

**DIFFERENTIAL OIL****Inspection**

1. Remove the filler plug and washer.
2. Verify that the oil is up to the brim of the filler plug hole, as shown.
If it is low, add the specified oil.
3. Install the filler plug and a new washer.

Tightening torque:

40—53 N·m { 4.0—5.5 kgf·m , 29—39 ft·lbf }

**Replacement**

1. Remove the drain plug, filler plug, and washers.
2. Drain the oil into a suitable container.
3. Wipe the plugs clean.
4. Install the drain plug and a new washer.

Tightening torque:

40—53 N·m { 4.0—5.5 kgf·m , 29—39 ft·lbf }

5. Add the specified oil through the filler plug hole until the level reaches the brim of the hole.

Specified oil**Type**

Above -18°C { 0°F } : API GL-5, SAE 90



Below -18°C { 0°F } : API GL-5, SAE 80W

Capacity: 1.7 L { 1.8 US qt , 1.5 Imp qt }


6. Install the filler plug and a new washer.

Tightening torque:


40—53 N·m { 4.0—5.5 kgf·m , 29—39 ft·lbf }

**OIL SEAL****Replacement of Companion Flange Oil Seal**


1. Jack up the vehicle and support it on safety stands.
2. Drain the differential oil. (Refer above.)




3. Remove the propeller shaft. (Refer to section L.)
4. Before loosening the locknut, measure the rotation starting torque of the drive pinion (within the range of the drive pinion and ring gear backlash).




5. Hold the companion flange by using the **SST**, and remove the locknut.




6. Remove the companion flange by using the **SST**.
7. Remove the oil seal.



8. Apply a thin coat of lithium-based grease to the lip of a new oil seal, and install it by using the **SST**.



9. Install the companion flange and tighten the locknut to get the starting torque measured in step 4.
10. Install the propeller shaft. (Refer to section L.)
11. Add differential oil to the specified level. (Refer to page M-35.)




Replacement of Differential Oil Seal (right side)

1. Jack up the vehicle and support it on safety stands.
2. Drain the differential gear oil. (Refer to page M-35.)
3. Disconnect the front axle drive shaft. (Refer to page M-24.)
4. Remove the oil seal from the differential.
5. Tap the new oil seal into the differential by using the **SST**.
6. Install the front axle drive shaft. (Refer to page M-24.)
7. Add differential oil to the specified level. (Refer to page M-35.)

FRONT DIFFERENTIAL AND AUTOMATIC FREEWHEEL UNIT

Removal / Installation


1. Drain the differential gear oil. (Refer to page M-35.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the front wheel alignment and adjust it if necessary. (Refer to section R.)




1. Wheel and tire
2. Tie-rod end
Service section N
3. Lower arm
4. Engine undercover
5. Left drive shaft and axle
Removal Note page M-39
6. Right drive shaft and axle
Removal Note page M-39
7. Front propeller shaft
Removal Note page M-39
Installation Note page M-40
Service section L

8. Connector and vacuum hoses
9. Front differential and AFW assembly
Removal Note page M-39
Installation Note page M-39
10. Automatic freewheel unit
Disassembly / Inspection /
Assembly page M-41
11. Front differential
Overhaul page M-47


N-m { kgf-m , ft-lbf }

**Removal note****Drive shaft and axle**


Separate the drive shafts from the differential by prying with a bar inserted between the outer ring and the differential. Suspend the drive shafts by using a rope after removal.

**Front propeller shaft**


Before removing the front propeller shaft, mark the flanges for proper reassembly.

**Front differential and AFW assembly**

1. Support the differential on a transmission jack.
2. Remove the bolts and nuts indicated by the arrows.




3. Remove the front differential and AFW assembly.

**Installation note****Front differential and AFW assembly**

1. Set the differential on a transmission jack.
2. Install the front differential and AFW assembly.

Tightening torque:

67—97 N·m { 6.8—9.9 kgf·m , 50—71 ft·lbf }

**Front propeller shaft**

Align the marks and install the front propeller shaft.


Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }


AUTOMATIC FREEWHEEL UNIT

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Control box assembly
Overhaul page M-45 2. Hub sleeve 3. Clip 4. Hub
Disassembly Note page M-42
Inspect for damage, wear, or cracks 5. Spacer 6. Retaining ring 7. Ball bearing
Disassembly Note page M-42
Inspect for damage or rough rotation | <ol style="list-style-type: none"> 8. Adjustment shim(s) 9. Dust seal 10. Bearing
Disassembly Note page M-42
Inspect for damage or rough rotation 11. Oil seal
Disassembly Note page M-43 12. Joint shaft
Inspection page M-43 13. Needle bearing
Inspect for damage or rough rotation 14. Clip 15. Output shaft and gear sleeve |
|--|--|

**Disassembly note****Hub**


Remove the hub by using the **SST**.

**Ball bearing**


1. Remove the ball bearing and the joint shaft by using a press.




2. Remove the ball bearing by using a press.

**Bearing**


1. Remove the dust seal and bearing by using the **SST**.



2. Remove the bearing by using a press.


**Oil seal**

Remove the oil seal by using the **SST**.


**Inspection****Joint shaft**

Measure the joint shaft runout.


Maximum runout: 0.03 mm { 0.0012 in }

**Assembly procedure**

1. Apply front differential oil to the new oil seal.
2. Install the oil seal by using the **SST**.



3. Set the removed shim(s) into the housing and install the ball bearing by using the **SST**.
4. Install the retaining ring.




5. Measure the clearance between the ball bearing and the retaining ring.

If not as specified, adjust by adding or removing shims. Use no more than two shims on either side.


Maximum clearance: 0.15 mm { 0.0059 in }

Available shim thickness:

0.15 mm { 0.0059 in }, 0.30 mm { 0.0118 in },
 0.35 mm { 0.0138 in }, 0.40 mm { 0.0157 in },
 0.50 mm { 0.0197 in }




6. Install the bearing by using the **SST**.



7. Remove the retaining ring.


8. Using the **SST**, install the joint shaft and bearing, with the seal facing upward.

9. Install the retaining ring.



10. Install the spacer removed during disassembly and the hub by using a suitable pipe and the **SST**.

11. Install a new clip.




12. Measure the clearance between the hub and the new clip.

If not as specified, adjust by adding or removing spacers. Use no more than two spacers on either side.

Maximum clearance: 0.15 mm { 0.0059 in }

Available spacer thickness:

0.15 mm { 0.0059 in }, 0.30 mm { 0.0118 in },
0.35 mm { 0.0138 in }, 0.40 mm { 0.0157 in },
0.50 mm { 0.0197 in }



13. Install a new dust seal by using the **SST**.


14. Apply front differential oil to the needle bearing and install it.

15. Install a new clip onto the joint shaft.

CONTROL BOX ASSEMBLY


Overhaul

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Actuator	
Inspection	page M-35
2. Automatic freewheel (AFW) switch	
Inspection	page M-33
3. Spring cap	
4. Spring and ball	
5. Change rod	
Disassembly Note	page M-46
Assembly Note	page M-46

6. Shift fork	
Inspection	page M-46
7. Boot	
Assembly Note	page M-46
8. Oil seal	
Assembly Note	page M-46
9. Control box	

**Disassembly note****Change rod**

Remove the roll pin as shown in the figure.


**Inspection****Shift fork**

Measure the clearance between the gear sleeve and shift fork.


Standard clearance:

0.1—0.40 mm { 0.0040—0.0157 in }


Maximum clearance: 0.50 mm { 0.0197 in }

**Assembly note****Oil seal**

Install a new oil seal by using the SST.

**Boot**

Install the boot as shown in the figure.


**Change rod**

Install a new roll pin as shown in the figure.


FRONT DIFFERENTIAL

Overhaul


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Output shaft
Disassembly Note page M-48
Inspect for damage, wear, or cracks 2. Front axle casing 3. Oil seal
Installation Note page M-55 4. Differential assembly
Disassembly Note page M-48 5. Bolt 6. Lock plate 7. Bearing cap 8. Adjusting screw 9. Bearing race 10. Locknut 11. Washer 12. Companion flange
Disassembly Note page M-48
Inspect splines for wear or damage 13. Oil seal 14. Washer 15. Front bearing
Inspect for damage or rough rotation 16. Collapsible spacer 17. Bearing race
Disassembly Note page M-49 18. Differential carrier
Inspect for cracks 19. Bearing race | <ol style="list-style-type: none"> 20. Rear bearing
Disassembly Note page M-49
Inspect for damage or rough rotation 21. Spacer 22. Drive pinion
Disassembly Note page M-48
Inspect for wear or damage
Adjustment of height page M-50
Adjustment of preload page M-52 23. Ring gear
Inspect for wear or damage
Inspection and adjustment of tooth
contact page M-54 24. Knock pin
Disassembly Note page M-49 25. Pinion shaft 26. Pinion gear
Adjustment of backlash page M-53 27. Side gear
Adjustment of backlash page M-53 28. Thrust washer 29. Side bearing
Disassembly Note page M-49
Inspect for damage or rough rotation 30. Gear case 31. Final gear set 32. Air bleeder
Inspect for clogging |
|--|--|

**Disassembly Note****Output shaft**


Remove the output shaft by using the SST.

**Differential assembly**


1. Mount the differential assembly on the SST.
2. Mark one bearing cap and the carrier.
3. Mark the bearing adjusters for the right and left side.

**Companion flange**


1. Hold the companion flange by using the SST and remove the locknut.




2. Remove the companion flange by using the SST.

**Drive pinion**


Push the drive pinion out by attaching a miscellaneous locknut to it, and tapping it with a copper hammer.

**Bearing race**


Mark the bearing races for proper reassembly, and remove them by alternately tapping through the two grooves in the carrier.

**Rear bearing**


While supporting the drive pinion, remove the rear bearing by using the **SST**.

**Knock pin**

Secure the gear case in a vise and remove the knock pin.


**Side bearing**

Mark the bearings for proper reassembly, and remove them by using the **SST**.




Assembly procedure Adjustment of pinion height


1. Install the front bearing race by using the **SST**.




2. Install the rear bearing race by using the **SST**.




3. Adjust the drive pinion height as follows by using the **SST**.




a) Slide the spacer and bearing onto the **SST**.




- b) Assemble the spacer, rear bearing, and **SST**. Secure the **SST** with the O-ring. Install the assembly in the carrier.
- c) Install the front bearing, **SST**, companion flange, washer, and nut.
- d) Tighten the nut to the extent that the companion flange can still be turned by hand.



- e) Place the **SST** on a surface plate and set the dial indicator to zero.



- f) Place the **SST** atop the drive pinion model. Set the gauge body atop the gauge block.
- g) Place the feeler of the dial indicator so that it contacts where the side bearing is installed in the carrier. Measure the lowest position on the left and right sides of the carrier.



- h) Add the two (left and right) values obtained by the measurements taken in step (g), and then divide the total by 2. From this result, subtract the result obtained by dividing the number inscribed on the end surface of the drive pinion by 100. (If there is no figure inscribed, use 0.) This is the pinion height adjustment value.

Caution


1. The number is inscribed by an electric marking pen.
2. If, for example, the measured results obtained in step (g) are 0.06 mm and 0.04 mm, and the figure inscribed on the end of the drive pinion is -2.:

Mark	Thickness	Mark	Thickness
08	3.08 mm { 0.1213 in }	29	3.29 mm { 0.1295 in }
11	3.11 mm { 0.1224 in }	32	3.32 mm { 0.1307 in }
14	3.14 mm { 0.1236 in }	35	3.35 mm { 0.1319 in }
17	3.17 mm { 0.1248 in }	38	3.38 mm { 0.1331 in }
20	3.20 mm { 0.1260 in }	41	3.41 mm { 0.1343 in }
23	3.23 mm { 0.1271 in }	44	3.44 mm { 0.1354 in }
26	3.26 mm { 0.1283 in }	47	3.47 mm { 0.1366 in }

$$\frac{0.06 + 0.04}{2} - \frac{-2}{100} = 0.07 = \text{pinion height adjustment value}$$


Thus, a spacer which is 0.07 mm thicker than the one now used should be used.

3. Select the spacer thickness that is closest to that necessary.




Adjustment of drive pinion preload

1. Install the spacer, selected in the procedure above, with the beveled side facing the drive pinion.
2. Using the SST, press the rear bearing onto the drive pinion until the force required starts to increase sharply.




3. Apply a light coat of grease to the end face of the companion flange.



4. Install a new collapsible spacer.
5. Install the drive pinion assembly.
6. Install the companion flange without installing the oil seal, and tighten the locknut.

Tightening torque: 128 N·m { 13.0 kgf·m , 94 ft·lbf }




7. Turn the companion flange by hand to seat the bearing.
8. Measure the drive pinion preload. Adjust the preload by tightening the locknut and record the tightening torque.


Preload:

0.9—1.3 N·m { 9—14 kgf·cm , 7.9—12.1 in·lbf }

**Tightening torque: 128—284 N·m
{ 13.0—29.0 kgf·m , 95—209 ft·lbf }**



9. Remove the nut, washer, and companion flange.
10. Tap a new oil seal into the differential carrier by using the **SST**.
11. Install the companion flange and washer, and tighten the locknut to the tightening torque stated in step 8.




Adjustment of backlash

1. Adjust the backlash of the side gears and pinion gear as follows.
 - (1) Set a dial gauge against the pinion gear as shown.
 - (2) Secure one of the side gears.
 - (3) Move the pinion gear and measure the backlash at the end of it.

Standard backlash: 0—0.1 mm { 0—0.0039 in }

- (4) If the backlash exceeds the standard, use the selectable thrust washers for adjustment.




2. Install a new knock pin to secure the pinion shaft. Stake the pin by using a punch to prevent it from coming out of the case.


3. Install the ring gear onto the gear case.


Tightening torque:

69—83 N·m { 7.0—8.5 kgf·m , 51—61 ft·lbf }




4. Press the bearing (side gear) on by using the **SST**.







5. Install the differential gear assembly in the carrier.
6. Note the identification mark on the bearing adjusters, and install them to their respective side.
7. Install the differential bearing caps, making sure that the identification mark on the marked cap corresponds with the one on the carrier.



8. Mark the ring gear at four points at **approx. 90°** intervals. Mount a dial indicator to the carrier so that the feeler comes into contact at right angle with one of the ring gear teeth.
9. Turn both bearing adjusters equally with the **SST** until the backlash is **0.09—0.11 mm { 0.0036—0.0043 in }**.




10. Check the backlash at the three other marked points, and verify that the minimum backlash is more than **0.05 mm { 0.002 in }** and the difference between the maximum and minimum is less than **0.07 mm { 0.0028 in }**.



11. Tighten the adjusters equally until the distance between the pilot sections on the bearing caps is as specified. Make sure that the backlash of the drive pinion and ring gear does not become misadjusted.


Specified distance:

184.78—185.50 mm { 7.275—7.303 in }




Inspection and adjustment of teeth contact


1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, adjust the pinion height and readjust the backlash.



- (1) Toe and flank contact
Replace the spacer with a thinner one to move the drive pinion outward.



- (2) Heel and face contact
Replace the spacer with a thicker one to bring the drive pinion inward.



















Installation note









Oil seal


Tap the new oil seal into the axle casing by using the SST.

REAR DIFFERENTIAL

PREPARATION SST

49 0107 680A Engine stand 	For disassembly / assembly of differential assembly	49 M005 561 Hanger, diff. carrier 	For disassembly / assembly of differential assembly
49 S120 710 Holder, coupling, flange 	For disassembly / assembly of companion flange	49 0839 425C Puller set, bearing 	For disassembly of companion flange and side bearing
49 H027 002 Remover, bearing 	For disassembly of rear bearing	49 8531 565 Pinion model 	For adjustment of pinion height
49 H027 001 Collar 	For adjustment of pinion height	49 U027 001 Collar 	For adjustment of pinion height
49 F027 0A0 Gauge set, pinion height adjust 	For adjustment of pinion height	49 0660 555 Gauge block (Part of 49 F027 0A0) 	For adjustment of pinion height
49 0727 570 Gauge body, pinion height (Part of 49 F027 0A0) 	For adjustment of pinion height	49 F027 0A1 Installer set, bearing 	For assembly of front bearing race and rear bearing race
49 F027 004 Attachment for bearing $\phi 80$ (Part of 49 F027 0A1) 	For assembly of rear bearing race	49 F027 007 Attachment for bearing $\phi 72$ (Part of 49 F027 0A1) 	For assembly of front bearing race
49 G030 338 Attachment E 	For assembly of rear bearing	49 F401 331 Body 	For assembly of rear bearing

<p>49 UB71 525</p> <p>Installer, bearing</p> 	<p>For assembly of side bearing</p>	<p>49 0259 720</p> <p>Adjustment wrench, side bearing</p> 	<p>For adjustment of backlash</p>
<p>49 V001 795</p> <p>Installer, oil seal</p> 	<p>For assembly of oil seal</p>	<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For removal / installation of brake pipe</p>
<p>49 8501 631A</p> <p>Attachment, rear axle shaft puller</p> 	<p>For removal of dust cover and rear axle shaft assembly</p>	<p>49 0223 630B</p> <p>Puller, rear axle shaft</p> 	<p>For removal of dust cover and rear axle shaft assembly</p>
<p>49 M005 795</p> <p>Installer set, oil seal</p> 	<p>For assembly of front bearing race and rear bearing race</p>	<p>49 M005 797</p> <p>Handle (Part of 49 M005 795)</p> 	<p>For assembly of front bearing race and rear bearing race</p>




DIFFERENTIAL OIL

Inspection

1. Remove the filler plug and washer.
2. Verify that the oil is up to the brim of the filler plug hole, as shown.
If it is low, add the specified oil.
3. Install the filler plug and a new washer.

Tightening torque:

40—53 N·m { 4.0—5.5 kgf·m , 29—39 ft·lbf }




Replacement

1. Remove the plugs.
2. Drain the oil into a container.
3. Wipe the plugs clean.
4. Install the drain plug and a new washer.

Tightening torque:

40—53 N·m { 4.0—5.5 kgf·m , 29—39 ft·lbf }



5. Add the specified oil from filler plug until the level reaches the brim of the plug hole.

Specified oil

Type

Above -18°C { 0°F }: GL-5, SAE 90

Below -18°C { 0°F }: GL-5, SAE 80 W

Capacity: 1.5 L { 1.6 US qt , 1.3 Imp qt }

6. Install the filler plug and a new washer.





Tightening torque:


40—53 N·m { 4.0—5.5 kgf·m , 29—39 ft·lbf }

OIL SEAL

Replacement

1. Jack up the vehicle and support it on safety stands.
2. Drain the differential gear oil.
3. Remove the propeller shaft. (Refer to section L.)
4. Before loosening the flange locknut, measure and record the rotation starting torque of the drive pinion (within range of the drive pinion and ring gear backlash).
5. Hold the companion flange by using the **SST** and remove the locknut.
6. Remove the companion flange by using the **SST**.
7. Remove the oil seal.
8. Apply lithium base grease to a new oil seal lip and install it by using the **SST**.






9. Tighten a new locknut using the **SST** to get the starting torque as stated in step 4.
10. Install the propeller shaft. (Refer to section L.)
11. Add the specified oil through the oil filler plug hole. (Refer to page M-57.)

DIFFERENTIAL (STANDARD)


Removal / Installation

When installing the differential, install it within 10 minutes after applying sealant. Allow the sealant to set at least 30 minutes after installation before filling the differential with the specified oil.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Brake caliper assembly
Service section P 2. Disc plate
Inspection section P 3. Parking brake shoes assembly
Service section P 4. Parking brake cable
Service section P 5. Brake pipe
Removal Note below
Installation Note page M-60 | <ol style="list-style-type: none"> 6. Dust cover and rear axle shaft assembly
Removal Note page M-61 7. Propeller shaft
Service section L 8. Rear-wheel ABS sensor
Service section P 9. Differential assembly
Installation Note page M-61 10. Air breather
Inspect for clogging 11. Dynamic damper |
|--|--|



Removal note


Brake pipe

Disconnect the brake pipe by using the **SST**, and then plug it.



Dust cover and rear axle shaft assembly

Remove the dust cover and rear axle shaft assembly by using the **SST**.




Installation note

Differential assembly

1. Apply sealant to the stud threads and carrier and housing faces.
2. Tighten the nuts and bolts.

Tightening torque:

23—26 N·m { 2.3—2.7 kgf·m , 17—19 ft·lbf }



Brake pipe


1. Tighten the brake pipe by using the **SST**.
2. Bleed the brake system. (Refer to section P.)

Tightening torque: 12.8—21.5 N·m


{ 130—220 kgf·cm , 113—190 in·lbf }

Overhaul

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts, repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|--|--|
| 1. Differential assembly
Disassembly Note page M-63 | 17. Rear bearing
Disassembly Note page M-64
Inspect for damage or rough rotation |
| 2. Bolt | 18. Bearing race
Disassembly Note page M-63 |
| 3. Lock plate | 19. Collapsible spacer |
| 4. Bearing cup | 20. Differential carrier
Inspect for cracks |
| 5. Adjusting screw | 21. Ring gear
Inspect teeth for wear or damage
Inspection and adjustment of
teeth contact page M-69 |
| 6. Bearing race | 22. Knock pin
Disassembly Note page M-64 |
| 7. Differential gear assembly | 23. Pinion shaft |
| 8. Locknut | 24. Pinion gear
Adjustment of backlash page M-67 |
| 9. Washer | 25. Side gear
Adjustment of backlash page M-67 |
| 10. Companion flange
Disassembly Note page M-63
Inspect splines for wear or damage | 26. Thrust washer |
| 11. Oil seal | 27. Side bearing
Disassembly Note page M-64
Inspect for damage or rough rotation |
| 12. Washer | 28. Gear case |
| 13. Front bearing
Inspect for damage or rough rotation | 29. Final gear set |
| 14. Bearing race
Disassembly Note page M-63 | |
| 15. Drive pinion
Disassembly Note page M-63
Inspect splines and teeth for wear or
damage
Adjustment of pinion height ... page M-64
Adjustment of pinion preload . page M-66 | |
| 16. Spacer | |




Disassembly note
Differential assembly

1. Mount the differential assembly on the **SST**.
2. Make matching marks on one bearing cap and the carrier.




Companion flange

1. Hold the companion flange by using the **SST**, then remove the locknut.




2. Remove the companion flange by using the **SST**.




Drive pinion

Push the drive pinion out by attaching a miscellaneous locknut to it, then tapping it with a brass hammer.




Bearing race

Mark the bearing races for proper reassembly, and remove them by alternately tapping through the two grooves in the carrier.




Rear bearing

While supporting the drive pinion, remove the rear bearing by using the **SST**.




Knock pin

Secure the gear case in a vise and remove the knock pin.



Side bearing


Mark the bearings for proper reassembly, and remove them by using the **SST**.




Assembly Procedure

Adjustment of pinion height


1. Install the front bearing race by using the **SST**.




2. Install the rear bearing race by using the **SST**.




3. Adjust the drive pinion height as follows by using the **SST**.




a) Install the spacer and bearing to the **SST**.




b) Assemble the spacer, rear bearing, and **SST**.
Secure the **SST** with the O-ring. Install the assembly in the carrier.
c) Install the front bearing, **SST**, companion flange, washer, and nut.
d) Tighten the nut to the extent that the companion flange can still be turned by hand.



e) Place the **SST** on the surface plate and set the dial indicator to "Zero".



- f) Place the **SST** atop the drive pinion model, then set the gauge body atop the gauge block.
- g) Place the feeler of the dial indicator so that it contacts where the side bearing is installed in the carrier. Measure the lowest position on both the left and right sides.



- h) Add the two (left and right) values obtained by the measurements taken in step (g), and then divide the total by 2. From this result, subtract the result obtained by dividing the number inscribed on the end surface of the drive pinion by 100. (If there is no figure inscribed, use 0.) This is the pinion height adjustment value.

Caution

- 1. The number is inscribed by an electric marking pen.
- 2. If, for example, the measured results obtained in step (g) are 0.06 mm and 0.04 mm, and the figure inscribed on the end of the drive pinion is -2.:

$$\frac{0.06 + 0.04}{2} - \frac{-2}{100} = 0.07 = \text{pinion height adjustment value}$$


Thus, a spacer which is 0.07 mm thicker than the one now used should be used.

- 3. Select the spacer thickness that is closest to that necessary.


Mark	Thickness	Mark	Thickness
08	3.08 mm { 0.1213 in }	29	3.29 mm { 0.1295 in }
11	3.11 mm { 0.1224 in }	32	3.32 mm { 0.1307 in }
14	3.14 mm { 0.1236 in }	35	3.35 mm { 0.1319 in }
17	3.17 mm { 0.1248 in }	38	3.38 mm { 0.1331 in }
20	3.20 mm { 0.1260 in }	41	3.41 mm { 0.1343 in }
23	3.23 mm { 0.1271 in }	44	3.44 mm { 0.1354 in }
26	3.26 mm { 0.1283 in }	47	3.47 mm { 0.1366 in }


Adjustment of drive pinion preload

- 1. Install the spacer.
- 2. Using the **SST**, press the rear bearing onto the drive pinion until the force required starts to increase sharply.




- 3. Apply a light coat of grease to the end face of the companion flange.





4. Install the collapsible spacer.
5. Install the drive pinion assembly.
6. Install the companion flange without installing the oil seal, and tighten the locknut.

Tightening torque: 128 N·m { 13.0 kgf·m , 94 ft·lbf }



7. Turn the companion flange by hand to seat the bearing.
8. Measure the drive pinion preload.
Adjust the preload by tightening the locknut.


Preload:

1.3—1.7 N·m { 13—18 kgf·cm , 11.3—15.6 in·lbf }

Tightening torque:

128—284 N·m { 13—29 kgf·m , 95—209 ft·lbf }

If the specified preload cannot be obtained, replace the collapsible spacer with a new one and check again.



9. Remove the nut, washer, and companion flange.
10. Tap a new oil seal into the differential carrier by using the SST.
11. Install the companion flange and washer, and tighten the locknut to set the preload.


Preload:

1.6—2.0 N·m { 16—21 kgf·cm , 13.9—18.2 in·lbf }

Tightening torque:

128—284 N·m { 13.0—29.0 kgf·m , 95—209 ft·lbf }


Adjustment of backlash



1. Adjust the backlash of the side gears and pinion gear as follows.
 - (a) Set a dial gauge against the pinion gear as shown.
 - (b) Secure one of the side gears.
 - (c) Move the pinion gear and measure the backlash at the end of it.


Standard backlash: 0—0.1 mm { 0—0.0039 in }

- (d) If the backlash exceeds the standard, use the selectable thrust washers for adjustment.



2. Install a new knock-pin to secure the pinion shaft. Stake the knock-pin into position by using a punch to prevent it from coming out.


Identification mark	Washer thickness mm { in }
0	2.00 { 0.0787 }
05	2.05 { 0.0807 }
1	2.10 { 0.0827 }
15	2.15 { 0.0846 }
2	2.20 { 0.0866 }




3. Apply about **0.04 cm³ { 0.0024 cu in }** of threadlocking compound to each of the bolt threads (A) and points (B).
4. Install the ring gear onto the gear case.

Tightening torque:


69—83 N·m { 7.0—8.5 kgf·m , 51—61 ft·lbf }




5. Press the bearing on by using the **SST**.




6. Install the differential gear assembly in the carrier.
7. Note the identification marks on the adjusters, and install the adjusters to their respective sides.
8. Install the differential bearing caps, making sure that the identification marks on the cap corresponds with the one on the carrier.



9. Mark the ring gear at four points at approx. **90°** intervals. Mount a dial indicator to the carrier so that the feeler comes into contact at a right angle with one of the ring gear teeth.
10. Turn both bearing adjusters equally by using the **SST** until the backlash is **0.09—0.11 mm { 0.0036—0.0043 in }**.




11. Check the backlash at the three other marked points, and make sure the minimum backlash is above **0.05 mm { 0.002 in }** and the difference between the maximum and minimum is less than **0.07 mm { 0.0028 in }**.



12. Tighten the adjusters equally until the distance between the pilot sections on the bearing caps is as specified. Make sure that the backlash of the drive pinion and ring gear does not become misadjusted.


Specified distance:

203.78—204.50 mm { 8.023—8.051 in }




Inspection and adjustment of teeth contact

1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, adjust the pinion height, and then adjust the backlash.



- (1) Toe and flank contact
Replace the spacer with a thinner one to move the drive pinion outward.




- (2) Heel and face contact
Replace the spacer with a thicker one to bring the drive pinion inward.

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

STEERING SYSTEM

INDEX	N- 2
OUTLINE	N- 3
SPECIFICATIONS	N- 3
ENGINE SPEED SENSING POWER STEERING ..	N- 3
PREPARATION	N- 3
TROUBLESHOOTING GUIDE	N- 6
AIR BLEEDING	N- 7
BOOTS (2WD)	N- 8
BOOTS (4WD)	N-10
STEERING WHEEL AND COLUMN	N-12
STEERING GEAR AND LINKAGE (2WD)	N-18
STEERING GEAR AND LINKAGE (4WD)	N-30
OIL PUMP	N-32
DRIVE BELT	N-35
POWER STEERING FLUID	N-36

INDEX



- 1. Boots
 - Removal / Installation (2WD) .. page N- 8
 - Removal / Installation (4WD) .. page N-10
- 2. Steering wheel and column
 - On-vehicle inspection page N-12
 - Removal / Installation page N-13
 - Disassembly / Assembly /
Inspection page N-15

- 3. Steering gear and linkage
 - Removal / Inspection /
Installation (2WD) page N-18
 - Disassembly / Inspection (2WD) page N-20
 - Assembly (2WD) page N-23
 - Removal / Inspection /
Installation (4WD) page N-30
 - Disassembly / Inspection (4WD) page N-20
 - Assembly (4WD) page N-23
- 4. Oil pump
 - Removal / Installation page N-32
 - Disassembly / Inspection /
Assembly page N-34
- 5. Drive belt
 - On-vehicle inspection page N-35

OUTLINE









SPECIFICATIONS

















Item		Specification	
		2WD	4WD
Steering wheel	Outer diameter mm { in }	380 { 15.0 }	
	Lock-to-lock turns	3.9	3.6
Steering shaft and joint	Shaft type	Collapsible, tilt	
	Joint type	2-cross joint	
	Tilt stroke mm { in }	69 { 2.72 }	
Power steering system	Power assist type	Engine speed sensing	
	Gear type	Rack and pinion	
	Rack stroke mm { in }	136 { 5.35 }	
	Power steering fluid	ATF Dexron®II or M-III	
	Fluid capacity L { US qt , Imp qt }	0.9 { 0.95 , 0.79 }	





N

ENGINE SPEED SENSING POWER STEERING

PREPARATION

<p>49 1232 670A</p> <p>Gauge set, power steering</p> 	<p>For inspection of power steering pressure</p>	<p>49 1232 672</p> <p>Gauge (Part of 49 1232 670A)</p> 	<p>For inspection of power steering pressure</p>
<p>49 1232 673</p> <p>Valve body (Part of 49 1232 670A)</p> 	<p>For inspection of power steering pressure</p>	<p>49 H002 671</p> <p>Adapter, power steering gauge</p> 	<p>For inspection of power steering pressure</p>
<p>49 B032 302</p> <p>Adapter, power steering gauge</p> 	<p>For inspection of power steering pressure</p>	<p>49 H028 301</p> <p>Installer, boot</p> 	<p>For installation of tie rod end boot (2WD)</p>
<p>49 F034 201</p> <p>Installer, boot</p> 	<p>For installation of tie rod end boot (4WD)</p>	<p>49 G032 354</p> <p>Adjust wrench</p> 	<p>For removal and installation of oil pump</p>

<p>49 G032 3A0</p> <p>Repair set, power steering</p>		<p>For disassembly and assembly of steering gear</p>	<p>49 G032 302</p> <p>Attachment (Part of 49 G032 3A0)</p>		<p>For removal of oil seal and needle bearing</p>
<p>49 G032 303</p> <p>Handle (Part of 49 G032 3A0)</p>		<p>For removal of lower bearing, oil seal, and needle bearing</p>	<p>49 G032 308</p> <p>Installer, oil seal (Part of 49 G032 3A0)</p>		<p>For installation of oil seal</p>
<p>49 G032 309</p> <p>Protector, Pinion shaft (Part of 49 G032 3A0)</p>		<p>For installation of oil seal</p>	<p>49 D032 316</p> <p>Protractor (Part of 49 G032 3A0)</p>		<p>For installation of adjusting cover</p>
<p>49 H032 321A</p> <p>Hexagon wrench (Part of 49 G032 3A0)</p>		<p>For removal and installation of adjusting cover</p>	<p>49 G032 312</p> <p>Installer, bearing (Part of 49 G032 3A0)</p>		<p>For installation of needle bearing</p>
<p>49 G032 313</p> <p>Installer, oil seal (Part of 49 G032 3A0)</p>		<p>For installation of oil seal</p>	<p>49 G032 3A1</p> <p>Joint hose</p>		<p>For hermetic inspection</p>
<p>49 G032 317</p> <p>Hose (Part of 49 G032 3A1)</p>		<p>For hermetic inspection</p>	<p>49 G032 319</p> <p>Adapter (Part of 49 G032 3A1)</p>		<p>For hermetic inspection</p>
<p>49 L032 301</p> <p>Removal body, rod seal</p>		<p>For removal of oil seal</p>	<p>49 L032 302</p> <p>Remover shaft, rod seal</p>		<p>For removal of oil seal</p>
<p>49 L032 303</p> <p>Protector, rod seal</p>		<p>For installation of oil seal</p>	<p>49 L032 304</p> <p>Guide, rod seal</p>		<p>For installation of oil seal</p>

<p>49 9200 020</p> <p>Tension gauge, V-ribbed belt</p> 	<p>For inspection of oil pump drive belt</p>	<p>49 T028 3A0</p> <p>Puller set, ball joint</p> 	<p>For removal of tie rod end</p>
<p>49 T028 303</p> <p>Body (Part of 49 T028 3A0)</p> 	<p>For removal of tie rod end</p>	<p>49 T028 304</p> <p>Attachment (Part of 49 T028 3A0)</p> 	<p>For removal of tie rod end</p>



TROUBLESHOOTING GUIDE

Problem	Possible Cause	Remedy	Page/Section
Steering "heavy"	Poor lubrication, foreign material, or abnormal wear of steering ball joint Stuck or damaged lower arm ball joints Improper steering pinion preload Damaged steering gear Malfunction of steering shaft joint Improperly adjusted wheel alignment Malfunctioning steering gear Incorrect tire pressure Loose or damaged oil pump drive belt Low fluid level or air in fluid Leakage of fluid Insufficient oil pump pressure	Lubricate or replace Replace Adjust Replace Replace Adjust Replace Adjust Adjust or replace Add fluid or bleed air Repair or replace Replace	N- 8, 10 section R N-28 N-18, 30 N-13 section R N-18, 30 section Q section B N- 7 — N-32
Steering wheel pulls to one side	Incorrect tire pressure Unevenly worn tires Weakened front coil spring Worn or damaged stabilizer and/or lower arm bushing Dragging brake Loose lower arm Improperly adjusted wheel alignment	Adjust Replace Replace Replace Repair Tighten Adjust	section Q section Q section R section R section P section R section R
General instability while driving	Incorrect tire pressure Damaged or unbalanced wheel Worn or damaged steering joints Improper steering pinion preload Weakened front coil spring Worn or damaged stabilizer and/or lower arm bushing Malfunctioning shock absorber Improperly adjusted wheel alignment	Adjust Adjust or replace Replace Adjust Replace Replace Replace Adjust	section Q section Q N-13 N-28 section R section R section R section R
"Shake" occurs (Steering wheel vibrates up /down)	Excessive tire and wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mount rubber Cracked or worn transmission mount rubber	Replace Tighten Adjust or replace Replace Replace	section Q section Q section Q section B section K1
"Shimmy" occurs (Steering wheel vibrates circumferentially)	Cracked or worn steering gear mount rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire and wheel runout Loose lug nuts Unbalanced wheel(s) Incorrect tire pressure Unevenly worn tires Malfunction of shock absorber Loose shock absorber mounting bolts Stuck or damaged lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Replace Replace Replace Adjust	N-18, 30 N-18, 30 N- 8, 10 section Q section Q section Q section Q section R section R section R section R section M section R
Excessive steering wheel play	Worn steering gear Worn or damaged steering joints Worn or damaged lower arm bushing Loose steering gear mounting bolts Worn linkage or tie rod end	Replace Replace Replace Tighten Replace	N-18, 30 N-13 section R N-18, 30 N- 8, 10
Poor steering wheel return	Incorrect tire pressure Stuck or damaged steering joints Improperly adjusted front wheel alignment Improper steering pinion preload Ball joint not operating smoothly Steering shaft contacting something	Adjust Replace Adjust Adjust Replace Repair	section Q N-13 section R N-28 N- 8, 10 N-13

TROUBLESHOOTING GUIDE (Cont'd)

Problem	Possible Cause	Remedy	Page/Section
Abnormal noise from steering system	Loose oil pump	Tighten	N-32
	Loose steering gear box	Tighten	N-18, 30
	Loose oil pump bracket	Tighten	section B
	Loose oil pump pulley nut	Tighten	N-32
	Belt loose/tight	Adjust	N-35
	Air in system	Bleed air	below
	Malfunction inside steering gear	Replace	N-18, 30
	Malfunction of oil pump	Replace	N-32
	Obstruction near steering column or pressure hose	Repair or replace	N-13
	Loose steering ball joint	Tighten or replace	N- 8, 10
Worn steering joints	Replace	N-13	

N




AIR BLEEDING

1. Check the fluid level. (Refer to page N-36.)
2. Turn the steering wheel fully to the left and right several times with the engine not running.
3. Recheck the fluid level. If the level has lowered, add fluid.
4. Repeat steps 2 and 3 until the fluid level stabilizes.
5. Start the engine and let it idle.
6. Turn the steering wheel fully to the left and right several times.
7. Check that the fluid is not foamy and that the fluid level has not dropped.
8. Add fluid if necessary and repeat steps 6 and 7.

BOOTS (2WD)


Removal / Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it on safety stands.
3. Remove the wheel.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all necessary nuts to the specified torque.
7. After installation, check the steering angle and toe-in and adjust if necessary. (Refer to section R.)




- | | |
|---------------------------|----------------|
| 1. Cotter pin | |
| 2. Nut | |
| 3. Tie-rod end ball joint | |
| Removal Note | page N-9 |
| 4. Locknut | |
| Removal Note | page N-9 |

- | | |
|-----------------------|----------------|
| 5. Tie-rod end | |
| 6. Tie-rod end boot | |
| Removal Note | page N-9 |
| Installation Note | page N-9 |
| 7. Boot clamp | |
| 8. Boot wire | |
| 9. Steering gear boot | |


**Removal note****Tie-rod end ball joint**

1. Remove the tie rod nut.
2. Separate the tie-rod end ball joint from the steering knuckle by using the **SST**.

**Locknut**

Before loosening the locknut from the tie-rod end, make a mark for reference when tightening.


N

**Tie-rod end boot**

Secure the tie-rod end in a vise. Place a chisel against the boot and hold it at the angle shown. Remove the boot by tapping with a hammer.

Caution

- Striking the tie-rod end with metal tools will cause raised areas, which could slice the new boot. When removing the old boot from the tie-rod end, always point the chisel away from the tie-rod end.


**Installation note****Tie-rod end boot**

1. Wipe away the grease on the ball joint.
2. Put a small amount of grease (lithium-based) into the new boot and set it onto the tie-rod end.
3. Press the boot onto the tie-rod end by using the **SST** and a press.
4. Wipe away any grease expelled from the dust boot.

BOOTS (4WD)


Removal / Installation

1. Loosen the wheel lug nuts.
2. Jack up front of the vehicle and support it on safety stands.
3. Remove the wheel.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all necessary nuts to the specified torque.
7. After installation, check the steering angle and toe-in and adjust if necessary. (Refer to section R.)




1. Cotter pin
2. Nut
3. Tie-rod end ball joint
Removal Note page N-11
4. Locknut
Removal Note page N-11


5. Tie-rod end
6. Tie-rod end boot
Removal Note page N-11
Installation page N-11
7. Boot wire
8. Boot clamp
9. Steering gear boot

**Removal note****Tie-rod end ball joint**

1. Remove the tie rod nut.
2. Separate the tie-rod end ball joint from the steering knuckle by using the **SST**.

**Locknut**


Before loosening the locknut from the tie-rod end, make a mark for reference when tightening.

**Tie-rod end boot**


Secure the tie-rod end in a vise. Place a chisel against the boot and hold it at the angle shown. Remove the boot by tapping with a hammer.

Caution

- **Striking the tie-rod end with metal tools will cause raised areas, which could slice the new boot. When removing the old boot from the tie-rod end, always point the chisel away from the tie-rod end.**

**Installation note****Tie-rod end boot**

1. Wipe away the grease on the ball joint.
2. Put a small amount of grease (lithium-based) into the new boot and set it onto the tie-rod end.
3. Press the boot onto the tie-rod end by using the **SST** and a press.
4. Wipe away any grease expelled from the dust boot.




STEERING WHEEL AND COLUMN


On-vehicle Inspection

Inspection of steering effort

1. With the vehicle on a hard, level surface, move the steering wheel to put the wheels in the straight-ahead position.



2. Start the engine and warm the power steering fluid to 50—60 °C { 122—140 °F }.




3. With the engine running at idle speed, attach a pull scale to the outermost point of the steering wheel spoke. Then, starting with the wheels in the straight-ahead position, check the steering effort required to turn the steering wheel to the left and to the right.

4. If the measured value exceeds the specification, check the following: fluid level, air in system, fluid leakage at hose or connections, function of oil pump and gearbox, and tire pressure.


Steering wheel effort: 29 N { 3.0 kgf , 6.6 lbf } or less

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal.
3. Tighten all necessary nuts and bolts to the specified torque.
4. After installation, check the selector lever for correct operation. (Refer to section K1.)



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Air bag module
Service section T 2. Locknut 3. Steering wheel
Removal Note page N-14 4. Column cover 5. Side panel 6. Lower panel 7. Shift-lock actuator 8. Selector cable 9. Retaining ring, wave washer, adjustment washer(s)
Service section K1 | <ol style="list-style-type: none"> 10. Selector lever assembly
Service section K1 11. Combination switch
Service section T 12. Joint cover 13. Fixing bolt (steering shaft/intermediate shaft) 14. Steering shaft
Disassembly / Assembly /
Inspection page N-15 15. Fixing bolt (universal joint/pinion shaft) 16. Fixing bolt (intermediate shaft/universal joint) 17. Universal joint 18. Intermediate shaft 19. Dust cover |
|---|---|



Removal note
Steering wheel


Remove the steering wheel by using a suitable puller.

Caution


- Do not try to remove the steering wheel by hitting the shaft with a hammer. The column will collapse.

Disassembly / Assembly / Inspection


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Nut 2. Bolt 3. Return spring 4. Lever 5. Steering lock mounting bolts and bracket
 Disassembly Note page N-16
 Assembly Note page N-17 | <ol style="list-style-type: none"> 6. Steering lock assembly
 Inspection page N-16 7. Steering shaft
 Inspection page N-16 |
|---|--|

**Disassembly note****Steering lock mounting bolts and bracket**


Use a chisel to make a groove in the head of the steering lock mounting bolts. Remove the bolts by using a screwdriver; then remove the steering lock assembly.

**Inspection**


Check for the following and replace the assembly if necessary.

Steering shaft

1. Column bushing wear




2. Column bearing damage




3. Steering shaft length

Specified length: 612—615 mm { 24.09—24.21 in }

**Steering lock assembly**

1. Turn the ignition switch to the LOCK position.
2. Verify that the key cannot be turned with the button pushed and can be turned with the button not pushed.


**Assembly note****Steering lock mounting bolts and bracket**

Install the steering lock assembly on the jacket. Install new steering lock mounting bolts, and tighten them until the heads break off.


STEERING GEAR AND LINKAGE (2WD)

Removal / Inspection / Installation


1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it on safety stands.
3. Remove the wheel.
4. Remove the undercover
5. Remove in the order shown in the figure, referring to **Removal Note**.
6. Install in the reverse order of removal, referring to **Installation Note**.
7. After installation:
 - (1) Bleed the air from the system. (Refer to page N-7.)
 - (2) Check the power steering fluid level and add fluid if necessary. (Refer to page N-36.)
 - (3) Check the system for fluid leakage. (Refer to page N-36.)
 - (4) Check the toe-in and adjust it if necessary. (Refer to section R.)
8. Inspect all parts and repair or replace as necessary.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Cotter pin 2. Nut 3. Tie-rod end ball joint
Removal Note page N- 9 4. Fixing bolt (intermediate shaft/pinion shaft) 5. Pressure pipe
Removal Note page N-19 6. Return hose | <ol style="list-style-type: none"> 7. Steering bracket mounting bolts
Removal Note page N-19 8. Steering gear, linkage, and steering brackets 9. Mounting bracket bolts
Installation Note page N-19 10. Steering gear and linkage 11. Steering brackets |
|--|--|

**Removal note****Pressure pipe**

Before removing the pressure pipe, make marks for reference during installation.

**Steering bracket mounting bolt**


Remove the change counter assembly to remove the protector plate mounting bolt indicated by the arrow. (Refer to section K1 for change counter assembly service.)

**Installation note****Mounting bracket bolts**


Tighten the mounting bracket bolts in the order shown in the figure.

Disassembly / Inspection (2WD), (4WD)


1. Plug all pipe fittings to prevent leakage.
2. Clean the steering gear and linkage.
3. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
4. Inspect all parts and repair or replace as necessary.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Oil pipe
Inspect for clogging and damage 2. Tie-rod end
Disassembly Note page N-21
Inspect for damage and operation 3. Tie-rod end locknut 4. Boot clamp 5. Boot wire 6. Boot
Inspect for cracking and tearing 7. Tie rod
Inspect for damage and operation 8. Adjusting cover locknut 9. Adjusting cover
Disassembly Note page N-21 10. Spring, pressure pad
Inspect for damage 11. Dust cover 12. Snap ring 13. Housing cover
Disassembly Note page N-21 14. Lower bearing locknut 15. Pinion shaft and control valve assembly
Disassembly Note page N-21
Inspect for wear and damage of pinion shaft teeth
Inspect for damage, clogging, and wear of control valve | <ol style="list-style-type: none"> 16. Oil seal 17. Upper bearing
Inspect for wear, damage, and operation 18. Rack bushing assembly
Disassembly Note page N-21 19. Rack
Inspect for cracking, damage, and wear of teeth
Inspect for wear and damage of seal ring holder
Inspect for corrosion of rack pinion side 20. Spacer, oil seal
Disassembly Note page N-22 21. Lower bearing
Disassembly Note page N-22
Inspect for damage and operation 22. Oil seal
Disassembly Note page N-22 23. Needle bearing
Disassembly Note page N-22
Inspect for damage and operation 24. Seal ring, O-ring
Disassembly Note page N-22 25. Mounting bracket 26. Mounting rubber mount 27. Gear housing
Inspect for cracking and damage |
|---|---|

**Disassembly note****Tie-rod end**


Before removing the tie-rod end, make a marks for proper installation.

**Adjusting cover**


1. Remove the locknut from the adjusting cover.
2. Remove the adjusting cover by using the **SST**.
3. Remove the spring and pressure pad.

**Housing cover**


1. Cut away the staked areas by using a drill.
2. Remove the housing cover.

**Pinion shaft and control valve assembly**


1. Remove the locknut.
2. Set the gear housing assembly on a press and remove the pinion shaft and control valve assembly as shown in the figure.

**Rack bushing assembly**


1. Cut away the staked areas by using a drill.
2. Remove the rack bushing.

**Spacer, oil seal**


Remove the spacer and the oil seal by using the **SST**, being careful not to scratch the inner surfaces of the gear housing.

**Lower bearing**

Drive the lower bearing out of the housing by using the **SST**.

**Oil seal, needle bearing**


1. Insert the **SST** (49 G032 302) so that it contacts the needle bearing.
2. Drive the oil seal and needle bearing out by using the **SST** (49 G032 303) bar.

**Seal ring, O-ring**

Remove the seal ring and the O-ring, being careful not to scratch the ring groove.


Assembly (2WD), (4WD)

Assemble in the order shown in the figure, referring to **Assembly Note**.




N·m { kgf·m , ft·lbf }


- | | |
|---|-------------------------------|
| 1. Gear housing | 14. Snap ring |
| 2. Mounting rubber mount | 15. Dust cover |
| 3. Mounting bracket | 16. Lower bearing locknut |
| 4. Seal ring, O-ring | Assembly Note page N-27 |
| Assembly Note page N-24 | 17. Housing cover |
| 5. Needle bearing | Assembly Note page N-27 |
| Assembly Note page N-24 | 18. Spring, pressure pad |
| 6. Oil seal | 19. Adjusting cover |
| Assembly Note page N-24 | Assembly Note page N-28 |
| 7. Spacer, oil seal | 20. Adjusting cover locknut |
| Assembly Note page N-25 | 21. Tie rod |
| 8. Rack | Assembly Note page N-28 |
| 9. Rack bushing assembly | 22. Boot |
| Assembly Note page N-26 | Assembly Note page N-28 |
| 10. Lower bearing | 23. Boot wire |
| Assembly Note page N-26 | 24. Boot clamp |
| 11. Pinion shaft and control valve assembly | 25. Tie-rod end |
| Assembly Note page N-26 | Assembly Note page N-29 |
| 12. Upper bearing | 26. Tie-rod end locknut |
| Assembly Note page N-27 | 27. Oil pipe |
| 13. Oil seal | |
| Assembly Note page N-27 | |

**Assembly note****Seal ring, O-ring**


1. Apply ATF to the seal ring and O-ring.
2. Install the O-ring in the ring groove of the rack.
3. Install the seal ring in the groove of the rack.
4. Compress the seal ring by hand to fit it into the groove.

**Needle bearing**


1. Apply grease to the end of the **SST**.
2. Apply ATF to the needle bearing.
3. Set the needle bearing on the **SST** so that the marked side of the bearing faces toward the **SST** handle.




4. Insert the needle bearing and the **SST** into the housing.




5. Set the housing on a press, and install the bearing into the housing.

**Oil seal**


1. Apply grease to the end of the **SST**.
2. Apply ATF to the new oil seal.
3. Set the oil seal on the **SST**.



4. Insert the oil seal and the **SST** into the housing.




5. Set the housing on a press and press in the seal.




Spacer, oil seal


1. Set the new oil seal on the **SST** (49 L032 304 and 49 L032 303) as shown.
2. Remove the **SST** (49 L032 304).



3. Set the oil seal on the rack through the rack teeth by using the **SST** (49 L032 303) as shown.
4. Apply grease to flat surface of the spacer.
5. Set the spacer so that the grease coated surface contacts the oil seal.
6. Apply ATF to the spacer and the oil seal.



7. Insert the rack from the tube side.




Rack bushing assembly


1. Install the rack bushing assembly in the rack housing.

Tightening torque:

108—127 N·m { 11—13 kgf·m , 80—94 ft·lbf }




2. Stake the rack housing at two points **approx 1.5 mm { 0.06 in }** from the end by using a hammer and center punch.




Hermetic inspection

1. Connect the **SST** to the cylinder housing.
2. Connect a vacuum pump to the **SST**.
3. Apply **53.3 kPa { 400 mmHg , 15.7 inHg }** vacuum.
4. Verify that the vacuum is held for at least **30 sec**. If not, check the seal and assembly.




Lower bearing

1. Secure the gear housing in a vise so that the lower bearing bore faces upward.
2. Apply ATF to the lower bearing, then install it in the housing.
3. Press the bearing into the gear housing with the housing cover. Tighten the cover until the tightening force suddenly increases.




Pinion shaft and control valve assembly


1. Apply grease (lithium base, NLGI No.2) to the teeth of the pinion shaft.
2. Apply ATF to the seal ring and the friction surface of the control valve.
3. Install the pinion shaft into the housing without allowing the teeth of the pinion to touch the oil seal.

**Upper bearing**


Apply ATF to the upper bearing, then install it.

**Oil seal**

1. Apply ATF to the new oil seal, and fill inside the lip with grease (lithium base, NLGI No.2).
2. Slide the **SST** over the serrations of the pinion shaft assembly.
3. Slide the oil seal over the **SST** and position it in the housing.




4. Tap the oil seal evenly into the housing by using the **SST** until the snap ring groove is just visible.
5. Install a new snap ring into the ring groove.

**Lower bearing locknut**

1. Temporarily install the tie rod on the tube side of the rack.
2. Invert the housing and install the locknut on the pinion shaft. Turn it until the tie rod contacts the tube.
3. Tighten the locknut.

Tightening torque:


40—49 N·m { 4.0—5.0 kgf·m , 29—36 ft·lbf }

**Housing cover**


1. Apply thread sealant to the housing cover threads.
2. Install the housing cover.

Tightening torque:

54—68 N·m { 5.5—7.0 kgf·m , 40—50 ft·lbf }




3. Stake between the rack housing and housing cover at two points with a center punch.



Adjusting cover


1. Set the rack in the center position.
2. Tighten the adjusting cover to **6.9—11.7 N·m { 70—120 kgf·cm , 61—104 in·lbf }**, then loosen it.
3. Tighten again to **5.0—6.3 N·m { 50—65 kgf·cm , 44—56 in·lbf }**, and then return it **35°—45°**.
4. Apply thread sealant to the exposed threads of the adjusting cover.



5. Install and tighten the locknut.

Tightening torque:

50—58 N·m { 5.0—6.0 kgf·m , 37—43 ft·lbf }




Tie rod

1. Secure the rack in a vise.
2. Install the tie rod onto the rack.


Tightening torque:

118—137 N·m { 12—14 kgf·m , 87—101 ft·lbf }



Boot

1. Apply grease to the inner surface of the small end of the boot.
2. Install the boot. Wrap a new boot wire around the large end of the boot two times and then twist it 4 to 4.5 times. Bend the twisted part toward the mounting bracket.
3. Install the boot clamp on the small end of the boot.




Tie-rod end

Align with the marks made before disassembly, and tighten the nut.


STEERING GEAR AND LINKAGE (4WD)

Removal / Inspection / Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it on safety stands.
3. Remove the wheel.
4. Remove the undercover.
5. Remove in the order shown in the figure, referring to **Removal Note**.
6. Install in the reverse order of removal, referring to **Installation Note**.
7. After installation:
 - (1) Bleed the air from the system. (Refer to page N-7.)
 - (2) Check the power steering fluid level and add fluid if necessary. (Refer to page N-36.)
 - (3) Check the system for fluid leakage. (Refer to page N-36.)
 - (4) Check the toe-in and adjust it if necessary. (Refer to section R.)
8. Visually inspect all parts and repair or replace as necessary.




- | | |
|---|--|
| 1. Cotter pin | 10. Nut and washer |
| 2. Tie-rod end ball joint
Removal Note page N-11 | 11. Front propeller shaft
Service section L |
| 3. Bolt | 12. Mounting bracket bolt
Installation Note page N-31 |
| 4. Pressure hose | 13. Front differential mounting bolt
Removal Note page N-31 |
| 5. Return hose | 14. Steering gear and linkage
Removal Note page N-31 |
| 6. Pressure and return pipes | Disassembly / Inspection page N-20 |
| 7. Fixing bolt (intermediate shaft/pinion shaft) | Assembly page N-23 |
| 8. Bolt and nut | |
| 9. Intermediate shaft and steering shaft assembly
Removal Note page N-31 | |

**Removal note****Intermediate shaft and steering shaft assembly**


1. Remove the lower panel.
2. Remove the column cover.
3. Remove the steering shaft mounting bolts and nuts.
4. Pull the steering shaft and intermediate shaft assembly to separate the intermediate shaft from the pinion shaft.

Front differential mounting bolt

1. Support the differential by using the transmission jack.
2. Remove the front differential mounting bolt.

**Steering gear and linkage**

1. Remove the pressure pipes and return pipes from the steering gear.
2. Remove the front propeller shaft.
3. Remove the bolts mounting the front differential and joint shaft assembly to the crossmember. Slide them rearward.
4. Slide the steering gear and linkage rearward and turn it 90°.
5. Remove the steering shaft and linkage to the left.


**Installation note****Mounting bracket bolts**

Tighten the gear housing mounting bracket bolts in the order shown in the figure.

OIL PUMP


Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal.
3. Tighten all necessary bolts and nuts to the specified torque.
4. After installation:
 - (1) Check the connections for fluid leakage. (Refer to page N-36.)
 - (2) Bleed the air from the system. (Refer to page N-7.)




N·m { kgf·m , ft·lbf }


- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Drive belt
Removal Note page N-33
Adjustment page N-35 2. Locknut
Removal Note page N-33 3. Oil pump pulley 4. Power steering pressure switch connector | <ol style="list-style-type: none"> 5. Pressure pipe
Removal Note page N-33 6. Return hose 7. Oil pump assembly
Disassembly / Inspection /
Assembly page N-34 |
|---|---|

**Removal note****Drive belt**

Loosen idler pulley locknut A, then loosen adjusting bolt B to remove the drive belt.

**Locknut**


Remove the locknut with the pulley held by using the SST.

**Pressure pipe**




Before removing the pressure pipe, make a mark for reference during installation.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. The following procedure is for replacement of the O-rings, gasket, and spring only. Replace the pump assembly if other repairs are necessary.
3. Assemble in the reverse order of disassembly.



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Bolt 2. Reserve tank
Inspect for damage or cracks 3. O-ring 4. Power steering pressure switch
Inspection section F 5. O-ring 6. Connector 7. O-ring 8. Joint 9. Control valve assembly
Inspect for cracks, damage, clogged valve hole, or wear of thrust section 10. Spring
Inspect for wear 11. Bolt 12. Rear body
Inspect for damage 13. Cam ring
Inspect for wear | <ol style="list-style-type: none"> 14. Vane
Inspect for wear 15. Rotor
Inspect for wear 16. Side plate
Inspect for wear 17. Pin 18. Spring
Inspect for wear 19. O-ring 20. Gasket 21. Snap ring 22. Bearing and shaft assembly
Inspect for wear of bearing and damage of shaft 23. Oil seal 24. Front body
Inspect for damage |
|---|--|



DRIVE BELT

On-vehicle Inspection

Inspection

1. Check the drive belt for looseness and damage.
2. Check the drive belt deflection (tension) by applying moderate pressure midway between the pulleys.

Deflection (Depressed at 98 N { 10 kgf , 22 lbf })

mm { in }

	New*	Used	Limit
JE engine	7.0—7.5 { 0.28—0.29 }	7.5—8.2 { 0.30—0.32 }	13.5 { 0.53 }

* A belt that has been on a running engine for less than five minutes.

Tension

N { kgf , lbf }

	New*	Used	Limit
JE engine	344—382 { 35—39 , 77—85 }	295—333 { 30—34 , 66—74 }	245 { 25 , 55 }

* A belt that has been on a running engine for less than five minutes.


Adjustment

After installation, adjust the deflection (tension) of the drive belt indicated by the arrow as follows:

- (1) Loosen the idler pulley locknut.
- (2) Adjust the deflection (tension) by turning the adjusting bolt.
- (3) Tighten the locknut to the specified torque.

Tightening torque:

38—51 N·m { 3.8—5.3 kgf·m , 28—38 ft·lbf }

**POWER STEERING FLUID****On-vehicle Inspection****Inspection of fluid level**


Pull the oil-level gauge from the reservoir filler tube and check the fluid level. The level should be between "H" and "L".


Inspection of fluid leakage

Start the engine and let it idle. Turn the steering wheel fully left and fully right to apply fluid pressure. Inspect the points shown in the figure for fluid leakage.

Caution

- **Never hold the steering wheel to the extreme left or right for more than 5 seconds with the engine running. This could damage the power steering pump.**




**Inspection of fluid pressure**


1. Assemble the SST as shown in the figure.

Tightening torque:


40—49 N·m { 4.0—5.0 kgf·m , 29—36 ft·lbf }



2. Mark both hose connections to ensure that the pipe is re-installed in its original position.
3. Disconnect the pressure pipe from the oil pump, and attach the SST.
4. Bleed the air from the system. (Refer to page N-7.)



5. Open the gauge valve fully. Start the engine and turn the steering wheel fully left and right to raise the fluid temperature to 50—60 °C { 122—140 °F }.





6. Close the gauge valve completely. Increase the engine speed to 1,000—1,500 rpm and measure the fluid pressure generated by the oil pump. If the pressure is below the specification, replace the oil pump assembly.

Oil pump fluid pressure: 7,601—8,335 kPa
{ 77.5—85.0 kgf/cm² , 1,103—1,208 psi }

Caution

- Do not keep the valve closed for more than 5 seconds. The increase in fluid temperature will damage the oil pump.



7. Open the gauge valve fully again and increase the engine speed to **1,000—1,500 rpm**.
8. Turn the steering wheel fully to the left and right and measure the fluid pressure generated by the gear housing. If the pressure is below the specification, replace the gear housing assembly.

Gear housing fluid pressure: 7,601—8,335 kPa
 { 77.5—85.0 kgf/cm² , 1,103—1,208 psi }

Caution

- **Never hold the steering wheel to the extreme left or right for more than 5 seconds with the engine running. This could damage the power steering pump.**

9. Remove the gauge set. Install and tighten the high-pressure hose to the specified torque.

Tightening torque:

32—47 N·m { 3.2—4.8 kgf·m , 24—34 ft·lbf }


10. Bleed the air from the system. (Refer to page N-7.)

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

BRAKING SYSTEM

INDEX	P- 2
OUTLINE	P- 3
SPECIFICATIONS	P- 3
CONVENTIONAL BRAKE SYSTEM	P- 4
PREPARATION	P- 4
TROUBLESHOOTING GUIDE	P- 5
BRAKE HYDRAULIC LINE	P- 6
BRAKE PEDAL	P- 7
MASTER CYLINDER	P- 9
POWER BRAKE UNIT	P-13
FRONT BRAKE (DISC)	P-16
REAR BRAKE (DISC)	P-20
DISC PAD	P-22
DISC PLATE	P-23
CALIPER	P-24
PROPORTIONING BYPASS VALVE (PBV)	P-26
PARKING BRAKE SYSTEM	P-27
PREPARATION	P-27
TROUBLESHOOTING GUIDE	P-27
PARKING BRAKE LEVER	P-27
PARKING BRAKE SHOES	P-29
PARKING BRAKE CABLE	P-33
ANTILOCK BRAKE SYSTEM (ABS)	P-34
PREPARATION	P-34
TROUBLESHOOTING	P-34
ON-BOARD DIAGNOSTIC FUNCTION	P-43
ABS HYDRAULIC UNIT ASSEMBLY (ABS HU ASSEMBLY)	P-50
ABS WHEEL-SPEED SENSOR (FRONT)	P-53
ABS WHEEL-SPEED SENSOR (REAR)	P-54
G SENSOR (4WD)	P-55

INDEX



- | | |
|--|---|
| <p>1. Brake hydraulic line
 On-vehicle inspection page P- 6
 Removal / Installation page P- 6
 Air bleeding page P- 6</p> <p>2. Brake pedal
 On-vehicle inspection page P- 7
 Removal / Installation /
 Inspection page P- 8</p> <p>3. Master cylinder
 Removal / Installation page P- 9
 Inspection page P-11
 Disassembly / Assembly /
 Inspection page P-11</p> <p>4. Power brake unit
 On-vehicle inspection page P-13
 Removal / Installation page P-15</p> <p>5. Front brake (disc)
 On-vehicle inspection page P-16
 Replacement page P-16
 Removal / Installation page P-17
 Inspection page P-18
 Disassembly (caliper) page P-18
 Inspection (caliper) page P-19
 Assembly (caliper) page P-19</p> <p>6. Rear brake (disc)
 Inspection (on-vehicle) page P-20
 Removal / Inspection /
 Installation page P-21</p> <p>7. Disc pad
 Replacement page P-22</p> <p>8. Disc plate
 Inspection page P-23</p> | <p>9. Caliper
 Disassembly / Inspection /
 Assembly page P-24</p> <p>10. Proportioning bypass valve (PBV)
 Inspection page P-26
 Replace page P-26</p> <p>11. Parking brake lever
 On-vehicle inspection page P-27
 Removal / Installation /
 Inspection page P-28</p> <p>12. Parking brake shoes
 Removal / Inspection /
 Installation page P-29
 Inspection page P-30</p> <p>13. Parking brake cable
 Removal / Inspection /
 Installation page P-33</p> <p>14. ABS hydraulic unit assembly
 (ABS HU assembly)
 Removal / Inspection /
 Installation page P-50
 Disassembly / Assembly page P-52</p> <p>15. ABS wheel-speed sensor (front)
 Removal / Inspection /
 Installation page P-53</p> <p>16. ABS wheel-speed sensor (rear)
 Removal / Inspection /
 Installation page P-54</p> <p>17. G sensor (4WD)
 Removal / Inspection /
 Installation page P-55</p> |
|--|---|

OUTLINE












SPECIFICATIONS

Item		Specification
Brake pedal	Type	Suspended
	Pedal lever ratio	4.01 : 1
	Maximum stroke mm { in }	130 { 5.12 }
Master cylinder	Type	Tandem (with level sensor)
	Cylinder inner diameter mm { in }	23.81 { 0.94 }
Front disc brake	Type	Ventilated disc
	Cylinder bore mm { in }	42.8 { 1.69 } × 2
	Pad dimensions (area × thickness) mm ² × mm { in ² × in }	6,000 × 10.5 { 9.30 × 0.41 }
	Disc plate dimensions mm { in } (outer diameter × thickness)	276 × 28 { 10.87 × 1.10 }
Rear disc brake	Type	Ventilated disc
	Cylinder bore	41.3 { 1.63 }
	Pad dimensions (area × thickness) mm ² × mm { in ² × in }	3,300 × 10 { 5.11 × 0.40 }
	Disc plate dimensions mm { in } (outer diameter × thickness)	286 × 18 { 11.3 × 0.71 }
Power brake unit	Type	Tandem diaphragm
	Size in	8 + 9
Rear wheel hydraulic control system	Type	Proportioning bypass valve
	Switching point (master cylinder pressure) kPa { kgf/cm ² , psi }	2,940 { 30.0, 427 }
Brake fluid		FMVSS116 DOT-3
Parking drum brake	Type	Mechanical, two rear wheel control
	Operation system	Center lever
	Drum brake type	Duo servo
	Lining dimensions (width × thickness) mm { in }	30 { 1.18 } × 3.1 { 0.12 }
	Drum inner diameter mm { in }	190 { 7.48 }

P

CONVENTIONAL BRAKE SYSTEM


**PREPARATION
SST**

<p>49 0259 770B Wrench, flare nut</p> 	<p>For removal and installation of brake pipe</p>	<p>49 F043 001 Adjust gauge</p> 	<p>For adjustment of push rod clearance</p>
<p>49 0221 600C Expand tool, disc brake</p> 	<p>For installation of brake caliper</p>	<p>49 0208 701A Air out tool, boot</p> 	<p>For removal of piston seal</p>
<p>49 U043 0A0 Gauge set, oil pressure</p> 	<p>For inspection of brake fluid pressure</p>	<p>49 U043 004 Gauge, oil pressure (Part of 49 U043 0A0)</p> 	<p>For inspection of brake fluid pressure</p>
<p>49 U043 005 Joint (Part of 49 U043 0A0)</p> 	<p>For inspection of brake fluid pressure</p>	<p>49 U043 006 Hose (Part of 49 U043 0A0)</p> 	<p>For inspection of brake fluid pressure</p>
<p>49 B043 004 Socket wrench</p> 	<p>For adjustment of push rod clearance</p>	<p>49 E043 003A Lock tool, turning</p> 	<p>For adjustment of push rod clearance</p>
<p>49 T033 001A Stopper, disc brake piston</p> 	<p>For removal of piston</p>	<p>—</p>	<p>—</p>

TROUBLESHOOTING GUIDE

Problem	Possible cause	Remedy	Page
Poor braking	Leakage of brake fluid	Repair	—
	Air in system	Air bleed	P- 6
	Worn disc pad	Replace	P-16, 22
	Brake fluid, grease, oil, or water on disc pad	Clean or replace	P-16, 22
	Hardening of disc pad surface or poor contact	Grind or replace	P-16, 22
	Malfunction of disc brake piston	Replace	P-18, 24
	Malfunction of master cylinder	Repair or replace	P-9, 11
	Malfunction of power brake unit	Repair or replace	P-15
	Malfunction of check valve (vacuum hose)	Repair or replace	P-15
	Damaged vacuum hose	Replace	P-15
Brakes pull to one side	Deterioration of flexible hose	Replace	—
	Malfunction of PBV	Replace	P-26
	Worn disc pad	Replace	P-16, 22
	Brake fluid, grease, oil, or water on disc pad	Clean or replace	P-16, 22
	Hardening of disc pad surface or poor contact	Grind or replace	P-16, 22
	Abnormal wear, distortion, or runout of disc plate	Repair or replace	P-16, 22
	Malfunction of automatic adjuster	Repair or replace	—
	Looseness of backing plate mounting bolts	Tighten	P-22
	Malfunction of caliper piston	Repair or replace	P-16, 22
	Improperly adjusted wheel alignment	Adjust	section R
Brakes do not release	Unequal tire air pressures	Repair or replace	section Q
	No brake pedal play	Adjust	P- 7
	Improperly adjusted push rod clearance	Adjust	P-10
	Clogged master cylinder return port	Clean	—
	Brake pad not returning properly	Repair	—
	Improper return or malfunction of caliper piston	Replace	P-18, 24
Pedal goes too far (too much pedal stroke)	Improper adjustment of wheel bearing preload	Adjustment or replace	section M
	Excessive runout of disc plate	Replace	P-17, 21
	Air in system because of insufficient brake fluid	Add fluid and bleed air	P- 6
	Improperly adjusted pedal play	Adjust	P- 7
Abnormal noise or vibration during braking	Worn disc pad	Replace	P-16, 22
	Deteriorated disc pad	Grind or replace	P-16, 22
	Brakes do not release	Repair	—
	Foreign material or scratches on disc plate contact surface	Clean	—
	Looseness of backing plate or caliper mounting bolts	Tighten	P-17, 21
	Damaged disc plate contact surface	Replace	P-17, 21
	Poor contact of disc pad	Repair or replace	P-17, 22
	Insufficient grease on sliding parts	Apply grease	—

P




BRAKE HYDRAULIC LINE

On-vehicle Inspection

Check for the following and replace parts as necessary.

1. Cracking, damage, or corrosion of brake hose
2. Damage to brake hose threads
3. Scars, cracks, or swelling of flexible hose
4. All lines for fluid leakage




Removal / Installation

1. Loosen or tighten the flare nut by using the SST.

Flare nut tightening torque:

12.8—21.5 N·m { 130—220 kgf·cm , 113—190 in·lbf }


2. When connecting the flexible hose, do not overtighten or twist it.
3. After installation:
 - (1) Check that the hose does not contact other parts when the vehicle bounces or when the steering wheel is turned fully right or left.
 - (2) Bleed the air from the brake system.




Air Bleeding

Note

- The brakes should be bled whenever a brake line is disconnected. If a hydraulic line is disconnected at the master cylinder, start at the master cylinder (Refer to page P-10.), and then the slave cylinder farthest from the brake master cylinder, and move to the next farthest slave cylinder until all four cylinders have been bled. If the disconnection point is anywhere except the master cylinder, start at the point closest to the disconnection, and move to the next closest slave cylinder until all four cylinders have been bled.



FRONT




REAR

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the bleeder cap and attach a vinyl tube to the bleeder screw.
3. Place the other end of the vinyl tube in a clear fluid-filled container.
4. One person should depress the brake pedal a few times, and then hold it in the depressed position.
5. A second person should loosen the bleeder screw, drain out the fluid, and close the screw by using the SST.
6. Repeat step 4 and 5 until no air bubbles are seen. The reservoir should be kept about 3/4 full during bleeding to prevent air from reentering the lines.

Tightening torque:

5.9—8.8 N·m { 60—90 kgf·cm , 53—78 in·lbf }

7. Check for correct brake operation.
8. Verify that there is no fluid leakage. Wipe off any spilled fluid immediately.
9. After bleeding the brakes, add brake fluid to MAX.



BRAKE PEDAL

On-vehicle Inspection

Pedal height Inspection

Check that the distance from the center of the upper surface of the pedal pad to the carpet is as specified.

Pedal height:

191—201 mm { 7.52—7.91 in } (With carpet)

Adjustment

1. Disconnect the brake switch connector.
2. Loosen locknut B and turn switch A until it does not contact the pedal.
3. Loosen locknut D and turn rod C to adjust the height.
4. Adjust the pedal free play and tighten locknut D.
5. Turn the brake switch until it contacts the pedal, then turn an additional 1/2 turn. Tighten locknut B.


Locknut B tightening torque:

13.8—17.6 N·m { 140—180 kgf·cm , 122—156 in·lbf }

Locknut D tightening torque:

24—34 N·m { 2.4—3.5 kgf·m , 18—25 ft·lbf }

P



Pedal play Inspection

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Gently depress the pedal again by hand and check the free play (until the valve plunger contacts the stopper plate = until the power piston begins to move).


Pedal play: 4—7 mm { 0.16—0.27 in }

Adjustment

Loosen locknut D of operating rod C, then turn the rod to adjust the free play.

Locknut D tightening torque:

24—34 N·m { 2.4—3.5 kgf·m , 18—25 ft·lbf }




Pedal-to-floor clearance

Inspection

Check that the distance from the floor panel to the center of the upper surface of the pedal pad is as specified when the pedal is depressed with a force of 589 N { 60 kgf , 132 lbf }.

Pedal-to-floor clearance:

85 mm { 3.3 in } min. (Without carpet)




If the distance is less than specified, check for the following problems:

1. Air in brake system
2. Worn pads

Removal / Installation / Inspection

1. Remove in the order shown in the figure.
2. Inspect all components and parts. Replace parts if necessary.
3. Install in the reverse order of removal.
4. After installation, check and adjust the pedal height and free play if necessary.




- | | |
|---|---|
| 1. Lower panel | 8. Brake pedal
Inspect for bending |
| 2. Duct No.3 | 9. Bushing
Inspect for wear |
| 3. Snap pin | 10. Guide pipe |
| 4. Clevis pin
Inspect for weakness or damage | 11. Pedal pad
Inspect for wear or damage |
| 5. Return spring | 12. Stop rubber
Inspect for wear or damage |
| 6. Nut | |
| 7. Bolt
Inspect for bending | |

MASTER CYLINDER
Removal / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed the air, and check for fluid leakage.

Caution

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.




- | | |
|--|---|
| 1. Fluid level sensor connector | 6. O-ring |
| 2. Brake pipe
Removal / Installation Note below | 7. Master cylinder
Installation Note page P-10
Disassembly / Assembly /
Inspection page P-11 |
| 3. Nut | |
| 4. Connector, bolt, and washers | |
| 5. Proportioning bypass valve (PBV)
Inspection page P-26
Replace page P-26 | |



Removal / Installation note

Brake pipe

Disconnect/connect the brake pipes from the master cylinder by using the SST.




Installation note

Master cylinder

Push rod clearance


Check the clearance between the push rod of the power brake unit and the piston of the master cylinder.

1. Place the **SST** atop the master cylinder. Turn the adjusting bolt until it contacts the bottom of the push rod hole in the piston.




2. Apply **66.7 kPa { 500 mmHg , 19.7 inHg }** vacuum to the power brake unit by using a vacuum pump.

3. Invert the **SST** used in step 1, and place it on the power brake unit.



4. Check the clearance between the end of the adjusting bolt and the push rod of the power brake unit.




5. If it is not **0 mm { 0 in }** , loosen the push rod locknut and turn the push rod to make the adjustment by using the **SST**.

Note


- This adjustment produces the following clearance.

	Push rod-to-piston clearance
When vacuum applied to unit is approx. 66.7 kPa { 500 mmHg , 19.7 inHg }	0.1—0.4 mm { 0.004—0.015 in }



Air bleeding

When removing the master cylinder bleed the air from the area shown, then bleed the air from the wheel side. (Refer to page P-6.)



Inspection

Fluid level sensor


1. Disconnect the sensor connector.
2. Connect an ohmmeter to the connector.
3. Starting with the fluid level above the MIN mark on the reservoir, verify that there is no continuity.
4. Remove the brake fluid and verify continuity when the level is below the MIN mark.
5. Replace the sensor if necessary.

Disassembly / Assembly / Inspection


1. After removing the brake fluid, disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all components and parts.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.

Caution


- The brake master cylinder is made of aluminum, and can be easily damaged by tightening in a vise. When securing the master cylinder in a vise, tighten only the master cylinder flange.
- If the master cylinder body is damaged, replace the unit as an assembly.
- Since the proportioning bypass valve is easily damaged, remove it before disassembling the master cylinder.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Fluid level sensor
Inspection above 2. Screw 3. Reservoir tank assembly
Inspect for abnormal wear, rust, or damage 4. Bushings 5. Bleeder valve 6. Stopper screw and O-ring (non-ABS model)
Assembly Note page P-12
Stop pin and O-ring (ABS model)
Assembly Note page P-12 | <ol style="list-style-type: none"> 7. Snap ring
Disassembly Note page P-12 8. Primary piston assembly 9. Secondary piston assembly
Disassembly Note page P-12 10. Master cylinder body
Inspect for abnormal wear, rust, or damage |
|---|---|

**Disassembly note****Snap ring**


Push the piston in to remove or install the snap ring by using snap-ring pliers.

**Secondary piston assembly**






Remove the secondary piston assembly by gradually blowing compressed air into the cylinder.

**Assembly note****Stopper screw and O-ring (non-ABS model)**

1. Push the secondary piston assembly in fully.
2. Install and tighten the new O-ring and stopper screw.
3. Push and release the piston to verify that it is held by the stopper screw.

**Stop pin and O-ring (ABS model)**

1. Install the secondary piston assembly with the piston hole facing the stop pin.
2. Install and tighten a new O-ring and stop pin.
3. Push and release the piston to verify that it is held by the stop pin.



POWER BRAKE UNIT

On-vehicle Inspection

Power brake unit function check (Simple method)

Step 1

1. With the engine stopped, depress the pedal a few times.
2. With the pedal depressed, start the engine.
3. If the pedal moves down slightly immediately after the engine starts, the unit is operating.

Step 2

1. Start the engine.
2. Stop the engine after it has run for **1 or 2 minutes**.
3. Depress the pedal with the usual force.
4. If the first pedal stroke is long and becomes shorter with subsequent strokes, the unit is operating.
5. If a problem is found, inspect for damage of the check valve or vacuum hose, and examine the installation. Repair if necessary, and inspect it once again.

Step 3

1. Start the engine.
2. Depress the pedal with the usual force.
3. Stop the engine with the pedal held depressed.
4. Hold the pedal down for **about 30 seconds**.
5. If the pedal height does not change, the unit is operating.
6. If there is a problem, check for damage to the check valve or vacuum hose, and check the connection. Repair if necessary, and check once again.

If the nature of the problem is still not clear after following the 3 steps above, follow the more detailed check described in "Inspection using testers," below.


(Inspection using the testers)

1. Connect the **SST** or equivalent, vacuum gauge(A), and pedal depression force gauge(B) as shown in the figure.
2. After bleeding the air from the **SST**, conduct the test as described in the steps below.

a) Checking for vacuum loss


Unloaded condition

1. Start the engine.
2. Stop the engine when the vacuum gauge reading reaches **66.7 kPa { 500 mmHg , 19.7 inHg }**.
3. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3—66.7 kPa { 475—500 mmHg , 18.7—19.7 inHg }**, the unit is operating.



Loaded condition


1. Start the engine.
2. Depress the brake pedal with a force of **196 N { 20 kgf , 44 lbf }**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge reading reaches **66.7 kPa { 500 mmHg , 19.7 inHg }**.
4. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3—66.7 kPa { 475—500 mmHg , 18.7—19.7 inHg }**, the unit is operating.



b) Checking for hydraulic pressure


1. If with the engine stopped (vacuum **0 kPa { 0 mmHg , 0 inHg }**) the fluid pressure is within the specification, the unit is operating.

Pedal force	Fluid pressure
196 N { 20 kgf , 44 lbf }	1,128 kPa { 11.5 kgf/cm ² , 164 psi } min



2. Start the engine. Depress the brake pedal when the vacuum reaches **66.7 kPa { 500 mmHg , 19.7 inHg }**. If the fluid pressure is within the specification, the unit is operating.

Pedal force	Fluid pressure
196 N { 20 kgf , 44 lbf }	8,044 kPa { 82 kgf/cm ² , 1,166 psi } min




Inspection of check valve

Inspection


1. Disconnect the vacuum hose from the engine.
2. Install the hose with the arrow mark pointing toward the engine.
3. Apply suction and pressure to the hose from the engine side. Verify that air flows only toward the engine. If air passes in both directions or not at all, replace the check valve and hose.

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. Perform the following steps after installation.
 - (1) Check and adjust the push rod and piston clearance. (Refer to page P-10.)
 - (2) Add fluid and bleed the air. (Refer to page P-6.)
 - (3) Check all parts for fluid leakage.
 - (4) Make an on-vehicle check of the unit. (Refer to page P-13.)
 - (5) Check that the vacuum hose does not contact other parts.



- | | |
|---|---------------------------------------|
| 1. Fluid level sensor connector | 5. Reserve tank and master cylinder |
| 2. Vacuum hose | Installation Note page P-10 |
| 3. Brake pipe | |
| Removal / Installation Note page P- 9 | |
| 4. Nuts | 6. Snap pin |
| | 7. Clevis pin |
| | 8. Nuts |
| | 9. Power brake unit |
| | Do not disassemble |
| | 10. Gasket |

**FRONT BRAKE (DISC)****On-vehicle Inspection****Disc pad**

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Look through the caliper inspection hole and inspect the remaining thickness of the pads.




Thickness: 2.0 mm { 0.08 in } min.

4. Replace the pads as a set (right and left wheels) if either is at or less than minimum thickness.


Replacement**Disc pad**

Brake pads must be replaced for both the left and right side of the caliper as a set.

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel and tires.
3. Remove the lower lock-pin bolt, then lift the caliper and support it.
4. Remove the pads.



5. Push the piston inward by using the **SST**.
6. Install the new pads in the mounting support.



7. Lower the caliper assembly onto the mounting support.
8. Tighten the lock bolt to the specified torque.


Tightening torque:

84—93 N·m { 8.5—9.5 kgf·m , 62—68 ft·lbf }

9. Mount the wheel and tires.
10. Apply the brakes 2 or 3 times and rotate the tires to see if the brakes drag.
11. Lower the vehicle.


Removal / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheels, then remove components in the order shown in the figure.
3. Install in the reverse order of removal.
4. Tighten all nuts and bolts to the specified torque, referring to the figure.
5. After installation, check the following.
 - (1) Add fluid and bleed the air. (Refer to page P-6.)
 - (2) Check for fluid leakage. (Refer to page P-6.)
 - (3) Depress the pedal a few times, then verify that the brakes do not drag while rotating the wheel by hand.



N-m { kgf-m , ft-lbf }

- | | |
|-----------------------------|----------------------------|
| 1. Brake hose | 6. Shim |
| 2. Clip | 7. Guide plate |
| 3. Lock bolt | 8. Bolt |
| 4. Brake caliper assembly | 9. Mounting support |
| Disassembly page P-18 | 10. Disc plate |
| Assembly page P-19 | Inspection page P-18 |
| 5. Disc pad | |
| Inspection page P-18 | |



Inspection


Check the following and replace parts as necessary.

Disc pad

1. Inspect for:
 - (a) Oil or grease on facing
 - (b) Abnormal wear or cracks
 - (c) Deterioration or damage by heat
2. Check the lining thickness and make sure it is within the specifications.

Thickness


Standard: 10.5 mm { 0.41 in }
Minimum: 2.0 mm { 0.08 in }



Disc plate

1. Verify that there is no looseness in the wheel bearing.
2. Measure the runout from the outer edge of the disc plate surface.

Runout: 0.05 mm { 0.002 in } max.




3. Inspect the disc plate for wear and damage.
4. Inspect the disc plate thickness, and make sure it is within the specification.

Thickness

Standard: 28 mm { 1.10 in }
Minimum: 26 mm { 1.02 in }
Minimum thickness after machining by using an on-vehicle brake lathe: 26.8 mm { 1.06 in }

Caution

- When it is necessary to machine the disc plate, if the disc plate is removed from the vehicle then machined, excessive runout may result. Machine the disc plate with it installed on the vehicle.



Disassembly (Caliper)

Disassemble in the order shown in the figure, referring to


Disassembly Note.


1. Dust seal
2. Piston
3. Piston seal
4. Cap and bleeder screw
5. Caliper body

Disassembly note

Piston


1. Place the **SST** in the caliper.
2. Gently blow compressed air through the pipe hole to force the piston out of the caliper.





Piston seal


Remove the piston seal from the caliper by using the SST.



Inspection (Caliper)


Inspect each part and replace if necessary.

1. Cylinder and piston for wear or rust
2. Caliper body for damage or cracks
3. Boot for damage or poor sealing




Assembly (Caliper)


1. Coat the new piston seal with the grease supplied in the seal kit then install it in the caliper.



2. Coat the piston and the cylinder with brake fluid and insert the piston squarely into the cylinder.
3. Coat the new dust seal with the grease supplied in the seal kit then install it in the caliper.



4. Coat the following parts with grease supplied in the seal kit.
 - (1) Lock bolt
 - (2) Boot
5. Fit the boot to the caliper.



REAR BRAKE (DISC)
Inspection (on-vehicle)
Disc pad


1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel.
3. Look through the caliper inspection hole and inspect the remaining thickness of the pads.

Thickness: 1.0 mm { 0.04 in } min.


4. Replace the pads as a set (right and left wheels) if either is at or less than the minimum thickness.

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the following.
 - (1) Add fluid and bleed the air. (Refer to page P-6.)
 - (2) Check for fluid leakage. (Refer to page P-6.)
 - (3) Depress the pedal a few time, then verify that the brake do not drag while rotating the wheel by hand.
 - (4) If the disc plate has been replaced, settle the parking brake shoes. (Refer to page P-32.)



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Flexible hose 2. Lock pin 3. Guide pin 4. Caliper
Disassembly / Inspection /
Assembly page P-24 5. V-spring | <ol style="list-style-type: none"> 6. Disc pad
Inspection page P-20
Installation Note page P-22 7. Outer shim 8. Inner shim 9. Guide plate 10. Mounting support 11. Disc plate
Inspection page P-23 |
|--|---|



Installation note


Disc pad

Before installing the disc pads, push the piston fully inward by using the **SST**.

DISC PAD


Replacement

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.



N-m { kgf-m , ft-lbf }

- | | |
|-------------------------|----------------|
| 1. Guide pin | 5. Outer shim |
| 2. Caliper | 6. Inner shim |
| 3. V-spring | 7. Guide plate |
| 4. Disc pad | |
| Installation Note | above |



DISC PLATE

Inspection

Disc plate thickness

1. Measure the thickness of the disc plate.

Standard: 18 mm { 0.71 in }


Minimum: 16 mm { 0.63 in }

Minimum thickness after machining by using an on-vehicle brake lathe: 16.8 mm { 0.66 in }

Caution

- When it is necessary to machine the disc plate, if the disc plate is removed from the vehicle then machined, excessive runout may result. Machine the disc plate with it installed on the vehicle.

2. If the thickness is not within the specification, replace the disc plate.



Disc plate runout

1. Verify that there is no looseness in the wheel bearing.
2. Measure the runout at the outer edge of the contact surface of the disc pad.


Runout: 0.05 mm { 0.002 in } max.

3. If the runout is not within the specification, replace the disc plate.


CALIPER

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Dust seal
Inspect for damage and poor sealing 2. Piston
Disassembly Note below
Inspect for wear and rust 3. Piston seal
Disassembly Note page P-25 | <ol style="list-style-type: none"> 4. Bleeder screw
Disassembly Note page P-25
Assembly Note page P-25 5. Caliper body
Inspect damage, wear and rust |
|---|--|




Disassembly note
Piston

1. Place a piece of wood in the caliper.
2. Gently blow compressed air through the pipe hole to force the piston out of the caliper.




Piston seal

Remove the piston seal from the caliper by using the SST.



Bleeder screw



Loosen the bleeder screw by using the SST.



Assembly note

Bleeder screw

Tighten the bleeder screw by using the SST.



PROPORTIONING BYPASS VALVE (PBV)

Inspection


1. With the proportioning bypass valve installed to the master cylinder, connect the **SST** to the proportioning bypass valve output side and to the master cylinder front brake side.
2. Bleed the air from the front brake line and the **SST**.
3. Measure the fluid pressure of the proportioning bypass valve output for the front and the rear brake.

kPa { kgf/cm², psi }

A	A'	B	B'
2,940 { 30, 427 }	2,940 ± 390 { 30 ± 4, 427 ± 57 }	5,880 { 60, 853 }	4,410 ± 390 { 45 ± 4, 640 ± 57 }

4. If not as specified, replace the proportioning bypass valve assembly.
5. Add fluid and bleed the air. (Refer to page P-6.)
6. Check for fluid leakage.


Replace



1. Brake pipe
2. Proportioning bypass valve
Inspection above
3. O-ring


PARKING BRAKE SYSTEM

**PREPARATION
SST**

<p>49 0221 600C Expand tool, disc brake</p>		<p>For installation of brake caliper</p>
---	---	--

TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
Brakes do not release	Improper return of parking brake cable or improper adjustment	Repair or adjust	P-33
Parking brake does not hold well	Excessive lever stroke Brake cable stuck or damaged Brake fluid or oil on lining Hardening of lining surface or poor contact	Adjust Repair or replace Clean or replace Grind or replace	P-27 P-33 — P-29




PARKING BRAKE LEVER

**On-vehicle Inspection
Inspection**

Check that the stroke is within the specification when the parking brake lever is pulled with a force of **98 N { 10 kgf , 22 lbf }**.

Stroke: 3—6 notches




Adjustment

1. Remove the screw and remove the parking brake lever cover.
2. Remove the adjusting nut clip and turn the adjusting nut at the front of the parking cable.
3. After adjustment, check the following points.
 - (1) Turn the ignition switch to ON, pull the parking brake lever one notch, and check that the parking brake warning light illuminates.
 - (2) Verify that the rear brakes do not drag.


Removal / Installation / Inspection

1. Block the wheels firmly.
2. Release the parking brake.
3. Remove in the order shown in the figure.
4. Inspect all components and parts. Replace parts if necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After installation:
Adjust the parking brake lever stroke. (Refer to page P-27.)



N-m { kgf-m , ft-lbf }

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Screw 2. Parking brake lever cover 3. Parking brake bracket cover 4. Parking brake switch connector 5. Clip 6. Adjusting nut
Adjustment page P-27 7. Bolt | <ol style="list-style-type: none"> 8. Parking brake lever
Inspect sector and ratchet pawl for wear or damage 9. Screw 10. Parking brake lever cover 11. Parking brake switch
Installation Note below 12. Button 13. Spring
Inspect for weakness or breakage |
|--|---|



Installation note


Parking brake switch

1. Install the parking brake switch so that it contacts the parking brake lever when the lever is fully released.
2. Turn the ignition switch to ON, and check that the parking brake warning light illuminates with the lever pulled one notch.


PARKING BRAKE SHOES

Removal / Inspection / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the following.
 - (1) Check the parking brake lever stroke. (Refer to page P-27.)
 - (2) Settle the parking brake shoes. (Refer to page P-32.)



- | | |
|------------------------|-----------------|
| 1. Service plug | |
| 2. Caliper | |
| Removal Note | page P-30 |
| Installation Note | page P-31 |
| 3. Disc plate | |
| Removal Note | page P-30 |
| Inspection | page P-30 |
| Installation Note | page P-31 |
| 4. Upper return spring | |
| 5. Lower return spring | |
| 6. Hold springs | |
| 7. Hold pins | |
| 8. Parking brake shoes | |
| Inspection | page P-30 |
| Installation Note | page P-30 |
| 9. Adjuster | |
| Installation Note | page P-31 |
| 10. Operating lever | |
| Installation Note | page P-31 |


**Removal note****Caliper**

Support the caliper as shown in the figure.

**Disc plate**

If the disc plate difficult to remove, loosen the parking brake shoes as described below.

1. Remove the service plug from the disc plate.
2. Insert a screwdriver into the hole, and turn the adjuster in the opposite direction of the arrow marked on the disc plate.


**Inspection****Disc plate**

1. Inspect the inside of disc plate for scratches and uneven or abnormal wear.
2. Measure the disc plate inner diameter.

Standard: 190.0 mm { 7.48 in }

Maximum: 191.0 mm { 7.51 in }

3. If the diameter is not within the specification, replace the disc plate.


**Parking brake shoes**

1. Inspect the lining for peeling, cracking, and uneven wear.
2. Measure the lining thickness.


Standard: 3.1 mm { 0.12 in }

Minimum: 1.0 mm { 0.04 in }

3. If the thickness is not within the specification, replace the parking brake shoes on the right and left wheels.


**Installation note****Parking brake shoes**

Before installing the parking brake shoes, apply grease to the shaded areas shown in the figure.




Operating lever

Connect the operating lever to the parking brake cable. The arrow mark on the operating lever should be facing the front.



Adjuster

1. Compress the adjuster to its smallest possible size by screwing the threaded part inward.
2. Install the adjuster between the brake shoes. For the left wheel, install the adjuster with the threaded part facing the front. For the right wheel, install the adjuster with the threaded part facing the rear.




Disc Plate

After installation the disc plate, adjust the parking brake shoe clearance as described below.

1. Remove the service plug from the disc plate.
2. Insert a screwdriver into the hole and turn the adjuster in the direction of the arrow until the disc plate locks.

Note

- The arrow is marked on the disc plate.




3. Turn the adjuster **3—5 notches** in the opposite direction to set the proper clearance.

Note

- When turning the adjuster **4 notches**, the shoe clearance will be **0.32 mm { 0.013 in }**.

4. Verify that the brakes do not drag when turning the disc plate by hand.
5. Install the disc plate service plug.



Caliper

1. Before installing the disc pads, push the piston fully inward by using the **SST**.
2. Install the caliper.

Settling the parking brake shoes

If the disc plate or parking brake shoes have been replaced or if the parking brake feels as if it is not working well, then do the following procedure.


Warning

- **Settling the brake shoes in a crowded area can cause traffic accidents, which can lead to death or serious injury.**

Do this procedure only in a wide open area, or in an area with good overall visibility, and be extremely careful of people, vehicles, and other obstacles in the area.

Caution

- **Doing this procedure more than 3 times during the life of the brake shoes will cause the lining to wear.**




1. Inspect the parking brake stroke, and adjust to specification if necessary.
2. Pull up the parking brake lever, with a force of **147 N { 15 kgf , 33 lbf }**.
3. With the lever pulled up, drive the vehicle for about 10 seconds at about **30 km/h { 19 MPH }**.
4. Stop the vehicle in a safe place, release the parking brake, and wait 5 minutes to cool the brakes.
5. Repeat steps 2 through 4 one or two more times.
6. After the procedure is completed, inspect the parking brake stroke, and adjust to the specification if necessary.

PARKING BRAKE CABLE

Removal / Inspection / Installation

1. Block the wheels firmly.
2. Release the parking brake and remove the parking brake lever adjusting nut. (Refer to page P-28.)
3. Remove rear seat No.1, front floormat. (Refer to section S.)
4. Jack up the vehicle and support it on safety stands.
5. Remove the parking brake cable in the order shown in the figure.
6. Install in the reverse order of removal.
7. After installation, check the following.
 - Adjust the parking brake lever stroke. (Refer to page P-27.)













- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Caliper
Removal Note page P-30 2. Disc plate 3. Parking brake shoes
Removal / Inspection /
Installation page P-29 4. Clip | <ol style="list-style-type: none"> 5. Cover 6. Rear parking cable
Inspect for damage and wear 7. Return spring 8. Front parking cable
Inspect the damage and wear |
|---|---|

ANTILOCK BRAKE SYSTEM (ABS)

PREPARATION

SST

<p>49 0259 770B Wrench, flare nut</p> 	<p>For removal and installation of brake pipe</p>	<p>49 T088 0A0 NGS set</p> 	<p>For diagnosis</p>
<p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p> 	<p>For diagnosis</p>	<p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For diagnosis</p>
<p>49 T088 003 Super MECS Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis</p>	<p>49 T088 005 STAR/DCL Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis</p>
<p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis</p>	<p>49 T088 008A Instruction Manual</p> 	<p>For diagnosis</p>
<p>49 T088 010B Program Card</p> 	<p>For diagnosis</p>	<p>49 L066 001 Harness adapter</p> 	<p>For inspection of wiring harness</p>

TROUBLESHOOTING

Troubleshooting Notes

The ABS is composed of electrical components, mechanical components (ABS hydraulic unit), and the components of the standard system.

Fundamentally, malfunction of the ABS electrical or mechanical components is judged by the on-board diagnostic function within the ABS control module. Malfunctions are indicated by the warning light in the instrument panel. The technicians can locate a malfunction by switching the system to the diagnostic test mode.

The on-board diagnostic system must be used when diagnosing the ABS.

Precaution


Conditions that are not malfunctions

1. Vibrations can sometimes be felt in the steering wheel, body, and/or brake pedal when the ABS is functioning; such vibrations are simply an indication that the ABS functioning.
2. The ABS warning light may illuminate under any of the following conditions:
 - When the vehicle is traveling on snow or ice with the parking brake activated or a brake dragging at one wheel.
 - When different size tires are used.

- When tires of different gripping performance are used.
 - When the vehicle is jacked up, stacked, or on a chassis roller with the front wheels locked, and the rear wheels are rotated according to the conditions below.
 - (2WD) . . . Rotated at a speed of 30 km/h { 18.6 MPH } or more for 80 seconds or more.
 - (4WD) . . . Rotated at a speed of 12 km/h { 7.4 MPH } or more for 20 seconds or more. (When in 2WD)
 If the ABS warning light illuminates for a few seconds then goes off when the ignition switch is turned to ON again, the ABS is functioning normally. However, diagnostic code 11 (front left wheel-speed sensor) and 12 (front right wheel-speed sensor) will be entered into the control module memory. Erase them from the memory by following the procedures below.
- (1) Activate the on-board diagnostic system and check for diagnostic trouble codes. (Refer to page P-43.)
 - (2) If code 11 and 12 are memorized, erase it. (Refer to page P-44.)
If code 11, 12 and other codes are memorized, check for the causes by referring to the applicable diagnostic chart for the other codes. (Refer to page P-45.)
3. When battery voltage is insufficient, the warning light will illuminate and the ABS will not work. In this condition, at the moment battery voltage increases to the specified level, the warning light will go off and the system will return to normal control. There will also be no diagnostic trouble code entries made to the control module memory.
 4. There are occasions when the ABS warning light does not go off when the ignition switch is turned to ON after repairs related to the ABS wheel speed sensor have been completed. If this should occur, drive the vehicle faster than 10 km/h { 6.2 MPH } and confirm that the service codes have been canceled after the ABS warning light has gone off.

Using This Section

Work flow



Diagnostic index

TROUBLESHOOTING ITEMS		DESCRIPTION	PAGE
No.	TROUBLE		
1	ABS warning light not illuminated when ignition switch turned ON	—	P-38
2	ABS warning light remains ON	ABS warning light remains ON, and ABS does not operate	P-39
3	ABS warning light goes off when vehicle started	ABS warning light goes off when vehicle started	P-39
		If IG SW turned ON again, ABS warning light goes off after a few seconds illumination	

No.:

Each troubleshooting item is assigned a number.

TROUBLESHOOTING ITEM:

There are 6 troubleshooting items. Choose the item indicated by the ABS warning light.

DESCRIPTION:

Describes details of the symptom.

PAGE:

Shows the reference page.

Symptom troubleshooting

1	ABS WARNING LIGHT NOT ILLUMINATED WHEN IGNITION SWITCH TURNED ON		
DESCRIPTION		—	
[TROUBLESHOOTING HINTS]			
<ul style="list-style-type: none"> • Malfunction of meter • Failed warning light or open in related wiring harness 			
STEP	INSPECTION	ACTION	
1	With IG ON, do other indicator illuminate?	Yes	Check if failure(s) is memorized Note and check it later if necessary Go to next step
		No	Inspect meter 15 A fuse
2		Yes	Go to next step
		No	Go to step 6

DESCRIPTION:

Further describes the system. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes an inspection procedure to quickly determine where the faulty parts are. If a detailed procedure is necessary to perform the INSPECTION, refer to the page specified by the "P" marks.

ACTION:

As a result of "Yes/No" answers given under INSPECTION, this section recommends the appropriate action to take. The "P" marks indicates the relevant reference page.


Diagnostic Index

TROUBLESHOOTING ITEMS		DESCRIPTION	PAGE
No.	TROUBLE		
1	ABS warning light not illuminated when IG SW turned ON	—	P-38
2	ABS warning light remains ON	ABS warning light remains ON, and ABS does not operate	P-39
3	ABS warning light flashes with vehicle stopped	ABS warning light goes off when vehicle started	P-39
4	ABS warning light illuminates during driving till IG SW turned OFF	If IG SW turned ON again, ABS warning light goes off after a few seconds illumination	P-40
5	ABS warning light illuminates/goes off with vehicle stopped and during driving	—	P-40
6	ABS warning light indicates normal, however ABS does not operate correctly	—	P-40

Diagnostic Chart

Symptom	Cause	ABS wheel-speed sensor	Brake switch	ABS hydraulic unit assembly				G sensor (4WD)	ABS warning light	Data link connector	Mechanical system	Power supply, ground
				Valve relay	Motor relay	Solenoid valve	ABS motor					
1	ABS warning light not illuminated when ignition switch turned ON							<input type="radio"/>				<input type="radio"/>
2	ABS warning light remains ON	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				<input type="radio"/>	<input type="radio"/>			<input type="radio"/>
3	ABS warning light flashes with vehicle stopped									<input type="radio"/>		<input type="radio"/>
4	ABS warning light illuminates during driving till IG SW turned OFF				<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				
5	ABS warning light illuminates/goes off with vehicle stopped and during driving								<input type="radio"/>			<input type="radio"/>
6	ABS warning light indicates normal, however, ABS does not operate correctly									<input type="radio"/>		

Symptom Troubleshooting

1	ABS WARNING LIGHT NOT ILLUMINATED WHEN IGNITION SWITCH TURNED ON		
DESCRIPTION	—		
[TROUBLESHOOTING HINTS]			
<ul style="list-style-type: none"> • Malfunction of meter • Failed warning light or open in related wiring harness 			
STEP	INSPECTION		ACTION
1	With IG ON, do other indicators illuminate?	Yes	Check if failure(s) is memorized Note and check it later if necessary Go to next step
		No	Inspect meter 15 A fuse
2	Disconnect ABS CM connector. Turn IG SW ON. Does ABS warning light illuminate?	Yes	Go to next step
		No	Go to step 6
3	Connect ABS CM connector. Turn IG SW ON. Does ABS warning light illuminate?	Yes	There was a temporarily poor contact in wiring harness or connector
		No	Go to next step
4	Is terminal AN of harness connector deformed?	Yes	Replace harness connector
		No	Replace ABS CM  page P-52
5	With ABS CM connector disconnected, ground terminal AN of harness connector Does ABS warning light illuminate?	Yes	Go to next step
		No	Go to step 7
6	With ABS CM connector disconnected, is there continuity between A and body GND?	Yes	Replace harness connector
		No	Repair harness
7	Is ABS warning light bulb burnt?	Yes	Replace bulb
		No	Go to next step
8	Is there continuity between AN of harness connector and 2l of meter?	Yes	Inspect meter
		No	Repair harness

Caution

- **Disconnecting and connecting the ABS CM connector must be done with the ignition switch OFF.**
- **When attaching the tester lead to the terminal of the harness connector, the SST must be used. (Refer to page P-41.)**
- **After above procedures have been completed, recheck for DTC and repair if necessary.**

Note

- If the above symptom has appeared in the past and it is normal at present, the possible cause is a temporarily poor contact in the wiring harness or connector. The ABS CM is normal.

2	ABS WARNING LIGHT REMAINS ON		
DESCRIPTION		—	
[TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> • Low battery voltage at ABS CM • Malfunction of ABS warning light harness (short to ground) • Malfunction of meter • ABS CM detects a failure 			
STEP	INSPECTION	ACTION	
1	Is battery voltage as specified?	Yes	Check if failure(s) is memorized and note it if necessary Go to next step
		No	Charge or replace if necessary
2	Verify that ABS CM connector is correctly connected. Turn IG SW ON. Does ABS warning light go off?	Yes	There was a temporarily poor contact in wiring harness or connector
		No	Go to next step
3	Disconnect ABS CM connector. Is voltage between D (voltage supply) and A (GND) terminals of harness connector at B+?	Yes	Go to next step
		No	Repair voltage supply harness
4	Are there any codes in step 1?	Yes	Follow diagnostic chart page P-37
		No	Go to next step
5	Disconnect ABS CM connector. Connect the SST (49 L066 001) and turn IG SW ON. Does ABS warning light go off?	Yes	Replace ABS CM page P-52
		No	Repair short of ABS warning light drive harness or meter

Caution

- **Disconnecting and connecting the ABS CM connector must be done with the ignition switch OFF.**
- **When attaching the tester lead to the terminal of the harness connector, the SST must be used. (Refer to page P-41.)**

Note



- If voltage between terminal D (voltage supply) and GND at ABS CM is below approx. 10 V, the ABS warning light will illuminate.


3	ABS WARNING LIGHT FLASHES WITH VEHICLE STOPPED		
DESCRIPTION		ABS warning light goes off when vehicle started	
[TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> • Terminal TBS at data link connector grounded • Low battery voltage at ABS CM 			
STEP	INSPECTION	ACTION	
1	Is battery voltage as specified?	Yes	Go to next step
		No	Charge or replace if necessary
2	Is there jumper wire between TBS and GND at data link connector?	Yes	Remove jumper wire
		No	Go to next step
3	Disconnect ABS CM connector. Is there continuity between terminal AD of harness connector and GND?	Yes	Repair TBS harness
		No	Replace ABS CM page P-52

Caution

- **Disconnecting and connecting the ABS CM connector must be done with the ignition switch OFF.**
- **When attaching the tester lead to the terminal of the harness connector, the SST must be used. (Refer to page P-41.)**


ANTILOCK BRAKE SYSTEM (ABS)


4	ABS WARNING LIGHT ILLUMINATED DURING DRIVING TILL IG SW TURNED OFF		
DESCRIPTION	If IG SW is turned ON again, ABS warning light goes off after illuminating for a few seconds		
[TROUBLESHOOTING HINTS]			
STEP	INSPECTION		ACTION
1	Activate OBD system and check for DTC. Are there any?	Yes	Read DTC and follow diagnostic chart  page P-37
		No	Go to next step
2	Verify that ABS CM connector is correctly connected. Drive vehicle and recheck for symptom. Does it remain?	Yes	Replace ABS CM  page P-52
		No	There was a temporarily poor contact in wiring harness or connector

5	ABS WARNING LIGHT ILLUMINATES/GOES OFF WITH VEHICLE STOPPED AND DURING DRIVING		
DESCRIPTION	—		
[TROUBLESHOOTING HINTS]			
<ul style="list-style-type: none"> • Low battery voltage at ABS CM • Malfunction of ground harness • Malfunction of ABS warning light harness (short to ground) • Malfunction of meter 			
STEP	INSPECTION		ACTION
1	Check if failure(s) is memorized. Note and check if later if necessary. Disconnect ABS CM connector. Turn IG SW ON. Does ABS warning light illuminate?	Yes	Go to next step
		No	Repair ABS warning light harness or meter
2	Disconnect ABS CM connector. Is voltage between D (voltage supply) and A (GND) terminals of harness connector at B+?	Yes	Go to next step
		No	Repair voltage supply or ground harness
3	Connect ABS CM connector. Drive vehicle and recheck for symptom. Does it remain?	Yes	Replace ABS CM  page P-52
		No	There was a temporarily poor contact in wiring harness or connector

Caution

- **Disconnecting and connecting the ABS CM connector must be done with the ignition switch OFF.**
- **When attaching the tester lead to the terminal of the harness connector, the SST must be used. (Refer to page P-41.)**

6	ABS WARNING LIGHT INDICATES NORMAL, HOWEVER, ABS DOES NOT OPERATE CORRECTLY		
DESCRIPTION	—		
[TROUBLESHOOTING HINTS]			
<ul style="list-style-type: none"> • Malfunction mechanical system 			
STEP	INSPECTION		ACTION
1	Activate OBD system and check for DTC. Are there any?	Yes	Read DTC and follow diagnostic chart  page P-37
		No	Inspect mechanical system




Inspection at ABS Control Module Harness Connector

Caution

- Disconnecting and connecting the ABS CM connector must be done with the ignition switch OFF.
- When checking the harness connector, the SST must be used.

1. Disconnect the ABS CM connector and connect the SST to the harness connector with the ignition switch OFF.
2. Attach the tester leads to the SST to check voltage, continuity or resistance, referring to the table below.

B+: Battery positive voltage



Terminal	Signal name	Connected to	Item	Condition	Specification	Possible cause
D	Power supply (system)	IG SW	Voltage	D—A (IG SW ON)	B+	Harness (IG SW — ABS CM connector)
				D—A (IG SW OFF)	0 V	
A	System ground	Ground point	Continuity	A—ground point	Yes	Harness (Each terminal — ground point)
				A—AN	Yes	Short plate of harness connector
V (W*) X	FR wheel speed	FR wheel-speed sensor	Voltage	V (W*)—X vehicle stopped	0 V (AC)	Harness (Sensor — ABS CM harness connector) Sensor, Installation condition
				V (W*)—X when turned 1 revolution per second	0.25—1.2 V (AC)	
			Resistance	V (W*)—X	1.6 ± 0.2 kΩ	
P Q	FL wheel speed	FL wheel-speed sensor	Voltage	P—Q vehicle stopped	0 V (AC)	Harness (Sensor — ABS CM harness connector) Sensor, Installation condition
				P—Q when turned 1 revolution per second	0.25—1.2 V (AC)	
			Resistance	P—Q	1.6 ± 0.2 kΩ	
T U	RR wheel speed	RR wheel-speed sensor	Voltage	T—U vehicle stopped	0 V (AC)	Harness (Sensor — ABS CM harness connector) Sensor, Installation condition
				T—U when turned 1 revolution per second	0.25—1.2 V (AC)	
			Resistance	T—U	1.6 ± 0.2 kΩ	
R S	RL wheel speed	RL wheel-speed sensor	Voltage	R—S vehicle stopped	0 V (AC)	Harness (Sensor — ABS CM harness connector) Sensor, Installation condition
				R—S when turned 1 revolution per second	0.25—1.2 V (AC)	
			Resistance	R—S	1.6 ± 0.2 kΩ	

*4WD

B+: Battery positive voltage

Terminal	Signal name	Connected to	Item	Condition	Specification	Possible cause
AD	On-board diagnosis TBS	Data link connector TBS	Continuity	AD—A	No	Harness (AD — TBS at DLC)
				AD—D (IG SW ON)	No	
				AD—TBS at DLC	Yes	
AC	On-board diagnosis FBS	Data link connector FBS	Continuity	AC—A	No	Harness (AC — FBS at DLC)
				AC—D (IG SW ON)	No	
				AC—FBS at DLC	Yes	
AN	Warning light	ABS warning light	Continuity	AN—A (IG SW OFF)	Yes	Harness (AN — meter, meter — IG SW) Meter
				AN—D (IG SW OFF)	No	
			Voltage	AN—A (IG SW ON)	B+	
AB	Brake switch	Brake switch	Voltage	When brake pedal depressed (IG SW ON)	B+	Harness (AV — brake sw) (when brake light normal) Brake switch
				When brake pedal released (IG SW ON)	0 V	
B	Motor (power supply)	Motor (power supply)	Voltage	B—A	B+	Harness (B — battery) ABS 60 A fuse
C	Solenoid valve (power supply)	Solenoid valve (power supply)	Voltage	C—A	B+	Harness (C — battery) ABS 20 A fuse
AF*	G sensor (power supply)	G sensor	Inspection not possible due to connection of connector end			—
H*	G sensor (ground)					
AG*	G sensor (signal)					

*4WD only

ON-BOARD DIAGNOSTIC FUNCTION



On-Board Diagnostic System

Inspection by diagnostic test mode


Outline

- The ABS control module contains an on-board diagnostic and memory functions to detect and indicate present and past failures.
Read and note the diagnostic indications by using the **SST**, and take action according to the Diagnostic Trouble Code Table. (Refer to page P-45.)
- The ABS CM has a nonvolatile memory. Diagnostic trouble codes are not erased if the battery is disconnected. The memory should be cleared when servicing is finished. (Refer to page P-44.)


Inspection using NGS




1. Connect the **SST** (NGS) to the data link connector and battery.
2. Set the **SST** (Super MECS Adapter) to ABS.



3. Select "VEHICLE & ENGINE SELECTION" on the **SST** (Control Unit) display, and then select the vehicle model, engine type, and model year.



4. Select "DIAGNOSTIC DATA LINK" on the **SST** (Control Unit) display.
5. Select "ANTI LOCK BRAKE MODULE" on the **SST** (Control Unit) display.



6. Select "DIAGNOSTIC TEST MODE" on the **SST** (Control Unit) display.
7. (1) If a trouble code is displayed, refer to the Diagnostic trouble code table (Refer to page P-47.) and inspect the appropriate system area.
(2) If "No codes received" is displayed, the system areas shown in the Diagnostic trouble code table are okay. Inspect another system area.

Memory cancel

The ABS control module has a nonvolatile memory. Diagnostic trouble codes are not erased if the battery is disconnected. The memory should be cleared when servicing is finished.

Diagnostic trouble codes memorized in the ABS control module are canceled by performing the following steps.

1. Connect the TBS terminal to GND at the data link connector.
2. Turn the ignition switch ON.
3. Output all memorized codes.
4. After verifying that the first code is repeated, depress the brake pedal 10 times at intervals of less than **one second (1 sec.)**.

Diagnostic trouble codes cannot be canceled if the following occur.

- If intervals of depressing the brake pedal exceed **one second (1 sec.)**.
- Brake switch has failed.

While performing the memory cancel operation, the ABS warning light is not illuminated.

When the memory cancel operation is completed, the ABS warning light comes on for **2—3 seconds**, then goes off.

After the memory is canceled, the ABS control module performs on-board diagnosis.

Diagnostic Trouble Code Table




DTC	Display on the NGS	Diagnosis system component		page
03*1	G SENSOR — OPEN OR SHORT, DEFECT	G sensor		P-46
05	BRAKE SW, MONITOR LINE — OPEN OR SHORT	Brake switch		P-46
11	WSS (RH-FRONT) — OPEN OR SHORT	FR	ABS wheel-speed sensor	P-46
12	WSS (LH-FRONT) — OPEN OR SHORT	FL		
13	WSS (RH-REAR) — OPEN OR SHORT	RR		
14	WSS (LH-REAR) — OPEN OR SHORT	RL		
15	WSS, SR — OPEN OR SHORT	One of the four wheel-speed sensors and sensor rotors		P-47
22	AV SOL, V (RH-FRONT) — OPEN OR SHORT	FR (AV)*2	Solenoid valve	P-47
23	EV SOL, V (RH-FRONT) — OPEN OR SHORT	FR (EV)*3		
24	AV SOL, V (LH-FRONT) — OPEN OR SHORT	FL (AV)*2		
25	EV SOL, V (LH-FRONT) — OPEN OR SHORT	FL (EV)*3		
26	AV SOL, V (REAR) — OPEN OR SHORT	R (AV)*2		
27	EV SOL, V (REAR) — OPEN OR SHORT	R (EV)*3		
41	WSS, SR (RH-FRONT) — MALFUNCTION, GND SHORT	FR	ABS wheel-speed sensor ABS sensor rotor	P-48
42	WSS, SR (LH-FRONT) — MALFUNCTION, GND SHORT	FL		
43	WSS, SR (RH-REAR) — MALFUNCTION, GND SHORT	RR		
44	WSS, SR (LH-REAR) — MALFUNCTION, GND SHORT	RL		
51	FAIL SAFE RELAY — OPEN OR HSORT	Valve relay		P-48
53	MOTOR, MOTOR RELAY — OPEN OR SHORT	ABS motor, motor relay		P-49
61	ABS CONTROL UNIT — DEFECT	ABS control module		P-49
63	POWER SUPPLY, GROUND — MALFUNCTION	Power supply, ground		P-49


*1 4WD only



*2AV: Pressure retention valve

*3EV: Pressure reduction valve

Diagnostic chart

Diagnostic trouble code No.03		G sensor	
Possible cause		<ul style="list-style-type: none"> • Malfunction of G sensor • Malfunction of related wiring harness 	
STEP	INSPECTION	ACTION	
1	Is ABS CM connector connected properly?	Yes	Go to next step
		No	Correct as necessary
2	Is G sensor OK?  page P-55	Yes	Repair harness
		No	Replace G sensor  page P-55
3	Erase diagnostic trouble code, and recheck for diagnostic trouble codes Is diagnostic trouble code 03 obtained?	Yes	Replace ABS CM  page P-52
		No	There was temporarily poor contact in wiring harness or connector

Diagnostic trouble code No.05		Brake switch	
Possible cause		<ul style="list-style-type: none"> • Malfunction of related wiring harness 	
STEP	INSPECTION	ACTION	
1	Inspect harness between brake light and ABS CM. • Open circuit Is harness normal?	Yes	Go to next step
		No	Repair harness
2	Erase diagnostic trouble code, and recheck for diagnostic trouble codes. Is diagnostic trouble code 05 obtained?	Yes	Replace ABS CM  page P-52
		No	There was temporarily poor contact in wiring harness or connector

Diagnostic trouble codes No.11—14		ABS wheel-speed sensor (11: Right front 12: Left front 13: Right rear 14: Left rear)	
Possible cause		<ul style="list-style-type: none"> • Malfunction of related wiring harness 	
STEP	INSPECTION	ACTION	
1	Is ABS CM connector connected properly?	Yes	Go to next step
		No	Correct as necessary
2	Is wiring harness between ABS CM and wheel-speed sensor OK?	Yes	Go to next step
		No	Repair harness
3	Is ABS wheel-speed sensor OK? Resistance: 1.4—1.8 kΩ Voltage: 0 V (AC) (When stopped)  page P-53	Yes	Go to next step
		No	Replace ABS wheel-speed sensor
4	Erase diagnostic trouble code, and recheck for diagnostic trouble codes. Is diagnostic trouble codes 11—14 obtained?	Yes	Replace ABS CM  page P-52
		No	There was temporarily poor contact in wiring harness or connector

Diagnostic trouble code No.15		ABS wheel-sensor, sensor rotor	
Possible cause		<ul style="list-style-type: none"> • There are missing or damaged teeth on sensor rotor • ABS wheel-speed sensor improperly installed • HU inoperable due to low pressure • Different size tires are used 	
STEP	INSPECTION		ACTION
1	Refer to Diagnostic trouble code 41—44 (step 3, 4, and 5) chart for each of the four wheel-speed sensors Is it OK?	Yes	Go to next step
		No	Inspect according to step for diagnostic trouble code 41—44
2	Inspect ABS HU assembly page P-51 Is ABS HU assembly and brake line OK?	Yes	Go to next step
		No	Replace ABS HU assembly or repair brake line
3	Repair malfunction, then erase diagnostic trouble code and recheck for diagnostic trouble codes after driving over 10 km/h { 6.2 MPH } Is diagnostic trouble code 15 obtained?	Yes	Replace ABS CM page P-52
		No	There was a temporarily poor contact in wiring harness or connector

Diagnostic trouble codes No.22—27		Solenoid valve (22: Right front AV 23: Right front EV 24: Left front AV 25: Left front EV 26: Rear AV 27: Rear EV)	
Possible cause		<ul style="list-style-type: none"> • Malfunction of solenoid valve • Malfunction of related wiring harness 	
STEP	INSPECTION		ACTION
1	Is ABS CM connector connected properly?	Yes	Go to next step
		No	Correct as necessary
2	Erase diagnostic trouble code, and recheck for diagnostic trouble codes. Are diagnostic trouble codes 22—27 obtained?	Yes	Replace ABS HU assembly page P-50
		No	There was temporarily poor contact in wiring harness or connector

Diagnostic trouble codes No.41—44		ABS wheel-speed sensor, sensor rotor (41: Right front 42: Left front 43: Right rear 44: Left rear)	
Possible cause		<ul style="list-style-type: none"> • Ground short in ABS wheel-speed sensor • There are missing or damaged teeth on sensor rotor • ABS wheel-speed sensor improperly installed 	
STEP	INSPECTION	ACTION	
1	Is ABS CM connector connected properly?	Yes	Go to next step
		No	Correct as necessary
2	Is wiring harness between ABS CM and wheel-speed sensor OK?	Yes	Go to next step
		No	Correct as necessary
3	Is ABS wheel-speed sensor (resistance) OK? Resistance: 1.4—1.8 kΩ 🔧 page P-53	Yes	Go to next step
		No	Replace ABS wheel-speed sensor 🔧 page P-53, 54
4	Is ABS wheel-speed sensor (output voltage) OK? Voltage: 0.25—1.2 V (AC) (When turned 1 revolution per second) 🔧 page P-53	Yes	Go to next step
		No	Adjust the sensor installation and/or the sensor clearance
5	Are there missing or damaged teeth on sensor rotor?	Yes	Replace sensor rotor
		No	Go to next step
6	Erase diagnostic trouble code, and recheck for diagnostic trouble codes after driving over 10 km/h { 6.2 MPH } Are diagnostic trouble codes 41—44 obtained?	Yes	Replace ABS CM 🔧 page P-52
		No	There was temporarily poor contact in wiring harness or connector

Note

- There are occasions when the ABS warning light does not go off. When the ignition switch is turned to ON after a short to ground malfunction has been repaired. If this should occur, drive the vehicle faster than 10 km/h { 6.2 MPH }, clean the service codes, and verify that the ABS warning light has gone out.

Diagnostic trouble code No.51		Valve relay	
Possible cause		<ul style="list-style-type: none"> • Malfunction of valve relay • Malfunction of related wiring harness 	
STEP	INSPECTION	ACTION	
1	Is ABS fuse (20 A) OK?	Yes	Go to next step
		No	Replace fuse
2	Erase diagnostic trouble code, and recheck for diagnostic trouble codes. Is diagnostic trouble code 51 obtained?	Yes	Replace ABS CM 🔧 page P-52
		No	Check C and D terminal (power supply) of ABS CM, A terminal (ground) harness, and for poor connector connections

Diagnostic trouble code No.53		ABS motor, motor relay	
Possible cause		<ul style="list-style-type: none"> • Malfunction of ABS motor or motor relay • Malfunction of related wiring harness 	
STEP	INSPECTION	ACTION	
1	With IG SW OFF, is motor operating?	Yes	Replace ABS HU assembly 📖 page P-50
		No	Go to next step
2	Is ABS fuse (60 A) OK?	Yes	Go to next step
		No	Replace fuse
3	Inspect ABS motor ground harness Is it OK?	Yes	Go to next step
		No	Correct harness as necessary
4	Erase diagnostic trouble code, and recheck for diagnostic trouble codes after driving over 10 km/h { 6.2 MPH } Is diagnostic trouble code 53 obtained?	Yes	Replace ABS CM 📖 page P-52
		No	Check B and D terminal (power supply) of ABS CM, A terminal (ground) harness, and for poor connector connections


Diagnostic trouble code No.61		ABS control module	
Possible cause		<ul style="list-style-type: none"> • Malfunction of ABS control module 	
STEP	INSPECTION	ACTION	
1	Is ABS CM connector connected properly?	Yes	Go to next step
		No	Correct as necessary
2	Erase diagnostic trouble code, and recheck for diagnostic trouble codes. Is diagnostic trouble code 61 obtained?	Yes	Replace ABS CM 📖 page P-52
		No	There was temporarily poor contact in wiring harness or connector

Diagnostic trouble code No.63		Power supply	
Possible cause		<ul style="list-style-type: none"> • Trouble in harness between ground and ABS HU assembly • Trouble in harness between battery and ABS HU assembly • Deleted battery 	
STEP	INSPECTION	ACTION	
1	Is battery terminal voltage OK?	Yes	Go to next step
		No	Charge or replace of battery
2	Is battery terminal connection OK? (When IG SW OFF)	Yes	Go to next step
		No	Tighten the battery terminal
3	Check connection of D terminal (power supply) and A terminal (ground) connector pins for ABS CM Is it OK?	Yes	Go to next step
		No	Repair ABS CM connector
4	Is voltage of ABS CM harness between D terminal (power supply) and A terminal (ground) 10—15 V when starting engine?	Yes	Go to next step
		No	Repair power supply harness or ground harness
5	Erase diagnostic trouble code, and recheck for diagnostic trouble codes after driving over 6 km/h { 3.7 MPH } Is diagnostic trouble code 63 obtained?	Yes	Replace ABS CM 📖 page P-52
		No	There was temporarily low battery voltage and battery capacity should be checked if this occurs frequently

ABS HYDRAULIC UNIT ASSEMBLY (ABS HU ASSEMBLY)

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Brake pipes
2. Connector
3. Nuts
4. Brake pipe connector


5. ABS hydraulic unit assembly
 Inspection (on-vehicle) page P-51
 Disassembly / Assembly page P-52
6. Bracket
7. Casing
8. Mount rubber

Disassembly / Assembly


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.

Caution

- If the ABS control module is malfunctioning or is not operating properly, replace it with a new one. The precision parts are easily damaged and if any repairs to the module is attempted, other malfunctions in the system may result.
- Do not replace the ABS control module outside in rainy weather or when the humidity is high. Moisture and high humidity have a negative effect on the precision parts which could become the cause of malfunctions in the system.



- 1. Bolts
 - 2. ABS control module
 - 3. ABS hydraulic unit
- Assembly Note Below



Assembly note
ABS control module

Caution


- Handle the ABS hydraulic unit carefully. If any of the precision parts are damaged, it may become the cause of malfunctions in the system.

1. Check that the two central connectors are securely connected, then install the ABS control module to the ABS hydraulic unit.
2. Tighten the bolts in the order shown in the figure.

ABS WHEEL-SPEED SENSOR (FRONT)


Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Connector
2. Bolt

3. ABS wheel-speed sensor
Inspection (on-vehicle) below



Inspection (on-vehicle)

Remove the wheel and tire, and inspect the sensor for looseness and damage. Replace the sensor if necessary.

Clearance inspection


Front

Check the clearance between the wheel-speed sensor and the sensor rotor.


Clearance: 0.5—1.3 mm { 0.0197—0.0512 in }

Rear

1. Remove the ABS wheel-speed sensor.
2. Measure ① and ② shown in the figure by using calipers.
3. Subtract ② from ①, then verify the clearance between the ABS wheel-speed sensor and the sensor rotor.




Clearance ①—②: 0.3—1.1 mm { 0.0119—0.0433 in }



Resistance of ABS wheel-speed sensor

1. Disconnect the ABS wheel-speed sensor connector.
2. Check the resistance at the ABS wheel-speed sensor.

Resistance: 1.4—1.8 kΩ



Voltage of ABS wheel-speed sensor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Disconnect the ABS wheel-speed sensor connector.
3. Check each wheel by rotating it at one revolution per second.


Voltage: 0.25—1.2 V (AC)

4. If not as specified, replace the ABS wheel-speed sensor or sensor rotor as necessary.

ABS WHEEL-SPEED SENSOR (REAR)

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N·m { kgf·m , ft·lbf }

1. Connector
2. Bolt

3. ABS wheel-speed sensor
 4. Bracket
- Inspection (on-vehicle) page P-53


G SENSOR (4WD)

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.


Caution

- Do not drop the G sensor or impose strong shock to it.




1. Connector
2. Nut

3. G sensor
Inspection below
4. Bracket




Inspection
G sensor

Turn the ignition switch to ON, then measure the voltage between the output terminal (b) and ground terminal (a) of the G sensor connector as shown on the following page.




(1) Level condition

Voltage: 2.4—2.6 V



(2) G sensor vertical (arrow up)

Voltage: 1.3—1.7 V



(3) G sensor vertical (arrow down)

Voltage: 3.3—3.7 V

If not as specified, replace the G sensor.

WHEELS AND TIRES

OUTLINE	Q-2
SPECIFICATIONS	Q-2
TROUBLESHOOTING GUIDE	Q-2
WHEELS AND TIRES	Q-3
SPECIAL NOTES ABOUT WHEELS AND TIRES	Q-3
NOTES REGARDING TIRE REPLACEMENT	Q-3
INSPECTION / ADJUSTMENT	Q-3
REMOVAL / INSTALLATION	Q-4
TIRE ROTATION	Q-5
WHEEL BALANCE ADJUSTMENT	Q-5

OUTLINE

SPECIFICATIONS

Standard tire

Item		Specification		
Wheel	Size	15×5 1/2JJ	15×6JJ	
	Offset	mm { in }	40 { 1.57 }	
	Pitch circle diameter	mm { in }	114.3 { 4.50 }	
	Material	Steel	Steel or Aluminum alloy	
Tire	Size	P195/75R15	P215/65R15	P215/70R15
	Air pressure	kPa { kgf/cm ² , psi }	240 { 2.4, 35 }	220 { 2.2, 32 }

Temporary spare tire

Item		Specification		
Wheel	Size	15×4T		
	Offset	mm { in }	45 { 1.77 }	
	Pitch circle diameter	mm { in }	114.3 { 4.50 }	
	Material	Steel		
Tire	Size	T135/70D15		
	Air pressure	kPa { kgf/cm ² , psi }	415 { 4.2, 60 }	

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Remedy	Page
Excessive or irregular tire wear	Refer to page Q- 4 for details.		
Premature tire wear	Incorrect tire pressure	Adjust	Q- 2
Tire squeal	Incorrect tire pressure	Adjust	Q- 2
	Tire deterioration	Replace	—
Road noise or body vibration	Insufficient tire pressure	Adjust	Q- 2
	Unbalanced wheel(s)	Adjust	Q- 5
	Deformed wheel(s) or tire(s)	Repair or replace	—
	Irregular tire wear	Replace	—
“Shake” occurs (Steering wheel vibrates up/down)	Excessive tire and wheel runout	Replace	—
	Loose lug nuts	Tighten	Q- 4
	Unbalanced wheel(s)	Adjust or replace	Q- 5
	Cracked or worn engine mount rubber	Replace	section B
	Cracked or worn transmission mount rubber	Replace	section K1
“Shimmy” occurs (Steering wheel vibrates circumferentially)	Cracked or worn steering gear mount rubber	Replace	section N
	Loose steering gear mounting bolts	Tighten	section N
	Stuck or damaged steering ball joint	Replace	section N
	Excessive tire and wheel runout	Replace	—
	Loose lug nuts	Tighten	Q- 4
	Unbalanced wheel(s)	Adjust or replace	Q- 5
	Insufficient tire pressure	Adjust	Q- 2
	Unevenly worn tires	Replace	—
	Malfunction of shock absorber	Replace	section R
	Loose shock absorber mounting bolts	Tighten	section R
	Struck or damaged lower arm ball joint	Replace	section R
	Cracked or worn suspension bushings	Replace	section R
	Damaged or worn front wheel bearing	Replace	section M
Improperly adjusted front wheel alignment	Adjust	section R	
Uneven (one-sided) braking	Unequal tire pressures	Adjust	Q- 2

Problem	Possible Cause	Remedy	Page
Steering wheel doesn't return properly or pulls to either left or right	Incorrect tire pressure	Adjust	Q- 2
	Irregular tire wear (left/right)	Replace	—
	Unequal tire pressures	Adjust	Q- 2
	Different types or brands of tires mixed (left/right)	Replace	—
	Loose lug nuts	Tighten	Q- 4
General driving instability	Unequal tire pressures	Adjust	Q- 2
	Damaged or unbalanced wheel(s)	Replace or adjust	Q- 5
	Loose lug nuts	Tighten	Q- 4
Excessive steering wheel play	Loose lug nuts	Tighten	Q- 4

WHEELS AND TIRES



SPECIAL NOTES ABOUT WHEELS AND TIRES

1. Do not use wheels or tires other than the specified types.
2. Aluminum wheels are easily scratched. When washing them, use a soft cloth, never a wire brush. If the vehicle is steam cleaned, do not allow boiling water to contact the wheels.
3. If alkaline compounds (such as saltwater or road salts) get on aluminum wheels, wash them as soon as possible to prevent damage. Use only a neutral detergent.

NOTES REGARDING TIRE REPLACEMENT

Note the following points when the tires are to be removed from or mounted onto the wheels.

1. Be careful not to damage the tire bead, the rim bead, or the edge of the rim.
2. Apply a soapy solution to the tire bead and the edge of the rim.
3. Use a wire brush, sandpaper, or cloth to clean and remove all rust and dirt from the rim edge and the rim bead. For aluminum wheels, use only a cloth for this purpose; never use a wire brush or sandpaper.
4. Remove any pebbles, glass, nails, and other foreign items embedded in the tire tread.
5. Be sure the air valve is installed correctly.
6. After mounting a tire onto a wheel, inflate the tire to **250—300 kPa { 2.55—3.06 kgf/cm², 36.27—43.51 psi }**. Check to be sure that the bead is seated correctly onto the rim and that there are no air leaks. Then reduce the pressure to the specified level.
7. If a tire iron is used to change a tire on an aluminum wheel, be sure to use a piece of rubber between the iron lever and the wheel to avoid damage to the wheel. Work should be done on a rubber mat, not on a hard or rough surface.




INSPECTION / ADJUSTMENT

Perform the following inspection and adjust or replace as necessary.

1. Air pressure
Check the air pressure of all tires when they are cold, including the spare tire, with an air pressure gauge. (Refer to page Q-2.)
2. Wheel runout
Set a dial indicator against the wheel. Turn the wheel one full revolution and check wheel runout.

**Wheel runout limit: Horizontal 2.0 mm { 0.079 in }
Vertical 1.5 mm { 0.059 in }**



3. Inspect for tire wear

Specifications


Remaining tread

Ordinary tires: 1.6 mm { 0.063 in } min.

(Tire should be replaced if wear indicators are exposed.)

Snow tires: 50% of tread


(Tire should be replaced if wear indicators are exposed.)



Troubleshooting guide

Abnormal tire wear patterns shown in the illustration can occur. Refer to the chart for the possible causes and remedies.


	Possible cause	Remedy
(a)	<ul style="list-style-type: none"> ● Underinflation (both sides worn) ● Incorrect camber (one side worn) ● Hard cornering ● Lack of rotation 	<ul style="list-style-type: none"> ● Measure and adjust pressure ● Repair or replace axle and suspension parts ● Reduce speed ● Rotate tires
(b)	<ul style="list-style-type: none"> ● Overinflation ● Lack of rotation 	<ul style="list-style-type: none"> ● Measure and adjust pressure ● Rotate tires
(c)	<ul style="list-style-type: none"> ● Incorrect toe-in 	<ul style="list-style-type: none"> ● Adjust toe-in
(d)	<ul style="list-style-type: none"> ● Incorrect camber or caster ● Malfunctioning suspension ● Unbalanced wheel ● Out-of-round brake drum or disc ● Other mechanical conditions ● Lack of rotation 	<ul style="list-style-type: none"> ● Repair or replace axle and suspension parts ● Repair or replace ● Balance or replace ● Correct or replace ● Correct or replace ● Rotate tires



4. Cracks, damage, or foreign materials (such as metal pieces, nails, and stones) in the tire and cracks, deformation, and damage to the wheel

5. Loose wheel lug nut(s)

6. Air leaking from the valve stem



REMOVAL / INSTALLATION


After making sure that the wheel-to-hub contact surfaces are clean. Tighten the lug nuts to the specified torque in a crisscross pattern.

Tightening torque:

89—117 N·m { 9—12 kgf·m , 66—86 ft·lbf }


Caution

- Applying oil to the lug nuts, studs, or wheels will cause the lug nuts to become loosened.



TIRE ROTATION

To prolong tire life and assure uniform tire wear, rotate all tires except the “TEMPORARY USE ONLY” spare tire. For U.S.A., rotate the tires every 3,750 miles { 6,000 km } or 15 months. For Canada, rotate the tires every 15,000 miles { 24,000 km } or 15 months. After rotating the tires, adjust each to the specified air pressure. (Refer to page Q-2.)




WHEEL BALANCE ADJUSTMENT

If a wheel has become unbalanced or if a tire has been repaired or replaced, rebalance the wheel.

Maximum unbalance at rim edge: 10 g { 0.35 oz }

When balancing a wheel:

- (1) Use no more than two balance weights on the inner or outer side of the wheel.
- (2) One balance weight; max. 60 g { 2.1 oz }
- (3) If the total weight of all the balance weights on one side exceeds 100 g { 3.53 oz }, then rebalance after repositioning the tire on the rim.
- (4) Attach the balance weights tightly so that they do not protrude more than 3 mm { 0.12 in } beyond the wheel edge.
- (5) Select suitable balance weights for steel or aluminum alloy wheels.



Caution

- **Using an on-vehicle balance may cause damage to the transmission. Always use an off-vehicle balancer whenever balancing a wheel.**



Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.


SUSPENSION

INDEX	R- 2
OUTLINE	R- 5
SPECIFICATIONS	R- 5
TROUBLESHOOTING GUIDE	R- 6
WHEEL ALIGNMENT	R- 7
PRE-INSPECTION	R- 7
FRONT WHEEL ALIGNMENT	R- 7
FRONT SUSPENSION (STRUT)	R- 8
PREPARATION	R- 8
FRONT SHOCK ABSORBER AND SPRING	R-10
COMPRESSION ROD (2WD)	R-15
FRONT LOWER ARM (2WD)	R-16
FRONT LOWER ARM (4WD)	R-18
FRONT STABILIZER	R-22
CROSSMEMBER	R-23
REAR SUSPENSION (5-LINK)	R-24
REAR STABILIZER	R-24
REAR SHOCK ABSORBER AND SPRING	R-26
UPPER LINK, LOWER LINK, AND LATERAL ROD	R-28
AUTOMATIC LOAD LEVELING (ALL)	R-29
PREPARATION	R-29
DESCRIPTION	R-30
TROUBLESHOOTING GUIDE	R-31
TROUBLESHOOTING MAIN FLOWCHART	R-33
AIR PIPE	R-36
ALL CONTROL MODULE	R-38
HEIGHT SENSOR	R-40
REAR SHOCK ABSORBER	R-41
COMPRESSOR ASSEMBLY	R-42
COMPRESSOR RELAY	R-43

INDEX

FRONT SUSPENSION

2WD



FRONT WHEEL ALIGNMENT

TOTAL TOE-IN: 4 ± 4 mm { 0.16 ± 0.15 in , $0.4^\circ \pm 0.4^\circ$ }

MAXIMUM STEERING ANGLE: $40^\circ 45' \pm 2^\circ$ (INNER)

$31^\circ 50' \pm 2^\circ$ (OUTER)


CAMBER ANGLE: $0^\circ 22' \pm 1^\circ$

CASTER ANGLE: RIGHT SIDE: $5^\circ 27' \pm 1^\circ$

LEFT SIDE: $4^\circ 57' \pm 1^\circ$

STEERING AXIS INCLINATION: $12^\circ 56'$

4WD



FRONT WHEEL ALIGNMENT

TOTAL TOE-IN: 4 ± 4 mm { 0.16 ± 0.15 in , $0.4^\circ \pm 0.4^\circ$ }

MAXIMUM STEERING ANGLE: $33^\circ 50' \pm 2^\circ$ (INNER)

$31^\circ 03' \pm 2^\circ$ (OUTER)

CAMBER ANGLE: $0^\circ 10' \pm 1^\circ$


CASTER ANGLE: RIGHT SIDE: $5^\circ 31' \pm 1^\circ$

LEFT SIDE: $5^\circ 01' \pm 1^\circ$

STEERING AXIS INCLINATION: $11^\circ 48'$

- | | |
|------------------------------------|-----------|
| 1. Front wheel alignment | |
| Specifications | page R- 7 |
| Adjustments | page R- 7 |
| 2. Front shock absorber and spring | |
| Removal / Installation | page R-10 |
| Disassembly / Inspection | page R-11 |
| Assembly | page R-12 |
| 3. Compression rod (2WD) | |
| Removal / Inspection / | |
| Installation | page R-15 |
| 4. Front lower arm (2WD) | |
| Removal / Inspection / | |
| Installation | page R-16 |
| 5. Front lower arm (4WD) | |
| Removal / Inspection / | |
| Installation | page R-18 |
| 6. Front stabilizer | |
| Removal / Inspection / | |
| Installation | page R-22 |
| 7. Crossmember | |
| Inspection | page R-23 |

REAR SUSPENSION




R

- 1. Rear stabilizer
Removal / Inspection /
Installation page R-24
- 2. Rear shock absorber and spring
Removal / Inspection /
Installation page R-26

- 3. Upper link, lower link, and lateral rod
Removal / Inspection /
Installation page R-28

AUTOMATIC LOAD LEVELING (ALL)



- | | |
|---|---|
| <p>1. Air pipe
 Inspection page R-36
 Replacement page R-37</p> <p>2. ALL control module
 Inspection page R-38</p> <p>3. Height sensor
 Inspection page R-40
 Replacement page R-40
 Adjustment page R-40</p> <p>4. Rear shock absorber
 Inspection page R-41
 Removal / Inspection /
 Installation page R-26</p> | <p>5. Compressor assembly
 Removal / Installation page R-42
 Inspection page R-42</p> <p>6. Compressor relay
 Inspection page R-43</p> <p>7. Door switch
 Inspection section T</p> <p>8. Vehicle speed sensor
 Inspection section T</p> |
|---|---|

OUTLINE

SPECIFICATIONS

Item		Specification		
Front suspension				
Type		Strut		
Stabilizer	Type	Torsion bar		
	Diameter	mm { in }	2WD: 34.0 { 1.34 } 4WD: 24.0 { 0.94 }	
Shock absorbers		Double-acting, oil-filled		
Rear suspension				
Type		5-link		
Stabilizer	Type	Torsion bar		
	Diameter	mm { in }	2WD: 24.0 { 0.94 } 4WD: 26.0 { 1.02 }	
Shock absorbers	Standard suspension	Double-acting, oil-filled		
	Automatic load leveling equipped	Double-acting, oil-filled with air diaphragm		
Wheel alignment				
Front wheel alignment (Unladen) *1	Total toe-in	mm { in }	4 ± 4 { 0.16 ± 0.15 }	
		degree	0.4 ° ± 0.4 °	
	Maximum steering angle	Inner	2WD: 40°45' ± 2°	4WD: 33°50' ± 2°
		Outer	2WD: 31°50' ± 2°	4WD: 31°03' ± 2°
	Camber angle*2		2WD: 0°22' ± 1°	4WD: 0°10' ± 1°
	Caster angle*2	Right side	2WD: 5°27' ± 1°	4WD: 5°31' ± 1°
		Left side	2WD: 4°57' ± 1°	4WD: 5°01' ± 1°
	Steering axis inclination		2WD: 12°56'	4WD: 11°48'

*1 Fuel tank full; radiator coolant and engine oil at specified level; spare tire, jack, and tools in designated position. Adjust to the median when carrying out wheel alignment.

*2 Difference between left and right must not exceed 1.5°.

TROUBLESHOOTING GUIDE

Problem	Possible cause	Remedy	Page
General instability	Weak coil springs Malfunction of shock absorber Worn or deteriorated lower arm or stabilizer bushing Worn or damaged lower arm ball joint Improperly adjusted front wheel alignment Worn or deteriorated fluid-enclosed bushing Worn or deteriorated lateral rod bushing Looseness of upper or lower link Worn or deteriorated upper or lower link bushing Deformation or damage of upper or lower link	Replace Replace Replace Replace Adjust Replace Replace Tighten Replace Replace	R-11, 26 R-10, 26 R-16, 18, 22, 24 R-16, 18 R- 7 R-15 R-28 R-28 R-28 R-28
Body "rolls"	Weak stabilizer Worn or deteriorated stabilizer, lower link, upper link, or lateral rod bushing	Replace Replace	R-22, 24 R-22, 24, 26
"Heavy" steering wheel operation	Insufficiently lubricated or stuck lower arm ball joint Worn or damaged strut bearing Improperly adjusted front wheel alignment	Replace Replace Adjust	R-16, 18 R-11 R- 7
Steering wheel pulls to one side	Weak coil spring Worn or damaged lower arm or stabilizer bushing Deformed lower arm or knuckle Loosen lower arm bushing	Replace Replace Replace Replace	R-11, 26 R-20, 22, 24 R-16, 18 R-16, 18
Excessive steering wheel play	Worn or damaged lower arm bushing Worn or damaged lower arm ball joint	Replace Replace	R-16, 18 R-16, 18
Body leans	Weak coil spring Weak stabilizer or lower arm bushing	Replace Replace	R-11, 26 R-16, 18, 22, 24
Abnormal noise from suspension system	Loose mounting component Poorly lubricated or worn lower arm ball joint Malfunction of shock absorber Worn or deteriorated stabilizer or suspension arm bushing Worn or damaged front strut bearing	Tighten Replace Replace Replace Replace	— R-16, 18 R-10, 26 R-15, 16, 18, 22, 24 R-11
"Shake" occurs (Steering wheel vibrates up/down)	Excessive tire and wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mount rubber Cracked or worn transmission mount rubber	Replace Tighten Adjust or replace Replace Replace	— section Q section Q section B section K1
"Shimmy" occurs (Steering wheel vibrates circumferentially)	Cracked or worn steering gear mount rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire and wheel runout Loose lug nuts Unbalanced wheel(s) Insufficient tire pressure Unevenly worn tires Malfunction of shock absorber Loose shock absorber mounting bolts Stuck or damaged lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Replace Replace Replace Replace Adjust	section N section N section N — section Q section Q section Q section Q R-10 R-10 R-16, 18 R-15, 16, 18, 26 section M R-7

WHEEL ALIGNMENT


PRE-INSPECTION

1. Check the tire inflations and set to the recommended pressure if necessary.
2. Inspect the front wheel bearing play and correct if necessary.
3. Inspect the wheel and tire runout.
4. Inspect the ball joints and steering linkage for any excessive looseness.
5. The vehicle must be on level ground and have no luggage or passenger load.
6. The difference in height between the left and right sides from the center of the wheel to the fender brim must not exceed **15 mm { 0.59 in }**.

FRONT WHEEL ALIGNMENT
Specifications

Item	Specification						
	2WD			4WD			
Front wheel alignment (Unladen)*1							
Total toe-in	mm { in }	4 ± 4 { 0.16 ± 0.16 }					
	degree	0.4° ± 0.4°					
Maximum steering angle	Inner	40°45' ± 2°			33°50' ± 2°		
	Outer	31°50' ± 2°			31°03' ± 2°		
Steering axis inclination	12°56'			11°48'			
Fuel gauge indication		Full	1/2	Empty	Full	1/2	Empty
Camber angle*2	Right side	0°22' ± 1°	0°25' ± 1°	0°28' ± 1°	0°10' ± 1°	0°13' ± 1°	0°16' ± 1°
	Left side	0°22' ± 1°	0°23' ± 1°	0°24' ± 1°	0°10' ± 1°	0°11' ± 1°	0°12' ± 1°
Caster angle*2	Right side	5°27' ± 1°	5°24' ± 1°	5°21' ± 1°	5°31' ± 1°	5°28' ± 1°	5°24' ± 1°
	Left side	4°57' ± 1°	4°56' ± 1°	4°54' ± 1°	5°01' ± 1°	5°00' ± 1°	4°58' ± 1°

*1 Radiator coolant and engine oil at specified level; spare tire, jack, and tools in designated position. Adjust to the median when carrying out wheel alignment.
*2 Difference between left and right must not exceed 1.5°.



Adjustments
Total toe-in

1. Adjust the steering angle.
2. Remove the steering gear boot clamp.
3. Loosen the left and right tie rod locknuts and turn the tie rods equally. Both tie rods are right-threaded, so turning the right tie rod toward the front of the vehicle and the left toward the rear increases toe-in.


Note

- Turning both tie rods one complete turn changes toe-in by about 14.4 mm { 0.57 in }.

4. Tighten the tie rod locknuts to the specified torque.

Tightening torque:

69—78 N·m { 7.0—8.0 kgf·m , 51—57 ft·lbf }



Camber and caster


1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the nuts that hold the mounting block to the fender.
3. Push the mounting block downward, and turn it to the desired position.
4. Retighten the nuts to the specified torque.

Tightening torque:

47—62 N·m { 4.7—6.4 kgf·m , 34—46 ft·lbf }

Note

- Changing the position of the mounting block changes the camber and caster about 26'.



Right side

Mark	Difference from standard position	
	Camber angle	Caster angle
A	0°	+26'
B	+26'	+26'
C	+26'	0°

Left side

Mark	Difference from standard position	
	Camber angle	Caster angle
A	+26'	0°
B	+26'	-26'
C	0°	-26'

FRONT SUSPENSION (STRUT)



















PREPARATION

SST



49 0180 510B Attachment, preload measuring		For inspection of ball joint preload	49 T028 3A0 Puller set, ball joint		For removal of lower arm
49 S120 785 Installer, dust boot		For installation of dust boot	49 0223 640B Arm, coil spring compressor		For disassembly and assembly of shock absorber and spring
49 G030 641 Screw		For disassembly and assembly of shock absorber and spring	49 H028 2A0 Replacer set, rubber bush		For removal and installation of crossmember bushing

FRONT SUSPENSION (STRUT)

R

<p>49 H028 201</p> <p>Shaft (Part of 49 H028 2A0)</p>		<p>For removal and installation of crossmember bushing</p>	<p>49 H028 202</p> <p>Block L (Part of 49 H028 2A0)</p>	 <p>For removal of crossmember bushing</p>
<p>49 H028 203</p> <p>Block S (Part of 49 H028 2A0)</p>		<p>For installation of crossmember bushing</p>	<p>49 W034 305</p> <p>Bearing (Part of 49 H028 2A0)</p>	 <p>For removal and installation of crossmember bushing</p>
<p>49 T028 303</p> <p>Body (Part of 49 T028 3A0)</p>		<p>For removal of lower arm</p>	<p>49 U034 2A0</p> <p>Lower arm bushing puller & installer</p>	 <p>For installation of lower arm bushing</p>
<p>49 U034 202</p> <p>Support block (Part of 49 U034 2A0)</p>		<p>For installation of lower arm bushing</p>	<p>49 D033 1A0</p> <p>Puller, wheel hub</p>	 <p>For removal and installation of lower arm bushing</p>
<p>49 G033 102</p> <p>Handle (Part of 49 D033 1A0)</p>		<p>For removal and installation of lower arm bushing</p>	<p>49 F027 0A1</p> <p>Installer set, bearing</p>	 <p>For removal and installation of lower arm bushing</p>
<p>49 F027 009</p> <p>Attachment 68 & 77 (Part of 49 F027 0A1)</p>		<p>For removal and installation of lower arm bushing</p>	<p>49 G026 103</p> <p>Support block</p>	 <p>For removal and installation of lower arm bushing</p>
<p>49 T034 1A0</p> <p>Compressor, coil spring</p>		<p>For disassembly and assembly of shock absorber and spring</p>	<p>49 T034 101</p> <p>Compressor, spring (Part of 49 T034 1A0)</p>	 <p>For disassembly and assembly of shock absorber and spring</p>
<p>49 T034 102</p> <p>Stand (Part of 49 T034 1A0)</p>		<p>For disassembly and assembly of shock absorber and spring</p>	<p>49 T034 103</p> <p>Hook (Part of 49 T034 1A0)</p>	 <p>For disassembly and assembly of shock absorber and spring</p>
<p>49 T034 104</p> <p>Support (Part of 49 T034 1A0)</p>		<p>For disassembly and assembly of shock absorber and spring</p>	<p>49 T034 105</p> <p>Attachment</p>	 <p>For disassembly and assembly of shock absorber and spring</p>


R

<p>49 0107 680A</p> <p>Engine stand</p> 	<p>For disassembly and assembly of shock absorber</p>	<p>49 T028 304</p> <p>Attachment (Part of 49 T028 3A0)</p> 	<p>For removal of lower arm</p>
---	---	--	---------------------------------

FRONT SHOCK ABSORBER AND SPRING


Removal / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Inspect the front wheel alignment and adjust it if necessary. (Refer to page R-7.)



1. Wheel and tire
2. Hose clip
3. Bolt and nut
4. Rubber cap
5. Nut

6. Shock absorber assembly
 - Installation Note page R-11
 - Disassembly / Inspection page R-11
 - Assembly page R-12




Installation note

Shock absorber assembly

Install the mounting block to the suspension tower with the white mark on the mounting block face as shown in the figure.


Disassembly / Inspection

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all components and parts. Replace parts if necessary.



1. Nut
Disassembly Note page R-12
2. Mounting block
3. Spring upper seat
4. Spring seat

5. Coil spring
6. Bump stopper
7. Ring rubber
8. Shock absorber
Inspect for oil leakage or abnormal noise



Disassembly note

Nut

Warning



- Removing the piston-rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SST before removing the piston-rod nut.

When using 49 0223 640B and 49 G030 641

1. Loosen the piston rod upper nut several turns, but do not remove it.
2. Compress the coil spring with the SST, then remove the nut.
3. Remove the coil spring.

When using 49 T034 1A0


1. Secure the mounting block in a vise.
2. Loosen the nut several turns, but do not remove it.
3. Assemble the SST.
4. Secure the shock absorber in the SST.
5. Compress the coil spring by using the SST and remove the nut.




Assembly

When using 49 0223 640B and 49 G030 641


1. Secure the shock absorber in a vise.
2. Apply rubber grease to the ring rubber and install it onto the bump stopper.
3. Install the bump stopper in the shock absorber as shown in the figure.



4. Install the compressed coil spring (compressed with the SST).
5. Install the spring seat.



6. Install the spring upper seat so that the flat part of the shock absorber rod fits into the upper seat as shown.
7. Install the mounting block.
8. Loosely tighten the piston rod upper nut.
9. Remove the **SST**.




10. Secure the spring upper seat in a vise.
11. Tighten the piston rod upper nut.

Tightening torque:


64—80 N·m { 6.5—8.2 kgf·m , 48—59 ft·lbf }

12. Verify that the spring is well seated.




When using 49 T034 1A0


1. Temporarily assemble the spring upper seat, spring seat, and coil spring to the shock absorber so that the flat part of the shock absorber rod fits into the upper seat as shown.
2. Mark the upper spring seat and coil spring for proper reassembly.




3. Align the marks of the upper spring seat and coil spring. Protect the upper spring seat and the coil spring with a piece of cloth, then assemble the **SST**.
4. Use the **SST** to compress the spring.



5. Apply rubber grease to the ring rubber and install it onto the bump stopper.
6. Install the bump stopper in the shock absorber as shown in the figure.



7. Install the shock absorber so that the flat part of the shock absorber rod fits into the upper seat as shown.
8. Install the mounting block.
9. Hand-tighten the piston rod nut.
10. Remove the **SST**.



11. Secure the spring upper seat in a vise.
12. Tighten the piston rod upper nut.

Tightening torque:


64—80 N·m { 6.5—8.2 kgf·m , 48—59 ft·lbf }

13. Verify that the spring is well seated.

COMPRESSION ROD (2WD)

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Inspect all components and parts. Replace parts if necessary.
4. With the vehicle unloaded, tighten the compression rod nut to the specified torque.
5. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Nut
Left side: left-threaded
Right side: right-threaded 2. Stabilizer bolt and nuts
Installation Note page R-23 3. Retainer 4. Rubber bushing 5. Spacer | <ol style="list-style-type: none"> 6. Bolt 7. Bolt 8. Washer 9. Fluid-enclosed rubber bushing
Inspect for deterioration, wear, or fluid leakage 10. Compression rod
Inspect for damage |
|--|---|


FRONT LOWER ARM (2WD)

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all components and parts, and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Lower the vehicle and tighten the lower arm fasteners to the specified torque.




- | | |
|------------------------------|-----------|
| 1. Wheel and tire | |
| 2. Caliper assembly | |
| Removal Note | below |
| 3. Compression rod | |
| Removal / Installation | page R-15 |
| 4. Tie-rod end | |
| Service | section N |
| 5. Bolt and nut | |
| 6. Lower arm ball joint | |
| Removal Note | page R-17 |
| Inspection | page R-17 |
| 7. Bolt and nut | |
| 8. Lower arm | |
| 9. Dust boot | |
| Removal Note | page R-17 |
| Installation Note | page R-17 |



Removal note

Caliper assembly


Remove the front disc caliper assembly and hang it from the shock absorber.

**Lower arm ball joint**

1. Remove the cotter pin and nut.
2. Separate the ball joint from the knuckle by using the **SST**.

Dust boot

Remove the dust boot by using a chisel.

**Inspection****Lower arm ball joint**

Check for the following and if necessary replace the lower arm assembly.

1. Lower arm for damage or cracks
2. Bushing for deterioration or wear
3. Damage or poor operation of the ball joint
4. Rotation torque of ball joint

Measurement of ball joint rotation torque


Move the ball joint stud back and forth a few times, then attach the **SST** to the stud and measure the preload by using a pull scale.

Rotation torque:

2.0—3.4 N·m { 20—35 kgf·cm , 18—30 in·lbf }

Pull-scale reading:

20—34 N { 2.0—3.5 kgf , 4.4—7.7 lbf }


**Installation note****Dust boot**

1. Liberally coat the inside of the new dust boot with grease (lithium base, NLGI No.2).
2. Press the dust boot onto the ball joint by using the **SST**.

FRONT LOWER ARM (4WD)


Removal / Inspection / Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it on safety stands.
3. Remove the wheel and tire.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Inspect all parts and repair or replace as necessary.
6. Install in the reverse order of removal, referring to **Installation Note**.
7. Lower the vehicle and tighten the lower arm fasteners to the specified torque.



1. Stabilizer bolt and nuts
Installation Note page R-20
2. Retainer, bushing, and spacer
3. Cotter pin
4. Nut
5. Bolt
6. Nut and washer
7. Bolt
8. Nut and washer
9. Bolt
10. Nut and washer
11. Bolt and washer


12. Lower arm ball joint
Removal Note page R-19
Inspection page R-21
13. Dust boot
Removal Note page R-19
Installation Note page R-20
14. Rubber washer
15. Bushing (Front)
Removal Note page R-19
Installation Note page R-20
16. Bushing (Rear)
Removal Note page R-19
Installation Note page R-20
17. Lower arm



Removal note


Lower arm ball joint

1. Remove the cotter pin and nut.
2. Separate the ball joint from the knuckle by using the **SST**.




Dust boot

1. Secure the ball joint in a vise protected with brass pads.
2. Place a chisel against the boot and hold it at the angle shown.
3. Remove the boot by tapping with a hammer.




Bushing (front)

1. Secure the lower arm in a vise protected with brass pads.
2. Cut the rim section of the lower arm bushing.




3. Remove the lower arm bushing from the lower arm by using the **SST** and a press.




Bushing (rear)


Remove the lower arm bushing from the lower arm by using the **SST** and a press.

**Installation note****Bushing (front)**


1. Apply soapy water to the outside of the new bushing surface.
2. Install the bushing into the lower arm by using the **SST** and a press.

**Bushing (rear)**


1. Set a new bushing in the lower arm with the direction marks (arrows) on the bushing aligned with the marks on the lower arm.




2. Install the new bushing into the lower arm by using the **SST** and a press.

**Dust boot**

1. Liberally coat the inside of the new dust boot with grease (lithium base, NLGI No.2).
2. Press the dust boot onto the ball joint by using the **SST**.

**Stabilizer bolt and nuts**

Tighten the stabilizer nuts so that 5—7 mm { 0.20—0.28 in } of thread is exposed at the end of the bolt.

**Inspection****Lower arm ball joint**

Do the following inspection and replace lower arm ball joint as necessary.

1. Inspect for damage and poor operation of the ball joint.
2. Move the ball joint stud back and forth a few times, then attach the **SST** to the stud and measure the preload by using a pull scale.

Rotation torque:

2.0—3.4 N·m { 20—35 kgf·cm , 18—30 in·lbf }


Pull scale reading:

20—34 N { 2.0—3.5 kgf , 4.4—7.7 lbf }


FRONT STABILIZER

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Inspect all components and parts. Replace parts if necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Undercover 2. Stabilizer bolt and nuts
Installation Note (2WD) page R-23
Installation Note (4WD) page R-20 3. Retainer
Inspect for bending or damage 4. Rubber bushing
Inspect for deterioration or wear | <ol style="list-style-type: none"> 5. Spacer
Inspect for bending or damage 6. Stabilizer bushing and bracket
Installation Note below 7. Stabilizer
Inspect for bending or damage |
|--|---|




Installation note

Stabilizer bushing and bracket

1. Install the bushing.
2. Align the bushing with the stabilizer installation mark.
3. Install with the stabilizer brackets and hand-tighten the bolts.
4. Lower the vehicle, then tighten the bolts to the specified torque with the vehicle unloaded.


Tightening torque

2WD: 51—60 N-m { 5.1—6.2 kgf-m , 37—44 ft-lbf }
4WD: 19—25 N-m { 1.9—2.6 kgf-m , 14—18 ft-lbf }



Stabilizer bolt and nuts (2WD)

Tighten the nut so that 9—11 mm { 0.35—0.43 in } of thread is exposed at the top of the bolt.




CROSSMEMBER

Inspection

Check for the following and replace parts as necessary.


1. Crossmember for bending or damage.
2. Rubber bushings for damage.



Replacement of Crossmember Bushing


Removal

1. Set the **SST** on the crossmember.
2. Remove the rubber bushing.



Installation

Apply soapy water to the new bushing, then press it into the crossmember by using the **SST**.



Crossmember Stay

Inspection

Inspect for bending and damage, and replace as necessary.

Replacement

Remove the bolts and replace the crossmember stay.

Tightening torque:


65—81 N·m { 6.6—8.3 kgf·m , 48—60 ft·lbf }

REAR SUSPENSION (5-LINK)


REAR STABILIZER

Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Inspect all components and parts.
4. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Stabilizer bolt and nuts
Installation Note page R-25 2. Retainer
Inspect for bending or damage 3. Rubber bushing
Inspect for deterioration or wear | <ol style="list-style-type: none"> 4. Spacer
Inspect for bending or damage 5. Stabilizer bushing and bracket
Installation note below 6. Stabilizer
Inspect for bending or damage |
|---|---|




Installation note

Stabilizer bushing and bracket

1. Install the bushing.
2. Align the bushing with the stabilizer installation mark.
3. Install with the stabilizer brackets and hand-tighten the bolts.
4. Lower the vehicle, then tighten the bolts to the specified torque with the vehicle unloaded.

Tightening torque:

35—50 N·m { 3.5—5.2 kgf·m , 26—37 ft·lbf }


**Stabilizer bolt and nuts**

Tighten the nuts so that **6—8 mm { 0.24—0.31 in }** of thread is exposed at the top of the bolt.

REAR SHOCK ABSORBER AND SPRING


Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. For vehicles with ALL, remove the height sensor.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all components and parts. Replace parts if necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten the shock absorber bolts to just under the specified torque.
7. Lower the vehicle.
8. With the vehicle unloaded, tighten the shock absorber bolts to the specified torque.




- 1. Splash shield
- 2. Stabilizer
Removal / Inspection /
Installation page R-24
- 3. Nut (ALL model)
Installation Note page R-27
- 4. Bolt
- 5. Bolt, nuts, and washers
- 6. Shock absorber
Removal Note page R-27
Inspect for oil leakage or abnormal noise

- 7. Coil spring
Installation Note page R-27
Inspect for degeneration, cracking, or
damage
- 8. Bolt
- 9. Bump stopper
- 10. Spring seat



Removal note
Shock absorber


1. Support the lower part of the shock absorber on a jack, and then raise the jack as necessary to lighten the load on the shock absorber.
2. Remove the shock absorber.



Installation note

Coil spring

Be sure that the larger diameter coil of the coil spring faces the axle case.




Nut (All model)

1. Install the nut.
2. Verify that the height sensor link is installed in the proper direction as shown.


UPPER LINK, LOWER LINK, AND LATERAL ROD

Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Inspect the links for bending or damage and the rubber bushings for deterioration or wear. Replace the link assembly if a problem is found.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Tighten all nuts and bolts to just under the specified torque, and then tighten to the specified torque after removing the safety stands and lowering the vehicle.



- | | |
|-------------------------------|---------------|
| 1. Lateral rod | 2. Upper link |
| Installation Note below | 3. Lower link |







Installation note

Lateral rod

Install the lateral rod with the mark toward the body.


AUTOMATIC LOAD LEVELING (ALL)

**PREPARATION
SST**

<p>49 L028 0A0 Gauge set, air pressure</p> 	<p>For inspection of shock absorber and compressor</p>	<p>49 B034 101 Gauge body (Part of 49 L028 0A0)</p> 	<p>For inspection of shock absorber and compressor</p>
<p>49 L028 001 Adapter (Part of 49 L028 0A0)</p> 	<p>For inspection of shock absorber and compressor</p>	<p>49 L028 002 Adapter (Part of 49 L028 0A0)</p> 	<p>For inspection of shock absorber</p>

DESCRIPTION

The ALL found on towing package equipped models is installed to detect changes in height of the rear of the vehicle caused by load changes and to regulate the rear vehicle height to maintain the proper front-to-rear attitude.



1. Air pipes
2. ALL control module
3. Height sensor
4. Rear shock absorber
5. Compressor assembly


6. Compressor relay
7. Door switch
8. Vehicle speed sensor
9. ALL indicator light

TROUBLESHOOTING GUIDE

Problem	Engine	Symptom	Possible cause	Page
Abnormal vehicle height	Running	Vehicle higher than designated height	<ul style="list-style-type: none"> ● Height sensor malfunction ● Improperly adjusted height sensor rod ● Exhaust valve stuck or damaged/ disconnected wiring ● Exhaust valve passage clogged or damaged/disconnected harness ● ALL control module malfunction ● Air pipe clogged ● Height sensor electrical circuit damaged/disconnected 	R-40 R-40 R-42 R-42 R-38 R-36 R-40
		Vehicle lower than designated height	<ul style="list-style-type: none"> ● Height sensor malfunction ● Improperly adjusted height sensor rod ● Poor contact of compressor relay or damaged/disconnected wiring ● Insufficient output pressure of compressor ● Compressor motor malfunction ● ALL control module malfunction ● Air pipe clogged or leaking ● Air leakage from shock absorber ● Damaged shock absorber rolling diaphragm ● Height sensor electrical circuit damaged/disconnected 	R-40 R-40 R-42 R-42 R-42 R-38 R-36 R-36, 41 R-41 R-40
		Vehicle occasionally changes (up or down)	<ul style="list-style-type: none"> ● Improperly adjusted height sensor rod ● ALL control module malfunction 	R-40 R-38
	Stopped (ignition switch OFF)	Vehicle higher than designated height	<ul style="list-style-type: none"> ● Exhaust valve passage clogged or damaged/disconnected harness ● Air pipe clogged ● Height sensor malfunction ● Improperly adjusted height sensor rod 	R-42 R-36 R-40 R-40
		Vehicle lower than designated height	<ul style="list-style-type: none"> ● Damaged exhaust valve ● Air leakage at air pipes or shock absorber connection 	R-42 R-36, 41
	Abnormal indication	Running	ALL indicator light remains illuminated	<ul style="list-style-type: none"> ● Height sensor malfunction or damaged/disconnected wiring ● Improperly adjusted height sensor rod ● Generator harness damaged or disconnected ● Generator malfunction ● Exhaust valve stuck or damaged/disconnected wiring ● Exhaust valve leakage ● Insufficient compressor output pressure or compressor motor malfunction ● ALL control module malfunction ● Air leakage at air pipes or shock absorber connection ● Damaged shock absorber rolling diaphragm
ALL indicator light does not stop flashing			<ul style="list-style-type: none"> ● Exhaust valve leakage ● Insufficient compressor output pressure ● ALL control module malfunction ● Air pipe clogged or air leakage from valve or shock absorber ● Damaged shock absorber rolling diaphragm 	R-42 R-42 R-38 R-36, 41, 42 R-41


Problem	Engine	Symptom	Possible cause	Page
Compressor operation abnormal	Running	Compressor operates too often	<ul style="list-style-type: none"> ● Exhaust valve stuck or harness short circuit ● Exhaust valve air leakage ● Air leakage at air pipes or shock absorber connection ● Damaged shock absorber rolling diaphragm ● ALL control module malfunction ● Door switch malfunction ● Vehicle speed sensor malfunction 	R-42 R-42 R-36, 41 R-41 R-38 section T section T
		Compressor does not stop	<ul style="list-style-type: none"> ● Exhaust valve stuck or harness short circuit ● Compressor relay malfunction ● ALL control module malfunction ● Air leakage at air pipes or shock absorber connection ● Damaged shock absorber rolling diaphragm 	R-42 R-43 R-38 R-36, 41 R-41
		Compressor does not start	<ul style="list-style-type: none"> ● Generator malfunction ● Compressor malfunction ● Compressor motor internal wiring damaged/disconnected ● ALL control module malfunction ● Compressor relay malfunction ● Door switch malfunction 	section G R-42 R-42 R-38 R-43 section T
		Compressor speed too slow	<ul style="list-style-type: none"> ● Compressor relay malfunction ● Compressor motor malfunction 	R-43 R-42

TROUBLESHOOTING MAIN FLOWCHART



On-board Diagnostic System


After the check terminal is grounded and the ignition switch is turned to ON, the ALL control module changes to the on-board diagnostic mode described below, which checks the operation of the air-intake system, the exhaust system, and the vehicle-height sensor. If the results indicate a problem, the ALL indicator light begins flashing, and the system with the problem is indicated by the pattern of the flashing. (Refer to page R-35 for procedure.)

**Flashing Pattern**

1) System OK



2) Malfunction of air-intake system




3) Malfunction of exhaust system



4) Malfunction of vehicle-height sensor



5) Combination malfunction (Example: Malfunction of air-intake system and exhaust system)




ALL INDICATOR LIGHT

Reference


Check contents

- ① Air-intake system check
A check is made to determine if vehicle height increases to NGH (abnormally high) within 150 seconds.
- ② Exhaust system check
A check is made to determine if vehicle height decreases from NGH (abnormally high) to L (low) within 110 seconds.
- ③ Vehicle-height sensor check
A check is made to determine if output is other than that specified from start of check to finish of check.



Preparations

- The work should be done on a surface that is smooth and flat.



Checking vehicle-height adjustment function

1. Ground the check connector.
2. To set the ALL system to the diagnostic test mode, turn the ignition switch to ON, but do not start the engine.
3. After returning to the standard height, look for flashing of the ALL indicator light.

Vehicle height*

Rear: 400 ± 20 mm { 15.7 ± 0.8 in }...2WD

465 ± 20 mm { 18.3 ± 0.8 in }...4WD


Difference between left and right : 15 mm { 0.6 in } or less

* Indicates from center of wheel to lower end of fender brim

Problem	Possible cause	Page
	<ul style="list-style-type: none"> • System OK 	—
	<ul style="list-style-type: none"> • Improper contact of compressor relay contacts or damaged/disconnected wiring • Insufficient output pressure of compressor • Compressor motor malfunction • Air pipe clogged or air leakage from each joint • Damaged shock absorber rolling diaphragm • Height sensor malfunction • Improper adjustment of height sensor rod • ALL control module malfunction 	R-43 R-42 R-42 R-36, 41 R-41 R-40 R-40 R-38
	<ul style="list-style-type: none"> • Exhaust valve passage clogged or damaged/disconnected harness • Air pipe clogged • Height sensor malfunction • Improper adjustment of height sensor rod • ALL control module malfunction 	R-42 R-36 R-40 R-40 R-38
	<ul style="list-style-type: none"> • Height sensor internal circuitry malfunction or damaged/disconnected harness • Improper adjustment of height sensor rod 	R-40 R-40

AIR PIPE**Inspection****Checking air pipes for air leakage**

1. Apply a soap-and-water solution to the areas indicated by the arrows.
2. Apply battery voltage (12 V) between terminals (a) and (d) of the compressor connector to activate the compressor and build pressure in the pipes.
3. Check for bubbles.



Checking airflow through air pipes

1. Disconnect both ends of the air pipe to be checked.
2. Blow air through the pipe to verify clear passage.

Replacement

A Type



- Disconnection Press at the base of the plug, and then pull the air pipe to disconnect it.
 Connection Push in until the air pipe's ridge catches on the tab on the plug.

B Type

- Disconnection 1. Remove the boot from the joint.
 2. Firmly grasp the air pipe joint tabs and pull out.
 Connection 1. Push in until a click is heard, then pull slightly to be sure the connection is secure.
 2. Cover the joint with the boot.


C Type

- Disconnection Remove the pipe by removing the nut.
 Connection Install the pipe by tightening the nut.



12.8—17.6 { 130—180, 113—156 }


N·m { kgf·cm, in·lbf }



ALL CONTROL MODULE

Inspection

1. Remove the No.1 rear seat.
2. Remove rear side trim A.
3. With the ALL control module connector connected, check the voltage of the connector terminals as described on page R-39.








AUTOMATIC LOAD LEVELING (ALL)

R

B+: Battery positive voltage

To	Terminal	Conditions and terminal voltage	
Height sensor	A D E	Varies according to vehicle height; Refer to "HEIGHT SENSOR" (Page R-40)	
Vehicle speed sensor	H	Vehicle running (10 km/h { 6.2 mph })	2—3 V
		Vehicle stopped	0 or B+
Generator (L terminal)	G	Engine running	B+
		Engine stopped	0—2.5 V
Door switch	B	Door open	0 V
		Door closed	B+
Exhaust valve	S	Valve ON	0 V
		Valve OFF	B+
Compressor relay	T	Compressor ON	0 V
		Compressor OFF	B+
Idle-up	O	Compressor ON	0—1 V
		Compressor OFF	B+
ALL indicator light	V	Ignition ON	0—2 V
		Engine running	B+
Battery power supply	M	Constant	B+
Ignition power supply	I	Ignition ON	B+
Height sensor power supply	C	Constant	5 V
Height sensor ground	J	Constant	0 V
Ground	N	Constant	0 V
Check terminal	P	Constant	10 V or more



HEIGHT SENSOR

Inspection

1. Use a screwdriver or similar tool to remove the cover from the height sensor connector.
2. Check for **5 V** at terminal (a) of the connector.
3. Disconnect the rod.
4. Check that the voltages shown in the table are present at terminals (c), (d), and (b) when the rod is moved.

Vehicle height	Sensor link position		Connector terminal		
	2WD	4WD	c (A*)	d (E*)	b (D*)
NGH*	①		0—0.5 V	4.5—5.5 V	4.5—5.5 V
	26.0—79.1°	31.5—77.7°			
H (high)	②		0—0.5 V	0—0.5 V	4.5—5.5 V
	17.3—29.0°	21.0—34.5°			
N (neutral)	③		0—0.5 V	0—0.5 V	0—0.5 V
	15.3—17.3°	19.1—21.1°			
L (low)	④		4.5—5.5 V	0—0.5 V	0—0.5 V
	-2.3—15.3°	3.3—19.1°			
NGL*	⑤		4.5—5.5 V	4.5—5.5 V	0—0.5 V
	-18.8—0.7°	-14.2—6.3°			

*NGH: (abnormally high)

*NGL: (abnormally low)

*: (A), (E), (D)...Control module terminal

Replacement

1. Jack up the rear of the vehicle and support it on safety stands.
2. Turn the spare tire carrier bolt counterclockwise and let the spare tire carrier down about 300 mm { 11.8 in }.
3. Disconnect the harness connector.
4. Remove the bolts, nuts, and the height sensor.
5. Install in the reverse order of removal. Tighten to the specified torque.

Bracket-to-body tightening torque:

18—26 N·m { 1.8—2.7 kgf·m , 14—19 ft·lbf }

Adjustment

1. Measure the length of the height sensor rod as shown in the figure.

Specified length:


59.5—60.5 mm { 2.35—2.38 in }...2WD

99.5—100.5 mm { 3.92—3.95 in }...4WD

2. If the rod length is not as specified, adjust as described below. Lengthening the height sensor rod increases vehicle height, and shortening it decreases vehicle height.
 - (1) Loosen the turn buckle by tightening nuts ①.
 - (2) Adjust the length by turning the center bolt ②.
 - (3) Tighten the nuts ①.

Tightening torque:

7.9—10.7 N·m { 80—110 kgf·cm , 70—95 in·lbf }




REAR SHOCK ABSORBER

Inspection



Checking rolling diaphragm for damage

If no air is in the cylinders and the vehicle is jacked up and then lowered suddenly, the rolling diaphragm may be folded double, as shown.

If the vehicle is driven in this condition, the diaphragm will be damaged. Check for such damage visually or by feeling the diaphragm by hand. If it is folded, repair as described below.



1. Ground the check connector.
2. Set the ALL system to the diagnostic test mode by turning the ignition switch to ON, but do not start the engine.
3. Disconnect the check terminal.
4. Before lowering the vehicle:
 - (a) Disconnect the air pipe if the pressure in the shock absorber air cylinders is abnormally low.
 - (b) Verify that the ALL indicator light is not flashing.
5. Lower the vehicle.




Checking for air leakage

If the location of an air leak cannot be found by using a soap and-water solution (Refer to page R-36.), check as described below.

1. Remove the shock absorber.
2. Visually check the diaphragm for damage.
3. Using the **SST**, make connections as shown in the figure.
4. Apply **approx. 490 kPa { 5 kgf/cm² , 71 psi }** air pressure.
5. Place the shock absorber in a tank of water and check for air leakage.

Note

- The shock absorber is coated with foam on its outer surface. Do not mistake it for leakage.



6. If the above check shows air leakage from the shock absorber, replace the shock absorber assembly. (Refer to page R-26.)
7. After the check is finished, remove all moisture by blowing with compressed air.


COMPRESSOR ASSEMBLY

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. Tighten all nuts and bolts to the specified torque, referring to the figure.


Note

- An internal circuit breaker is incorporated within the compressor. It opens to stop the motor if the motor temperature exceeds **approx. 150 °C { 302 °F }**. It automatically resets itself and restarts the motor when the temperature drops below approx. **100 °C { 212 °F }**.



1. Battery
2. Battery bracket
3. Headlight bulb

4. Washer tank
 5. Compressor assembly
- Inspection below




Inspection

Compressor assembly

Checking compressor and exhaust valve


1. Jack up the rear of the vehicle and support it on safety stands.
2. Disconnect the air pipes from the shock absorbers (Refer to page R-37). Connect the **SST** as shown in the figure.



3. Apply battery voltage (12 V) between terminals (a) and (d) of the compressor connector to activate the compressor.
4. Close the valve on the pressure gauge, and check the output pressure.

Standard:


981—1,274 kPa { 10—13 kgf/cm² , 143—184 psi }



5. Stop the compressor.
6. While maintaining the compressor pressure, apply battery voltage (12 V) between terminals (c) and (b) of the compressor connector.
7. Verify that the exhaust valve operation sound is heard and that the pressure gradually decreases. Check that the following pressure is finally reached and held.

Standard:


20—78 kPa { 0.2—0.8 kgf/cm² , 3—11 psi }



8. Lower the jack slowly.
9. Connect the air pipe to the shock absorbers.

Tightening torque: 12.8—17.6 N·m

{ 130—180 kgf·cm , 113—156 in·lbf }



COMPRESSOR RELAY

Inspection

1. Remove the compressor relay.
2. Connect battery voltage (12 V) to terminal (b) and ground terminal (a).
3. Verify continuity between terminals (c) and (d).

Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

BODY

HOOD	S- 3	SIDE PROTECTOR No.1, No.2, No.3, No.4	S-33
HOOD	S- 3	STONE GUARD	S-34
FRONT FENDER PANEL	S- 5	POWER OUTSIDE MIRROR	S-35
FRONT FENDER PANEL	S- 5	POWER OUTSIDE MIRROR	S-35
DOOR	S- 6	POWER OUTSIDE MIRROR SWITCH	S-36
FRONT DOOR	S- 6	REARVIEW MIRROR	S-36
REAR DOOR	S- 9	REARVIEW MIRROR	S-36
POWER WINDOW SYSTEM	S-12	REAR WINDOW DEFROSTER	S-37
STRUCTURAL VIEW	S-12	STRUCTURAL VIEW	S-37
POWER WINDOW MAIN SWITCH ASSEMBLY	S-13	REAR WINDOW DEFROSTER SWITCH	S-37
POWER WINDOW SUBSWITCH ...	S-14	REAR WINDOW DEFROSTER RELAY	S-38
POWER WINDOW REGULATOR ...	S-14	FILAMENT	S-38
POWER DOOR LOCK SYSTEM	S-16	WINDOW GLASS	S-39
STRUCTURAL VIEW	S-16	PREPARATION	S-39
FRONT DOOR LOCK ACTUATOR .	S-17	WINDSHIELD	S-39
REAR DOOR LOCK ACTUATOR ...	S-17	QUARTER WINDOW GLASS	S-42
LIFTGATE LOCK ACTUATOR	S-18	DOOR QUARTER WINDOW GLASS	S-42
DOOR LOCK TIMER UNIT	S-19	REAR WINDOW GLASS	S-43
KEYLESS UNIT	S-21	SLIDING SUNROOF	S-47
TRANSMITTER	S-23	COMPONENTS	S-47
LIFTGATE	S-25	DECORATION COVER	S-48
LIFTGATE	S-25	SLIDE PANEL	S-48
FUEL-FILLER LID AND OPENER	S-28	FRONT GUIDE	S-49
FUEL-FILLER LID AND OPENER ...	S-28	DEFLECTOR	S-49
BUMPER	S-29	GUIDE RAIL COVER	S-49
FRONT BUMPER	S-29	SUNROOF MOTOR ASSEMBLY	S-49
REAR BUMPER	S-29	SUNROOF UNIT	S-51
EXTERIOR ATTACHMENT	S-30	SUNSHADE	S-51
RADIATOR GRILLE	S-30	SET PLATE	S-51
EXTRACTOR CHAMBER	S-30	REAR GUIDE	S-51
REAR FINISHER	S-30	GUIDE RAIL	S-51
MOLDING	S-31	SUNROOF HARNESS	S-52
WINDSHIELD MOLDING	S-31	SUNROOF RELAY	S-52
WINDSHIELD UPPER MOLDING ...	S-31	DRIVE UNIT	S-53
WINDSHIELD LOWER MOLDING ...	S-31	FRONT DRAIN HOSE	S-54
FRONT BELTLINE MOLDING	S-31	REAR DRAIN HOSE	S-54
REAR BELTLINE MOLDING (REAR DOOR)	S-32	SUNROOF SWITCH	S-55
REAR BELTLINE MOLDING	S-32	WEATHERSTRIP	S-55
FRONT DRIP MOLDING	S-32	DASHBOARD	S-56
REAR DRIP MOLDING	S-32	STRUCTURAL VIEW	S-56
REAR WINDOW MOLDING	S-32	DASHBOARD	S-57
PROTECTOR	S-33	SIDE PANEL	S-59
SIDE PROTECTOR No.1, No.2, No.3	S-33		
SIDE PROTECTOR No.4	S-33		


GLOVE COMPARTMENT	S-59
GLOVE COMPARTMENT COVER ..	S-59
COLUMN COVER	S-59
METER HOOD	S-60
LOWER PANEL	S-60
CENTER LOWER PANEL	S-60
CENTER UPPER PANEL	S-60
TRIM	S-61
A-PILLAR TRIM	S-61
B-PILLAR LOWER TRIM	S-61
B-PILLAR UPPER TRIM	S-61
D-PILLAR TRIM	S-61
REAR COOLER TRIM	S-62
FRONT SIDE TRIM	S-63
FRONT SCUFF PLATE	S-63
REAR SCUFF PLATE	S-63
FRONT DOOR TRIM	S-63
REAR DOOR TRIM	S-64
FRONT HEADER TRIM	S-64
REAR HEADER TRIM	S-64
TIRE HOUSE TRIM (RH)	S-65
TIRE HOUSE TRIM (LH)	S-65
TIRE HOUSE REAR TRIM	S-65
REAR SIDE TRIM	S-65
MAT SET END PLATE	S-66
LIFTGATE UPPER TRIM	S-66
LIFTGATE LOWER TRIM	S-66
LIFTGATE SIDE TRIM	S-66
HEADLINER	S-67
FRONT HEADLINER	S-67
REAR HEADLINER	S-68
FLOOR COVERING	S-69
FRONT CABIN CARPET	S-69
REAR CABIN CARPET	S-70
SEAT BELT	S-71
FRONT SEAT BELT	S-71
FRONT BUCKLE	S-72
REAR No.1 SEAT BELT	S-73
REAR No.1 BUCKLE	S-74
REAR No.2 SEAT BELT	S-75
REAR No.2 BUCKLE	S-76
SEAT	S-77
FRONT SEAT	S-77
REAR SEAT No.1	S-79
REAR SEAT No.2	S-82

HOOD

HOOD

Removal / Installation


1. Remove in the order shown in the figure. To remove the hood hinge, remove the front fender panel. (Refer to page S-5.) To remove the hood lock, remove the radiator grille. (Refer to page S-30.)
2. Install in the reverse order of removal.



- 1. Windshield washer pipe
- 2. Deflector
- 3. Weatherstrip
- 4. Hood

- 5. Hood hinge
- 6. Hood stay
- 7. Hood lock
- Adjustment page S-4
- 8. Hood release cable

Adjustment page S-4




Adjustment

Hood

1. Measure the gap and height between the hood and the front fender panel.

Clearance ①: $4.0 \pm 1.0 \text{ mm}$ { $0.16 \pm 0.04 \text{ in}$ }
 ②: $0.8 \pm 1.0 \text{ mm}$ { $0.03 \pm 0.04 \text{ in}$ }

2. If not as specified, adjust the gap and height.
3. Adjust the hood lock after the hood has been aligned. (Refer below.)




Gap

Loosen the hood-to-hinge installation bolts and reposition the hood.


Tightening torque:

$19\text{--}25 \text{ N}\cdot\text{m}$ { $1.9\text{--}2.6 \text{ kgf}\cdot\text{m}$, $14\text{--}18 \text{ ft}\cdot\text{lbf}$ }



Height

Turn the stop rubber to adjust the height of the hood.



Hood lock


1. Verify that the hood is properly aligned. (Refer above.)
2. Loosen the hood lock installation bolts and nut, and align the lock with the striker on the hood.

Tightening torque:

$7.9\text{--}10.7 \text{ N}\cdot\text{m}$ { $80\text{--}110 \text{ kgf}\cdot\text{cm}$, $70\text{--}95.4 \text{ in}\cdot\text{lbf}$ }

FRONT FENDER PANEL**FRONT FENDER PANEL****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the front bumper. (Refer to page S-29.)
3. Remove the windshield molding. (Refer to page S-31.)
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal.



1. Mud guard


2. Front fender panel

DOOR

FRONT DOOR

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the checker, remove the door speaker. (Refer to section T.)
3. Install in the reverse order of removal.




1. Harness connector
2. Checker pin
3. Front door

4. Door hinge
5. Checker
6. Door lock striker

Adjustment page S-7

Adjustment page S-7

**Adjustment****Front door**

1. Verify that the front door can be closed easily and that there is no looseness or excessive clearance.


Clearance ①: $5.0 + 1.0 \text{ mm}$ { $0.2 + 0.04 \text{ in}$ }

②: $5.8 \pm 1.5 \text{ mm}$ { $0.23 \pm 0.06 \text{ in}$ }

2. If not as specified, loosen the door-hinge-to-body installation bolts and nuts, and reposition the front door.

Tightening torque:

$22\text{--}30 \text{ N}\cdot\text{m}$ { $2.2\text{--}3.1 \text{ kgf}\cdot\text{m}$, $16\text{--}22 \text{ ft}\cdot\text{lbf}$ }

**Door lock striker**


1. Verify that the door can be closed easily and that there is no looseness.
2. If not correct, loosen the striker installation screws and move the striker horizontally or vertically.

Tightening torque:

$18\text{--}26 \text{ N}\cdot\text{m}$ { $1.8\text{--}2.7 \text{ kgf}\cdot\text{m}$, $14\text{--}19 \text{ ft}\cdot\text{lbf}$ }

Disassembly / Assembly

1. Raise the door glass **180 mm { 7.09 in }** from the fully lowered position.
2. Disconnect the negative battery cable.
3. Remove the front door trim. (Refer to page S-63.)
4. Disassemble in the order shown in the figure.
5. Assemble in the reverse order of disassembly.




- | | |
|---------------------------|-------------------------------------|
| 1. Inner handle | 7. Front door outer handle |
| 2. Bracket | 8. Front door key cylinder retainer |
| 3. Door screen | 9. Front door key cylinder |
| 4. Front door glass | 10. Front door lock |
| 5. Glass run channel | 11. Front door lock actuator |
| 6. Power window regulator | |

REAR DOOR

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the checker, remove the door speaker. (Refer to section T.)
3. Install in the reverse order of removal.




S

1. Harness connector
2. Checker pin
3. Rear door

4. Door hinge
5. Checker
6. Door lock striker

Adjustment page S-10

Adjustment page S-10

**Adjustment****Rear door**


1. Verify that the rear door can be closed easily and that there is no looseness or excessive clearance.

Clearance ①: $5.0 \pm 0.8 \text{ mm}$ { $0.2 \pm 0.03 \text{ in}$ }
 ②: $5.8 \pm 1.5 \text{ mm}$ { $0.23 \pm 0.06 \text{ in}$ }

2. If not as specified, loosen the door-hinge-to-body installation bolts and nuts, and reposition the rear door.

Tightening torque:

$22\text{--}30 \text{ N}\cdot\text{m}$ { $2.2\text{--}3.1 \text{ kgf}\cdot\text{m}$, $16\text{--}22 \text{ ft}\cdot\text{lbf}$ }

**Door lock striker**


1. Verify that the door can be closed easily and that there is no looseness.
2. If not correct, loosen the striker installation screws and move the striker horizontally or vertically.

Tightening torque:

$18\text{--}26 \text{ N}\cdot\text{m}$ { $1.8\text{--}2.7 \text{ kgf}\cdot\text{m}$, $14\text{--}19 \text{ ft}\cdot\text{lbf}$ }


Disassembly / Assembly

1. Raise the door glass **85 mm { 3.35 in }** from the fully lowered position.
2. Disconnect the negative battery cable.
3. Remove the rear door trim. (Refer to page S-64.)
4. Disassemble in the order shown in the figure.
5. Assemble in the reverse order of disassembly, referring to **Assembly note**.




- | | |
|----------------------------|---------------------------|
| 1. Inner handle | 7. Rear door glass |
| 2. Door screen | 8. Power window regulator |
| 3. Rear door lock | 9. Glass run channel |
| 4. Rear door lock actuator | 10. Inner lock knob |
| 5. Rear door outer handle | |
| 6. Glass guide | |

Assembly note page S-12


**Assembly note****Glass guide**

1. Install the glass guide installation screw.
2. Move the glass guide in the direction shown in the figure, then install the bolt.

POWER WINDOW SYSTEM**STRUCTURAL VIEW**

1. Power window main switch assembly
Removal / Installation page S-13
Inspection page S-13
2. Power window subswitch
Removal / Installation page S-14
Inspection page S-14


3. Power window regulator
Removal / Installation page S-14
Inspection page S-15



POWER WINDOW MAIN SWITCH ASSEMBLY

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the switch panel as shown.
3. Remove the power window main switch assembly installation screws.
4. Install in the reverse order of removal.




Inspection

1. Remove the power window main switch assembly. (Refer above.)
2. Check for continuity between the terminals of the main switch assembly connector by using an ohmmeter.
3. If not as specified, replace the power window main switch assembly.

○—○: Continuity


Switch Terminal	Driver				Passenger				Left rear				Right rear			
	L	N	H	F	D	B	H	F	M	K	J	F	A	C	J	F
UP	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
AUTO UP	○	○	○	○												
OFF (with power-cut switch at ON)	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
DOWN	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
AUTO DOWN	○	○	○	○												



POWER WINDOW SUBSWITCH

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the switch panel as shown.
3. Remove the power window subswitch installation screws.
4. Install in the reverse order of removal.




Inspection

1. Remove the power window subswitch. (Refer above.)
2. Check for continuity between the terminals of the sub-switch connector by using an ohmmeter.

○—○: Continuity

Terminal Switch position	A	B	D	E	F
UP	○—○	○—○	○—○	○—○	
OFF	○—○		○—○	○—○	○—○
DOWN		○—○	○—○	○—○	○—○

3. If not as specified, replace the power window subswitch.




POWER WINDOW REGULATOR

Removal / Installation


Front

1. Disconnect the negative battery cable.
2. Remove the front door glass. (Refer to page S-8.)
3. Disconnect the power window regulator connector.
4. Remove the power window regulator installation bolts and nuts.
5. Install in the reverse order of removal.



Rear

1. Disconnect the negative battery cable.
2. Remove the rear door glass. (Refer to page S-11.)
3. Disconnect the power window regulator connector.
4. Remove the power window regulator installation bolts and nuts.
5. Install in the reverse order of removal.



Inspection

1. Remove the power window regulator.
(Refer to page S-14.)
2. Apply battery positive voltage to the power window regulator connector terminals and check the operation of the regulator.


B+: Battery positive voltage

Connection		Regulator operation
B+	GND	
A	B	UP
B	A	DOWN

3. If not as specified, replace the power window regulator.


POWER DOOR LOCK SYSTEM

STRUCTURAL VIEW



- 1. Front door lock actuator
Removal / Installation page S-17
Inspection page S-17
- 2. Rear door lock actuator
Removal / Installation page S-17
Inspection page S-17
- 3. Liftgate lock actuator
Removal / Installation page S-18
Inspection page S-18
- 4. Door lock timer unit
Removal / Installation page S-19
Inspection page S-19


- 5. Keyless unit
Removal / Installation page S-21
Inspection page S-21
Changing the ID code page S-22
- 6. Transmitter
Battery replacement page S-23
Inspection page S-23
- 7. CPU
Removal / Installation section T
Inspection section T



FRONT DOOR LOCK ACTUATOR

Removal / Installation

1. Raise the front door glass fully.
2. Remove the door screen. (Refer to page S-8.)
3. Disconnect the front door lock actuator connector.
4. Remove the front door lock installation screws.
5. Remove the front door lock.
6. Remove the front door lock actuator installation screws.
7. Install in the reverse order of removal.



Inspection

1. Remove the door screen. (Refer to page S-8.)
2. Disconnect the front door lock actuator connector.
3. Check for continuity between the terminals of the front door lock actuator connector with the lock rod in the following positions by using an ohmmeter.

○—○: Continuity


Terminal	C	D	F
Knob position			
Lock	○—○		○—○
Unlock	○—○	○—○	

4. Apply battery positive voltage to the connector terminals and check the operation of the actuator.

B+: Battery positive voltage

Connection		Actuator operation
B+	GND	
B	A	Lock
A	B	Unlock

5. If not as specified, replace the front door lock actuator.



REAR DOOR LOCK ACTUATOR

Removal / Installation

1. Remove the door screen. (Refer to page S-11.)
2. Disconnect the rear door lock actuator connector.
3. Remove the rear door lock installation screws.
4. Remove the rear door lock.
5. Remove the rear door lock actuator installation screws.
6. Install in the reverse order of removal.


Inspection


1. Remove the door screen. (Refer to page S-11.)
2. Disconnect the rear door lock actuator connector.
3. Apply battery positive voltage to the connector terminals and check the operation of the actuator.

B+: Battery positive voltage

Connection		Actuator operation
B+	GND	
B	A	Lock
A	B	Unlock

4. If not as specified, replace the door lock actuator.






LIFTGATE LOCK ACTUATOR

Removal / Installation

1. Remove the liftgate screen. (Refer to page S-27.)
2. Disconnect the liftgate lock actuator connector.
3. Remove the liftgate lock actuator installation nuts.
4. Install in the reverse order of removal.




Inspection

1. Remove the liftgate screen. (Refer to page S-27.)
2. Disconnect the liftgate lock actuator connector.
3. Apply battery positive voltage to the connector terminals and check the operation of the actuator.

B+: Battery positive voltage

Connection		Actuator operation
B+	GND	
A	B	Lock
B	A	Unlock


4. If not as specified, replace the liftgate lock actuator.



DOOR LOCK TIMER UNIT

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the glove compartment cover.
(Refer to page S-59.)
3. Remove the door lock timer unit installation bolt.
4. Install in the reverse order of removal.




Inspection

1. Remove the glove compartment cover.
(Refer to page S-59.)
2. Measure the voltage at the door lock timer unit terminals.
3. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
4. If the parts and wiring harnesses are OK but the system still does not work properly, replace the door lock timer unit.

**Terminal voltage list
(without keyless entry system)**


B+: Battery positive voltage




Terminal	Signal	Connection	Test condition	Voltage (V)	Inspection area
B	B+	Fuse (DOOR LOCK 30 A)	Constant	B+	Fuse (DOOR LOCK 30 A)
A	GND	Body ground	Constant: check for continuity to ground	0	GND
F	Actuator unlock control	Door lock actuator	Door lock actuator unlocked	0 → B+ → 0	Wiring harness (Door lock timer unit—Door lock actuator)
			Other	0	
C	Power door lock control	CPU	Door lock actuator unlocked	B+ → 0 → B+	Wiring harness (Door lock timer unit—CPU)
			Other	B+	
E	Actuator lock control	Door lock actuator	Door lock actuator locked	0 → B+ → 0	Wiring harness (Door lock timer unit—Door lock actuator)
			Other	0	
D	Power door lock control	CPU	Door lock actuator locked	B+ → 0 → B+	Wiring harness (Door lock timer unit—CPU)
			Other	B+	

(with keyless entry system)

B+: Battery positive voltage




Terminal	Signal	Connection	Test condition	Voltage (V)	Inspection area
B	B+	Fuse (DOOR LOCK 30 A)	Constant	B+	Fuse (DOOR LOCK 30 A)
A	GND	Body ground	Constant: check for continuity to ground	0	GND
F	Actuator unlock control	Door lock actuator	Door lock actuator unlocked	0→B+ →0	Wiring harness (Door lock timer unit—Door lock actuator)
			Other	0	
C	Power door lock control	CPU	Door lock actuator unlocked	B+→0 →B+	Wiring harness (Door lock timer unit—CPU)
			Other	B+	
E	Actuator lock control	Door lock actuator	Door lock actuator locked	0→B+→0	Wiring harness (Door lock timer unit—Door lock actuator)
			Other	0	
D	Power door lock control	CPU	Door lock actuator locked	B+→0→B+	Wiring harness (Door lock timer unit—CPU)
			Other	B+	



KEYLESS UNIT

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the glove compartment cover.
(Refer to page S-59.)
3. Remove the keyless unit installation bolt.
4. Install in the reverse order of removal.




Inspection

1. Remove the glove compartment cover.
(Refer to page S-59.)
2. Measure the voltage at the keyless unit terminals.
3. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
4. If the parts and wiring harnesses are OK but the system still does not work properly, replace the keyless unit.

Terminal voltage list

B+: Battery positive voltage

Terminal	Signal	Connection	Test condition	Voltage (V)	Inspection area
A	B+	Fuse (ROOM 15 A)	Constant	B+	Fuse (ROOM 15 A)
B	Lock/Unlock	CPU	Harness connector disconnected	5	Wiring harness (Keyless unit — CPU)
			Harness connector reconnected	Refer to *1 below	Replace the keyless unit
C	GND	Body ground	Constant: check for continuity to ground	0	GND





*1

Harness connector disconnected		Harness connector reconnected	
4.5—4.6	→	1—4.4	
4.6—4.7	→	1—4.5	
4.7—4.8	→	1—4.6	
4.8—4.9	→	1—4.7	
4.9—5.0	→	1—4.8	
5.0—5.1	→	1—4.9	
5.1—5.2	→	1—5.0	
5.2—5.3	→	1—5.1	
5.3—5.4	→	1—5.2	
5.4—5.5	→	1—5.3	

Changing The ID Code

- Up to 3 transmitters can be used with the keyless entry system. If there are two, work with both of them when changing the ID code.





TRANSMITTER
Replacing the Battery


1. Insert a flathead screwdriver into the notch of the transmitter.
2. Remove the cover by using the screwdriver as shown.
3. Install the new batteries with the ⊕ side facing up.

Battery specification: Lithium CR 2025 × 1

4. Install the cover.

Note


- The batteries will last about 2 years when used 10 times a day.



Inspection

1. Remove the batteries.
2. Leave the batteries on a table for **30 minutes** and allow them to warm to room temperature (**20—30 °C { 65—85 °F}**).
3. Measure the voltage of each battery by using a digital circuit tester.

Voltage	Action
2.9 V or more	Install batteries and go to step 4
Less than 2.9 V	Replace transmitter batteries



4. Verify that the keyless entry system is functioning properly by operating the system with the second transmitter.

Voltage	Action
Yes	Replace the defective transmitter
No	Check antenna feeder — keyless unit

MEMO

LIFTGATE

LIFTGATE


Removal / Installation

1. Disconnect the negative battery cable.

Warning

- Removing the stay damper without supporting the liftgate can be dangerous. The liftgate may fall and injure you. Open the liftgate fully and support it before removing the stay damper.

2. Remove in the order shown in the figure. To disconnect the harness connector, remove the rear side trim. (Refer to page S-65.) To remove the liftgate hinge, remove the rear edge of the rear headliner. (Refer to page S-68.)
3. Install in the reverse order of removal.



1. Harness connector

2. Washer pipe

3. Stay damper

4. Liftgate


Adjustment page S-26

5. Liftgate hinge

6. Mat end set plate

7. Liftgate lock striker

Adjustment page S-26




Disposal Stay damper

Note

- ⦿ The gas in the stay damper is colorless, odorless, and non-toxic.

1. Lay the stay damper flat.
2. Saw through the stay damper body by using a hacksaw.
3. Allow the gas to escape from the stay damper.
4. Discard the stay damper.



Adjustment Liftgate


1. Verify that the liftgate can be closed easily and that there is no looseness or excessive clearance.

- Clearance**
- ①: $6.4 \pm 1.5 \text{ mm}$ { $0.25 \pm 0.06 \text{ in}$ }
 - ②: $0.8 \pm 1.0 \text{ mm}$ { $0.03 \pm 0.04 \text{ in}$ }
 - ③: $7.0 \pm 2.0 \text{ mm}$ { $0.28 \pm 0.08 \text{ in}$ }
 - ④: $9.95 \pm 3.0 \text{ mm}$ { $0.39 \pm 0.12 \text{ in}$ }

2. If not as specified, loosen the liftgate-to-hinge installation bolts and reposition the liftgate.

Tightening torque:

$8.9\text{--}12.7 \text{ N}\cdot\text{m}$ { $90\text{--}130 \text{ kgf}\cdot\text{cm}$, $79\text{--}112 \text{ in}\cdot\text{lbf}$ }



Liftgate lock striker

1. Verify that the liftgate can be closed easily and that there is no looseness.
2. If the offset is excessive, loosen the striker installation bolts and adjust the striker.

Tightening torque:

$18\text{--}26 \text{ N}\cdot\text{m}$ { $1.8\text{--}2.7 \text{ kgf}\cdot\text{m}$, $14\text{--}19 \text{ ft}\cdot\text{lbf}$ }


Disassembly / Assembly

1. Disconnect the negative battery cable.

Note

- Remove the liftgate screen carefully so that it may be reused.

2. Disassemble in the order shown in the figure. To remove the liftgate outer handle, remove the rear finisher. (Refer to page S-30.)
3. Assemble in the reverse order of disassembly.




- | | |
|-----------------------------------|--------------------------|
| 1. Liftgate screen | 5. Liftgate lock knob |
| 2. Liftgate key cylinder retainer | 6. Remote controller |
| 3. Liftgate key cylinder | 7. Liftgate outer handle |
| 4. Liftgate lock actuator | 8. Liftgate lock |

FUEL-FILLER LID AND OPENER

FUEL-FILLER LID AND OPENER

Removal / Installation

1. Remove in the order shown in the figure. To remove the fuel-filler lid opener cable and fuel-filler lid opener lever, remove the rear side trim (Refer to page S-65.) and front cabin carpet (Refer to page S-69.).
2. Install in the reverse order of removal.



Fuel-filler lid opener lever

1. Fuel-filler lid opener bezel
2. Fuel-filler lid opener lever
3. Fuel-filler lid opener cable

Fuel-filler lid and opener


4. Lift spring
5. Fuel-filler lid opener
6. Fuel-filler lid opener cable
7. Fuel-filler lid

BUMPER

FRONT BUMPER

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the radiator grille. (Refer to page S-30.)
3. Remove as shown in the figure.
4. Install in the reverse order of removal.




1. Front bumper

REAR BUMPER

Removal / Installation


1. Remove as shown in the figure.
2. Install in the reverse order of removal.




1. Rear bumper

EXTERIOR ATTACHMENT**RADIATOR GRILLE****Removal / Installation**


1. Remove as shown in the figure.
2. Install in the reverse order of removal.


**EXTRACTOR CHAMBER****Removal / Installation**

1. Remove the rear bumper. (Refer to page S-29.)
2. Remove as shown in the figure.
3. Install in the reverse order of removal.

**REAR FINISHER****Removal / Installation**

1. Remove the liftgate screen. (Refer to page S-27.)
2. Remove as shown in the figure.
3. Install in the reverse order of removal.





MOLDING


WINDSHIELD MOLDING

Removal

Remove the windshield molding installation screws and clips as shown.

Installation

1. Insert the windshield molding to the front drip molding.
2. Install in the reverse order of removal.




WINDSHIELD UPPER MOLDING

Removal

1. Remove the windshield molding. (Refer above.)
2. Remove the windshield upper molding.

Installation


1. Install clip A to the body stud and clip B to the windshield upper molding as shown.
2. Install in the reverse order of removal.



WINDSHIELD LOWER MOLDING

Removal / Installation


1. Remove the windshield wiper arm and blade. (Refer to section T.)
2. Remove the windshield lower molding installation screws.
3. Install in the reverse order of removal.



FRONT BELTLINE MOLDING

Removal / Installation


1. Remove the front door glass. (Refer to page S-8.)
2. Remove the power outside mirror. (Refer to page S-35.)
3. Remove the front beltline molding installation screw.
4. Insert a flathead screwdriver which has been wrapped in tape under the clip.
5. Lift the flathead screwdriver and pull up on the molding to remove it.
6. Install in the reverse order of removal.



REAR BELTLINE MOLDING (REAR DOOR)

Removal / Installation

1. Remove the rear door glass. (Refer to page S-11.)
2. Remove the door quarter window glass. (Refer to page S-42.)
3. Remove the rear beltline molding installation screw.
4. Insert a flathead screwdriver which has been wrapped in tape under the clip.
5. Lift the flathead screwdriver and pull up on the molding to remove it.
6. Install in the reverse order of removal.




REAR BELTLINE MOLDING

Removal

Remove the rear beltline molding installation clips.

Installation

Align the rear end of the molding with the rear drip molding and install the molding from rear toward front end.




FRONT DRIP MOLDING

Removal

Remove the front drip molding by pulling on it.

Installation


1. Align the rear end of the front drip molding with the front end of the rear drip molding (①).
2. Install the front drip molding from rear toward front end (②).



REAR DRIP MOLDING

Removal / Installation


1. Remove the rear beltline molding. (Refer above.)
2. Remove the front drip molding. (Refer above.)
3. Remove the rear drip molding installation clips as shown.
4. Install in the reverse order of removal.



REAR WINDOW MOLDING

Removal / Installation

1. Remove the rear window glass. (Refer to page S-43.)
2. Remove the rear window molding.
3. Install in the reverse order of removal.




PROTECTOR

SIDE PROTECTOR No.1, No.2, No.3


Removal

1. Soften the adhesive by using a hot-air blower.



2. Pry the protector end **20—30 mm { 0.79—1.18 in }** by using a flathead screwdriver or razor knife, being careful not to damage the painted surface.


3. Pull the separated portion to remove the protector.



SIDE PROTECTOR No.4

Removal


Remove the side protector No.4 installation fasteners.



SIDE PROTECTOR No.1, No.2, No.3, No.4

Installation

1. Use a razor knife to remove the adhesive remaining on the body and protector (if the protector will be reused). Remove as much adhesive as possible without damaging the painted surface. If the adhesive is difficult to remove, soften it by using a hot-air blower.




2. Remove any grease or dirt from the adhesion surface of the protector (if the protector will be reused) and body.

3. Attach double-sided adhesive tape to the protector as shown (if the protector will be reused.)

Clearance

- A: $1 \pm 1 \text{ mm } \{ 0.04 \pm 0.04 \text{ in } \}$
- B: $30 \text{ mm } \{ 1.18 \text{ in } \}$
- C: $2 \pm 1 \text{ mm } \{ 0.08 \pm 0.04 \text{ in } \}$
- D: $8 \text{ mm } \{ 0.31 \text{ in } \}$
- E: $35 \text{ mm } \{ 1.38 \text{ in } \}$



4. Align the protector on the body and press on it with a force of 5 kg.


Clearance

$$A: 0_{-0}^{+1.0} \text{ mm } \{ 0_{-0}^{+0.04} \text{ in } \}$$

$$B: 2_{-0}^{+1.0} \text{ mm } \{ 0.08_{-0}^{+0.04} \text{ in } \}$$

$$C: 2.5_{-0}^{+1.0} \text{ mm } \{ 0.1_{-0}^{+0.04} \text{ in } \}$$


$$D: 3 \pm 2.0 \text{ mm } \{ 0.12 \pm 0.08 \text{ in } \}$$



STONE GUARD

Removal / Installation

1. Remove the stone guard installation fasteners and clips.
2. Install in the reverse order of removal.



POWER OUTSIDE MIRROR

POWER OUTSIDE MIRROR

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the front door trim. (Refer to page S-63.)
3. Remove the power outside mirror installation screws.
4. Install in the reverse order of removal.

Inspection

1. Remove the power outside mirror. (Refer above.)
2. Apply battery positive voltage and check the operation of the power outside mirror.

B+: Battery positive voltage

Connection				Mirror operation
B+		GND		
LH	RH	LH	RH	
C	A	A	C	UP
A	C	C	A	DOWN
C		D		LEFT
D		C		RIGHT




3. If not as specified, replace the power outside mirror.


Replacement of Mirror Glass

Removal

1. Warm the frame and the mirror glass by using a hot-air blower.





2. Insert a scraper between the mirror glass and the frame, and pry the glass loose.
3. Remove the remaining adhesive.




Installation

1. Warm the adhesive surface of the frame and the mirror by using a hot-air blower. If the frame is stained with oil, degrease it.
2. Peel off the wax paper from the double-sided adhesive tape on the rear side of the new mirror glass.





3. Install the glass in the mirror frame and gently press it in to secure it.




POWER OUTSIDE MIRROR SWITCH

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the switch panel as shown.
3. Remove the power outside mirror switch installation screws.
4. Install in the reverse order of removal.

Inspection

1. Remove the power outside mirror switch. (Refer above.)
2. Check for continuity between the switch terminals by using an ohmmeter



○—○: Continuity

Terminal		Switch position						
		F	D	H	L	J	K	I
LH	UP	○	○—○	○—○	○			○
	DOWN	○	○	○				○
	LEFT	○	○	○	○			
	RIGHT	○	○	○	○			○
RH	UP	○	○			○	○	○
	DOWN	○	○			○		○
	LEFT	○	○			○	○	
	RIGHT	○	○			○	○	○


3. If not as specified, replace the power outside mirror switch.

REARVIEW MIRROR

REARVIEW MIRROR


Removal / Installation

1. Remove the lens. (Refer to section T.)
2. Remove the rearview mirror installation screws.
3. Install in the reverse order of removal.




REAR WINDOW DEFROSTER

STRUCTURAL VIEW



- | | |
|--|--|
| <p>1. Rear window defroster switch
 Removal / Installation below
 Inspection below</p> <p>2. Rear window defroster relay
 Removal / Installation page S-38
 Inspection page S-38</p> | <p>3. Filament
 Inspection page S-38
 Repair page S-38</p> |
|--|--|



REAR WINDOW DEFROSTER SWITCH

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the center upper panel. (Refer to page S-60.)
3. Remove the rear window defroster switch.
4. Install in the reverse order of removal.

Inspection


1. Remove the rear window defroster switch. (Refer above.)
2. Check for continuity between the relay terminals by using an ohmmeter.

○—○: Continuity B+: Battery positive voltage

Terminal	A	B	C	D	F
Switch position					
ON	○—⊕—○		○—○—⊕—○		
OFF	○—⊕—○		○—○—⊕—○		



3. If not as specified, replace the rear window defroster switch.



REAR WINDOW DEFROSTER RELAY

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the joint box. (Refer to section T.)
3. Remove the rear window defroster relay.
4. Install in the reverse order of removal.

Inspection

1. Remove the rear window defroster relay. (Refer above.)
2. Check for continuity between the relay terminals by using an ohmmeter.

○—○: Continuity B+: Battery positive voltage

Connection		A	B	C	D
B+	GND				
—	—	○—○	○—○		
A	B			○—○	○—○



3. If not as specified, replace the rear window defroster relay.

FILAMENT

Inspection

1. Turn the rear window defroster switch on.
2. Connect the (+) terminal of a voltmeter to the center of each filament and the (-) terminal to the body and check the voltage.

Standard voltage: 5—7 V

Note




- If the meter indication is high, there is an open circuit between the center and the ground side of the filament.
- If the meter indication is low or zero, the malfunction is between the center and positive side of the filament.

3. If not as specified, repair the filament. (Refer below.)

Repair

Caution


- Use only white gasoline for cleaning. Other solvents can damage the surrounding filament.




1. Use white gasoline to clean around the damaged section of the filament.
2. Attach tape above and below the damaged section of the filament.
3. Using a small brush or marking pen, repair the filament with silver paint or equivalent.
4. Use a hot-air blower heated to 150°C { 302°F } for 30 minutes or let the paint set for 24 hours at 25°C { 77°F } to allow it to dry completely. Do not use the defroster until the paint is dry.

WINDOW GLASS


**PREPARATION
SST**

<p>49 0305 870A</p> <p>Tool set, window</p>		<p>For removal / installation of glass</p>
---	---	--




**WINDSHIELD
Removal**

1. Disconnect the negative battery cable.
2. Remove the following parts.
 - (1) Windshield upper molding. (Refer to page S-31.)
 - (2) Windshield lower molding. (Refer to page S-31.)
 - (3) Rearview mirror. (Refer to page S-36.)
 - (4) A-pillar trim. (Refer to page S-61.)
3. Remove the grommet as shown in the figure.
4. Apply protective tape along the edge of the body.




If the glass will not be reused


5. Use a tool like that shown in the figure and insert the blade into the sealant.
6. Pull through the sealant around the edge of the glass.
7. Remove the glass



8. Remove the spacers from the body.




9. Remove the dam from the glass.




If the glass will be reused

5. Use protective tape or cloth along the front edge of the headliner to protect it from damage.



6. Make a hole through the sealant from the inside of the vehicle by using an awl.

7. Pass piano wire through the hole.




8. Wind each end of the wire around a bar.

9. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.

10. Remove the glass.

11. Remove the spacers from the body.

12. Remove the dam from the glass.









Installation

1. Cut away the old sealant by using a razor knife so that **1 to 2 mm { 0.04 to 0.08 in }** thickness of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then put on new sealant to create a **2 mm { 0.08 in }** layer.

2. Clean and degrease around the circumference of the glass and the bonding area on the body.

3. Securely bond a new dam along the circumference of the glass **7 mm { 0.28 in }** from the edge. Allow it to dry completely.





4. Install the spacers onto the body as shown. If a spacer is damaged, replace it.
5. Temporarily install the glass onto the body and make a mark on the glass directly above the V-notch of the spacers.
6. Remove the glass.

7. Use a brush to apply primer to the bonding area of the glass and the body. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately **30 minutes**.

8. Prepare the nozzle of the sealant tube so that it has a flange that can run along the edge of the glass and a V from which the sealant can flow. Once the primer is dry, apply repair sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant **12 mm { 0.47 in }** high. Keep the bead of sealant smooth and even, reshaping it where necessary by using a spatula.

9. Align the glass marks with the V notches in the spacers and install the glass onto the body.
10. Press firmly inward on the glass to compress the sealant.
11. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact.
12. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.


Hardening time of repair sealant

Temperature	Surface hardening time	Time required until car can be put into service
5 °C { 41 °F }	Approx. 1.5 hr	12 hr
20 °C { 68 °F }	Approx. 1 hr	4 hr
35 °C { 95 °F }	Approx. 10 min	2 hr

13. Check for water leaks. If a leak is found, wipe the water off well and add repair sealant where needed.
14. Install the following parts.
 - a. A-pillar trim. (Refer to page S-61.)
 - b. Rearview mirror. (Refer to page S-36.)
 - c. Windshield lower molding. (Refer to page S-31.)
 - d. Windshield upper molding. (Refer to page S-31.)

QUARTER WINDOW GLASS**Removal / Installation**

1. Disconnect the negative battery cable (if equipped with a rear cooler).
2. Remove the B-pillar upper trim (Refer to page S-61.) and D-pillar trim (Refer to page S-61.).
3. Remove the rear cooler trim (Refer to page S-62.) (if equipped with a rear cooler).
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal.




1. Quarter window
2. Quarter window lock

3. Quarter window hinge


DOOR QUARTER WINDOW GLASS**Removal / Installation**

1. Remove the glass guide. (Refer to page S-11.)
2. Remove the door quarter window glass with the door quarter window glass weatherstrip.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Door quarter window glass weatherstrip


2. Door quarter window glass



REAR WINDOW GLASS


Removal

1. Disconnect the negative battery cable.
2. Remove the rear wiper arm. (Refer to section T.)
3. Apply protective tape along the edge of the body to protect it from damage.
4. Cut the lip of the rear window molding by using a razor knife, and remove the lip.




If the glass will not be reused

5. Use a tool like that shown in the figure and insert the blade into the sealant.
6. Pull through the sealant around the edge of the glass.




Note






- The rear window glass has fastener-type pins as shown.



7. Make a hole through the sealant between the rear window glass and the pins from the inside of the vehicle by using an awl.
8. Pass piano wire through the hole.
9. Wind each end of the wire around a bar.
10. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
11. Remove the glass.
12. Turn the pin 90° clockwise and remove it.



13. Remove the dam and spacers.



If the glass will reused

5. Make a hole through the sealant from the inside of the vehicle by using an awl.
6. Pass piano wire through the hole.


Note

- The rear window glass has fastener-type pins as shown.
- If it is difficult to cut the sealant with the piano wire, cut it by using a razor knife.


7. Wind each end of the wire around a bar.
8. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking. Make sure the wire does not rub on the body.
9. Remove the glass.
10. Turn the pin **90°** clockwise and remove it.
11. Remove the dam and spacers.

Installation


1. Cut away the old sealant by using a razor knife so that **1 to 2 mm { 0.04 to 0.08 in }** of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then put on new sealant to create a **2 mm { 0.08 in }** layer.
2. Carefully clean an area **50 mm { 2.0 in }** wide around the circumference of the glass and clean the bonding area on the body.
3. Securely bond a new dam along the circumference of the glass **11.5 mm { 0.45 in }** from the edge. Allow it to dry completely.
4. Securely bond new spacers to the glass as shown.




5. Install the rear window molding to the glass.
 - (1) Align the molding to the center of the lower. (①)
 - (2) Align the molding to the lower corners. (②)
 - (3) Install the molding from outside to inside. (③)
 - (4) Install the molding from the sides to the top. (④)



6. Apply primer to the bonding area of the glass, body, and pin by using a brush. Use only glass primer on the glass, and body primer on the body and pin. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately **30 minutes**.




7. Apply the sealant to the glass pins installation positions as shown.
8. Keep the bead of sealant smooth and even, reshaping it where necessary by using a spatula.




9. Install the pins.

Hardening time of repair sealant

Temperature	Surface hardening time	Time required until car can be put into service
5 °C { 41 °F }	Approx. 1.5 hr	12 hr
20 °C { 68 °F }	Approx. 1 hr	4 hr
35 °C { 95 °F }	Approx. 10 min	2 hr




10. Apply an **11 mm { 0.43 in }** high bead of repair sealant around the circumference of the glass as shown. Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.



11. Align the glass via the pins and install it onto the body.
12. Press firmly inward on the glass to compress the sealant.
13. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant


Temperature	Surface hardening time	Time required until car can be put into service
5 °C { 41 °F }	Approx. 1.5 hr	12 hr
20 °C { 68 °F }	Approx. 1 hr	4 hr
35 °C { 95 °F }	Approx. 10 min	2 hr




14. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact.
15. Check for water leaks. If a leak is found, wipe the water off well and reinstall the rear window glass.
16. Install the rear wiper arm. (Refer to section T.)

SLIDING SUNROOF


COMPONENTS




- | | |
|---|---|
| 1. Decoration cover
Removal / Installation page S-48 | 10. Rear guide
Removal / Installation page S-51 |
| 2. Slide panel
Removal / Installation page S-48
Adjustment page S-48 | 11. Guide rail
Removal / Installation page S-51 |
| 3. Front guide
Removal / Installation page S-49 | 12. Sunroof harness
Removal / Installation page S-52
Inspection page S-52 |
| 4. Deflector
Removal / Installation page S-49 | 13. Sunroof relay
Removal / Installation page S-52
Inspection page S-52 |
| 5. Guide rail cover
Removal / Installation page S-49 | 14. Drive unit
Removal / Installation page S-53 |
| 6. Sunroof motor assembly
Removal / Installation page S-49
Inspection page S-50 | 15. Front drain hose
Removal / Installation page S-54 |
| 7. Sunroof unit
Removal / Installation page S-51
Disassembly / Assembly page S-51 | 16. Rear drain hose
Removal / Installation page S-54 |
| 8. Sunshade
Removal / Installation page S-51 | 17. Sunroof switch
Removal / Installation page S-55
Inspection page S-55 |
| 9. Set plate
Removal / Installation page S-51 | 18. Weatherstrip
Removal / Installation page S-55 |

**DECORATION COVER****Removal / Installation**


1. Slide the sunshade all the way to the rear.
2. Fully close the slide panel.




3. Remove the decoration cover mounting screws and remove the left and right decoration covers.
4. Install in the reverse order of removal.

**SLIDE PANEL****Removal / Installation**

1. Remove the decoration cover. (Refer above.)
2. Remove the six installation nuts from the slide panel and bracket.




3. Remove the shims from between the slide panel and the bracket.
4. Remove the slide panel by pushing it upward from inside the vehicle.
5. Install in the reverse order of removal.

**Adjustment Height**

1. Remove the decoration cover. (Refer above.)
2. Loosen the slide panel installation nuts and insert a shim(s) between the brackets and slide panel.

Allowable height clearance

- ①: $3.1^{+1.5}_{-0.5}$ mm { $0.12^{+0.06}_{-0.02}$ in }
- ②: $5.6^{+1.5}_{-0.5}$ mm { $0.22^{+0.06}_{-0.02}$ in }
- ③: $1.0^{+1.5}_{-0.5}$ mm { $0.04^{+0.06}_{-0.02}$ in }

**Gap**

1. Open the sliding panel about **100 mm { 3.9 in }** from the fully closed position.
2. Pull up on the weatherstrip surrounding the section which is to be measured.
3. Fully close the slide panel.
4. Remove the decoration cover. (Refer to page S-48.)
5. Loosen the set plate mounting screws and adjust the gap.

Allowable gap clearance



- ①: $6.0 \pm 0.3 \text{ mm } \{ 0.24 \pm 0.01 \text{ in } \}$
 ②: $6.6 \pm 0.3 \text{ mm } \{ 0.26 \pm 0.01 \text{ in } \}$

FRONT GUIDE**Removal**

1. Remove the slide panel. (Refer to page S-48.)
2. Remove the front guide.

Installation

Insert the front guide into the guide rail, and set it to press the deflector link (sunroof at fully closed position).

**DEFLECTOR****Removal / Installation**


1. Fully open the slide panel.
2. Remove the E-ring at the rear of the deflector link, and remove the pin.
3. Remove the screws and remove the deflector.
4. Install in the reverse order of removal.

GUIDE RAIL COVER**Removal**


1. Fully open the slide panel.
2. Remove the guide rail cover mounting screws and remove the guide rail cover.


Installation

1. Insert the hook into the frame.
2. Install in the reverse order of removal.

**SUNROOF MOTOR ASSEMBLY****Removal**


1. Disconnect the negative battery cable.
2. Remove the front headliner. (Refer to page S-67.)
3. Disconnect the harness connector from the sunroof motor assembly.
4. Remove the sunroof motor assembly mounting screws and remove the sunroof motor assembly.






Installation

1. Open the slide panel **200 mm { 7.87 in }** from the front end of deflector.




2. Turn the sunroof motor by using an allen wrench until the motor limit switch reaches the position shown in the figure.
3. Install the sunroof motor.
4. Connect the harness connector.
5. Install the front headliner. (Refer to page S-67.)



Inspection

1. Remove the front headliner. (Refer to page S-67.)
2. Disconnect the sunroof connector.
3. Connect battery positive voltage to terminal F and terminal E to ground. Verify that the motor rotates in the opening direction.
4. Reverse the above connections and verify that the motor rotates in the closing direction.
5. If not as specified, replace the sunroof motor.




(Limit switch)

1. Remove the front headliner. (Refer to page S-67.)
2. Disconnect the sunroof harness connector.
3. Check for continuity between terminals C and D of the sunroof motor assembly harness connector with the slide panel in the following positions. Operate the slide panel by using an allen wrench.

○—○: Continuity

Terminal	C	D
Panel position		
Open		
Close		
Close (200 mm { 7.87 in } from the front end of the deflector)	○—○	○—○

4. If not as specified, replace the sunroof motor.




SUNROOF UNIT Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the front headliner. (Refer to page S-67.)
3. Remove the slide panel. (Refer to page S-48.)
4. Remove the sunroof unit mounting nuts and remove the sunroof unit.
5. Install in the reverse order of removal.

Disassembly / Assembly


1. Remove the sunshade. (Refer below.)
2. Remove the deflector. (Refer to page S-49.)
3. Remove the front guide. (Refer to page S-49.)
4. Remove the set plate. (Refer to page S-51.)
5. Remove the rear guide. (Refer to page S-51.)
6. Remove the drive unit. (Refer to page S-53.)
7. Assemble in the reverse order of disassembly.



SUNSHADE

Removal / Installation


1. Remove the guide rail. (Refer below.)
2. Remove the sunshade.
3. Install in the reverse order of removal.



SET PLATE

Removal / Installation


1. Fully open the slide panel.
2. Remove the set plate mounting screws and remove the set plate.
3. Install in the reverse order of removal.



REAR GUIDE

Removal / Installation


1. Remove the sunroof unit. (Refer above.)
2. Remove the guide rail mounting screws.
3. Lift up the rear end of the guide rail and pull out the rear guide.
4. Install in the reverse order of removal.



GUIDE RAIL

Removal / Installation


1. Remove the rear guide. (Refer above.)
2. Lift up the end of the guide rail and remove the guide rail.
3. Install in the reverse order of removal.



SUNROOF HARNESS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the front headliner. (Refer to page S-67.)
3. Remove the sunroof harness installation clip and remove the sunroof harness.
4. Install in the reverse order of removal.



Inspection


1. Remove the sunroof harness. (Refer above.)
2. Check for continuity between the terminals of the sunroof harness connectors by using an ohmmeter.

○—○: Continuity

TERMINAL						
1A	1B	1C	2B	2E	3B	3F
○			○			
	○				○	
		○		○		○

TERMINAL					
2G	2H	2D	3D	3E	3C
○				○	
	○		○		
		○			○


3. If not as specified, replace the sunroof harness.



SUNROOF RELAY

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the front headliner. (Refer to page S-67.)
3. Remove the sunroof relay bracket mounting screw and remove the sunroof relay.
4. Install in the reverse order of removal.



Inspection


1. Measure the voltage at the sunroof relay terminals by using a voltmeter. (Refer to page S-53.)
2. If not as specified, replace the sunroof relay.

Terminal voltage list
Relay

B+: Battery positive voltage




Terminal	Signal	Connection	Test condition	Voltage (V)	Inspection area
A	—	—	—	—	—
B	Sunroof open control	Sunroof switch	Sunroof opening	B+	Wiring harness (Sunroof switch — Sunroof relay)
			Other	0	
C	—	—	—	—	—
D	Limit switch ON	Sunroof motor (Limit switch)	Momentarily stops during sunroof closing (Limit switch ON)	0	Wiring harness (Sunroof relay — Sunroof motor)
			Other	0—B+	
E	Sunroof close control	Sunroof switch	Sunroof closing	B+	Wiring harness (Sunroof relay — Sunroof switch)
			Other	0	
F	—	—	—	—	—
G	Sunroof motor control	Sunroof motor	Sunroof opening	B+	Wiring harness (Sunroof relay — Sunroof motor)
			Sunroof closing	0	
H	Limit switch ON	Sunroof motor (Limit switch)	Momentarily stops during sunroof closing (Limit switch ON)	0	Wiring harness (Sunroof relay — Sunroof motor)
			Other	0—B+	



DRIVE UNIT

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the sunroof unit. (Refer to page S-51.)
3. Remove the sunroof motor. (Refer to page S-49.)
4. Remove the guide rail cover. (Refer to page S-49.)
5. Remove the drive unit mounting screw and remove the drive unit.
6. Install in the reverse order of removal.

**FRONT DRAIN HOSE****Removal**

1. Remove the front headliner. (Refer to page S-67.)
2. Remove the front drain hose from the clips.
3. Pull the front drain hose into the room side and remove the front drain hose.

Installation


1. Apply soapy water to the drain hose.
2. Insert one end of the hose into the sunroof frame, set the hose along the clips, and insert the other end into the floor side panel hole.

**REAR DRAIN HOSE****Removal**

1. Remove the rear headliner. (Refer to page S-68.)
2. Remove the rear drain hose from the clips.
3. Pull the rear drain hose into the room side and remove the rear drain hose.


Installation

1. Apply soapy water to the rear drain hose.
2. Insert one end of the hose into the sunroof frame, set the hose along the clips, and insert the other end into the floor side panel.



SUNROOF SWITCH
Removal / Installation

1. Remove the negative battery cable.
2. Remove the sunroof switch installation clip and remove the sunroof switch.
3. Install in the reverse order of removal.




Inspection

1. Remove the sunroof switch. (Refer above.)
2. Check for continuity between the terminals with the sunroof switch in the following positions by using an ohmmeter.

○—○: Continuity

Terminal / Switch position	A	B	C	D	E
Open		○—○		○—○	
Off	○—○	○—○	○—○		
Close			○—○	○—○	

3. If not as specified, replace the sunroof switch.




WEATHERSTRIP
Removal / Installation

1. Remove the slide panel. (Refer to page S-48.)
2. Peel the weatherstrip off the slide panel and remove the weatherstrip.
3. Install in the reverse order of removal.

DASHBOARD

STRUCTURAL VIEW



- | | |
|--|--|
| 1. Dashboard | 5. Column cover |
| Removal / Installation page S-57 | Removal / Installation page S-59 |
| Disassembly / Assembly page S-58 | 6. Meter hood |
| 2. Side panel | Removal / Installation page S-60 |
| Removal / Installation page S-59 | 7. Lower panel |
| 3. Glove compartment | Removal / Installation page S-60 |
| Removal / Installation page S-59 | 8. Center lower panel |
| Disassembly / Assembly page S-59 | Removal / Installation page S-60 |
| 4. Glove compartment cover | 9. Center upper panel |
| Removal / Installation page S-59 | Removal / Installation page S-60 |

DASHBOARD


Removal / Installation

1. Disconnect the negative battery cable.

Warning

- **Handling the air bag module improperly can accidentally deploy the air bag, which may seriously injure you. Read SERVICE WARNINGS, section T, before handling the air bag module.**

2. Remove the A-pillar trim. (Refer to page S-61.)
3. Remove the front side trim. (Refer to page S-63.)
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal.



- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Side panel
Removal / Installation page S-59 2. Glove compartment
Removal / Installation page S-59
Disassembly / Assembly page S-59 3. Glove compartment cover
Removal / Installation section T 4. Driver-side air bag
Removal / Installation section T 5. Steering wheel
Removal / Installation section N | <ol style="list-style-type: none"> 6. Column cover
Removal / Installation page S-59 7. Steering shaft
Removal / Installation section N 8. Lower panel
Removal / Installation page S-60 9. Dashboard
Installation note below
Disassembly / Assembly page S-58 |
|--|--|


Installation note

Dashboard

On vehicles with a wire-type heater control unit, adjust each wire. (Refer to section U.)


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




1. Pad bracket
2. Side demister duct
3. Duct
4. Center duct No.1
5. Center duct No.2
6. Dashboard harness


7. Dashboard member
8. Demister grille
9. Side ventilator
10. Defroster grille
11. Dashboard crush pad

**SIDE PANEL****Removal / Installation**


1. Pull the front edge of the side panel forward to remove the clips from the body.
2. Pull the side panel forward to remove the pins from the body.
3. Install in the reverse order of removal.

**GLOVE COMPARTMENT****Removal / Installation**


1. Slide the glove compartment to the left.
2. Pull the right side forward to release the pin.
3. Remove the glove compartment by sliding it to the right.
4. Install in the reverse order of removal.

**Disassembly / Assembly**


1. Remove the glove compartment lock installation screws.
2. Install in the reverse order of removal.

**GLOVE COMPARTMENT COVER****Removal / Installation**


1. Remove the side panel. (Refer above.)
2. Remove the glove compartment. (Refer above.)
3. Remove the glove compartment cover installation screws.
4. Pull the glove compartment cover forward to remove the clip from the body.
5. Install in the reverse order of removal.

**COLUMN COVER****Removal / Installation**


1. Remove the column cover installation screws.
2. Install in the reverse order of removal.

**METER HOOD****Removal / Installation**


1. Remove the meter hood installation screws.
2. Pull the meter hood forward to remove the clips from the body.
3. Install in the reverse order of removal.

**LOWER PANEL****Removal / Installation**


1. Remove the hood release lever.
2. Remove the side panel. (Refer to page S-59.)
3. Remove the lower panel installation screws.
4. Pull the lower panel forward to remove the clips from the body.
5. Install in the reverse order of removal.

**CENTER LOWER PANEL****Removal / Installation**


1. Remove the lower panel. (Refer above.)
2. Remove the glove compartment cover. (Refer to page S-59.)
3. Remove the center lower panel installation screws.
4. Pull the center lower panel forward to remove the clips from the body.
5. Install in the reverse order of removal.

**CENTER UPPER PANEL****Removal / Installation**


1. Remove the center lower panel. (Refer above.)
2. Remove the center upper panel installation screws.
3. Pull the center upper panel forward to remove the clips from the body.
4. Install in the reverse order of removal.

**TRIM****A-PILLAR TRIM****Removal / Installation**


1. Remove the front header trim. (Refer to page S-64.)
2. Remove the B-pillar upper trim. (Refer below.)
3. Pull the A-pillar trim to disengage clips (A) and pin (B) from the body.
4. Install in the reverse order of removal.

**B-PILLAR LOWER TRIM****Removal / Installation**


1. Remove the front scuff plate. (Refer to page S-63.)
2. Remove the rear scuff plate. (Refer to page S-63.)
3. Pull the B-pillar lower trim to disengage clips (A) and pin (B) from the body.
4. Install in the reverse order of removal.

**B-PILLAR UPPER TRIM****Removal / Installation**

1. Remove the D-pillar trim. (Refer below.)
2. Remove the B-pillar lower trim. (Refer above.)
3. Remove the rear side trim. (Refer to page S-65.)
4. Remove the front seat belt upper anchor (page S-71) and the rear No.1 seat belt upper anchor (page S-73).
5. Pull the B-pillar upper trim to disengage clips (A) and pins (B) from the body.
6. Install in the reverse order of removal.

**D-PILLAR TRIM****Removal / Installation**


1. To remove the left side D-pillar trim, disconnect the negative battery cable.
2. Remove the rear header trim. (Refer to page S-64.)
3. Remove the rear side trim. (Refer to page S-65.)
4. Remove the mat set end plate. (Refer to page S-66.)
5. Remove the installation bolts (left side only).
6. Remove the installation fasteners.
7. Pull the D-pillar trim to disengage clips (A) from the body.
8. Install in the reverse order of removal.



REAR COOLER TRIM


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the rear header trim. (Refer to page S-64.)
3. Remove the rear side trim. (Refer to page S-65.)
4. Remove the mat set end plate. (Refer to page S-66.)
5. Remove the rear heater control unit. (Refer to section U.)
6. Remove the rear cooler grille by using a flathead screwdriver wrapped in tape.
7. Remove the screws and bolts.
8. Pull the rear cooler trim to disengage clips (C) and pins (D).
9. Install in the reverse order of removal.




Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




1. Bracket No.1
2. Bracket No.2
3. Bracket No.3
4. Rear cooler duct


5. Harness
Assembly note page S-63
6. Rear cooler trim

**Assembly note****Harness**


Assemble the harness as shown.

**FRONT SIDE TRIM****Removal / Installation**


1. Remove the fastener.
2. Pull the front side trim to disengage clips (A) and pins (B) from the body.
3. Install in the reverse order of removal.

**FRONT SCUFF PLATE****Removal / Installation**


1. Remove the screws.
2. Pull the front scuff plate to disengage clips (A) and pin (B) from the body.
3. Install in the reverse order of removal.

**REAR SCUFF PLATE****Removal / Installation**


1. Remove the screws.
2. Pull the rear scuff plate to disengage clips (A) and pin (B) from the body.
3. Install in the reverse order of removal.

**FRONT DOOR TRIM****Removal / Installation**


1. Disconnect the negative battery cable.
2. Remove the switch panel. (Refer to page S-13.)
3. Remove the caps.
4. Remove the screws.
5. Pull the front door trim to disengage the clips (A) from the body.
6. Lift the front door trim to disengage the pins (B) from the body.
7. Disconnect the harness connectors.
8. Install in the reverse order of removal.

**TIRE HOUSE TRIM (RH)****Removal / Installation**


1. Remove the rear scuff plate. (Refer to page S-63.)
2. Pull the tire house trim to disengage clips (A) and pins (B) from the body.
3. Install in the reverse order of removal.

**TIRE HOUSE TRIM (LH)****Removal / Installation**


1. Remove the rear scuff plate. (Refer to page S-63.)
2. Remove the rear side trim. (Refer below.)
3. Remove the screws.
4. Remove the tire house trim.
5. Install in the reverse order of removal.

**TIRE HOUSE REAR TRIM****Removal / Installation**


1. Remove the rear side trim. (Refer below.)
2. Remove the tire house trim. (Refer above.)
3. Remove the fasteners.
4. Remove the tire house rear trim.
5. Install in the reverse order of removal.

**REAR SIDE TRIM****Removal / Installation**


1. Remove the mat set end plate. (Refer to page S-66.)
2. Remove the screws.
3. Pull the rear side trim to disengage clips (A) and pins (B) from the body.
4. Install in the reverse order of removal.

**Disassembly / Assembly**


1. Remove the screws to disassemble the rear side trim.
2. Assemble in the reverse order of disassembly.

**MAT SET END PLATE****Removal / Installation**


1. Remove the screws.
2. Remove the mat set end plate.
3. Install in the reverse order of removal.

**LIFTGATE UPPER TRIM****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the high-mount brake light. (Refer to section T.)
3. Remove the caps.
4. Remove the screws.
5. Pull the liftgate upper trim to disengage clips (A) and pins (B) from the body.
6. Install in the reverse order of removal.

**LIFTGATE LOWER TRIM****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the cargo compartment light.
3. Remove the fasteners.
4. Remove the liftgate lock knob bezel.
5. Remove the pull handle cover.
6. Remove the screws.
7. Remove the pull handle.
8. Pull the liftgate to disengage clips (A) and pins (B) from the body.
9. Install in the reverse order of removal.


**LIFTGATE SIDE TRIM****Removal / Installation**

1. Remove the liftgate upper trim. (Refer above.)
2. Remove the liftgate lower trim. (Refer above.)
3. Pull the liftgate to disengage clips (A) and pins (B) from the body.
4. Install in the reverse order of removal.

HEADLINER

FRONT HEADLINER
Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the rear headliner. (Refer to page S-68.)
3. Remove the A-pillar trim. (Refer to page S-61.)
4. Remove the rearview mirror. (Refer to page S-36.)
5. Remove the interior light. (Refer to section T.)
6. Remove the overhead console, if equipped. (Refer to section T.)
7. Remove in the order shown in the figure.
8. Install in the reverse order of removal.



1. Sunvisor and adapter
2. Assist handle cover
3. Assist handle


4. Hole cover (without front side assist handle)
5. Front headliner

Removal note page S-68

REAR HEADLINER


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the interior light. (Refer to section T.)
3. Remove the B-pillar upper trim. (Refer to page S-61.)
4. Remove the rear header trim. (Refer to page S-64.)
5. Remove in the order shown in the figure.
6. Install in the reverse order of removal.



1. Assist handle cover
2. Assist handle
3. Hole cover (Without assist handle)


4. Rear headliner
Removal note below



Removal note
Front headliner, rear headliner
 Remove the clips by using the fastener remover.

FLOOR COVERING**FRONT CABIN CARPET****Removal / Installation**


1. Disconnect the negative battery cable.
2. Remove the following parts.
 - a) Parking brake lever (Refer to section P.)
 - b) Fuel-filler lid opener (Refer to page S-28.)
 - c) Front seat (Refer to page S-77.)
 - d) Rear seat No.1 (Refer to page S-78.)
 - e) Dashboard center lower panel (Refer to page S-60.)
 - f) Front side trim (Refer to page S-63.)
 - g) Front scuff plate (Refer to page S-63.)
 - h) Rear scuff plate (Refer to page S-63.)
 - i) B-pillar lower trim (Refer to page S-61.)
 - j) Rear No.1 seat belt lower anchor (Refer to page S-73.)
3. Remove as shown in the figure.
4. Install in the reverse order of removal.



1. Front cabin carpet

REAR CABIN CARPET**Removal / Installation**

1. Remove the following parts.
 - a) Rear side trim (Refer to page S-65.)
 - b) Mat end set plate (Refer to page S-66.)
 - c) Rear seat No.2 (Refer to page S-79.)
 - d) Rear No.2 seat belt lower anchor (Refer to page S-75.)
2. Remove as shown in the figure.
3. Install in the reverse order of removal.



1. Rear cabin carpet

SEAT BELT


FRONT SEAT BELT

Removal / Installation

Caution

- The ELR (emergency locking retractor) has a spring that will unwind if the retractor's cover is removed. The spring cannot be rewound by hand. If this occurs, the ELR will not work properly. Therefore, do not disassemble the retractor.

1. Remove the B-pillar lower trim. (Refer to page S-61.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



N·m { kgf·m , ft·lbf }


1. Anchor cover

2. Front seat belt

Inspection page S-72

Inspection**Front seat belt**


1. Inspect the webbing for scars, tears, and wear.
2. Inspect the fittings for deformation and damage.
3. If a problem is found, replace the front seat belt.

**ELR (emergency locking retractor)**

1. Verify that the belt can be pulled out smoothly, and that it moves smoothly when worn.
2. Verify that the retractor locks when the belt is quickly pulled.
3. Remove the retractor. (Refer to page S-71.)
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at approximately 30° inclination.
7. If not as specified, replace the front seat belt.

ALR (Automatic locking retractor)


1. Pull the seat belt all the way out, insert the tongue into the buckle, and verify that the retractor locks after the slack is taken up.
2. Unfasten the tongue from the buckle and let the seat belt retract.
3. Verify that the belt can be pulled out smoothly and that it moves smoothly when worn.
4. Verify that the retractor locks when the belt is quickly pulled.

**FRONT BUCKLE****Removal / Installation**

1. Disconnect the negative battery cable.
2. Disconnect the driver's buckle switch connector.
3. Remove the front buckle installation bolt.
4. Install in the reverse order of removal.

Tightening torque:

39—78 N·m { 3.9—8.0 kgf·m , 29—57 ft·lbf }

**Inspection**

1. Disconnect the buckle switch connector.
2. Check for continuity between the connector terminals.

○—○: Continuity

Terminal	Driver	
	A	B
Buckled		
Unbuckled	○—○	○—○


3. If not as specified, replace the front buckle.

REAR No.1 SEAT BELT
Removal / Installation

Caution

- The ELR (emergency locking retractor) has a spring that will unwind if the retractor's cover is removed. The spring cannot be rewound by hand. If this occurs, the ELR will not work properly. Therefore, do not disassemble the retractor.

1. Remove the rear side trim. (Refer to page S-65.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




1. Anchor cover

2. Rear No.1 seat belt
Inspection page S-74

Inspection**Rear No.1 seat belt**


1. Inspect the webbing for scars, tears, and wear.
2. Inspect the fittings for deformation or damage.
3. If a problem is found, replace the rear No.1 seat belt.

**ELR (emergency locking retractor)**

1. Verify that the belt can be pulled out smoothly, and that it moves smoothly when worn.
2. Verify that the retractor locks when the belt is quickly pulled.
3. Remove the retractor. (Refer to page S-73.)
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at approximately 30° inclination.
7. If not as specified, replace the front seat belt.

ALR (Automatic locking retractor)

1. Pull the seat belt all the way out, insert the tongue into the buckle, and verify that the retractor locks after the slack is taken up.
2. Unfasten the tongue from the buckle and let the seat belt retract.
3. Verify that the belt can be pulled out smoothly and that it moves smoothly when worn.
4. Verify that the retractor locks when the belt is quickly pulled.

**REAR No.1 BUCKLE****Removal / Installation**

1. Remove the rear No.1 buckle installation bolt.
2. Install in the reverse order of removal.

Tightening torque:


39—78 N·m { 3.9—8.0 kgf·m , 29—57 ft·lbf }

REAR No.2 SEAT BELT Removal / Installation

Caution

- The ELR (emergency locking retractor) has a spring that will unwind if the retractor's cover is removed. The spring cannot be rewound by hand. If this occurs, the ELR will not work properly. Therefore, do not disassemble the retractor.

1. Remove the rear side trim. (Refer to page S-65.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




1. Anchor cover

2. Rear No.2 seat belt

Inspection page S-76

Inspection**Rear No.2 seat belt**


1. Inspect the webbing for scars, tears, and wear.
2. Inspect the fittings for deformation and damage.
3. If a problem is found, replace the rear No.2 seat belt.

**ELR (emergency locking retractor)**

1. Verify that the belt can be pulled out smoothly, and that it moves smoothly when worn.
2. Verify that the retractor locks when the belt is quickly pulled.
3. Remove the retractor. (Refer to page S-75.)
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at approximately 30° inclination.
7. If not as specified, replace the front seat belt.

ALR (Automatic locking retractor)

1. Pull the seat belt all the way out, insert the tongue into the buckle, and verify that the retractor locks after the slack is taken up.
2. Unfasten the tongue from the buckle and let the seat belt retract.
3. Verify that the belt can be pulled out smoothly and that it moves smoothly when being worn.
4. Verify that the retractor locks when the belt is quickly pulled.

**REAR No.2 BUCKLE****Removal / Installation**

1. Remove the rear No.2 buckle installation bolt.
2. Install in the reverse order of removal.

Tightening torque:


39—78 N·m { 3.9—8.0 kgf·m , 29—57 ft·lbf }

SEAT

FRONT SEAT

Removal / Installation

1. Disconnect the negative battery cable.
2. Disconnect the driver's buckle switch connector.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Fuel-filler lid opener
2. Parking brake lever
3. Seat set bracket cover


4. Leg cover
5. Front seat

Disassembly / Assembly page S-78

6. Seat under tray

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




- | | |
|---------------------|----------------------|
| 1. Armrest | 8. Buckle |
| 2. Headrest | 9. Seat back |
| 3. Headrest guide | 10. Slide adjuster |
| 4. Knob | 11. Seat set bracket |
| 5. Side cover | 12. Seat cushion |
| 6. Knuckle cable | |
| 7. Recliner knuckle | |


Disassembly note page S-84

REAR SEAT No.1
Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Rear seat No.1
 Disassembly / Assembly page S-80




1. Rear seat No.1
 Disassembly / Assembly page S-81

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.

(7-PASSENGER MODEL)




N·m { kgf·m , ft·lbf }

- | | |
|---------------------|---|
| 1. Armrest | 8. Buckle |
| 2. Headrest | 9. Seat back |
| 3. Headrest guide | 10. Slide adjuster |
| 4. Knob | 11. Seat set bracket |
| 5. Side cover | 12. Seat cushion |
| 6. Knuckle cable | 13. Cup stand cover (Rear seat No.1 RH) |
| 7. Recliner knuckle | 14. Cup stand (Rear seat No.1 RH) |

Disassembly note page S-84

(8-PASSENGER MODEL)



N-m { kgf-m , ft-lbf }

Rear seat cushion

1. Lower side cover
2. Slide protector No.1
3. Slide protector No.2
4. Knob
5. Side cover No.1
6. Side cover No.2
7. Knuckle lever
8. Recliner knuckle
9. Connecting rod
10. Seat set bracket
11. Slide adjuster
12. Seat cushion trim
13. Seat cushion pad

14. Seat cushion frame

15. Rear No.1 buckle

16. Walk in lever

Rear seat back

17. Headrest

18. Headrest guide

19. Armrest bracket

20. Cup stand

21. Armrest

22. Seat back board


23. Seat back trim

24. Seat back pad


25. Seat back frame

REAR SEAT No.2 Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



SEAT MOUNTING



N·m { kgf·m , ft·lbf }

Rear seat No.2

1. Safety stand
2. Rear seat No.2


Disassembly / Assembly page S-83

Seat mounting


3. Seat mount bar
4. Front hinge

Disassembly / Assembly


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



- | | |
|---------------------|-------------------------------|
| 1. Headrest | 8. Seat back board |
| 2. Headrest guide | 9. Seat back |
| 3. Safety stand | 10. Rear catch cover |
| 4. Front catch | 11. Rear catch |
| 5. Knuckle lever | 12. Rear No.2 buckle |
| 6. Side cover | 13. Seat cushion trim and pad |
| 7. Recliner knuckle | |

**Disassembly Note****Recliner knuckle**

1. Remove the hog rings from the rear of the seat back.



2. Lift the seat back trim until the recliner knuckle installation bolts are accessible.


3. Remove the recliner knuckle installation bolts and remove the recliner knuckle.

BODY ELECTRICAL SYSTEM

POWER SYSTEM	T- 2	WARNING AND INDICATOR	
STRUCTURAL VIEW	T- 2	SYSTEM	T-39
FUSES	T- 3	PREPARATION	T-39
IGNITION SWITCH	T- 4	STRUCTURAL VIEW	T-40
KEY REMINDER SWITCH	T- 4	INSTRUMENT CLUSTER	T-41
CPU	T- 5	SPEEDOMETER CABLE	T-44
EXTERIOR LIGHTING SYSTEM	T- 9	WARNING AND INDICATOR	
STRUCTURAL VIEW	T- 9	LIGHT	T-45
HEADLIGHT	T-10	FUEL GAUGE SENDER UNIT	T-46
FRONT COMBINATION LIGHT	T-12	WATER TEMPERATURE SENDER	
REAR COMBINATION LIGHT	T-12	UNIT	T-46
BACK-UP LIGHT	T-13	OIL PRESSURE SWITCH	T-47
HIGH-MOUNT BRAKE LIGHT	T-13	HORN	T-47
LICENCE PLATE LIGHT	T-13	HORN RELAY	T-47
COMBINATION SWITCH	T-14	AUDIO	T-48
HAZARD WARNING SWITCH	T-17	PREPARATION	T-48
FLASHER UNIT	T-18	STRUCTURAL VIEW	T-48
DRL RELAY	T-19	AUDIO UNIT, CD PLAYER	T-49
DRL RESISTOR	T-19	DOOR SPEAKER	T-49
INTERIOR LIGHTING SYSTEM	T-20	ANTENNA	T-50
STRUCTURAL VIEW	T-20	ANTENNA FEEDER	T-51
INTERIOR LIGHT	T-21	CRUISE CONTROL SYSTEM	T-52
SPOT LIGHT	T-23	PREPARATION	T-52
CARGO COMPARTMENT LIGHT	T-24	STRUCTURAL VIEW	T-53
DOOR SWITCH	T-24	ON-BOARD DIAGNOSTIC	T-54
CARGO COMPARTMENT LIGHT		CRUISE CONTROL MODULE	T-59
SWITCH	T-25	CRUISE ACTUATOR	T-62
PANEL LIGHT CONTROL SWITCH	T-25	ACTUATOR CABLE	T-63
WIPER AND WASHER	T-27	CRUISE CONTROL MAIN	
STRUCTURAL VIEW	T-27	SWITCH	T-64
WINDSHIELD WIPER MOTOR	T-28	CRUISE CONTROL SWITCH	T-64
WINDSHIELD WIPER ARM AND		AIR BAG SYSTEM	T-65
BLADE	T-30	PREPARATION	T-65
WINDSHIELD WIPER LINK		STRUCTURAL VIEW	T-65
AND FRAME	T-31	SERVICE WARNINGS	T-66
WINDSHIELD WASHER TANK	T-32	GENERAL PROCEDURES	T-67
WINDSHIELD WASHER MOTOR	T-32	TROUBLESHOOTING	T-68
WINDSHIELD WASHER NOZZLE	T-32	DRIVER-SIDE AIR BAG MODULE	T-74
REAR WIPER MOTOR	T-33	PASSENGER-SIDE AIR BAG	
REAR WIPER ARM AND BLADE	T-35	MODULE	T-75
REAR WASHER TANK	T-36	SAS UNIT	T-76
REAR WASHER MOTOR	T-36	AIR BAG MODULE DISPOSAL	
REAR WASHER NOZZLE	T-37	PROCEDURE	T-77
REAR WIPER AND WASHER		INSPECTION OF SST	
SWITCH	T-37	(DEPLOYMENT TOOL)	T-79
INTERMITTENT WIPER RELAY	T-38		

POWER SYSTEM

STRUCTURAL VIEW




- 1. MAIN fuse
Removal / Installation page T-3
- 2. ROOM fuse
Installation page T-3
- 3. Ignition switch
Removal / Installation page T-4
Inspection page T-4

- 4. Key reminder switch
Inspection page T-4
- 5. Joint box
Removal / Installation page T-5
- 6. CPU
Removal / Installation page T-5
Inspection page T-6

FUSES


Caution

- Determine and correct the cause of the burnt fuse before replacing it with the specified type. If the fuse is replaced before doing this, it may burn again.

**MAIN Fuse
Removal / Installation**


1. Remove the main fuse block cover.
2. Remove the main fuse block mounting bolts.
3. Remove the main fuse mounting bolts.
4. Remove the MAIN fuse.
5. Install in the reverse order of removal.

T

**ROOM Fuse
Installation****Note**

- When the ROOM fuse is burnt or removed, the malfunction indicator lamp illuminates. If the ROOM fuse is replaced or installed with the ignition switch at ON, the malfunction indicator lamp will continue to illuminate.


1. Turn the ignition switch to LOCK.
2. Install the ROOM fuse.



IGNITION SWITCH

Removal / Installation

1. Remove the column cover and lower panel.
(Refer to section S.)
2. Remove the screw.
3. Disconnect the connector.
4. Extract the key reminder switch terminals from the ignition switch.
5. Remove the ignition switch.
6. Install in the reverse order of removal.



Inspection

1. Remove the column cover and lower panel.
(Refer to section S.)
2. Disconnect the connector.
3. Check for continuity between the terminals of the ignition switch.

○—○: Continuity

Switch position \ Terminal	C	D	F	B	A	E
LOCK						
ACC	○—○		○—○			
ON	○—○	○—○	○—○	○—○	○—○	
START	○—○	○—○	○—○	○—○		○—○


4. If not as specified, replace the ignition switch.

KEY REMINDER SWITCH

Inspection

1. Remove the column cover.
2. Disconnect the connector.
3. Check for continuity between the terminals of the key reminder switch.

○—○: Continuity




Key condition \ Terminal	G	H
Key inserted	○—○	○—○
Key removed		

4. If not as specified, replace the steering lock assembly.
(Refer to section N.)

CPU

Removal / Installation

1. Remove the scuff plate and front side trim.
(Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




T


1. Nut
2. Bolt
3. Cover
4. Nut

5. Connectors
6. Joint box
7. CPU

Inspection page T-6

**Inspection****Connector A**


1. Remove the CPU from the joint box.
2. Measure the voltage at the CPU terminals from the joint box side, referring to the terminal voltage list on page T-7.
3. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
4. If the parts and wiring harnesses are OK but the system still does not work properly, replace the CPU.

**Connector B**

1. Follow the appropriate procedure, referring to the terminal voltage list on page T-8.

Terminals 2A, 2G, 2I, 2M, 2O


- (1) Disconnect the CPU connector.
- (2) Check for continuity between the terminals of the CPU connector and ground.

**Terminals except 2A, 2G, 2I, 2M, 2O**

- (1) Install the CPU onto the joint box.
 - (2) Measure the voltage at the CPU terminals.
2. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
 3. If the parts and wiring harnesses are OK but the system still does not work properly, replace the CPU.

Terminal voltage list (Reference)


B+: Battery positive voltage

CONNECTOR A						
						
Terminal	Signal	Connection	Test condition		Voltage/ Continuity	Inspection area
1A	Rear wiper	Rear wiper motor	IG switch at ON		B+	<ul style="list-style-type: none"> R.WIP 15 A fuse Rear wiper motor
1B	Idle-up input	Front fan switch	Continuity inspection	Front fan switch at OFF or 1st	No	Front fan switch
				Front fan switch at 2nd, 3rd, or 4th	Yes	
1C	ACC	CIGAR 15 A fuse	IG switch at ACC or ON		B+	CIGAR 15 A fuse
1D	Idle-up input	Combination switch	Headlight switch at 2nd position		B+	<ul style="list-style-type: none"> HEAD 30 A fuse Combination switch
1E	Shift lock	Shift-lock solenoid	IG switch at ON		B+	<ul style="list-style-type: none"> METER 10 A fuse Shift-lock solenoid
1F	Idle-up output	ECM	IG switch at ON		B+	ECM
1G	CPU ground	GND	Continuity inspection	Constant	Yes	—
1H	Brake	Brake switch	Brake switch on		B+	<ul style="list-style-type: none"> STOP 20 A fuse Brake switch
1I	P range	TR switch	IG switch at ON and selector lever at P range		B+	<ul style="list-style-type: none"> METER 10 A fuse TR switch
1J	+B	ROOM 15 A fuse	Constant		B+	ROOM 15 A fuse
1K	Key inserted	Key reminder switch	Key inserted into steering lock assembly		B+	<ul style="list-style-type: none"> ROOM 15 A fuse Key reminder switch
1L	TNS	Combination switch	Headlight switch at 1st position		B+	<ul style="list-style-type: none"> TAIL 15 A fuse Combination switch
1M	IG 1	METER 10 A fuse	IG switch at ON		B+	METER 10 A fuse
1N	Seat belt warning	<ul style="list-style-type: none"> Seat belt warning light Buckle switch 	IG switch at ON	Seat belt fastened	B+	<ul style="list-style-type: none"> METER 10 A fuse Instrument cluster Buckle switch
				Seat belt unfastened	0 V	
1O	Door open/closed	Door switch	IG switch at ON	Any door open	0 V	<ul style="list-style-type: none"> ROOM 15 A fuse Door switch Courtesy light
				All doors closed	B+	
1P	Idle-up input	<ul style="list-style-type: none"> Rear window defroster relay Rear window defroster switch 	IG switch at ON	Rear window defroster switch on	0 V	<ul style="list-style-type: none"> A/C 15 A fuse Rear window defroster relay Rear window defroster switch
				Rear window defroster switch off	B+	

T

B+: Battery positive voltage

CONNECTOR B




Terminal	Signal		Connection	Test condition		Voltage/ Continuity	Inspection area
2A	Door lock input		Door lock-link switch (driver)	Continuity inspection	Locked	Yes	Door lock-link switch
					Unlocked	No	
2B	—		—	—		—	—
2C	Door lock output		Door lock timer unit	The moment door lock-link switch locks		0 V	Door lock timer unit
				Other		B+	
2D	DRL		DRL relay	IG switch at ON		0 V	DRL relay
2E	Door lock output		Door lock timer unit	The moment door lock-link switch unlocks		0 V	Door lock timer unit
				Other		B+	
2F	Horn output		Horn relay	Horn switch pushed		0 V	<ul style="list-style-type: none"> • HORN 10 A fuse • Horn relay
				Other		B+	
2G	Door lock input		Door lock-link switch (driver)	Continuity inspection	Locked	No	Door lock-link switch
					Unlocked	Yes	
2H	—		—	—		—	—
2I	USA		—	—		—	—
	Canada	Brake system warning	Parking brake switch	Continuity inspection	Parking brake switch on	Yes	Parking brake switch
					Parking brake switch off	No	
2J	—		—	—		—	—
2K	Brake system warning		Brake system warning light	IG switch at ON and parking brake switch off		B+	<ul style="list-style-type: none"> • METER 10 A fuse • Instrument cluster
2L	—		—	—		—	—
2M	Rear wiper		Rear wiper switch	Continuity inspection	Rear wiper switch on	Yes	Rear wiper switch
2N	Keyless		Keyless unit	No operation by keyless unit		5 V	keyless unit
2O	Rear washer		Rear washer switch	Continuity inspection	Rear washer switch on	Yes	Rear washer switch
2P	R range		TR switch	IG switch at ON and selector lever at R range		B+	<ul style="list-style-type: none"> • METER 10 A fuse • TR switch

EXTERIOR LIGHTING SYSTEM

STRUCTURAL VIEW


Exterior



T

1. Headlight		5. High-mount brake light	
Removal / Installation page T-10	Removal / Installation page T-13
Aiming page T-11	Bulb replacement page T-13
Bulb replacement page T-11	6. Licence plate light	
2. Front combination light		Removal / Installation page T-13
Removal / Installation page T-12	7. DRL relay	
3. Rear combination light		Inspection page T-19
Removal / Installation page T-12	8. DRL resistor	
4. Back-up light		Removal / Installation page T-19
Removal / Installation page T-13	Inspection page T-19

Interior




- | | |
|--|--|
| <p>1. Combination switch
 Removal / Installation page T-14
 Disassembly / Assembly page T-14
 Inspection page T-15
 Adjustment page T-16</p> | <p>2. Hazard warning switch
 Removal / Installation page T-17
 Inspection page T-17</p> <p>3. Flasher unit
 Removal / Installation page T-18
 Inspection page T-18</p> |
|--|--|


HEADLIGHT

Removal / Installation

1. Remove the radiator grille.
(Refer to section S.)
2. Remove the front combination light.
(Refer to page T-12.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.




- | | |
|--|---|
| <p>1. Bolt
 2. Connector</p> | <p>3. Headlight
 Aiming page T-11
 Bulb replacement page T-11</p> |
|--|---|



Aiming

Vertical-horizontal aiming method


1. Adjust the tire air pressure to the specification.
(Refer to section Q.)
2. Fill the fuel tank and remove excess cargo.
3. Position the unloaded vehicle on a flat, level surface.
4. Rock the vehicle by hand several times.
5. Turn the adjusting screws to adjust the headlights. Use a "HOPPY" brand aimer or equivalent to aim the headlights to specification numbers 10H14V.



Bulb Replacement

Warning

- If the glass surface of a halogen bulb is touched with bare hands, natural body oil could cause the bulb to overheat when it is lit. Because a halogen bulb contains pressurized gas, this overheating will cause the bulb to burst. The flying glass may seriously injure you. Hold the metal flange, not the glass, when replacing the bulb.




1. Disconnect the headlight connector.
2. Remove the cover.
3. Remove the clip to remove the headlight bulb.
4. Install in the reverse order of removal.

Headlight bulb: High/Low 60/55 W

FRONT COMBINATION LIGHT**Removal / Installation**


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|----------------------------|--|
| 1. Screw | 4. Socket |
| 2. Front combination light | 5. Bulb (front turn light/parking light): 27/8 W |
| 3. Connector | |

REAR COMBINATION LIGHT**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




- | | |
|---------------------------|---|
| 1. Screw | 4. Socket |
| 2. Rear combination light | 5. Bulb (brake light/taillight): 27/8 W |
| 3. Connector | 6. Bulb (rear turn light): 27 W |

BACK-UP LIGHT


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Screw
2. Back-up light
3. Connector


4. Socket
5. Bulb (27 W)



HIGH-MOUNT BRAKE LIGHT

Removal / Installation


1. Remove the fasteners and cover.
2. Remove the bolts.
3. Disconnect the high-mount brake light connector and remove the high-mount brake light.
4. Install in the reverse order of removal.



Bulb Replacement

1. Remove the fasteners and cover.
2. Remove the sockets.
3. Remove the bulbs.
4. Install in the reverse order of removal.

High-mount brake light bulb: 21 W, 18 W × 2



LICENCE PLATE LIGHT

Removal / Installation


1. Remove the screws.
2. Remove the lens.
3. Disconnect the licence plate light connector.
4. Remove the licence plate light.
5. Remove the bulb.
6. Install in the reverse order of removal.

Licence plate light bulb: 5 W

COMBINATION SWITCH

Removal / Installation


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|--|--|
| 1. Cap | 6. Screw |
| 2. Bolt | 7. Column cover |
| 3. Air bag module | Removal / Installation section S |
| Removal / Installation page T-74 | 8. Connector |
| 4. Nut | 9. Combination switch |
| 5. Steering wheel | Inspection page T-15 |
| Removal / Installation section N | Adjustment page T-16 |

Disassembly / Assembly





1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of removal.



- | | |
|-----------------|----------------|
| 1. Clock spring | 5. Wiper lever |
| 2. Cancel cam | 6. Light lever |
| 3. Spring | 7. Light unit |
| 4. Band | |

Inspection

1. Remove the column cover.
(Refer to section S.)
2. Disconnect combination switch connector.
3. Check for continuity or resistance between the terminals as indicated below.
4. If not as specified, replace the necessary parts.



Headlight switch

○—○: Continuity

Light	Dimmer	Flash-to-pass	Terminal					
			1A	2B	2D	1B	2F	2C
OFF	—	OFF						
		ON	○—○					
Parking	—	OFF				○—○		
		ON	○—○			○—○		
Headlight	HL	OFF	○—○		○—○	○—○	○—○	○—○
		ON	○—○			○—○	○—○	○—○
	HU	—	○—○			○—○	○—○	○—○

Turn switch



○—○: Continuity

Switch position	Terminal	3H	3G	3F
Left		○—○	○—○	
OFF				
Right		○—○		○—○

Windshield wiper and washer switch

○W—○: Resistance ○—○: Continuity

Switch position	Terminal	4A	4F	4H	4C	4B	4D	4I	4J
		Wiper switch	OFF				○—○		○—○
	One-touch switch OFF								
	One-touch switch ON	○—○				○—○			
	INT	○—○		○—○	○—○		○—○		
	LO	○—○			○—○				
	HI	○—○				○—○			
Washer switch	ON	○—○							
INT volume	LO position							○W—○	50 kΩ
	MID position							○W—○	35 kΩ
	HI position							○W—○	15 kΩ



Clock spring

Warning

- Handling the air bag module improperly can accidentally deploy the air bag, which may seriously injure you. Read **SERVICE WARNINGS**, page T-66, before handling the air bag module.

1. Disconnect the negative battery cable.
2. Remove the lower panel.
(Refer to section S.)
3. Disconnect the clock spring connectors.
4. Remove the air bag module.
(Refer to page T-74.)
5. Check for continuity between the terminals of the clock spring connector.



○—○: Continuity

Step	Terminal	1A	2A	2B	3A	3B	3C
1		○			○		
2			○			○	
3				○			○

Note

- When terminals 3A and 3B are disconnected from the vehicle's main harness, they are shorted to prevent unexpected air bag deployment.

6. If not as specified, replace the combination switch.
(Refer to page T-14.)



Adjustment Clock spring


Before installing the steering wheel, adjust the clock spring.

1. Set the front wheels straight ahead.


Caution

- The clock spring will break if is over wound. Do not force the spring when turning it.

2. Turn the clock spring clockwise until it stops.
3. Turn the clock spring counter clockwise 2.75 turns.




- Align the marks on the clock spring connector with that on the outer housing.



HAZARD WARNING SWITCH

Removal / Installation

- Remove the center upper panel.
(Refer to section S.)
- Remove the hazard warning switch.
- Install in the reverse order of removal.




Inspection

- Remove the hazard warning switch.
- Check for continuity between the terminal of the hazard warning switch.

○—⊕—○ : Bulb ○—○ : Continuity

Terminal	A	B	C	D
OFF	○—⊕—○			
ON	○—⊕—○		○—○	○—○

- If not as specified, replace the hazard warning switch.



FLASHER UNIT

Removal / Installation

1. Remove the driver's-side front side trim.
(Refer to section S.)
2. Disconnect the flasher unit connector.
3. Remove the nut.
4. Remove the bracket to remove the flasher unit.
5. Install in the reverse order of removal.


Inspection

1. Remove the driver's-side front side trim.
(Refer to section S.)
2. Measure the voltage at the flasher unit terminals as indicated below.
3. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
4. If the parts and wiring harnesses are OK but the system still does not work properly, replace the flasher unit.

Terminal voltage list (Reference)

B+: Battery positive voltage

Terminal	Signal	Connection	Test condition	Voltage/ Continuity	Inspection area
A	Flasher unit ground	GND	Constant: check for continuity to ground	Yes	Wiring harness (Flasher unit-GND)
B	—	—	—	—	—
C	Hazard warning on	Hazard warning switch	Hazard warning switch on	0 V	Hazard warning switch
			Hazard warning switch off	B+	
D	Turn signal flasher (LH)	Turn signal light (LH)	Turn signal light (LH) flashes	Alternates 0 V and B+	Turn signal light (LH)
			Other	0 V	
E	Turn switch on/off (RH)	Combination switch	Ignition switch at ON and turn switch (RH) on	B+	<ul style="list-style-type: none"> • METER 10 A fuse • Combination switch
			Other	0 V	
F	Turn switch on/off (LH)	Combination switch	Ignition switch at ON and turn switch (LH) on	B+	<ul style="list-style-type: none"> • METER 10 A fuse • Combination switch
			Other	0 V	
G	Turn signal flasher (RH)	Turn signal light (RH)	Turn signal light (RH) flashes	Alternates 0 V and B+	Turn signal light (RH)
			Other	0 V	
H	+B	HAZARD 10 A fuse	Constant	B+	HAZARD 10 A fuse




DRL RELAY
Canada Only
Inspection

1. Remove the DRL relay.
2. Apply battery positive voltage and check for continuity between the relay terminals.

○—○: Continuity B+ : Battery positive voltage

Step	Terminal	A	B	C	F	E
1		○—○	○—○	○—○	○—○	
2		B+	GND	○—○		○—○


3. If not as specified, replace the DRL relay.



DRL RESISTOR
Canada Only

Removal / Installation

1. Remove the left side headlight.
 (Refer to page T-10.)
2. Disconnect the DRL resistor connector.
3. Remove the bolts.
4. Remove the DRL resistor.
5. Install in the reverse order of removal.



Inspection


1. Remove the left side headlight.
 (Refer to page T-10.)
2. Disconnect the DRL resistor connector.
3. Check for resistance between terminals A and B of the DRL resistor.

Resistance: 0.3 Ω

4. Check the DRL resistor 10 A fuse.
5. If not as specified, replace the DRL resistor.

INTERIOR LIGHTING SYSTEM

STRUCTURAL VIEW




1. Interior light	
Removal / Installation	page T-21
2. Spot light	
Removal / Installation	page T-23
3. Cargo compartment light	
Removal	page T-24
Installation	page T-24
Bulb replacement	page T-24


4. Door switch	
Removal / Installation	page T-24
Inspection	page T-24
5. Cargo compartment light switch	
Inspection	page T-25
6. Panel light control switch	
Removal / Installation	page T-25
Inspection	page T-25

INTERIOR LIGHT
Removal / Installation
Center interior light

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | | |
|----------------|--------------------------|--------------|
| 1. Lens | | 3. Screw |
| 2. Bulb (10 W) | Removal note below | 4. Connector |
| | | 5. Housing |




Removal note

Lens


1. Insert a flathead screwdriver which has been wrapped in tape as shown in the figure.
2. Twist the screwdriver to remove the lens.

Right interior light, Left interior light

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|--------------------------|--------------|
| 1. Lens | 3. Screw |
| Removal note below | 4. Connector |
| 2. Bulb (10 W) | 5. Housing |




Removal note Lens


1. Insert a flathead screwdriver which has been wrapped in tape as shown in the figure.
2. Twist the screwdriver to remove the lens.

SPOT LIGHT
Removal / Installation
With sunroof

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




- | | | |
|--------------------|--------------------------|--------------|
| 1. Lens | | 3. Connector |
| 2. Bulbs (5 W × 2) | Removal note below | 4. Housing |




Removal note
Lens


1. Insert a flathead screwdriver which has been wrapped in tape into the service hole between the lens and housing.
2. Twist the screwdriver to remove the lens.

**CARGO COMPARTMENT LIGHT****Removal**

1. Remove the liftgate trim.
(Refer to section S.)
2. Push the side of the housing and pull to remove it.


**Installation**

1. Connect the cargo compartment light connector.
2. Insert the side of the cargo compartment light as shown and push to install it.


**Bulb Replacement**

1. Push the sides of the lens as indicated by the arrows, and pull to remove it.
2. Remove the cargo compartment light bulb.
3. Install in the reverse order of removal.

Cargo compartment light bulb: 8 W

**DOOR SWITCH****Removal / Installation**


1. Remove the screw.
2. Disconnect the door switch connector and remove the door switch.
3. Install in the reverse order of removal.

**Inspection**

1. Remove the door switch.
2. Check for continuity between the terminal and the switch body as shown in the figure.

Switch condition	Continuity
Pressed	No
Released	Yes

3. If not as specified, replace the door switch.




CARGO COMPARTMENT LIGHT SWITCH

Inspection

1. Remove the liftgate trim.
(Refer to section S.)
2. Disconnect the cargo compartment light switch connector.
3. Check for continuity between the terminal of the cargo compartment light switch and ground.

Switch condition	Continuity
Pressed (liftgate closed)	No
Released (liftgate open)	Yes



4. If not as specified, replace the liftgate lock.
(Refer to section S.)

PANEL LIGHT CONTROL SWITCH

Removal / Installation


1. Remove the side panel.
(Refer to section S.)
2. Disconnect the panel light control switch connector.
3. Remove the panel light control switch.
4. Install in the reverse order of removal.

Inspection




1. Remove the side panel.
(Refer to section S.)
2. Measure the voltage at the panel light control switch as indicated below.
3. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
4. If the parts and wiring harnesses are OK but the system still does not work properly, replace the panel light control switch.

Terminal voltage list (Reference)

B+: Battery positive voltage



Terminal	Signal	Connection	Test condition	Voltage/Continuity	Inspection area
A	Illumination	Each illumination	Inspect by using an oscilloscope (Refer to A terminal inspection)	—	—
B	—	—	—	—	—
D	TNS	Combination switch	Headlight switch at first or second position	B+	<ul style="list-style-type: none"> • Combination switch • TAIL 15 A fuse
			Other	0 V	
F	—	—	—	—	—
G	Ground	GND	Constant: check for continuity to ground	Yes	GND
H	—	—	—	—	—



A terminal inspection

1. Measure the wave pattern of the A terminal on the panel light control switch by using an oscilloscope.

2. Set the headlight switch to either the first or second position.

3. Set the panel light control switch to the brightest position.


4. Verify that the pattern on the screen is as shown in Fig. 1.

5. Verify that the pattern on the screen changes to the pattern shown in Fig. 2 as the panel light control switch is gradually turned to the darkest position.

6. If the wave pattern is not as shown, replace the panel light control switch.

WIPER AND WASHER

STRUCTURAL VIEW




- | | |
|--|--|
| 1. Windshield wiper motor | 8. Rear wiper motor |
| Removal / Installation page T-28 | Removal / Installation page T-33 |
| Disassembly / Assembly page T-28 | Disassembly / Assembly page T-33 |
| Inspection page T-29 | Inspection page T-34 |
| 2. Windshield wiper arm and blade | 9. Rear wiper arm and blade |
| Removal / Installation page T-30 | Removal / Installation page T-35 |
| Adjustment page T-31 | Adjustment page T-35 |
| 3. Windshield wiper link and frame | 10. Rear washer tank |
| Removal / Installation page T-31 | Removal / Installation page T-36 |
| 4. Windshield washer tank | 11. Rear washer motor |
| Removal / Installation page T-32 | Removal / Installation page T-36 |
| 5. Windshield washer motor | Inspection page T-36 |
| Removal / Installation page T-32 | 12. Rear washer nozzle |
| Inspection page T-32 | Removal page T-37 |
| 6. Windshield washer nozzle | Adjustment page T-37 |
| Adjustment page T-32 | 13. Rear wiper and washer switch |
| 7. Combination switch | Removal / Installation page T-37 |
| Removal / Installation page T-14 | Inspection page T-37 |
| Inspection page T-15 | 14. Intermittent wiper relay |
| | Removal / Installation page T-38 |
| | Inspection page T-38 |

WINDSHIELD WIPER MOTOR

Removal / Installation

1. Remove the windshield wiper frame.
(Refer to page T-31.)
2. Pry off the connection between the windshield wiper motor and windshield wiper link.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.




1. Nut
2. O-ring
3. Motor link
4. Connector

5. Bolt
6. Windshield wiper motor
Disassembly / Assembly below
Inspection page T-29





Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Screw
2. Brush plate holder

3. Motor gear shaft



Inspection

1. Turn the ignition switch to LOCK while the windshield wiper is operating. Verify that the windshield wiper does not stop in the proper park position.
2. Disconnect the windshield wiper motor connector.
3. Check for continuity between the terminals of the windshield wiper motor.

○—○: Continuity

Terminal	A	B	C	D	E
Windshield wiper motor position					
Except autostop	○—○	○—○	○—○	○—○	○—○

4. Connect the windshield wiper motor connector.
5. Turn the wiper switch off while windshield wiper is operating. Verify that the windshield wiper stops in the park position.
6. Disconnect the windshield wiper motor connector.
7. Check for continuity between the terminals of the windshield wiper motor.

○—○: Continuity

Terminal	A	B	C	E
Windshield wiper motor position				
Auto stop	○—○	○—○	○—○	○—○

8. Apply battery positive voltage and check the operation of the wiper motor as indicated below.

B+: Battery positive voltage


Connection		Operation speed
B+	GND	
C	E	Low
A		High

9. If not as specified, replace the necessary parts.


WINDSHIELD WIPER ARM AND BLADE

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. Adjust the windshield wiper arm.
(Refer to page T-31.)



1. Nut
 2. Windshield wiper arm
 3. Windshield wiper blade
 4. Rubber brush
- Installation note below




Installation note

Windshield wiper arm

Clean the wiper arm connector shafts with a wire brush before installing the wiper arms.

Adjustment


1. Operate the windshield wiper motor to set the wipers in the park position.
2. Set the windshield wiper arm height as shown.



WINDSHIELD WIPER LINK AND FRAME


Removal / Installation

1. Remove the windshield wiper arm and blade.
(Refer to page T-30.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Nut
2. Seal ring
3. Bolt


4. Connector
5. Windshield wiper link
6. Windshield wiper frame



WINDSHIELD WASHER TANK

Removal / Installation


1. Remove the front combination light.
(Refer to page T-12.)
2. Disconnect the windshield washer motor connector.
3. Remove the bolt and nut.
4. Disconnect the windshield washer pipe and remove the windshield washer tank.
5. Install in the reverse order of removal.



WINDSHIELD WASHER MOTOR

Removal / Installation

1. Remove the windshield washer tank.
2. Extract the washer fluid.
3. Remove the windshield washer motor and rubber cap.
4. Install in the reverse order of removal.




Inspection

1. Disconnect the windshield washer motor connector.
2. Connect battery positive voltage to terminal B and ground to terminal A of the windshield washer motor.
3. Verify that the windshield washer motor operates.
4. If the motor does not operate, replace it.

WINDSHIELD WASHER NOZZLE

Adjustment


Adjust the windshield washer nozzle direction as shown in the figure by using a needle or equivalent tool.



REAR WIPER MOTOR

Removal / Installation

1. Remove the liftgate trim and liftgate screen.
(Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




1. Outer bush
2. Connector
3. Bolt

4. Rear wiper motor
Disassembly / Assembly below
Inspection page T-34


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




1. Screw
2. Brush plate holder


3. Motor gear shaft

**Inspection**


1. Remove the liftgate trim and liftgate screen.
(Refer to section S.)
2. Disconnect the rear wiper motor connector.
3. Check for continuity between terminals A and B of the rear wiper motor.
4. If there is no continuity, replace the necessary parts.
(Refer to page T-33.)



5. Connect battery positive voltage to terminal A and ground terminal B. Verify that the rear wiper motor operates.
6. If the rear wiper motor does not operate, replace the necessary parts.
(Refer to page T-33.)



7. Connect battery positive voltage to terminal A and ground to terminal B and the rear wiper motor body to operate the motor.




8. While the rear wiper motor is operating, remove the ground from terminal B. Verify that the auto stop function operates.
9. If not as specified, replace the necessary parts.
(Refer to page T-33.)


REAR WIPER ARM AND BLADE

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. Adjust the rear wiper arm.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Nut 2. Rear wiper arm | <ol style="list-style-type: none"> 3. Rear wiper blade 4. Rubber brush |
|---|--|
- Installation note below



Installation note


Rear wiper arm

Clean the wiper arm connector shafts with a wire brush before installing the wiper arms.



Adjustment


1. Operate the rear wiper motor to set the wiper in the park position.
2. Align the rear wiper with the bottom ceramic end line by moving the position of the wiper arm connector shaft.



REAR WASHER TANK

Removal / Installation


1. Remove the rear side trim.
(Refer to section S.)
2. Remove the bolts.
3. Disconnect the rear washer pipe and rear washer motor connector.
4. Remove the rear washer tank.
5. Install in the reverse order of removal.



REAR WASHER MOTOR


Removal / Installation

1. Remove the rear washer tank.
2. Extract the washer fluid.
3. Remove the screws.
4. Remove the rear washer motor.
5. Install in the reverse order of removal.



Inspection


1. Remove the rear washer tank.
2. Connect battery positive voltage to terminal B and ground to terminal A of the motor.
3. Verify that the rear washer motor operates.
4. If the rear washer motor does not operate, replace it.



REAR WASHER NOZZLE


Removal

1. Apply protective tape to the body around the washer nozzle.
2. Insert a tape-wrapped, flathead screwdriver under the side ① of the nozzle and push the nozzle clip.
3. Insert another tape-wrapped, flathead screwdriver under the rear ② of the nozzle.
4. Remove the first screwdriver and insert it under the side ③ of the nozzle.
5. Disconnect the washer pipe from the washer nozzle to remove the nozzle.



Adjustment


Adjust the rear washer nozzle direction as shown in the figure by using a needle or equivalent tool.



REAR WIPER AND WASHER SWITCH

Removal / Installation

1. Remove the center upper panel.
(Refer to section S.)
2. Remove the rear wiper and washer switch.
3. Install in the reverse order of removal.




Inspection

1. Remove the rear wiper and washer switch.
2. Check for continuity between the terminals of the rear wiper and washer switch.

○—⊕—○ : Bulb ○—○ : Continuity

Switch position \ Terminal	A	B	F	G	H
OFF	○—⊕—○				
Washer switch ON	○—⊕—○		○—○		
Wiper switch ON	○—⊕—○		○—○		○—○

3. If not as specified, replace the rear wiper and washer switch.



INTERMITTENT WIPER RELAY

Removal / Installation

1. Remove the passenger's-side front side trim. (Refer to section S.)
2. Disconnect the intermittent wiper relay connector.
3. Remove the nut.
4. Remove the bracket to remove the intermittent wiper relay.
5. Install in the reverse order of removal.

Inspection

1. Remove the passenger's-side front side trim. (Refer to section S.)
2. Measure the voltage at the intermittent wiper relay as indicated below.
3. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
4. If the parts and wiring harnesses are OK but the system still does not work properly, replace the intermittent wiper relay.









Terminal voltage list (reference)

B+: Battery positive voltage


<table border="1" style="margin: auto;"> <tr> <td>G</td> <td>E</td> <td>C</td> <td>A</td> </tr> <tr> <td>H</td> <td>F</td> <td>D</td> <td>B</td> </tr> </table>							G	E	C	A	H	F	D	B
G	E	C	A											
H	F	D	B											
Terminal	Signal	Connection	Test condition		Voltage/Continuity/Resistance		Inspection area							
A	Auto stop	Windshield wiper motor	Windshield wipers operate		Alternates 0 V and B+		Windshield wiper motor							
			Other		0 V									
B	Windshield washer switch on	Windshield washer switch	Ignition switch at ON	Windshield washer switch on	B+		<ul style="list-style-type: none"> • WIPER 20 A fuse • Combination switch 							
				Windshield washer switch off	0 V									
C	INT	Windshield wiper switch	Ignition switch at ON	Windshield wiper switch INT	B+		<ul style="list-style-type: none"> • WIPER 20 A fuse • Combination switch 							
				Other	0 V									
D	IG 2	WIPER 20 A fuse	Ignition switch at ON		B+		WIPER 20 A fuse							
E	INT speed	INT volume	Disconnect intermittent wiper relay connector	Measure the resistance between the H terminal at each speed setting of the INT volume	LO position	Approx 50 kΩ	<ul style="list-style-type: none"> • WIPER 20 A fuse • Combination switch 							
					MID position	Approx 35 kΩ								
					HI position	Approx 15 kΩ								
F	Auto stop	Windshield wiper switch	Ignition switch at ON	Intermittent wiper operate	Alternates 0 V and B+		<ul style="list-style-type: none"> • WIPER 20 A fuse • Combination switch 							
				Other	0 V									
G	Ground	GND	Constant: check for continuity to ground		Yes		GND							
H	INT speed	INT volume	Disconnect intermittent wiper relay connector	Measure the resistance between the E terminal at each speed setting of the INT volume	LO position	Approx 50 kΩ	<ul style="list-style-type: none"> • WIPER 20 A fuse • Combination switch 							
					MID position	Approx 35 kΩ								
					HI position	Approx 15 kΩ								

WARNING AND INDICATOR SYSTEM

PREPARATION
SST

<p>49 0839 285</p> <p>Checker, fuel thermometer</p> 	<p>For inspection of fuel and water temperature gauges</p>	<p>49 T088 0A0</p> <p>NGS set</p> 	<p>For inspection of tachometer</p>
<p>49 T088 002</p> <p>Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For inspection of tachometer</p>	<p>49 T088 010B</p> <p>Program Card</p> 	<p>For inspection of tachometer</p>
<p>49 T088 001</p> <p>Control unit (Part of 49 T088 0A0)</p> 	<p>For inspection of tachometer</p>	<p>49 T088 004</p> <p>NGS OBD II Adapter (Part of 49 T088 0A0)</p> 	<p>For inspection of tachometer</p>
<p>49 T088 006</p> <p>Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For inspection of tachometer</p>	<p>49 T088 008A</p> <p>Instruction Manual</p> 	<p>For inspection of tachometer</p>

STRUCTURAL VIEW




- | | | | |
|--------------------------------|-----------------|----------------------------------|-----------------|
| 1. Instrument cluster | | 5. Water temperature sender unit | |
| Removal / Installation | page T-41 | Removal | page T-46 |
| Disassembly / Assembly | page T-42 | Installation | page T-46 |
| Inspection | page T-43 | Inspection | page T-46 |
| 2. Speedometer cable | | 6. Oil pressure switch | |
| Inspection | page T-44 | Inspection | page T-47 |
| 3. Warning and indicator light | | 7. Horn | |
| Structural view | page T-45 | Removal / Installation | page T-47 |
| Bulb replacement | page T-45 | On-vehicle inspection | page T-47 |
| 4. Fuel gauge sender unit | | 8. Horn relay | |
| Inspection | page T-46 | Inspection | page T-47 |

INSTRUMENT CLUSTER


Removal / Installation

1. Shift the selector lever to L range.
2. Remove the meter hood.
(Refer to section S.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Screws
2. Speedometer cable
Removal note below
3. Connectors

4. Instrument cluster
Disassembly / Assembly page T-42
Inspection page T-43




Removal note

Speedometer cable

1. Remove the speedometer cable from the clips.
2. Insert the speedometer cable into the cabin.
3. Insert your hand into the dashboard from the bottom right of the instrument cluster as shown.
4. Disconnect the speedometer cable.

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



- | | |
|-----------------|--------------------------------------|
| 1. Glass | 6. Tachometer |
| 2. Window plate | 7. Speedometer |
| 3. Socket | 8. Fuel and water temperature gauges |
| 4. Bulb | 9. Sheet warning |
| 5. Screw | 10. Case |


Inspection
Speedometer

- Using a speedometer tester, verify that the indication of speedometer is within the error can be permitted range shown below.

Indication of speedometer (km/h)	Error can be permitted (km/h)
40	36.0—46.0
90	81.0—103.5

Indication of speedometer (MPH)	Error can be permitted (MPH)
30	27.0—34.5
80	72.0—92.0

- If the speedometer does not operate or the indication error is excessive, inspect the speedometer cable.
(Refer to page T-41.)
- If the speedometer cable is OK, replace the speedometer.
(Refer to pages T-41, 42.)








Tachometer

- Connect the **SSTs** (NGS) to the data link connector-2, located under the dashboard on the driver's side, and to the battery.
- Referring to NGS operation manual, select the PID DATA MONITOR function.
- Using the PID DATA MONITOR function, measure the engine speed.
- Compare the values of the vehicle tachometer and the **SST** (NGS).

Indication of tachometer (rpm)	Error can be permitted (rpm)
1000	880—1060
2000	1970—2150
3000	3000—3180
4000	4000—4240
5000	5000—5300

- If the tachometer does not operate or the indication error is excessive, inspect the wiring harness.
- If the wiring harness is OK, inspect the ECM.
(Refer to section F.)
- If the ECM is OK, replace the tachometer.
(Refer to pages T-41, 42.)



Fuel gauge

1. Remove the instrument cluster.
(Refer to page T-41.)
2. Connect battery positive voltage to terminal 1H and ground to terminal 3L of the instrument cluster.
3. Connect the positive (+) lead of the **SST** to terminal 1I of the instrument cluster and the negative (-) lead to ground.
4. Verify that the fuel gauge indicates the values shown below.

Resistance of SST (Ω)	Indication of fuel gauge
95	E
32.5	(1/2)
7	F

5. If not as specified, replace the fuel and water temperature gauges.
(Refer to page T-42.)

Water temperature gauge

1. Remove the instrument cluster.
(Refer to page T-41.)
2. Connect battery positive voltage to terminal 1H and ground to terminal 3L of the instrument cluster.
3. Connect the positive (+) lead of the **SST** to terminal 1J of the instrument cluster and the negative (-) lead to ground.
4. Verify that the water temperature gauge indicates the values shown below.

Resistance of SST (Ω)	Indication of water temperature gauge
125.3	C
16.9	H


5. If not as specified, replace the fuel and water temperature gauges.
(Refer to page T-42.)

SPEEDOMETER CABLE


Inspection

1. Disconnect the speedometer cable from the instrument cluster and transmission case.
2. Verify that the cable spin easily when turned by hand.
3. If the cable is stiff, replace the speedometer cable.

WARNING AND INDICATOR LIGHT
Structural View




	Bulb		Specification
1	Door ajar warning light		1.4W
2	Air bag system warning light		1.4W
3	Oil pressure warning light		1.4W
4	Generator warning light		1.4W
5	MIL		1.4W
6	Brake system warning light		1.4W
7	Seat belt warning light		1.4W
8	Fuel-level warning light		3.4W
9	ABS warning light		1.4W
10	ALL indicator light		1.4W
11	4WD indicator light	4WD only	3.4W
12	Center differential lock indicator light	4WD only	3.4W
13	Cruise set indicator light		1.4W
14	Rear window defroster indicator light		1.4W
15	AT oil temperature indicator light	4WD only	1.4W
16	High beam indicator light		1.4W
17	O/D OFF indicator light		1.4W
18	AT position indicator light		2.0W×6
19	Turn signal indicator light		3.0W×2
—	Instrument cluster illumination		3.4W×4



Bulb Replacement


1. Remove the instrument cluster.
(Refer to page T-41.)
2. Replace the faulty bulbs. Use only the bulbs specified above.



FUEL GAUGE SENDER UNIT

Inspection


1. Remove the fuel gauge sender unit.
(Refer to section F.)
2. Measure the resistance between terminals A and B while moving the unit arm from point F to point E.
3. If not as specified, replace the fuel gauge sender unit.
(Refer to section F.)



WATER TEMPERATURE SENDER UNIT

Removal

1. Disconnect the water temperature sender unit connector.
2. Remove the water temperature sender unit.




Installation

1. Apply sealant from the third thread to the top thread.
2. Install in the reverse order of removal.

Tightening torque:

6.4—9.3 N·m { 65—95 kgf·cm , 57—82 in·lbf }




Inspection

1. Remove the water temperature sender unit.
2. Place the water temperature sender unit in a container of water.
3. Heat the water gradually, and measure the resistance of the water temperature sender unit.

Temperature	°C { °F }	50 { 122 }
Resistance	Ω	192.4—259.6


4. If not as specified, replace the water temperature sender unit.



OIL PRESSURE SWITCH

Inspection


1. Turn the ignition switch to ON and verify that the oil pressure warning light illuminates.
2. Start the engine and verify that the warning light goes out.
3. If not as specified, inspect the oil pressure warning light bulb and wiring harness (Instrument cluster — Oil pressure switch).
4. If the bulb and wiring harness are normal, inspect the oil pressure.
(Refer to section D.)
5. If the oil pressure is normal, replace the oil pressure switch.
(Refer to section D.)



HORN


Removal / Installation

1. Remove the headlight.
(Refer to page T-10.)
2. Disconnect the horn connector.
3. Remove the bolt and the horn.
4. Install in the reverse order of removal.



On-Vehicle Inspection

While turning the steering wheel, verify that the horn sounds when the horn switch is pressed.



HORN RELAY

Inspection

1. Remove the horn relay.
2. Apply battery positive voltage and check for continuity between the relay terminals.

○—○: Continuity B+: Battery positive voltage


Step \ Terminal	A	C	B	D
1			○—○	○—○
2	○—○	○—○	B+	GND

3. If not as specified, replace the horn relay.


AUDIO

PREPARATION

SST

49 UN01 050		For removal of audio unit
Radio removing tool		

STRUCTURAL VIEW



1. Audio unit, CD player

Removal page T-49
 Installation page T-49

2. Door speaker




Removal / Installation page T-49
 Inspection page T-50

3. Antenna

Removal / Installation page T-50
 Inspection page T-51

4. Antenna feeder

Removal / Installation page T-51
 Inspection page T-51



AUDIO UNIT, CD PLAYER

Removal

1. Remove the hole covers by inserting a small, tape-wrapped, flathead screwdriver into the slot and carefully prying them off without scratching the center panel. Pry up and pull off the covers carefully to prevent the posts from breaking off.
2. With the beveled parts of the **SST** facing inward, insert them into the audio unit.
3. Pull the **SST** outward and rearward to slide out the unit.
4. Disconnect the connector and antenna jack.
5. Remove the audio unit and/or CD player.

Installation

Caution


- Make certain that the wiring harness and antenna feeder are not caught between the unit and center panel assembly. If the harness or the antenna feeder are caught between the unit and center panel assembly, it may become the cause of trouble or malfunctions.

1. Connect the connector and antenna jack.
2. Insert and push in the unit each clip clicks.
3. Install the service hole covers.

DOOR SPEAKER


Removal / Installation

1. Remove the front door trim or rear door trim. (Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Screw
2. Door speaker
3. Door speaker connector

Inspection page T-50



Inspection

1. Remove the door speaker.
(Refer to page T-49.)
2. Measure the resistance between the speaker terminals.

Resistance: 4 Ω

3. Touch the leads of an ohmmeter to the speaker terminals and verify that the speaker clicks.


Range: × 1 Ω

4. If not as specified, replace the door speaker.

ANTENNA

Removal / Installation


1. Remove the mud guard.
(Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse of removal.




- | | |
|--------------------------|-----------------|
| 1. Mounting nut | 3. Antenna jack |
| Removal note below | 4. Bolt |
| 2. Spacer | 5. Antenna |

Removal note
Mounting nut

Remove the mounting nut by using snap-ring pliers as shown.





Inspection

1. Remove the audio unit.
(Refer to page T-49.)
2. Disconnect the antenna jack.
3. Measure the resistance at the antenna jack terminal as shown.


Resistance: Infinite

4. If not as specified, replace the antenna feeder.

ANTENNA FEEDER


Removal / Installation

1. Remove the lower panel.
(Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Clip

2. Antenna feeder



Inspection









1. Disconnect the antenna jack.
2. Measure the resistance at the antenna jack terminal as shown.

Resistance: Infinite


3. Check the antenna cable for continuity.
4. If not as specified, replace the antenna feeder.

CRUISE CONTROL SYSTEM

PREPARATION SST

<p>49 T088 0A0 NGS set</p> 	<p>For diagnosis of cruise control system</p>	<p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p> 	<p>For diagnosis of cruise control system</p>
<p>49 T088 003 Super MECS Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis of cruise control system</p>	<p>49 T088 010B Program Card</p> 	<p>For diagnosis of cruise control system</p>
<p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p> 	<p>For diagnosis of cruise control system</p>	<p>49 T088 005 STAR/DCL Adapter (5 pin) (Part of 49 T088 0A0)</p> 	<p>For diagnosis of cruise control system</p>
<p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p> 	<p>For diagnosis of cruise control system</p>	<p>49 T088 008A Instruction Manual</p> 	<p>For diagnosis of cruise control system</p>

STRUCTURAL VIEW




- | | |
|--|--|
| <p>1. Cruise control switch
 Inspection page T-64</p> <p>2. Cruise control main switch
 Removal / Installation page T-64
 Inspection page T-64</p> <p>3. Cruise control module
 Removal / Installation page T-59
 Inspection page T-60</p> <p>4. Cruise actuator
 Removal / Installation page T-62
 Inspection page T-62</p> | <p>5. Actuator cable
 Removal / Installation page T-63
 Adjustment page T-64</p> <p>6. Transmission range switch
 Inspection section K</p> <p>7. Brake switch
 Inspection section P</p> <p>8. Vehicle speed sensor
 Inspection page T-44</p> |
|--|--|

ON-BOARD DIAGNOSTIC**Outline**



- There are two on-board diagnostic functions: Condition Detection Mode, which indicates troubles in the system; and Operation Mode, which checks for and indicates correct operation of the input signals to the control module.
- The two functions can be done by using either of the following methods:
 - 1) Checking the output of the data link connector by using the **SST** (NGS set)
 - 2) Checking the flashing pattern of the cruise set indicator light

Operation Order


Use Condition Detection Mode or Operation Mode, or both, to inspect the cruise control system. Either diagnostic function can be done before the other. If one diagnostic function does not locate the trouble, carry out the other function.





Condition Detection Mode
Using NGS



1. Position the vehicle on a chassis roller.
2. Connect the **SST** (NGS) to the data link connector and battery.
3. Set the **SST** (Super MECS Adapter) to AUX 2.



4. Select "VEHICLE & ENGINE SELECTION" on the **SST** (Control Unit) display, and then select the vehicle model, engine type, and model year.





5. Select "DIAGNOSTIC DATA LINK" on the **SST** (Control Unit) display.
 6. Select "CCM-CRUISE CONTROL MODULE" on the **SST** (Control Unit) display, and then select the "DIAGNOSTIC TEST MODE".
 7. Increase the vehicle speed to over 16 km/h { 10 MPH }.
8. Select "CRUISE CONTROL SELF TEST" on the **SST** (Control Unit) display.
 9. (1) If a diagnostic trouble code is displayed, refer to the diagnostic trouble code table (Refer to page T-57) and inspect the appropriate system area.
(2) If "NO CODES RECEIVED" is displayed, the system areas shown in the diagnostic trouble code table are OK. Inspect another system area.
 10. After the problems are corrected, repeat the condition detection mode procedure to verify that the system is operating normally.

Cancel

To cancel condition detection mode, do any one of the following:

- Turn the cruise control main switch off.
- Turn the ignition switch to LOCK.



Using cruise set indicator light

Reference

- If the RESUME/ACCEL switch on the cruise control switch is malfunctioning, the cruise set indicator light will not give a correct indication when you inspect the system. Use the **SST** (NGS set) to determine the cause of the malfunction. (Refer to page T-55.)

Inspection

1. Turn the ignition switch to ON.
2. Turn the cruise control main switch on.
3. Press and hold the RESUME/ACCEL switch for at least 3 seconds and drive the vehicle at less than 16 km/h { 10 MPH } to activate the on-board diagnostic. The cruise set indicator light will illuminate for 3 seconds and then go out for at least 2 seconds.
4. If a problem is present, the cruise set indicator light will flash in one of the patterns shown below. If there is no problem in the system, the light will not flash.

Cancel


To cancel condition detection mode, do any one of the following:

- Turn the cruise control main switch off.
- Turn the ignition switch to LOCK.
- Drive the vehicle at over 16 km/h { 10 MPH }.

Diagnostic trouble code table



If there are two or more problems in the cruise control system, the problem with the highest priority will be indicated.

Priority	DTC	Display on the NGS	Possible cause	Action
1	1	ACTUATOR — CIRCUIT MALFUNCTION	Defective wiring (Actuator — Cruise control module) Defective cruise control module Defective actuator	Repair wiring harness Inspect actuator Replace cruise control module
2	5	STOP FUSE — CIRCUIT MALFUNCTION	Burnt STOP 20 A fuse Defective brake switch Defective wiring (Fuse — Brake switch — Cruise control module)	Inspect brake switch Replace fuse Repair wiring harness
3	7	BRAKE SW — DEFECT	Defective brake switch	Inspect brake switch
4	11	SET/COAST SW — DEFECT (ALWAYS ON)	Defective cruise control switch (SET/COAST) (always on)	Inspect cruise control switch
5	12	RESUME/ACCEL SW — DEFECT (ALWAYS ON)	Defective cruise control switch (RESUME/ACCEL) (always on)	Inspect cruise control switch
6	15	CRUISE CONTROL MODULE — DEFECT	Defective cruise control module	Replace cruise control module



Operation Mode Using NGS

1. Carry out steps 1—6 of the condition detection mode procedure.
2. Select "CRUISE CONTROL INPUT SW SELF TEST" on the **SST** (Control Unit) display.
3. Operate each switch as it is shown on the **SST** (Control Unit) display and note the diagnostic trouble code.
4. Refer to the diagnostic trouble code table on page T-59. If the diagnostic trouble code shown in the table does not appear on the **SST** (Control Unit) display, inspect the corresponding system area.
5. After the problems are corrected, repeat the operation mode procedure to verify that the system is operating normally.



Using cruise set indicator light Inspection

1. Turn the ignition switch to ON.
2. Verify that the cruise control main switch is off.
3. Shift the transmission to D range.
4. Press the RESUME/ACCEL switch and the cruise control main switch simultaneously to activate the system inspection. (The cruise set indicator light will illuminate.)
5. Operate each switch as described and note the diagnostic trouble code pattern. If the cruise set indicator light does not flash, inspect the corresponding system area.

Canceling operation mode

To cancel the operation mode, do any one of the following:

- Turn off the cruise control main switch.
- Turn the ignition switch to LOCK.

Diagnostic trouble code table


The table below shows the code numbers and flash patterns that will be indicated if the system is operating correctly.

Procedure	Normal		Malfunction	
	DTC	Display on the NGS	Possible cause	Action
Press SET/COAST switch	21	SET/COAST SW — PRESS	Defective cruise control switch Defective wiring (Cruise control module — SET/COAST switch — GND)	Inspect cruise control switch Repair wiring harness
Press RESUME/ACCEL switch	22	RESUME/ACCEL SW — PRESS	Defective RESUME/ACCEL switch Defective wiring (Cruise control module — RESUME/ACCEL switch — GND)	Inspect cruise control switch Repair wiring harness
Depress brake pedal	31	BRAKE PEDAL — DEPRESS	Defective brake switch Defective wiring (Cruise control module — Brake switch — GND)	Inspect brake switch Repair wiring harness
Shift transmission to P or N range	35	P OR N RANGE — SHIFT	Defective transmission range sensor Defective wiring (Cruise control module — Transmission range switch)	Inspect transmission range sensor Repair wiring harness
Drive vehicle above 40 km/h { 25 MPH }	37	VEHICLE SPEED — ABOVE 40 km/h { 25 MPH }	Defective vehicle speed sensor or speedometer Defective wiring (Cruise control module — Speedometer — Vehicle speed sensor)	Inspect vehicle speed sensor Inspect speedometer Repair wiring harness

CRUISE CONTROL MODULE

Removal / Installation

1. Remove the passenger-side front side trim.
(Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Bolt
2. Cruise control module connector


3. Cruise control module
Inspection page T-60

Inspection

1. Remove the passenger-side front side trim.
(Refer to section S.)
2. Pull out the cruise control module with the cruise control module connector connected.
(Refer to page T-59.)
3. Measure the voltage at the cruise control module terminals as indicated below.
4. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
5. If the parts and wiring harnesses are OK but the system still does not work properly, replace the cruise control module.

Terminal voltage list (Reference)

B+: Battery positive voltage



Terminal	Signal	Connection	Test condition		Voltage	Inspection area
A	Cruise actuator on	Cruise actuator (vent 1)	Ignition switch at ON	Cruise control main switch on	9 V	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch • Cruise actuator
				Other	0 V	
B	Cruise actuator on	Cruise actuator (vac)	Ignition switch at ON	Cruise control main switch on	9 V	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch • Brake switch • Cruise actuator
				Other	0 V	
C	Cruise actuator on	Cruise actuator (vent 2)	Ignition switch at ON	Cruise control main switch on	9 V	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch • Brake switch • Cruise actuator
				Other	0 V	
D	IG1	Instrument cluster (cruise set indicator light)	Ignition switch at ON		B+	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise set indicator light bulb
			Cruise set indicator light illuminated		0 V	
E	Cruise control main switch on/off	Cruise control main switch	Ignition switch at ON	Cruise control main switch off	0 V	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch
				Cruise control main switch on	B+	
F	—	—	—		—	—
G	O/D off	ECM	Ignition switch at ON		B+	ECM
H	Brake on	Brake switch	Ignition switch at ON and cruise control main switch on		B+	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch
I	TEST	Data link connector	—		—	—
J	Selector lever position	Transmission range switch	Ignition switch at ON	N or P range	0 V	Transmission range switch
				Other	B+	
K	—	—	—		—	—
L	—	—	—		—	—
M	Brake on	Brake switch	Depress brake pedal		B+	<ul style="list-style-type: none"> • STOP 15 A fuse • Brake switch
			Other		0 V	

Cont'd


B+: Battery positive voltage

Terminal	Signal	Connection	Test condition		Voltage/ Continuity	Inspection area
N	Cruise control switch on	Cruise control switch	Ignition switch at ON and cruise control main switch on		5 V	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch • Clock spring • Cruise control switch
			Ignition switch at ON and cruise control main switch on	SET/COAST switch pushed	1.5 V	
				RESUME/ACCEL switch pushed	3.1 V	
O	Brake on	Brake switch	Ignition switch at ON and cruise control main switch on	Release brake pedal	B+	<ul style="list-style-type: none"> • METER 10 A fuse • Cruise control main switch • Brake switch
				Depress brake pedal	0 V	
P	Vehicle speed sensor on	Vehicle speed sensor	Rear tires rotating		Alternates 0 V and 5 V	<ul style="list-style-type: none"> • Vehicle speed sensor • Instrument cluster
Q	—	—	—	—	—	—
R	—	—	—	—	—	—
S	—	—	—	—	—	—
T	GND	GND	Check for continuity to ground		Yes	GND

CRUISE ACTUATOR


Removal / Installation

1. Disconnect the cruise actuator connector.
2. Disconnect the actuator cable and vacuum hose from the cruise actuator.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.
5. Adjust the actuator cable.
(Refer to page T-64.)



1. Bolt
2. Nut

3. Bracket
4. Cruise actuator




Inspection

1. Disconnect the cruise actuator connector.
2. Measure the cruise actuator resistance.

Terminal	Resistance
C—A	25—35 Ω
C—B	
C—D	

3. If not as specified, replace the cruise actuator.



4. Disconnect the actuator cable from the accelerator pedal.
5. Run the engine at idle speed.
6. Apply battery positive voltage to the following terminals, and check the actuator cable operation.


B+: Battery positive voltage

Connection				Actuator cable operation
A	B	C	D	
GND	GND	B+	GND	Pull
GND	—	B+	GND	Hold
GND	—	B+	—	Extend
—	—	—	—	Release

7. If not as specified, replace the cruise actuator.
(Refer to page T-62.)


**ACTUATOR CABLE
Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Nut
2. Clip
3. Nut
4. Bracket


5. Grommet
6. Actuator cable
Adjustment page T-64



Adjustment

Adjust the nut so that actuator cable free play is as shown when the actuator cable is pressed lightly.


Cable play on both the cruise actuator side and throttle body side: 1.0—5.0 mm { 0.04—0.19 in }



CRUISE CONTROL MAIN SWITCH

Removal / Installation

1. Remove the meter hood.
(Refer to section S.)
2. Press the stoppers of the switch and remove the cruise control main switch.
3. Install in the reverse order of removal.




Inspection

1. Remove the cruise control main switch.
2. Check for continuity between the terminals of the cruise control main switch.

○—○ : Continuity ○—⊕—○ : Bulb

Switch position \ Terminal	A	B	C	D	F
OFF	○—⊕—○	○—○	○—○	○—⊕—○	○—○
ON	○—⊕—○	○—○	○—○	○—○	○—⊕—○

3. If not as specified, replace the cruise control main switch.



CRUISE CONTROL SWITCH

Inspection

1. Remove the combination switch.
(Refer to page T-14.)
2. Check for continuity between the terminals of the combination switch connector.

○—⚡—○ : Resistance



Switch position \ Terminal	A	D
SET/COAST	○—⚡—○	○—○ 240 Ω
RES/ACCEL	○—⚡—○	○—○ 910 Ω

3. If not as specified replace the combination switch.
(Refer to page T-14.)


AIR BAG SYSTEM

PREPARATION


SST

<p>49 0839 285 Checker, fuel thermometer</p>		<p>For inspection of air bag system</p>	<p>49 H066 002 Deployment tool</p>		<p>For deployment of air bag module</p>
--	---	---	--	---	---


STRUCTURAL VIEW




- | | |
|---|--|
| <p>1. Driver-side air bag module
Removal / Installation page T-74
Disposal procedure page T-77</p> | <p>4. SAS unit
Removal / Installation page T-76
Deployment Authorization
procedure page T-77</p> |
| <p>2. Clock spring
Inspection page T-16
Adjustment page T-16</p> | <p>5. Air bag system warning light
Bulb replacement page T-45</p> |
| <p>3. Passenger-side air bag module
Removal / Installation page T-75
Disposal procedure page T-77</p> | |

**SERVICE WARNINGS****Component Disassembly**


- Disassembling and reassembling the components of the air bag system can render the system inoperative, which may result in serious injury or death in the event of an accident. Do not disassemble any air bag system components.

**Air Bag Module Inspection**


- Inspecting the air bag module with an ohmmeter can deploy the air bag, which can cause serious injury. Do not use an ohmmeter to inspect the air bag module.

**Air Bag Module Handling**


- A live (undeployed) air bag may accidentally deploy when it is handled and cause serious injury. When carrying a live air bag module, point the trim cover away from your body to lessen the chance of injury in case it deploys.




- A live air bag placed face down on a surface is dangerous. If the air bag deploys, the motion of the module can cause serious injury. Always face the trim cover up to reduce the motion of the module in case it accidentally deploys.

**SAS Unit Handling**

- Disconnecting the SAS unit connector or removing the SAS unit with the ignition switch at ON can cause the air bags to deploy, which may seriously injure you. Before disconnecting the SAS unit connector or removing the SAS unit, turn the ignition switch to LOCK.




- Connecting the SAS unit connector before installing the SAS unit is dangerous. The shock of installation can cause the air bags to deploy, which may seriously injure you. Before connecting the SAS unit connector, firmly mount the SAS unit to the vehicle.



GENERAL PROCEDURES


Before Servicing

1. Turn the ignition switch to LOCK.
2. Disconnect the negative battery cable and wait for more than one minute to allow the backup power supply to deplete its stored power.
3. Remove the column cover.
(Refer to section S.)
4. Disconnect the orange and blue clock spring connectors.
5. Remove the glove compartment cover.
(Refer to section S.)
6. Disconnect the orange and blue passenger-side air bag module connector.



After Servicing

1. Connect the negative battery cable.
2. Turn the ignition switch to ON.
3. Verify that the air bag system warning light illuminates for approximately 6 seconds and then goes off.




TROUBLESHOOTING




Troubleshooting Procedure

The SAS unit has an on-board diagnostic function that flashes or illuminates the air bag system warning light to indicate trouble in the air bag system. The trouble can be determined by the warning light illumination or flashing pattern.

Flowchart



Diagnostic Trouble Code Table

Priority	Code No.	Warning light indication	Possible cause	Inspection area	Refer to page
1	0	Remains on	SAS unit	SAS unit connector	T-69
2	3		Battery	<ul style="list-style-type: none"> Battery Wiring harness (Battery — ENGINE 15 A fuse — SAS unit, Battery — METER 10 A fuse — SAS unit) 	T-70
3	6		Driver-side air bag module	<ul style="list-style-type: none"> Clock spring Wiring harness (Clock spring — SAS unit) 	T-71
4	7		Passenger-side air bag module	Wiring harness (Passenger-side air bag module — SAS unit)	T-73


Note

- If the air bag system warning light flashes continuously after the SAS unit is replaced, refer to the Deployment Authorization Procedures. (Refer to page T-77.)

Flowchart No.1	Symptom	Air bag system warning light remains on
-----------------------	----------------	---

Possible cause

- Damaged SAS unit
- Open or short circuit in wiring harness
- Poor connection of connector



Remedy

Warning

- Handling the SAS unit improperly can accidentally deploy the air bags, which may seriously injure you. Read SERVICE WARNINGS, page T-66, before handling the SAS unit.


- Carry out the "Before Servicing" procedure under GENERAL PROCEDURES, page T-67.
- Remove the center lower panel. (Refer to section S.)
- Make sure the SAS unit connector is securely connected to the SAS unit.

Connection	Action
OK	Replace SAS unit (Refer to page T-76)
Poor	Reconnect connector

Flowchart No.2	Symptom	Diagnostic trouble code 3
-----------------------	----------------	---------------------------

Possible cause


- Weak battery
- Poor connection of connector



Step 1

Measure the battery voltage.

Voltage	Action
More than 8 V	Go to Step 2
Less than 8 V	Battery is weak Check charge/discharge system (Refer to section G)



Step 2

Warning

- Handling the SAS unit improperly can accidentally deploy the air bags, which may seriously injure you. Read **SERVICE WARNINGS**, page T-66, before handling the SAS unit.

1. Carry out the "Before Servicing" procedure under GENERAL PROCEDURES, page T-67.
2. Remove the center lower panel.
(Refer to section S.)
3. Disconnect the SAS unit connector.
4. Connect the negative battery cable.
5. Turn the ignition switch to ON.
6. Measure the voltage at the terminals of the SAS unit connector.

Terminal	Voltage	Action
Z (LG)	More than 8 V	Measure voltage at terminal AB
	Less than 8 V	Repair wiring harness (Battery — ENGINE 15 A fuse — SAS unit)
AB (B/Y)	More than 8 V	Replace SAS unit (Refer to page T-76)
	Less than 8 V	Repair wiring harness (Battery — METER 10 A fuse — SAS unit)



Flowchart No.3	Symptom	Diagnostic trouble code 6
----------------	---------	---------------------------

Possible cause

- Damaged driver-side air bag module
- Damaged clock spring
- Damaged SAS unit
- Open or short circuit in wiring harness
- Poor connection of connector

Warning

- **Handling the air bag module and SAS unit improperly can accidentally deploy the air bag, which may seriously injure you. Read SERVICE WARNINGS, page T-66, before handling the air bag module and SAS unit.**



Step 1


1. Carry out the “Before Servicing” procedure under GENERAL PROCEDURES, page T-67.
2. Remove the driver-side air bag module. (Refer to page T-74.)
3. Verify that the driver-side air bag module connector pin is not broken.

Pin	Action
OK	Go to Step 2
Broken	Replace combination switch (Refer to page T-14)

Step 2


1. Connect the leads of the **SST** to terminals B and C of the driver-side air bag module connector.
2. Set the resistance of the **SST** to 2 ohms.
3. Connect the clock spring connector.
4. Connect the negative battery cable.
5. Turn the ignition switch to ON and check the diagnostic trouble code.

Diagnostic trouble code	Action
6	Go to Step 3
Other	Replace driver-side air bag module (Refer to page T-74)

**Step 3**


1. Turn the ignition switch to LOCK.
2. Disconnect the negative battery cable and wait for more than one minute to allow the backup power supply to deplete its stored power.
3. Disconnect the clock spring connector.
4. Verify that the clock spring connector.

Pin	Action
OK	Go to Step 4
Broken	Repair wiring harness (Clock spring — SAS unit)

**Step 4**

1. Connect the leads of the **SST** to terminals B and C of the clock spring connector.
2. Set the resistance of the **SST** to 2 ohms.
3. Connect the negative battery cable.
4. Turn the ignition switch to ON and check the diagnostic trouble code.

Diagnostic trouble code	Action
6	Go to Step 5
Other	Replace combination switch (Refer to page T-14)

**Step 5**

1. Turn the ignition switch to LOCK.
2. Disconnect the negative battery cable and wait for more than one minute to allow the backup power supply to deplete its stored power.
3. Remove the center lower panel.
(Refer to section S.)
4. Disconnect the SAS unit connector.
5. Check the wiring harness between the terminals of the SAS unit connector and the clock spring connector for the following.
 - Ground short circuit
 - Line short circuit
 - Open circuit
6. If the wiring harness is normal, replace the SAS unit.
(Refer to page T-76.)
7. If the wiring harness is faulty, repair it.
(Clock spring — SAS unit)



Flowchart No.4	Symptom	Diagnostic trouble code 7
----------------	---------	---------------------------

Possible cause

- Damaged passenger-side air bag module
- Damaged SAS unit
- Open or short circuit in wiring harness
- Poor connection of connector

Warning

- Handling the air bag module and SAS unit improperly can accidentally deploy the air bag, which may seriously injure you. Read SERVICE WARNINGS, page T-66, before handling the air bag module and SAS unit.



Step 1


1. Carry out the “Before Servicing” procedure under GENERAL PROCEDURES, page T-67.
2. Verify that the passenger-side air bag module connector pin is not broken.

Pin	Action
OK	Go to Step 2
Broken	Repair wiring harness (Passenger-side air bag module — SAS unit)

Step 2

1. Connect the leads of the SST to terminals B and C of the passenger-side air bag module connector.
2. Set the resistance of the SST to 2 ohms.
3. Connect the clock spring connector.
4. Connect the negative battery cable.
5. Turn the ignition switch to ON and check the diagnostic trouble code.

Diagnostic trouble code	Action
7	Go to Step 3
Other	Replace passenger-side air bag module (Refer to page T-75)



Step 3

1. Turn the ignition switch to LOCK.
2. Disconnect the negative battery cable and wait for more than one minute to allow the backup power supply to deplete its stored power.
3. Remove the column cover.
(Refer to section S.)
4. Disconnect the clock spring connector.
5. Remove the center lower panel.
(Refer to section S.)
6. Disconnect the SAS unit connector.
7. Check the wiring harness between the terminals of the SAS unit connector and the passenger-side air bag connector for the following.
 - Ground short circuit
 - Line short circuit
 - Open circuit
8. If the wiring harness is normal, replace the SAS unit.
(Refer to page T-76.)
9. If the wiring harness is faulty, repair it.
(Passenger-side air bag module — SAS unit)

**DRIVER-SIDE AIR BAG MODULE
Removal / Installation**


Warning

- Handling the air bag module improperly can accidentally deploy the air bag, which may seriously injure you. Read **SERVICE WARNINGS**, page T-66, before handling the air bag module.


Warning

- Installing the driver-side air bag module when a service code 6 is not indicated can accidentally deploy the air bag, which can cause serious injury. Carry out the proper troubleshooting procedures and verify that service code 6 is indicated before installing the driver-side air bag module.

1. Carry out the “Before Servicing” procedure under **GENERAL PROCEDURES**, page T-67.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.
4. Follow the troubleshooting flowchart (page T-68) to verify that the air bag system is operating normally.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Bolt | <ol style="list-style-type: none"> 2. Driver-side air bag module 3. Connector |
|---|---|
- Installation note page T-75

**Installation note****Bolt**

Tighten the bolts in the order shown in the figure.

Tightening torque:

7.9—11.7 N·m { 80—120 kgf·cm , 70—104 in·lbf }

PASSENGER-SIDE AIR BAG MODULE Removal / Installation


Warning

- Handling the air bag module improperly can accidentally deploy the air bag, which may seriously injure you. Read **SERVICE WARNINGS**, page T-66, before handling the air bag module.

Warning

- Installing the passenger-side air bag module when a service code 7 is not indicated can accidentally deploy the air bag, which can cause serious injury. Carry out the proper troubleshooting procedures and verify that service code 7 is indicated before installing the passenger-side air bag module.

1. Carry out the “Before Servicing” procedure under **GENERAL PROCEDURES**, page T-67.
2. Remove the glove compartment and undercover.
(Refer to section S.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.
5. Follow the troubleshooting flowchart (page T-68) to verify that the air bag system is operating normally.



1. Bolt
2. Connectors

3. Passenger-side air bag module


SAS UNIT

Removal / Installation

Warning

- Handling the SAS unit improperly can accidentally deploy the air bags, which may seriously injure you. Read **SERVICE WARNINGS**, page T-66, before handling the SAS unit.

1. Carry out the "Before Servicing" procedure under GENERAL PROCEDURES, page T-67.
2. Remove the center lower panel.
(Refer to section S.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.
5. Follow the troubleshooting flowchart (page T-68) to verify that the air bag system is operating normally.
6. Perform the Deployment Authorization Procedures when installing a new SAS unit.
(Refer to page T-77.)




1. Connector

2. Nut

3. SAS unit

Installation note below



Installation note

Bolt

Tighten the bolts in the order shown in the figure.

Tightening torque:


7.9—11.7 N·m { 80—120 kgf·cm , 70—104 in·lbf }

Deployment Authorization Procedures

1. Install a new SAS unit then verify that the air bag system warning light flashes approximately 6 seconds after the ignition switch is turned to ON.
2. If a service code is indicated, perform the appropriate troubleshooting.
3. Turn the ignition switch to LOCK then back to ON while the air bag system warning light is flashing continuously if the procedures have been performed correctly, the air bag system warning light illuminates the goes out afted approximately 6 seconds.


AIR BAG MODULE DISPOSAL PROCEDURE

Before scrapping a vehicle with an undeployed air bag module, deploy the air bag. Never dispose of a live air bag module. If the **SST** is not available, consult the nearest Mazda representative for assistance.




Air Bag Deployment

1. Move the vehicle to an open space, away from strong winds, and open all of the vehicle's doors.
2. Disconnect the negative battery cable and wait for more than one minute to allow the backup power supply to deplete its stored power.
3. Follow the appropriate procedure for the driver-side or passenger-side air bag module.




Driver-side air bag

- (1) Make sure the air bag module is firmly mounted to the steering wheel.
- (2) Remove the column cover.
(Refer to section S.)
- (3) Disconnect the orange and blue clock spring connectors.




- (4) Inspect the **SST**.
(Refer to page T-79.)
- (5) Connect the **SST** to the clock spring connector as shown in the figure.




Passenger-side air bag


- (1) Make sure the air bag module is firmly mounted to the dashboard.
- (2) Remove the glove compartment cover.
(Refer to section S.)
- (3) Disconnect the orange and blue passenger-side air bag module connector.



- (4) Inspect the **SST**.
(Refer to page T-79.)
- (5) Connect the **SST** to the passenger-side air bag module connector as shown in the figure.



4. Connect the red clip of the **SST** to the positive battery terminal and the black clip to the negative terminal.
5. Verify that the red light on the **SST** is illuminated.
6. Make sure all persons are standing at least **6 m { 20 ft }** from the vehicle.
7. Press the activation switch on the **SST** to deploy the air bag.



Air Bag Disposal

Warning


- The air bag is very hot immediately after it deploys. You can be burned. Do not touch the air bag module for at least 15 minutes after deployment.

Warning

- Pouring water on a deployed air bag is dangerous. The water will mix the residual gases to form a gas that can make breathing difficult if inhaled. Do not pour water on the deployed air bag module.

Warning



- A deployed air bag module may contain deposits of sodium hydroxide, a caustic by-product of the gas-generated combustion. If this substance gets in your eyes or on your hands, it can cause irritation and itching. When handling a deployed air bag module, wear gloves and safety glasses.



1. Put on gloves and safety glasses.
2. Place the deployed air bag module in a plastic bag, seal it, and then dispose of it.
3. Wash your hands after removing your gloves.

INSPECTION OF SST (DEPLOYMENT TOOL)


- Use the **SST** to deploy a live air bag module before disposing of it.
- Before connecting the **SST** to the clock spring connector or air bag module connector, inspect the operation of the **SST**.




Inspection Procedure

1. Follow the steps below to inspect the operation of the **SST**.

Step	Inspection procedure	Light condition	
		Green	Red
1	Connect red clip to positive battery terminal and black clip to negative battery terminal.	ON	OFF
2	Connect connectors A and B of SST .	OFF	ON
3	Press activation switch.	ON	OFF



2. If not as specified, do not use the **SST** because it may cause the air bag to unexpectedly deploy upon connection to the harnesses.



Before beginning any service procedure, refer to section T of this manual for air bag system service warnings.

HEATER AND AIR CONDITIONER SYSTEMS

R-134a SYSTEM INTRODUCTION	U- 2	CONTROL SYSTEM	U-30
OUTLINE	U- 2	PREPARATION	U-30
SERVICE WARNINGS	U- 3	STRUCTURAL VIEW	U-30
SERVICE CAUTIONS	U- 4	CONDENSER FAN	U-31
REFRIGERANT SYSTEM SERVICE		MAGNETIC CLUTCH	U-32
PROCEDURES	U- 5	REFRIGERANT PRESSURE	
MANIFOLD GAUGE SET		SWITCH	U-34
INSTALLATION	U- 5	RELAY	U-34
CHARGING	U- 5	BLOWER MOTOR	U-34
CHECKING REFRIGERANT		RESISTOR	U-35
AMOUNT	U- 7	THERMOSWITCH	U-36
CHECKING REFRIGERANT		MAGNETIC SOLENOID VALVE	U-36
PRESSURE	U- 7	HEATER CONTROL UNIT	U-37
PERFORMANCE TEST	U- 8	REAR MAIN SWITCH	U-39
BASIC SYSTEM	U- 9	REAR HEATER FAN SWITCH	U-41
PREPARATION	U- 9	REAR COOLER FAN SWITCH	U-42
STRUCTURAL VIEW	U- 9	TROUBLESHOOTING	U-43
BLOWER UNIT	U-10	TROUBLESHOOTING NOTES	U-43
HEATER UNIT	U-11	USING THIS SECTION	U-43
COOLING UNIT	U-13	TROUBLESHOOTING	U-46
REAR HEATER UNIT	U-15		
REAR BLOWER UNIT	U-17		
REAR COOLING UNIT	U-18		
A/C COMPRESSOR	U-20		
CONDENSER	U-25		
RECEIVER/DRIER	U-26		
HEATER HOSES AND PIPES	U-27		
REFRIGERANT LINES	U-28		
REAR HEAT DUCT	U-29		

R-134a SYSTEM INTRODUCTION

OUTLINE

- R-12 and other fluorocarbons now used in air conditioners can destroy the ozone layer in the stratosphere. The result is an increase in hazardous ultraviolet rays which over time can adversely affect both human health and the biosphere.
- Because of this concern, Mazda has chosen to use Refrigerant-134a (R-134a), a hydrofluorocarbon-based refrigerant that does not deplete the ozone layer, in this vehicle.
- R-12 and R-134a are not interchangeable; system parts and system service tools also differ. The table below compares the two systems.

Refrigerant system

Part	R-12 system	R-134a system	Remarks
Refrigerant	Chlorofluorocarbon-12 (CFC-12) [CCl ₂ F ₂]	Hydrofluorocarbon-134a (HFC-134a) [CH ₂ FCF ₃]	If the refrigerants are mixed or one refrigerant is used in a system that requires the other, the compressor oil will separate from the refrigerant and not circulate within the system. This can damage the A/C compressor. In addition, mixing R-134a with R-12 or using R-134a instead of R-12 in an R-12 system can lower the durability of the NBR O-ring and dissolve the fluorine rubber O-rings. If the fluorine rubber O-rings are dissolved, refrigerant may leak.
Compressor oil	Mineral oil	Polyalkylene glycol oil (PAG oil) [ND-OIL8]	If the oils are mixed or one oil is used in a system that requires the other, the compressor oil will separate from the refrigerant and not circulate within the system. This can damage the A/C compressor. Mixing PAG oil with mineral oil or using PAG oil instead of mineral oil in an R-12 system can lower the durability of the NBR and fluorine rubber O-rings.
O-ring	Nitrile butadiene rubber (NBR) Fluorine rubber	Rubber in behalf of R-134a (RBR)	If an NBR O-ring is used in an R-134a system, the PAG oil and R-134a will lower the durability of the O-ring. If a fluorine rubber O-ring is used in an R-134a system, the R-134a will dissolve the O-ring and cause the refrigerant to leak.
Joint nuts	Inch threads	Metric threads	Thread standards for joint nuts connecting pipes and hoses have been changed to avoid connecting R-12 system parts with R-134a system parts.
Charging valve	Screw-on type HI: 3/8-24 UNF LO: 7/16-20 UNF	Quick-connect type HI: 16 mm { 0.6 in } dia. LO: 13 mm { 0.5 in } dia.	The shape of the charging valve differs for each system to avoid confusion. The quick connect charging valve prevents refrigerant from leaking when the charging hose is connected to the valve.


Service tools

Part	R-12 system	R-134a system	Remarks
Tool joints	Inch threads	Metric threads	Thread standards for tool joints have been changed to avoid connecting R-12 system tools with R-134a system tools.
Charging valve joints	Screw-on type HI: 3/8-24 UNF LO: 7/16-20 UNF	Quick-connect type HI: 16 mm { 0.6 in } dia. LO: 13 mm { 0.5 in } dia.	The shape of the charging valve joints differ for each system to avoid confusion. The quick-connect charging valve joint prevents refrigerant from leaking when the charging hose is connected to the valve.
Manifold gauge	High-pressure-side maximum reading: 2.9 MPa { 30 kgf/cm ² , 430 psi }	High-pressure-side maximum reading: 3.5 MPa { 35 kgf/cm ² , 500 psi }	R-134a requires a higher pressure to condense than R-12.
Leak tester	Gas type Electric type	Electric type	A gas leak tester reacts with chlorine in R-12 to indicate the location of a leak. This kind of tester does not work with an R-134a system, however, because R-134a has no chlorine. Two kinds of electric testers are available; those that work exclusively with one system or the other, and those that work with both.

SERVICE WARNINGS


Using/Handling Unapproved Refrigerant

- Using a flammable refrigerant, such as OZ-12, in this vehicle is dangerous. In an accident, the refrigerant may catch fire, resulting in serious injury or death. When servicing this vehicle, use only R-134a.
- Checking for system leaks on a vehicle that has been serviced with flammable refrigerant, such as OZ-12, is dangerous. Conventional leak detectors use an electronically generated arc which can ignite the refrigerant, causing serious injury or death. If a flammable refrigerant has been used to service the system, or if you suspect a flammable refrigerant may have been used, contact the local fire marshall or EPA office for information on handling the refrigerant.



Storing Refrigerant


- The refrigerant container is highly pressurized. If it is subjected to high heat, it could explode, scattering metal fragments and liquid refrigerant that can seriously injure you. Store the refrigerant at temperatures below 40 °C { 104 °F }.



Servicing Refrigerant System

- Do not allow the refrigerant to leak near fire or any kind of heat. A poisonous gas may be generated if the refrigerant gas contacts fire or heat such as from cigarettes and heaters. When carrying out any operation that can cause refrigerant leakage, extinguish or remove the above-mentioned heat sources and maintain adequate ventilation.

U



Handling Refrigerant


- Handling liquid refrigerant is dangerous. A drop of it on the skin can result in localized frostbite. When handling the refrigerant, wear gloves and safety goggles. If refrigerant splashes into the eyes, immediately wash them with clean water and consult a doctor.








SERVICE CAUTIONS

Compressor Oil (ND-OIL8)

- Do not spill compressor oil on the vehicle. A drop of compressor oil on the vehicle surface can eat away at the paint. If oil gets on the vehicle, wipe it off immediately.



- PAG compressor oil has a higher moisture absorption efficiency than the previously used mineral oil. If moisture mixes with the compressor oil, the refrigerant system could be damaged. Therefore, install caps immediately after using the compressor oil or removing refrigerant system parts to prevent moisture absorption.



REFRIGERANT SYSTEM SERVICE PROCEDURES

MANIFOLD GAUGE SET INSTALLATION

1. Fully close the valves of the manifold gauge.
2. Connect charging hoses to the high- and low-pressure side joints of the manifold gauge set.
3. Connect quick couplers to the ends of the charging hoses.
4. Remove the caps from the charging valves of the high- and low-pressure side cooler pipes.
5. Connect the quick couplers to the charging valves of the cooler pipes.

CHARGING


1. Install the manifold gauge set.
2. Connect the tap pin side of the charging hose to the air purge valve of the manifold gauge.
3. Connect the vacuum pump hose to the center joint of the manifold gauge.
4. Connect the vacuum pump hose to the vacuum pump.
5. Connect can puncture valves to a 4-way joint.
6. Fully open the can puncture valves and connect the service cans to the valves.

Regular amount of refrigerant

Single A/C : 900 g { 31.8 oz , 1.98 lb }

Twin A/C : 1000 g { 35.30 oz , 2.20 lb }


7. Fully close any can puncture valve that is not connected to a service can.
8. Connect the 4-way joint to the charging hose that is connected to the gauge set air purge valve.
9. Open all the valves of the manifold gauge.
10. Start the vacuum pump and let it operate for 15 minutes.
11. After 15 minutes, verify that the high- and low-pressure-side readings of the manifold gauge set are at **-101 kPa { -760 mmHg , -29.9 inHg }**. Close each valve of the manifold gauge.
12. Stop the vacuum pump and wait for about 5 minutes.
13. After 5 minutes, check the low-pressure-side reading of the manifold gauge. If the reading has changed, check for leaks and then repeat from step 9. If the reading has not changed, go to step 14.
14. Open the service cans by using the can puncture valves.
15. Open the low-pressure side valve of the manifold gauge set and charge with refrigerant until the low-pressure-side reading is at **100 kPa { 1 kgf/cm² , 10 psi }**.
16. Close the low-pressure side valve of the manifold gauge.




17. Check for leaks by using a leak tester. If there are no leaks, go to step 18. If a leak is found at a loose joint, tighten the joint and check for leaks again. If there is still a leak at the same joint, discharge the refrigerant and then repair the joint. Repeat the charging procedure from step 9. If there are no leaks after tightening the joint, go to step 18.

Warning


- **Running the engine with the high-pressure side valve open is dangerous. Pressure within the service cans will increase and the cans could explode, scattering metal fragments and liquid refrigerant that can seriously injure you. Therefore, do not open the high-pressure side valve while the engine is running.**




18. Open the low-pressure side valve of the manifold gauge and charge with the remaining refrigerant.



19. Close the low-pressure side valve of the manifold gauge.
20. Check for leaks by using a leak tester. If there are no leaks, go to step 21. If a leak is found at a loose joint, tighten the joint and check for leaks again. If there is still a leak at the same joint, discharge the refrigerant and then repair the joint. Repeat the charging procedure from step 9. If there are no leaks after tightening the joint, go to step 21.




21. Disconnect the high- and low-pressure side quick couplers from the charging valves that are connected to the high and low-pressure side cooler pipes of the refrigerant system.
22. Install the caps to the charging valves of the cooler pipes.



CHECKING REFRIGERANT AMOUNT



1. Install the manifold gauge set. (Refer to page U-5.)
2. Check the refrigerant pressure reading with the engine stopped.
3. Verify that the high- and low-pressure-side readings of the manifold gauge are at **493—788 kPa { 5.02—8.04 kgf/cm² , 71—114 psi }**. If the pressure readings are lower than specified, recharge the refrigerant. (Refer to page U-5.)
If the pressure readings are within the specification but there is insufficient cooling, go to the next step. If the pressure readings are within the specification and there are no leaks, the refrigerant amount is OK.
4. Start the engine and run it at a constant **2,000 rpm**.
5. Turn the A/C switch on, set the front fan switch at the fourth position, and set the intake mode at recirculate.
6. If the A/C compressor is short-cycling, note the low-pressure-side reading at which the magnetic clutch kicks out.
7. If the pressure is **170 kPa { 1.7 kgf/cm² , 24 psi }** or lower, evacuate and recharge the refrigerant system with the proper amount of refrigerant. (Refer to page U-5.) If the pressure is **210 kPa { 2.1 kgf/cm² , 30 psi }** or higher, inspect the thermostitch. (Refer to page U-36.)



CHECKING REFRIGERANT PRESSURE

1. Close the doors and windows and open the hood.
2. Install the manifold gauge set. (Refer to page U-5.)
3. Start the engine and run it at **1,500 rpm**.
4. Turn the A/C switch on and set the front fan switch to the fourth position.
5. Set the REC/FRESH lever to RECIRCULATE.
6. Set the MODE lever to VENT.
7. Set the TEMP lever to MAX COLD.
8. Verify that the pressure readings of the manifold gauge are in the shaded zones.
9. If the pressures are not as specified, inspect and repair the refrigerant system.
10. If the pressures are abnormal, refer to flowchart No.14 and troubleshoot the system.





PERFORMANCE TEST

After finishing repairs, conduct a performance test of the air conditioning system as follows.

1. Install the manifold gauge set. (Refer to page U-5.)
2. Start the engine and keep the engine speed at **1,500 rpm**.
3. Operate the air conditioner at maximum cooling.
4. Close all windows and doors.
5. Place a dry-bulb thermometer in the center ventilator outlet.
6. Place a dry-and-wet thermometer close to the blower inlet.
7. Wait until the air conditioner outlet temperature stabilizes. If the high-pressure side becomes too high, pour cool water on the condenser. If it is too low, cover the front of the condenser.

Stabilized condition

Blower inlet temperature: 30—35 °C { 86—95 °F }



**High pressure: 1.38—1.56 MPa
{ 14.0—16.0 kgf/cm² , 200—227 psi }**

8. After the air conditioner stabilizes, read the dry-and-wet thermometer at the air inlet.
9. Calculate the relative humidity from the below chart by comparing the wet-bulb and dry-bulb readings.

HOW TO READ THE GRAPH:

After measuring the temperatures of wet- and dry-bulb thermometer at the blower inlet, relative humidity (%) can be obtained.

Example; Supposing dry- and wet-bulb temperatures at the blower inlet are 25°C {77°F} and 19.5°C {67.1°F}, respectively, the point of intersection of the dotted lines in the graph is 60%.




10. Read the dry-bulb thermometer at the air outlet, and calculate the difference between the inlet dry-bulb and outlet dry-bulb temperature.
11. Verify that the intersection of the relative humidity and temperature difference is in the shaded zone.


BASIC SYSTEM

PREPARATION

SST

0000-41-0812-13		For protection damage of shaft seal
Seal sleeve protector		

STRUCTURAL VIEW




- | | |
|---|--|
| <p>1. Blower unit
Removal / Installation page U-10
Disassembly / Assembly page U-10</p> | <p>6. Rear cooling unit
Removal / Installation page U-18
Disassembly / Assembly page U-19
Inspection page U-19</p> |
| <p>2. Heater unit
Removal / Installation page U-11
Disassembly / Assembly page U-12
Inspection page U-12</p> | <p>7. A/C compressor
Removal / Installation page U-20
Disassembly page U-20
Assembly page U-22</p> |
| <p>3. Cooling unit
Removal / Installation page U-13
Disassembly / Assembly page U-14
Inspection page U-14</p> | <p>8. Condenser
Removal / Installation page U-25
Inspection page U-26</p> |
| <p>4. Rear heater unit
Removal / Installation page U-15
Disassembly / Assembly page U-16
Inspection page U-16</p> | <p>9. Receiver/drier
Removal / Installation page U-26</p> <p>10. Heater hoses and pipes
Removal / Installation page U-27</p> |
| <p>5. Rear blower unit
Removal / Installation page U-17
Disassembly / Assembly page U-17</p> | <p>11. Refrigerant lines
Removal / Installation page U-28</p> <p>12. Rear heat duct
Removal / Installation page U-29</p> |



BLOWER UNIT

Removal / Installation

1. Remove the glove compartment cover. (Refer to section S.)
2. Disconnect the blower unit connectors.
3. Disconnect the air intake wire.
4. Remove the cooling unit bracket, keyless unit and door lock timer unit bracket.
5. Remove in the order shown in the figure.
6. Install in the reverse order of removal.




1. Seal plate

2. Blower unit
Disassembly / Assembly below


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Front blower motor
2. Blower fan
3. Resistor
4. Case (bottom)


5. Air guider
6. Air intake door
7. Case (top)



**HEATER UNIT
Removal / Installation**

1. Drain the engine coolant. (Refer to section E.)
2. Remove the nuts.
3. Remove the hose clamps and heater hoses.
4. Remove the dashboard. (Refer to section S.)

5. Remove in the order shown in the figure.
6. Install in the reverse order of removal.




1. Heater unit
 Disassembly / Assembly page U-12
 Inspection page U-12

2. Seal plate

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



- | | |
|--|----------------------|
| 1. Heater core
Inspection below | 6. Airflow mode door |
| 2. Duct | 7. Air mix link set |
| 3. Airflow mode link set | 8. Heater case (2) |
| 4. Crip | 9. Heater case (3) |
| 5. Heater case (1) | 10. Air mix door |

Inspection


Heater core

1. Remove the heater core from the heater unit.
2. Check for cracks, damage, and coolant leakage. Repair or replace the heater core if necessary.
3. Check for bent fins. If they are bent, use a flat-head screwdriver to straighten them.
4. Check for fittings for cracks or damage. Replace the heater core if necessary.

COOLING UNIT

Removal / Installation

1. Discharge the refrigerant from the system.
2. Disconnect the thermoswitch connector.
3. Disconnect front cooler pipe No.1 and front cooler hose (LO) from the cooling unit.
(Refer to page U-29.)
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal, referring to **Installation note**.
6. Test its performance after charging the system. (Refer to page U-5, 8.)



1. Seal plate


2. Cooling unit
 Installation note below
 Disassembly / Assembly page U-14
 Inspection page U-14

Installation note


When installing a new cooling unit (evaporator), add 40 ml { 40 cc , 1.4 fl oz } of compressor oil through the high-pressure side of the A/C compressor.

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Disassembly note**.



- | | |
|---------------------------|---------------------------|
| 1. Case (top) | 4. Inlet pipe |
| 2. Case (bottom) | 5. Expansion valve |
| 3. Thermostat switch | Assembly note below |
| Assembly note below | 6. Evaporator |
| | Inspection below |



Assembly note

Expansion valve

Apply clean compressor oil to the O-rings before connecting the fittings; do not apply compressor oil to the fitting nuts.

Thermostat switch

Assemble the sensor part of the thermostat switch as shown in the figure.

Inspection


Evaporator

1. Check the evaporator fins for blockage. If the fins are clogged, clean them with compressed air. Do not use water.
2. Check the fittings for cracks and damage. Replace the evaporator if necessary.

REAR HEATER UNIT

Removal / Installation

1. Drain the engine coolant. (Refer to section E.)
2. Remove the hose clamps and disconnect the rear heater hoses from the rear heater unit.
3. Remove the driver's seat. (Refer to section S.)
4. Disconnect the rear heater unit connector.
5. Remove in the order shown in the figure.
6. Install in the reverse order of removal.



1. Cover


2. Rear heater unit

Disassembly / Assembly page U-16

Inspection page U-16

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Rear heater blower motor
2. Blower fan
3. Blower relay
4. Rear heater resistor
5. Panel
6. Rear heater pipe

7. Rear heater pipe
 8. Rear heater case (top)
 9. Rear heater case (bottom)
 10. Heater core
- Inspection below

Inspection


Heater core

1. Disassemble the rear heater unit.
2. Check for cracks, damage, and coolant leakage. Repair or replace the heater core if necessary.
3. Check for bent fins. If they are bent, use a flat-head screwdriver to straighten them.
4. Check for fittings for cracks or damage. Replace the heater core if necessary.


REAR BLOWER UNIT

Removal / Installation

1. Remove the left rear side trim. (Refer to section S.)
2. Remove the magnetic solenoid valve relay and rear blower relay bracket.
3. Disconnect the rear blower unit connector.
4. Remove as shown in the figure.
5. Install in the reverse order of removal.



1. Rear blower unit
Disassembly / Assembly below




Disassembly / Assembly

1. Remove the rear blower motor.
2. Remove the blower fan.
3. Remove the case (top).
4. Remove the case (bottom).
5. Assemble in the reverse order of disassembly.

REAR COOLING UNIT

Removal / Installation

1. Discharge the refrigerant from the system.
2. Remove the rear blower unit. (Refer to page U-17.)
3. Disconnect the rear cooling unit connector.
4. Disconnect rear cooler pipes No.8 and No.9 from the rear cooling unit. (Refer to page U-29.)
5. Remove as shown in the figure.
6. Install in the reverse order of removal, referring to **Installation note**.
7. Test its performance after charging the system. (Refer to page U-5, 8.)




1. Rear cooling unit
 Installation note below
 Disassembly / Assembly page U-19
 Inspection page U-19

Installation note

When installing a new rear cooling unit (evaporator), add **40 ml { 40 cc , 1.4 fl oz }** of compressor oil through the high-pressure side of the A/C compressor.

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Rear cooler harness
2. Magnetic solenoid valve
3. Rear resistor
4. Rear cooler unit case (top)
5. Rear cooler unit case (bottom)

6. Expansion valve
 Assembly note below
7. Evaporator
 Inspection below

Assembly note






Expansion valve

Apply clean compressor oil to the O-rings before connecting the fittings. Do not apply compressor oil to the fitting nuts.

Inspection

Evaporator

1. Check the evaporator fins for blockage. If the fins are clogged, clean them with compressed air. Do not use water.
2. Check the fittings for cracks and damage. Replace the evaporator if necessary.



A/C COMPRESSOR

Removal / Installation

1. Discharge the refrigerant from the system.
2. Remove the fresh-air duct. (Refer to section F.)
3. Loosen the A/C drive belt. (Refer to section B.)
4. Disconnect the front cooler hoses from the A/C compressor.

5. Remove the mounting bolts and the A/C compressor.
6. Install in the reverse order of removal. When replacing the A/C compressor with a new one, remove the following amount of compressor oil from the new A/C compressor.

Compressor oil to be removed


= 200—215 ml { 200—215 cc , 6.76—7.26 fl oz } –
 (oil from old A/C compressor + 10—15 ml { 10—15 cc , 0.4—0.5 fl oz })

Disassembly


1. Disassemble the magnetic clutch. (Refer to page U-32.)
2. Remove the bolts and the valve assembly.

3. Remove the oil seal.

4. Drain the compressor oil.




5. Remove the bolts and the front housing.




6. Remove the valves in the following order.

- 1) Pins
- 2) Gasket
- 3) Discharge valve
- 4) Valve plate
- 5) Suction valve
- 6) O-ring




7. Remove the rear housing.




8. Remove the valves in the following order.


- 1) Pins
- 2) Gasket
- 3) Discharge valve
- 4) Valve plate
- 5) Suction valve
- 6) O-ring




9. Remove the clip and the oil felt.



10. Remove the snap ring by using snap ring pliers.




11. Remove the shaft seal by using a suitably sized bushing.




Assembly

1. Install the shaft seal by using a suitably sized bushing.




2. Install the snap ring.




3. Install the valves in the following order.


- 1) Pins
- 2) New O-ring




- 1) Suction valve
- 2) Valve plate
- 3) Discharge valve
- 4) New gasket
- 5) Rear housing




4. Install the valves in the following order.
 - 1) Pins
 - 2) New O-ring



- 1) Suction valve
- 2) Valve plate
- 3) Discharge valve
- 4) New gasket




5. Set the **SST** onto the shaft to prevent damaging the shaft seal.




6. Install the front housing.

Tighten torque:
 25—26 N·m { 2.5—2.7 kgf·m , 18—19 ft·lbf }




7. Install the oil felt and the clip.




8. Pour compressor oil into the A/C compressor.

Compressor oil (specified amount):
200—215 ml { 200—215 cc , 6.76—7.26 fl oz }



9. Install a new oil seal.




10. Install the valve assembly.

11. Assemble the magnetic clutch. (Refer to page U-32.)

CONDENSER

Removal / Installation


1. Discharge the refrigerant from the system.
2. Remove the receiver/drier. (Refer to page U-26.)
3. Remove the condenser fan. (Refer to page U-31.)
4. Remove the center stay.
5. Remove the hood lock assembly. (Refer to section S.)
6. Remove in the order shown in the figure.
7. Install in the reverse order of removal, referring to **Installation note**.
8. Test its performance after charging the system. (Refer to page U-5, 8.)



- | | |
|--|--|
| <p>1. Front cooler hose (HI)
Installation note page U-29</p> <p>2. Condenser bracket</p> | <p>3. Condenser
Installation note below
Inspection page U-26</p> |
|--|--|

Installation note

When installing a new condenser, add **40 ml { 40 cc , 1.4 fl oz }** of compressor oil through the high-pressure side of the A/C compressor.




Inspection

1. Check for cracks, damage, and oil leakage. Repair or replace the condenser if necessary.
2. Check for bent fins. If they are bent, use a flathead screwdriver to straighten them.

RECEIVER/DRIER

Removal / Installation

1. Discharge the refrigerant from the system.
2. Remove the radiator grille. (Refer to section S.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation note**.
5. Charge the system and test its performance. (Refer to page U-5, 8.)



N-m { kgf·m , ft·lbf }

- | | |
|--|-----------|
| 1. Front cooler pipe No.2
Installation note | page U-29 |
| 2. Front cooler pipe No.3
Installation note | page U-29 |

- | | |
|--|-------|
| 3. Receiver/drier
Installation note | below |
|--|-------|

Installation note

When installing a new receiver/drier, add **10 ml { 10 cc , 0.3 fl oz }** of compressor oil through the high-pressure side of the A/C compressor.


HEATER HOSES AND PIPES

Removal / Installation

1. Drain the engine coolant. (Refer to section E.)
2. Remove the following parts, depending on the pipe and hose to be removed.

Removal heater pipe and hose	Removal parts	Section
Rear heater pipe No.1 Rear heater pipe No.2	Undercover	E

3. Remove the heater hose or heater pipe as shown in the figure.
4. Install in the reverse order of removal.



1. Front heater hose No.1
2. Front heater pipe No.1
3. Front heater hose No.2
4. Front heater hose No.3
5. Front heater hose No.4
6. Front heater pipe No.2

7. Rear heater hose No.1
8. Rear heater hose No.2
9. Rear heater pipe No.1
10. Rear heater pipe No.2
11. Rear heater hose No.3
12. Rear heater hose No.4


REFRIGERANT LINES

Removal / Installation

1. Discharge the refrigerant from the system.
2. Remove the following parts, depending on the pipe and hose to be removed.

Removal cooler pipe and hose	Removal parts	Section
Front cooler pipe No.2 Front cooler pipe No.3 Front cooler hose (HI)	Radiator grille	S
Front cooler hose (LO)	Air cleaner	F
Rear cooler pipe No.6 Rear cooler pipe No.7	Rear bumper seal Seal plate	—


3. Remove the cooler pipe or cooler hose as shown in the figure. Do not allow compressor oil to spill. Immediately plug all open fittings to keep moisture out of the system.
4. Install in the reverse order of removal, referring to **Installation note**.
5. Charge the system and test its performance. (Refer to page U-5, 8.)



- | | |
|--|--|
| 1. Front cooler pipe No.1
Installation note page U-29 | 8. Rear cooler pipe No.3
Installation note page U-29 |
| 2. Front cooler pipe No.2
Installation note page U-29 | 9. Rear cooler pipe No.4
Installation note page U-29 |
| 3. Front cooler pipe No.3
Installation note page U-29 | 10. Rear cooler pipe No.5
Installation note page U-29 |
| 4. Front cooler hose (LO)
Installation note page U-29 | 11. Rear cooler pipe No.6
Installation note page U-29 |
| 5. Front cooler hose (Hi)
Installation note page U-29 | 12. Rear cooler pipe No.7
Installation note page U-29 |
| 6. Rear cooler pipe No.1
Installation note page U-29 | 13. Rear cooler pipe No.8
Installation note page U-29 |
| 7. Rear cooler pipe No.2
Installation note page U-29 | 14. Rear cooler pipe No.9
Installation note page U-29 |

Installation note**Cooler pipe, Cooler hose**


1. Replace the O-rings at the pipe and/or hose joints when installing pipes.
2. Apply compressor oil to the O-rings and connect the joints.
3. When installing a new cooler pipe or cooler hose, add **10 ml { 10 cc , 0.3 fl oz }** of compressor oil through the high-pressure side of the A/C compressor.



4. Tighten the joints in the following order.
 - 1) Verify that the O-rings are installed.
 - 2) Tighten the nut or bolt of the joint by hand.
 - 3) Fix the bracket and clip installed on the hose or pipe to the vehicle.
 - 4) Tighten the joint to the specified torque. If it is a nut joint, tighten in the procedure shown in the figure.

REAR HEAT DUCT**Removal / Installation**

1. Remove the heater unit. (Refer to page U-11.)
2. Remove the under seat tray.
3. Turn over the floor covering. (Refer to section S.)
4. Remove the rear heat duct as shown in the figure.
5. Install in the reverse order of removal.





1. Rear heat duct No.1
2. Rear heat duct No.2
3. Rear heat duct No.3


4. Rear heat duct No.4
5. Rear heat duct No.5

CONTROL SYSTEM

PREPARATION SST

<p>0000-41-0812-05 Clutch holder</p> 	<p>For removal and installation of magnetic clutch</p>	<p>4992-02-020 Pressure plate remover</p> 	<p>For removal of pressure plate</p>
--	--	---	--------------------------------------


STRUCTURAL VIEW




- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Condenser fan
Removal / Installation page U-31
On-vehicle inspection page U-31 2. Magnetic clutch
Disassembly / Assembly page U-32
Inspection page U-33 3. Refrigerant pressure switch
Inspection page U-34 4. Relay
Inspection page U-34 5. Blower motor
Removal / Installation page U-34
Inspection page U-34 6. Resistor
Removal / Installation page U-35
Inspection page U-35 7. Thermoswitch
Inspection page U-36 | <ul style="list-style-type: none"> 8. Magnetic solenoid valve
On-vehicle inspection page U-36 9. Heater control unit
Removal / Installation page U-37
Wire adjustment page U-37
Disassembly / Assembly page U-38
Inspection page U-39 10. Rear main switch
Removal / Installation page U-39
Disassembly / Assembly page U-40
Inspection page U-40 11. Rear heater fan switch
Removal / Installation page U-41
Inspection page U-41 12. Rear cooler fan switch
Removal / Installation page U-42
Inspection page U-42 |
|---|--|

CONDENSER FAN**Removal / Installation**


1. Remove the radiator grille. (Refer to section S.)
2. Disconnect the condenser fan connector.
3. Remove as shown in the figure.
4. Install in the reverse order of removal.

**1. Condenser fan**

On-vehicle inspection below


**On-vehicle Inspection**

1. Disconnect the condenser fan connector.
2. Connect battery positive voltage to terminal A and ground to terminal B of the condenser fan and verify its operation.
3. If the condenser fan does not operate, replace the condenser fan.




MAGNETIC CLUTCH Disassembly / Assembly


1. Remove the A/C compressor. (Refer to page U-20.)
2. Remove the shaft bolt by using the **SST**.




3. Remove the pressure plate by using the **SST**.




4. Remove the shims.




5. Remove the snap ring.




6. Remove the rotor by tapping it with a plastic hammer.



7. Disconnect the stator lead wires from the A/C compressor housing.



8. Remove the snap ring and the stator.
9. Assemble in the reverse order of disassembly.



Inspection


Pressure plate

1. Measure the clearance between the pressure plate and the rotor pulley.
 - 1) Set the A/C compressor on a level block.
 - 2) Fix a dial gauge on a magnetic base and set the measuring probe on the pressure plate surface.
 - 3) Alternately apply and remove battery positive voltage as shown in the figure. The clearance is the difference in the dial gauge readings.
 - 4) Compare the measured clearance with the specified clearance below.

Clearance: 0.4—0.6 mm { 0.016—0.023 in }


2. If not as specified, install shims to adjust the clearance.

Part No.	Thickness
KA10 61L21	0.10 mm { 0.004 in }
KA10 61L22	0.30 mm { 0.012 in }
KA10 61L23	0.50 mm { 0.020 in }



Stator


1. Set the ohmmeter to the $\times 1,000 \Omega$ range.
2. Verify that there is continuity between the stator connector and the A/C compressor body.
3. If there is no continuity, replace the stator.




REFRIGERANT PRESSURE SWITCH

Inspection

1. Install the manifold gauge set. (Refer to page U-5.)
2. Make sure the high-pressure side is in the ON range as shown in the figure.



3. Disconnect the refrigerant pressure switch connector.
4. Verify that there is continuity between terminals A and B of the refrigerant pressure switch.
5. If there is no continuity, replace the front cooler pipe No.2



RELAY


Inspection

A/C relay, condenser fan relay, front blower relay, rear heater blower relay, rear blower relay, magnetic solenoid valve relay

1. Remove the relay.
2. Check for continuity between the relay terminals by using an ohmmeter.

○—○: Continuity B+: Battery positive voltage

Step	Terminals	A	B	C	D
1		○—○	○—○		
2		B+	GND	○—○	○—○




3. If not as specified, replace the relay.

BLOWER MOTOR

Removal / Installation

Front blower motor


1. Remove the glove compartment cover. (Refer to section S.)
2. Disconnect the front blower motor connector.
3. Remove the screws and the front blower motor.
4. Install in the reverse order of removal.



Inspection

Front blower motor

1. Remove the glove compartment cover. (Refer to section S.)
2. Disconnect the blower motor connector.
3. Connect battery positive voltage to terminal A and ground to terminal B.
4. If the motor does not operate, replace the front blower motor. (Refer to page U-10.)




Rear heater blower motor

1. Remove the rear heater unit. (Refer to page U-15.)
2. Disconnect the rear heater blower motor connector.
3. Connect battery positive voltage to terminal A and ground to terminal B.
4. If the motor does not operate, replace the rear heater blower motor. (Refer to page U-16.)

Rear blower motor

1. Remove the left rear side trim. (Refer to section S.)
2. Disconnect the rear blower motor connector.
3. Connect battery positive voltage to terminal A and ground to terminal B.
4. If the motor does not operate, replace the rear blower motor. (Refer to page U-17.)




RESISTOR

Removal / Installation


Front resistor

1. Remove the glove compartment cover. (Refer to section S.)
2. Disconnect the front resistor connector.
3. Remove the screws and the front resistor.
4. Install in the reverse order of removal.




Rear heater resistor

1. Remove the driver's seat. (Refer to section S.)
2. Disconnect the rear heater unit connector and rear heater blower relay connector.
3. Remove the screws and the rear heater resistor.
4. Install in the reverse order of removal.



Rear resistor

1. Remove the left rear side trim. (Refer to section S.)
2. Disconnect the rear resistor connector.
3. Remove the screws and the rear resistor.
4. Install in the reverse order of removal.



Inspection


Front resistor

1. Disconnect the front resistor connector.
2. Verify that the continuity and resistance between terminals of the front resistor as shown below.

○—○: Continuity ○—Ω—○: Resistance

1A	2A	2B	3B	3A	3D	3C
○—○	○—○	○—○	○—Ω—○	○—Ω—○	○—Ω—○	○—Ω—○
			0.42 Ω	0.69 Ω	1.37 Ω	

3. If not as specified, replace the front resistor.




Rear heater resistor

1. Disconnect the rear heater unit connector.
2. Verify that the resistance between terminals of the rear heater resistor as shown below.

Terminal	Resistance (Ω)
C—D	1.7
D—E	4.3

3. If not as specified, replace the rear heater resistor.




Rear resistor

1. Remove the left rear side trim. (Refer to section S.)
2. Disconnect the rear resistor connector.
3. Verify that the resistance between terminals of the rear resistor as shown below.

Terminal	Resistance (Ω)
A—B	1.4
B—C	3.7

4. If not as specified, replace the rear resistor.




THERMOSWITCH

Inspection

1. Remove the thermoswitch from the cooling unit. (Refer to page U-14.)
2. Immerse the sensor part of the thermoswitch in a container of ice water.
3. Check for continuity between terminals A and B of the thermoswitch.

Temperature	Continuity
Above 5 °C { 41 °F }	Yes
Below 0 °C { 32 °F }	No

4. If not as specified, replace the thermoswitch. (Refer to page U-14.)



MAGNETIC SOLENOID VALVE

On-vehicle Inspection

1. Disconnect the magnetic solenoid valve connector.
2. Measure the resistance of the magnetic solenoid valve.


Resistance: Approx. 20 Ω

3. If not as specified, replace the magnetic solenoid valve. (Refer to page U-19.)


HEATER CONTROL UNIT

Removal / Installation

1. Remove the center upper panel. (Refer to section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




- | | |
|---------------------------------|--|
| 1. Airflow mode wire | 4. A/C switch connector |
| Wire adjustment below | 5. Fan switch connector |
| 2. Air mix wire | 6. Heater control unit |
| Wire adjustment below | Disassembly / Assembly page U-38 |
| 3. Air intake wire | Inspection page U-39 |
| Wire adjustment page U-38 | |



Wire Adjustment


Airflow mode wire

1. Set the MODE lever to VENT.
2. Connect and clamp the wire with the shutter lever on the heater unit at its closest point.
3. Move the MODE lever to make sure the wire is securely attached and that it moves fully from DEF to VENT.



Air mix wire

1. Set the temperature control lever to MAX-HOT.
2. Connect and clamp the wire with the shutter lever on the heater unit at its closest points.
3. Move the temperature control lever to make sure the wire is securely attached and that it moves fully from MAX-COLD to MAX-HOT.




Air intake wire


1. Set the REC/FRESH lever to FRESH.
2. Connect and clamp the wire with the shutter lever on the blower unit at its closest point.
3. Move the REC/FRESH lever to make sure the wire is securely attached and that it moves fully from REC to FRESH.

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



- | | |
|----------------------------|-------------------------------|
| 1. Knob | 8. REC/FRESH lever |
| 2. Panel | 9. MODE lever |
| 3. A/C switch | 10. Temperature control lever |
| Inspection page U-39 | 11. Bulb |
| 4. Clip | 12. Front fan switch |
| 5. Air intake wire | Inspection page U-39 |
| 6. Airflow mode wire | 13. Body |
| 7. Air mix wire | |



**Inspection
A/C switch**

1. Remove the A/C switch. (Refer to page U-38.)
2. Check for continuity between the terminals of the A/C switch.


○—○: Continuity

Terminal	B	D
Switch position OFF		
Switch position ON	○—○	○—○

3. Connect battery positive voltage to terminal A and ground to terminal D.
4. Turn the A/C switch on and check that indicator light illuminates.
5. If not as specified, replace the A/C switch. (Refer to page U-38.)

Front fan switch

1. Remove the heater control unit. (Refer to pge U-37.)
2. Check for continuity between the terminals of the front fan switch.




○—⊕—○: Bulb ○—○: Continuity

Terminal	1A	1C	1B	1H	1D	1F	1E	1G	2D	2A	3A	2B	3B
Switch position OFF	○—⊕—○				○—○					○—○		○—○	○—○
1	○—⊕—○		○—○		○—○				○—○	○—○		○—○	○—○
2	○—⊕—○		○—○		○—○	○—○				○—○		○—○	○—○
3	○—⊕—○		○—○		○—○		○—○			○—○		○—○	○—○
4	○—⊕—○		○—○		○—○			○—○		○—○		○—○	○—○

3. If not as specified, replace the front fan switch. (Refer to page U-38.)


**REAR MAIN SWITCH
Removal / Installation**

1. Remove the center upper panel. (Refer to section S.)
2. Remove the screws and the rear main switch.
3. Install in the reverse order of removal.




Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Knob
2. Panel
3. Nut
4. Case
5. Bulb

6. Rear heater main switch
Inspection below
7. Rear cooler main switch
Inspection page U-41



Inspection


Rear heater main switch

1. Remove the center upper panel. (Refer to section S.)
2. Check for continuity between the terminals of the rear heater main switch.

○—○: Continuity

Terminal Switch position	A	C	E	F	D
OFF					
REAR SW	○—○				
1	○—○		○		
2	○—○			○	
3	○—○				○

3. If not as specified, replace the rear heater main switch.




Rear cooler main switch

1. Check for continuity between the terminals of the rear cooler main switch

○—○: Continuity

Terminal / Switch position	A	B	C	E	F	D
OFF						
REAR SW	○—○	○—○	○—○			
1	○—○	○—○		○—○		
2	○—○	○—○			○—○	
3	○—○	○—○				○—○


2. If not as specified, replace the rear cooler main switch. (Refer to page U-40.)



REAR HEATER FAN SWITCH

Removal / Installation

1. Remove the rear heater fan switch knob and cover.
2. Remove the screws and the rear heater fan switch.
3. Install in the reverse order of removal.




Inspection

1. Remove the rear heater fan switch.
2. Check for continuity between the terminals of the rear heater fan switch.

○—○: Continuity

Terminal / Switch position	A	B	C	D
OFF				
1			○—○	○—○
2	○—○			○—○
3		○—○		○—○


3. If not as specified, replace the rear heater fan switch.




REAR COOLER FAN SWITCH

Removal / Installation

1. Pull out the rear cooler fan switch assembly.
2. Disconnect the rear cooler fan switch connector.



3. Remove the rear cooler fan switch as shown in the figure.
4. Install in the reverse order of removal.



Inspection

1. Remove the rear cooler fan switch.
2. Check for continuity between the terminals of the rear cooler fan switch.

○—○: Continuity

Switch position \ Terminal	A	B	C	D
OFF				
1			○—○	
2	○—○			○—○
3		○—○		○—○

3. If not as specified, replace the rear cooler fan switch.


TROUBLESHOOTING

TROUBLESHOOTING NOTES

- Precise understanding of customer complaints is the key to diagnosing problems.
- Diagnosis of air conditioning system problems can be difficult because of the surrounding temperatures. Therefore, checking the system operation is important. Further checking the system operation in a logical order is necessary for the accurate understanding of problems.

USING THIS SECTION

When troubleshooting, follow the procedure shown below.



- Note the following points when using the flowcharts.


Flowchart No.	A/C signal system inspection	Symptom.....	Related parts...
5	A/C signal system inspection	Magnetic clutch, condenser fan, and A/C compressor idle-up do not operate	A/C amplifier, refrigerant pressure switch, heater control unit, PCM, wiring harness

Step	Inspection procedure	Terminal	Result	Action
3	1) Connect jumper wire between terminal B or C of A/C amplifier connector (female) and ground. 2) Verify that temperature around evaporator temperature sensor is 3.5°C (38.3°F) or more. 3) Start engine. 4) Do magnetic clutch and condenser fan operate?	Jumper wire between terminal B and ground	YES	Disconnect jumper wire from terminal B and connect to terminal C.
			NO	Repair wiring harness [Refrigerant pressure switch-A/C amplifier:A-8]
		Jumper wire between terminal C and ground	YES	Remove jumper wire and go to Step 4
			NO	Check A/C amplifier (Refer to page U-36)
4	Measure voltage at terminal of heater control unit connector (female:16-pin). ⑤	B+ ⑤ 2D	B+ Other	Go to Step 5 Repair wiring harness [A/C amplifier-heater control unit:C-2D]
5	1) Turn the ignition switch to OFF. 2) Disconnect midway connector (X-26). 3) Is there continuity between terminals of heater control unit connector (female:16-pin) and midway connector (female)?	⑥ 2E-A	YES	Replace heater control unit (Refer to page U-34)
			NO	Repair wiring harness [Heater control unit -midway connector:2E-A]


B+: Battery positive voltage

③


- Follow the Steps in order when troubleshooting the system.
- Before inspection, turn all switches to OFF. When moving from step to step, keep the switches, connectors, and jumper wire in their former position unless otherwise instructed.
Before connecting or disconnecting a jumper wire, turn the ignition switch to OFF to prevent burning the electrical parts. After the jumper wire is connected or disconnected, the ignition switch can be turned to ON again.
- When checking for continuity of the wiring harness, the terminal names are shown under "Terminal" and their corresponding connector names are shown under "Inspection procedure." When repairing the wiring harness, the terminal names and the corresponding part names to which they are connected are shown under "Action."



4. Inspect connectors from either the male or female side stated after the connector name.



5. When more than one connector is attached to the same part, the pin number enclosed in () after the connector name distinguishes the connectors. The wiring diagram connector number shown before the alphabet letter distinguishes the terminals.



6. When more than one harness connects 2 different parts, the wiring diagram connector number enclosed in () after the connector name distinguishes the connectors.

TROUBLESHOOTING

Checklists

Determine the symptoms of the problem based on the customer's complaints. Refer to the fuse checklist and match the symptoms obtained from the customer with those listed in the table. Check the appropriate fuse. If the fuse is OK, operate the system. Determine the general area of the problem; for example, airflow, or temperature.


Look at the main checklist and locate the general problem area (first column). Follow each step of the instructions for the specific system (second column). If the system does not operate properly (third column), determine the symptoms and corresponding flowchart number (fourth and fifth columns). Refer to the appropriate flowchart and troubleshoot the system.

Fuse checklist

Symptom	Related fuse
Entire control system does not operate	AIR CON 15 A
Front blower motor does not operate	HEATER 40 A
Magnetic clutch and condenser fan do not operate	AIR COND2 15 A
Condenser fan does not operate	ADD FAN 20 A
Rear heater blower motor and rear cooler blower motor do not operate	R. A/C 20 A

Main checklist

Start and warm up the engine so that the engine coolant temperature reaches 40—100 °C { 104—212 °F }. Keep the engine running while doing the procedures.



General problem area	Procedure	Proper operation	Symptom	Flowchart No. (Reference)
Entire control system	Operate A/C switch, front fan switch, rear main switch, rear cooler fan switch and rear heater fan switch.	Following control system parts operate when switches are operated: <ul style="list-style-type: none"> • Magnetic clutch • Condenser fan • Front blower motor • Rear heater blower motor • Rear blower motor 	Control system does not operate	1 (page U-49)
			Rear cooling unit and rear heater unit do not operate	2 (page U-49)
Air outlet volume system	(Front) Set front fan switch in order at 1st, 2nd, 3rd, and 4th.	Front blower motor operates corresponding to front fan switch operation	Front blower motor does not operate	4 (page U-49)
			Front blower motor does not operate properly with front fan switch position	5 (page U-50)
	(Rear heater) Set rear heater fan switch in order at 1st, 2nd, and 3rd.	Rear heater blower motor operates corresponding to rear heater fan switch operation	Rear heater blower motor does not operate	6 (page U-50)
			Rear heater blower motor does not operate properly with rear heater fan switch position	7 (page U-51)
			Rear heater blower motor does not operate properly with rear heater main switch position	8 (page U-52)
	Set rear heater main switch in order at REAR CTRL, 1st, 2nd, and 3rd.			
	(Rear cooler) Set rear cooler fan switch in order at 1st, 2nd, and 3rd.	Rear blower motor operates corresponding to rear cooler fan switch operation	Rear blower motor does not operate	9 (page U-52)
			Rear blower motor does not operate properly with rear cooler fan switch position	10 (page U-53)
			Rear blower motor does not operate properly with rear cooler main switch position	11 (page U-53)
	Set rear cooler main switch in order at REAR CTRL, 1st, 2nd, and 3rd.			
	Air intake mode system	1. Set front fan switch at 4th. 2. Set REC/FRESH lever in order at each air intake mode.	Air intake wire (air intake mode) operates (changes) corresponding to REC/FRESH lever operation	Air intake mode does not change
Airflow mode system	1. Set front fan switch at 4th. 2. Set MODE lever in order at each airflow mode.	Airflow mode wire (Airflow mode) operates (changes) corresponding to MODE lever operation	Airflow mode does not change	Wire adjustment (page U-37)
Electrical load idle-up system	Set front fan switch in order at 1st, 2nd, 3rd, and 4th. (Electrical load should be blower motor only.)	Electrical load idle-up operates with front fan switch at 2nd, 3rd, and 4th	Electrical load idle-up does not operate with front fan switch at 2nd, 3rd, and 4th	3 (page U-49)
Air outlet temperature system	(Front) 1. Set fan switch at 4th. 2. Change temperature control lever from MAX COLD to MAX HOT.	Air mix wire (air outlet temperature) operates (changes) corresponding to temperature control lever	Air outlet temperature does not change	Wire adjustment (page U-37)

General problem area	Procedure	Proper operation	Symptom	Flowchart No. (Reference)
Air outlet temperature system	3. Turn A/C switch on.	Magnetic clutch, condenser fan, and A/C compressor idle-up operate	Magnetic clutch, condenser fan, and A/C compressor idle-up do not operate	12 (page U-54)
			A/C compressor idle-up operates, but magnetic clutch and condenser fan do not operate	13 (page U-55)
			Only magnetic clutch does not operation	14 (page U-55)
			Only condenser fan does not operation	15 (page U-56)
	(Rear cooler) 1. Turn A/C switch on. 2. Set front fan switch at 1st. 3. Set rear cooler main switch at 3rd.	Check air outlet temperature is cold	Cool air does not discharge or air cooling ability is low	16 (page U-57)

Flowcharts

Flowchart No.	A/C main power source system inspection	Symptom Control system does not operate
1		Related parts Wiring harness

Remedy

Repair the wiring harness [Front fan switch—Ground: B—GND]

Flowchart No.	Rear cooling unit and rear heater unit power source system inspection	Symptom Rear cooling unit and rear heater unit do not operate
2		Related parts Wiring harness

Remedy

Repair the wiring harness (Fuse—Rear cooling unit: R.A/C 20 A—G)
 Repair the wiring harness (Fuse—Rear heater unit: R.A/C 20 A—A)

Flowchart No.	Electrical load idle-up system inspection	Symptom Electrical load idle-up does not operate with front fan switch at 2nd, 3rd, and 4th
3		Related parts Front fan switch, CPU, ECM, Wiring harness

Check the following parts. Repair or replace any abnormal parts.

1. Wiring harness [Front fan switch—CPU: H—B]
2. Wiring harness [CPU—ECM: F—1P]
3. Front fan switch (Refer to page U-39.)
4. Terminals B and F of CPU (Refer to section T.)
5. Terminal P of ECM (Refer to section F.)

Flowchart No.	Front blower motor system inspection	Symptom Front blower motor does not operate
4		Related parts Front resistor, Front blower motor, Front blower relay, Front fan switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Measure voltage at terminals of connector	A	B+	Measure voltage at terminal C
			Other	Repair wiring harness (Fuse—Front blower relay: AIR CON 15 A—A)
		C	B+	Repair wiring harness (Front blower relay—GND)
			Other	Measure voltage at terminal D
		D	B+	Measure voltage at terminal E
			Other	Repair wiring harness (Fuse—Front blower relay: HEATER 40 A—D)
E	B+	Go to Step 2		
	Other	Replace front blower relay		
2	Measure voltage at terminal of front blower motor	A	B+	Go to Step 3
			Other	Repair wiring harness (Front blower relay—Front blower motor)
3	1) Turn front fan switch off 2) Measure voltage at terminal of front resistor connector	A (1-pin connector)	B+	Go to Step 5
			Other	Go to Step 4
4	1) Disconnect front blower motor connector 2) Check for continuity between terminal of front blower motor connector and front resistor connector	A—A (1-pin connector)	Yes	Check front blower motor
			No	Repair wiring harness (Front blower motor—Front resistor)

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
5	Measure voltage at terminal of front fan switch	B	B+	Repair wiring harness (Front fan switch—GND)
			Other	Check front resistor and front fan switch

Flowchart No.	Front blower motor system inspection	Symptom	Front blower motor does not operate properly with front fan switch position
5		Related parts	Front resistor, Front fan switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Turn front fan switch off 3) Measure voltage at terminals of front resistor connector	B	B+	Measure voltage at terminal A
			Other	Check front resistor
		A	B+	Measure voltage at terminal D
			Other	Check front resistor
		D	B+	Measure voltage at terminal C
			Other	Check front resistor
		C	B+	Go to Step 2
			Other	Check front resistor
2	Measure voltage at terminals of front fan switch connector	D	B+	Measure voltage at terminal F
			Other	Repair wiring harness (Front resistor—Front fan switch)
		F	B+	Measure voltage at terminal E
			Other	Repair wiring harness (Front resistor—Front fan switch)
		E	B+	Measure voltage at terminal G
			Other	Repair wiring harness (Front resistor—Front fan switch)
		G	B+	Check front fan switch
			Other	Check wiring harness (Front resistor—Front fan switch)

Flowchart No.	Rear heater blower motor system inspection	Symptom	Rear heater blower motor does not operate
6		Related parts	Rear heater 10 A fuse, Rear heater blower relay, Rear heater blower motor, Rear heater fan switch, Rear heater main switch, Wiring harness

Step	Inspection procedure	Terminal	Result	Action
1	Check rear heater 10 A fuse in rear heater unit	—	OK	Go to Step 2
			Burnt	Check for a short circuit in the wiring harness before replacing the rear heater 10 A fuse
2	1) Disconnect rear heater main switch connector 2) Check for continuity between terminal of rear heater main switch connector and ground	A—GND	Yes	Go to Step 3
			No	Repair wiring harness (Rear heater main switch—GND)

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action		
3	1) Turn ignition switch to ON 2) Measure voltage at terminal of rear heater unit connector	C	B+	Measure voltage at terminal D		
			Other	Go to Step 4		
		D	B+	Measure voltage at terminal E		
			Other	Check rear heater resistor		
		E	B+	Check rear heater fan switch and rear heater main switch		
			Other	Check rear heater resistor		
4	Measure voltage at terminals of rear heater blower relay connector	A	B+	Measure voltage at terminal		
			Other	Repair wiring harness (Fuse—Rear heater blower relay: AIR CON 15 A—A)		
		B	B+	Repair wiring harness (Rear heater blower relay—GND)		
			Other	Measure voltage at terminal		
		C	B+	Measure voltage at terminal		
			Other	Repair wiring harness (Fuse—Rear heater blower relay: R.A/C 20 A—C)		
		D	B+	Go to Step 5		
			Other	Replace rear heater blower relay		
		5	Measure voltage at terminals of rear heater blower motor	A	B+	Repair wiring harness (Rear heater blower motor—Rear heater resistor)
					Other	Measure voltage at terminal
B	B+			Check blower motor		
	Other			Repair wiring harness (Blower relay—Blower motor)		

Flowchart No.	Rear heater blower motor system inspection	Symptom	Rear heater blower motor does not operate properly with rear heater fan switch position
7		Related parts	Rear heater fan switch, Rear heater main switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Turn rear heater main switch off 3) Set rear heater fan switch at 3rd 4) Measure voltage at terminals of rear heater fan switch connector	C	B+	Measure voltage at terminal A
			Other	Repair wiring harness (Rear heater unit—Rear heater fan switch)
		A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Rear heater unit—Rear heater fan switch)
		B	B+	Measure voltage at terminal D
			Other	Repair wiring harness (Rear heater unit—Rear heater fan switch)
		D	B+	Go to Step 2
			Other	Check rear heater fan switch
2	Measure voltage at terminal of rear heater main switch connector	D	B+	Check rear heater fan switch and rear heater main switch
			Other	Repair wiring harness (Rear heater fan switch—Rear heater main switch)

Flowchart No.	Rear heater blower motor system inspection	Symptom Rear heater blower motor does not operate properly with rear heater main switch position
8		Related parts Rear heater main switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Turn rear heater main switch off 3) Measure voltage at terminals of rear heater main switch connector	C	B+	Measure voltage at terminal E
			Other	Repair wiring harness (Rear heater unit—Rear heater main switch)
		E	B+	Measure voltage at terminal F
			Other	Repair wiring harness (Rear heater unit—Rear heater main switch)
		F	B+	Check rear heater main switch
			Other	Repair wiring harness (Rear heater unit—Rear heater main switch)

Flowchart No.	Rear blower motor system inspection	Symptom Rear blower motor does not operate
9		Related parts Rear resistor, Rear blower motor, Rear blower relay, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Disconnect rear cooler main switch connector 2) Check for continuity between terminal of rear cooler main switch connector and ground	A—GND	Continuity	Go to Step 2
			No continuity	Repair wiring harness (Rear cooler main switch—GND)
2	1) Turn ignition switch to ON 2) Measure voltage at terminal of rear resistor connector	A	B+	Check rear resistor
			Other	Go to Step 3
3	Measure voltage at terminals of rear blower relay connector	A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Fuse—Rear blower relay: AIR CON 15 A—A)
		B	B+	Repair wiring harness (Rear blower relay—GND)
			Other	Measure voltage at terminal C
		C	B+	Measure voltage at terminal D
			Other	Repair wiring harness (Fuse—Rear blower relay: R.A/C 20 A—C)
		D	B+	Go to Step 4
			Other	Check rear blower relay
4	Measure voltage at terminals of rear blower motor connector	B	B+	Repair wiring harness (Rear blower motor—Rear blower relay)
			Other	Measure voltage at terminal A
		A	B+	Check rear blower motor
			Other	Repair wiring harness (Rear blower relay—Rear blower motor)

Flowchart No.	Rear blower motor system inspection	Symptom	Rear blower motor does not operate properly with rear cooler fan switch position
10		Related parts	Rear cooler fan switch, Rear cooler main switch, Rear cooling unit, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Turn rear cooler main switch off 3) Set rear cooler fan switch at 3rd 4) Measure voltage at terminals of rear cooler fan switch connector	C	B+	Measure voltage at terminal A
			Other	Repair wiring harness (Rear resistor—Rear cooler fan switch)
		A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Rear resistor—Rear cooler fan switch)
		B	B+	Measure voltage at terminal D
			Other	Repair wiring harness (Rear resistor—Rear cooler fan switch)
D	B+	Go to Step 2		
	Other	Check rear cooler fan switch		
2	Measure voltage at terminal of rear cooler main switch connector	D	B+	Check rear cooler fan switch and rear cooler main switch
			Other	Go to Step 3
3	Measure voltage at terminal of rear cooling unit connector (8-pin)	D	B+	Repair wiring harness (Rear cooling unit—Rear cooler main switch)
			Other	Go to Step 4
4	Measure voltage at terminal of rear cooling unit connector (4-pin)	D	B+	Repair wiring harness (Rear cooling unit [8-pin, terminal D]—Rear cooling unit [4-pin, terminal D])
			Other	Repair wiring harness (Rear cooler fan switch—Rear cooling unit)

Flowchart No.	Rear blower motor system inspection	Symptom	Rear blower motor does not operate properly with rear cooler main switch position
11		Related parts	Rear cooler main switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Turn rear cooler main switch off 3) Measure voltage at terminals of rear cooler main switch connector	C	B+	Measure voltage at terminal E
			Other	Repair wiring harness (Rear resistor—Rear cooler main switch)
		E	B+	Measure voltage at terminal F
			Other	Repair wiring harness (Rear resistor—Rear cooler main switch)
		F	B+	Check rear cooler main switch
			Other	Repair wiring harness (Rear resistor—Rear cooler main switch)

Flowchart No. 12	A/C signal system inspection	Symptom	Magnetic clutch, condenser fan, and A/C compressor idle-up do not operate
		Related parts	A/C relay, ECM, Thermoswitch, A/C switch, Front fan switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Measure voltage at terminals of A/C relay connector	C	B+	Measure voltage at terminal C
			Other	Repair wiring harness (Fuse—A/C relay: AIR COND2 15 A—C)
		D	B+	Repair wiring harness (A/C relay—Refrigerant pressure switch)
			Other	Measure voltage at terminal A
		A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Fuse—A/C relay: AIR CON 15 A—A)
B	B+	Go to Step 2		
	Other	Check A/C relay		
2	1) Turn ignition switch to ON 2) Disconnect ECM connector (22-pin) 3) Connect jumper wire between terminal 1G of ECM connector and ground 4) Start engine 5) Do magnetic clutch, condenser fan, and A/C compressor operate?	—	Yes	Reconnect ECM connector (22-pin), remove jumper wire, and go to Step 3
			No	Check wiring harness (A/C relay—ECM) Check ECM (Refer to section F)
3	1) Turn ignition switch to ON 2) Turn front fan switch off 3) Check evaporator temperature at above 5 °C { 41 °F } 4) Measure voltage at terminals of thermostat connector	A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (ECM—Thermoswitch)
		B	B+	Go to Step 4
			Other	Check thermostat
4	1) Turn A/C switch on 2) Measure voltage at terminals of A/C switch connector	B	B+	Measure voltage at terminal A
			Other	Repair wiring harness (Thermoswitch—A/C switch)
		A	B+	Measure voltage at terminal D
			Other	Repair wiring harness (Fuse—A/C switch: AIR CON 15 A—A)
		D	B+	Go to Step 5
			Other	Check A/C switch
5	1) Set front fan switch at 1st 2) Measure voltage at terminal of front fan switch connector	B	B+	Repair wiring harness (Front fan switch—GND)
			Other	Go to Step 6
6	1) Disconnect front fan switch connector 2) Disconnect A/C switch connector 3) Check for continuity between terminal of A/C switch connector and front fan switch connector	D—D	Yes	Check front fan switch
			No	Repair wiring harness (A/C switch—Front fan switch)

Flowchart No.	A/C power source system inspection	Symptom A/C compressor idle-up operates, but magnetic clutch and condenser fan do not operate
13		Related parts A/C relay, Refrigerant pressure switch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Turn ignition switch to ON 2) Measure voltage at terminals of A/C relay connector	C	B+	Measure voltage at terminal D
			Other	Repair wiring harness (Fuse—A/C relay: AIR COND2 15 A—C)
		D	B+	Go to Step 2
			Other	Check A/C relay
2	Measure voltage at terminals of refrigerant pressure switch connector	B	B+	Measure voltage at terminal A
			Other	Repair wiring harness (A/C relay—Refrigerant pressure switch)
		A	B+	Repair wiring harness (Pressure switch—Magnetic clutch, Refrigerant pressure switch—Condenser fan relay)
			Other	Check refrigerant pressure switch

Flowchart No.	A/C power source system inspection	Symptom Only magnetic clutch does not operate
14		Related parts Magnetic clutch, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Run engine at idle 2) Turn A/C switch and fan switch on 3) Measure voltage at terminal of magnetic clutch connector	GND	B+	Repair the ground connection
			Other	Measure voltage at terminal A
		A	B+	Check magnetic clutch
			Other	Repair wiring harness (Refrigerant pressure switch—Magnetic clutch)

Flowchart No.	A/C power source system inspection	Symptom Only condenser fan does not operate
15		Related parts Condenser fan relay, Condenser fan, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Run engine at idle 2) Turn A/C switch and front fan switch on 3) Measure voltage at terminals of condenser fan relay connector	A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Refrigerant pressure switch—Condenser fan relay)
		B	B+	Repair wiring harness (Condenser fan relay—GND)
			Other	Measure voltage at terminal C
		C	B+	Measure voltage at terminal D
			Other	Repair wiring harness (Fuse—Condenser fan relay: ADD FAN 20 A—C)
		D	B+	Go to Step 2
			Other	Check condenser fan relay
2	Measure voltage at terminals of condenser fan connector	A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Condenser fan relay—Condenser fan)
		B	B+	Repair wiring harness (Condenser fan—GND)
			Other	Replace condenser fan

Flowchart No.	Rear cooling unit system inspection	Symptom	Cool air does not discharge or air cooling ability is low
16		Related parts	Magnetic solenoid valve, Magnetic solenoid valve relay, Rear cooler main switch, Diode, Rear resistor, Wiring harness

B+: Battery positive voltage

Step	Inspection procedure	Terminal	Result	Action
1	1) Run engine at idle 2) Turn A/C switch and fan switch on 3) Verify rear cooler main switch off 4) Measure voltage at terminal of magnetic solenoid valve relay connector	A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (A/C relay—Magnetic solenoid valve)
		B	B+	Go to Step 2
			Other	Check magnetic solenoid valve
2	Measure voltage at terminal of magnetic solenoid valve relay connector	A	B+	Measure voltage at terminal C
			Other	Repair wiring harness (Fuse—Magnetic solenoid valve relay: AIR CON 15 A—A)
		C	B+	Set rear cooler main switch to 1st and measure voltage at terminal D
			Other	Repair wiring harness (Magnetic solenoid valve—Magnetic solenoid valve relay)
		D	B+	Repair wiring harness (Magnetic solenoid valve relay—GND)
			Other	Measure voltage at terminal B
		B	B+	Go to Step 3
			Other	Check magnetic solenoid valve relay
3	Measure voltage at terminal of rear cooler main switch connector	C	B+	Check rear cooler main switch
			Other	Go to Step 4
4	Measure voltage at terminal of diode connector	A	B+	Measure voltage at terminal B
			Other	Repair wiring harness (Magnetic solenoid valve relay—Diode)
		B	B+	Repair wiring harness (Diode—Rear cooler main switch)
			Other	Go to Step 5
5	1) Remove diode 2) Connect ⊕ lead to terminal B and ⊖ lead of circuit tester to terminal A of diode connector 3) Check for continuity between terminals of diode connector	A—B	Yes	Go to Step 6
			No	Replace rear cooler harness
6	Measure voltage at terminal of rear resistor connector	C	B+	Repair wiring harness (Diode—Rear resistor)
			Other	Check rear resistor